



# Renault MASTER

Vehicle user manual

<https://www.truck-manuals.net/>



# A passion for performance



ELF, partner of  
**world series**  
by RENAULT



## RENAULT recommends ELF

Partners in cutting-edge automotive technology, Elf and Renault combine their expertise on both the racetrack and the city streets. This enduring partnership gives drivers a range of lubricants perfectly suited to Renault cars. Lasting protection and optimum performance for your engine – guaranteed. Whether changing the oil or simply topping up, to find the approved ELF lubricant best suited to your vehicle, ask your Renault dealer for a recommendation or consult your vehicle maintenance handbook.



[www.lubricants.elf.com](http://www.lubricants.elf.com)



<https://www.truck-manuals.net/>

A brand from **TOTAL**

# ***Welcome to your new vehicle***



---


**This driver's handbook** contains the information necessary:

- for you to familiarise yourself with your vehicle, to use it to its best advantage and to benefit fully from all the functions and the technical developments it incorporates.
- to ensure that it always gives the best performance by following the simple, but comprehensive advice concerning regular maintenance.
- to enable you to deal quickly with minor faults not requiring specialist attention.

It is well worth taking a few minutes to read this handbook to familiarise yourself with the information and guidelines it contains about the vehicle and its functions and new features. If certain points are still unclear, our Network technicians will be only too pleased to provide you with any additional information.

To help you, you will find the following symbols:

 and  These appear in the vehicle and indicate that you should consult the manual for detailed information and/or limits on operations with respect to your vehicle's equipment.

 anywhere in the manual indicates a hazard, danger or a safety recommendation.

The descriptions of the models given in this handbook are based on the technical specifications at the time of writing. **This handbook covers all items of equipment** (both standard and optional) **available for these models but whether or not these are fitted to the vehicle depends on the version, options selected and the country where the vehicle is sold.** **This handbook may also contain information about items of equipment to be introduced later in the model year.**

Enjoy driving your new vehicle.

Translated from French. Copying or translation, in part or in full, is forbidden unless prior written permission has been obtained from the car manufacturer.



# C O N T E N T S

## Sections

**Getting to know your vehicle** .....

**1**

**Driving** .....

**2**

**Your comfort** .....

**3**

**Maintenance** .....

**4**

**Practical advice** .....

**5**

**Technical specifications** .....

**6**

**Alphabetical index** .....


**7**



# Section 1: Getting to know your vehicle

Key, remote control . . . . .	1.2
Deadlocking. . . . .	1.7
Hands-free access transmitter/receiver. . . . .	1.8
Locking/unlocking the doors . . . . .	1.10
Doors. . . . .	1.13
Steering wheel/power-assisted steering . . . . .	1.19
Headrests . . . . .	1.20
Front seats. . . . .	1.21
Seat belts. . . . .	1.24
Methods of restraint in addition to the front seat belts. . . . .	1.28
Side protection devices . . . . .	1.31
Child safety: General information . . . . .	1.33
choosing a child seat mounting . . . . .	1.36
fitting a child seat, general information. . . . .	1.38
Child seats: attachment by seat belt or by Isofix system. . . . .	1.40
deactivating/activating the front passenger airbag. . . . .	1.70
Rear view mirrors . . . . .	1.73
Driving position: left-hand drive . . . . .	1.74
Driver's position, right-hand drive . . . . .	1.76
Warning lights . . . . .	1.78
Trip computer . . . . .	1.84
Clock . . . . .	1.93
Exterior temperature . . . . .	1.93
Windscreen washer/wiper . . . . .	1.94
Exterior lighting and signals. . . . .	1.96
Electrical adjustment of the dipped beam headlights . . . . .	1.100
Audible and visual signals . . . . .	1.101
Fuel tank . . . . .	1.102
Reagent tank. . . . .	1.104


## KEY, RADIO FREQUENCY REMOTE CONTROL: general information (1/3)



### Radio frequency remote control A

- 1 Locking all the opening elements.
- 2 Unlocking all the opening elements.
- 3 Key for ignition switch, doors and fuel filler cap.

The key must not be used for any function other than those described in the handbook (removing the cap from a bottle, etc.).



### Radio frequency remote control B

- 1 Locking all the opening elements.
- 2 Unlocking all the opening elements.
- 3 Key for ignition switch, doors and fuel filler cap.
- 4 Locking/unlocking the luggage compartment and, depending on the vehicle, the sliding side doors.

#### Advice

Avoid leaving the remote control in hot, cold or humid areas.



### Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.


They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**




## KEY, RADIO FREQUENCY REMOTE CONTROL: general information (2/3)



### Radio frequency remote control C

- 1 Locking all the opening elements.
- 2 Unlocking all the opening elements.
- 3 Key for ignition switch, doors and fuel filler cap.
- 5 Locking/unlocking the key insert for remote control C.  
To release the insert from its housing, press button 5, it comes out automatically.  
Press button 5 and guide the insert back into its housing.



### Radio frequency remote control D

- 1 Locking all the opening elements.
- 2 Unlocking all the opening elements.
- 3 Key for ignition switch, doors and fuel filler cap.
- 5 To release the insert from its housing, press button 5, it comes out automatically. Press button 5 and guide the insert back into its housing.
- 6 Locking/unlocking the luggage compartment and, depending on the vehicle, the sliding doors.

### Radio frequency remote control operating range

This varies according to the environment: take care not to lock or unlock the doors by inadvertently pressing the buttons on the remote control.

**Note:** on certain vehicles, if a door is not opened within approximately 2 minutes of the door being unlocked by remote control, the doors will lock again automatically.

### Interference

Interference by factors in the immediate vicinity (external installations or the use of equipment operating on the same frequency as the remote control) may affect the operation of the remote control.



## Hands-free access transmitter/receiver *E*

This enables the vehicle doors to be locked/unlocked without using the remote control unit. Refer to the information on “Hands-free access transmitter/receiver: use” in section 1.

### Replacement, additional remote control or transmitter/receiver

You must only contact an approved Dealer.

- To replace a remote control, the vehicle must be taken to an approved Dealer as both the vehicle and the remote control are needed to initialise the system.
- Depending on the vehicle, you may use up to four remote controls or two transmitter/receivers.

### Remote control unit failure

Make sure that the correct battery type is being used, and that the battery is in good condition and inserted correctly. These batteries have a service life of approximately two years.

Refer to the information on the “Key, radio frequency remote control: batteries” in Section 5 for the battery changing procedure.



### Driver's responsibility when parking or stopping the vehicle


Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**


## KEY, RADIO FREQUENCY REMOTE CONTROL: use (1/2)



Remote controls **A** and **B** are used to lock and unlock the doors. They are powered by a battery which must be replaced (refer to the information on the “Key/radio frequency remote control: batteries” in section 5).

### Locking the doors

Pressing button **1** locks the doors and tailgate. The hazard warning lights and side indicator lights **flash twice** to indicate that the doors have locked.



**Note:** depending on the vehicle, when a door or the tailgate is left open or not properly closed, all the doors and the tailgate lock/unlock quickly without the hazard warning lights flashing.

### Unlocking the doors

Pressing button **2** unlocks the doors and tailgate. The hazard warning lights and side indicator lights **flash once** to indicate that the doors have unlocked.

To lock/unlock the doors from inside, refer to the information on “Central door locking/unlocking” in section 1.



### Driver's responsibility when parking or stopping the vehicle


Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**

## KEY/RADIO FREQUENCY REMOTE CONTROL: use (2/2)




Remote controls **C** and **D** are used to lock and unlock the doors and the luggage compartment.

They are powered by a battery which must be replaced (refer to the information on the "Key/radio frequency remote control: batteries" in section 5).

### Locking the doors

Pressing button **1** locks the doors and tailgate.

A short press on button **3** locks/unlocks the luggage compartment and, depending on the vehicle, the sliding side doors.



The hazard warning lights and side indicator lights **flash twice** to indicate that the doors have locked.

**Note:** depending on the vehicle, when a door or the tailgate is left open or not properly closed, all the doors and the tailgate lock/unlock quickly without the hazard warning lights flashing.


### Unlocking the doors

Pressing button **2** unlocks the doors and tailgate.

A short press on button **3** locks/unlocks the tailgate and, depending on the vehicle, the sliding side doors. The hazard warning lights and side indicator lights **flash once** to indicate that the doors have unlocked.

The key must not be used for any function other than those described in the handbook (removing the cap from a bottle, etc.).

# DEADLOCKING



2651B

If fitted to the vehicle, this allows the doors to be locked and prevents them from being opened with the interior handles (for example, by breaking the window and then trying to open the doors from the inside).



Never use deadlocking if someone is still inside the vehicle.

27414



## To activate deadlocking

Press button **1** twice in quick succession.


The side indicator lights and hazard warning lights **flash five times** to indicate that the doors have locked.

## To deactivate deadlocking


Unlock the vehicle using button **2**.

The hazard warning lights and side indicator lights **flash once** to indicate that the doors have unlocked.

27415



102A



## HANDS-FREE ACCESS TRANSMITTER, RECEIVER: use (1/2)


31505



For vehicles equipped with transmitter/receiver **1**, in addition to the functions of the remote control, it can be used to lock/unlock without using the remote control locking unit when it is in access zone **2**.

**Note:** the hands-free access transmitter/receiver only works with the front doors and the tailgate.

30020



It is powered by a battery which must be replaced (refer to the information on the “Hands-free access transmitter/receiver: batteries” in Section 5).



### Driver's responsibility when parking or stopping the vehicle


Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.


**RISK OF DEATH OR SERIOUS INJURY.**

## HANDS-FREE ACCESS TRANSMITTER, RECEIVER: use (2/2)



### Interference

Interference by factors in the immediate vicinity (external installations or the use of equipment operating on the same frequency as the remote control) may affect the operation of the remote control.



### Unlocking the vehicle

With the transmitter/receiver in one of the access zones **2**, press button **3** or **4**, and all the doors will unlock.

The hazard warning lights **flash once** to indicate that the doors have been unlocked.




### Locking the vehicle

With the transmitter/receiver in one of the access zones **2**, press button **3** or **4**, and all the doors will lock.

The hazard warning lights **flash once for 4 seconds** to indicate the doors have been locked.

**Note:** when a door or the tailgate is left open or is not properly closed, all the doors and the tailgate lock/unlock quickly without the hazard warning lights flashing.

# CENTRAL DOOR LOCKING, UNLOCKING



## Interior locking/unlocking door control

This enables all the doors to be locked simultaneously.

Lock or unlock the doors by pressing switch **1**.

If a door or the tailgate is open or not closed properly, the doors and tailgate lock/unlock quickly.

## Locking the opening elements without the remote control

With the engine off, the rear doors closed and a front door open, press switch **1** for more than five seconds.

Make sure you have your key with you before you leave your vehicle.

When the door is closed, all the doors and tailgate will be locked.

Unlocking the driver's door from outside the vehicle is only possible with the key or the remote control.

## Doors and tailgate status indicator light

**When the ignition is on**, the indicator light integrated in switch **1** informs you of the status of the doors and tailgate:

- indicator light on, the doors and tailgate are locked;
- light off, the doors and tailgate are unlocked.

When the ignition is off, the indicator light remains lit and then goes out when you lock the doors.

## Locking the doors with the tailgate open

To lock the vehicle leaving a door open (e.g. when transporting something in the luggage compartment which prevents it from being closed), or when the vehicle is located in a zone of high electromagnetic radiation, or if the key is faulty: with the engine switched off, press and hold switch **1** for more than five seconds.



Never leave your vehicle with the key, remote control or transmitter/receiver inside.




### Driver's responsibility

If you decide to keep the doors locked when you are driving, remember that it may be more difficult for those assisting you to gain access to the passenger compartment in the event of an emergency.



# MANUAL DOOR LOCKING, UNLOCKING



## Manual control


### Using the key

Lock or unlock the doors equipped with locks by inserting the key fully into lock **1**, then turning it.



## Locking the doors manually

With the door open, turn screw **2** (using the end of the key) or press button **3** and close the door. This means that the doors are then locked from the outside. The doors may then only be opened from inside the vehicle or with the key for the front doors.



## RAID (AUTOMATIC LOCKING WHEN DRIVING)



You can decide whether you want to activate this function.

### To activate

With the ignition on, press switch **1** for approximately 5 seconds until you hear a beep.

The indicator light built into the switch comes on when the doors are locked.

### To deactivate

With the ignition on, press and hold switch **1** for approximately 5 seconds, until you hear a beep. The indicator light in the switch goes out.

### Operating principle

When the engine is started, the system automatically locks the doors when the vehicle reaches a speed of approximately 4 mph (7 km/h).

### Operating faults

If you notice an operating fault (automatic locking impossible), first check that all doors are correctly locked. If they are correctly locked and the fault is still present, contact an approved Dealer.

Also make sure that locking has not been inadvertently deactivated.


If it has, switch the ignition off and on again and reactivate it.



### Driver's responsibility

If you decide to keep the doors locked when you are driving, remember that it may be more difficult for those assisting you to gain access to the passenger compartment in the event of an emergency.

## FRONT DOORS (1/2)



### Opening the doors from the outside

Unlock a door equipped with lock 2 using the key.

#### Vehicles with a remote control

Pull handle 1.

#### Vehicles with a transmitter/receiver

Press button 3 and pull handle 1.

### Closing from the outside

Push the door. Use the key in lock 2 to lock it, or use the remote control or the hands-free access transmitter/receiver by pressing button 3.



### Opening from the inside

Pull handle 6 and open the door.

### Closing from the inside

Pull the door using only handle 5.



As a safety precaution, the doors should only be opened or closed when the vehicle is stationary.

## FRONT DOORS (2/2)

### Manual locking

With the door closed, lock the door by pressing button **4**.

#### NOTE

The front door mechanism cannot be locked if the door is open.

### Lights-on reminder buzzer

If you have switched off the ignition and left the lights switched on, a reminder buzzer will sound when a door is opened.



#### **Driver's responsibility when parking or stopping the vehicle**


Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or by locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**

## SLIDING SIDE DOOR (1/2)




### Opening the doors from the outside

Unlock the lock with the key or with the remote control, if the vehicle is equipped with this function.

Pull handle **1** towards you and slide the door towards the rear.

**Note:** the transmitter/receiver does not work on the sliding side door (no button on the handle).



### Opening from the inside

Pull lever **2** towards the rear and open the sliding door until it locks into position.

### Closing from the outside

Pull handle **1** and slide the door towards the front of the vehicle until it closes completely. Lock with the key or using the remote control.

### Closing from the inside

Pull lever **2** towards the front and close the door until it latches.

### Manual locking from inside

Lower button **3**.



As a safety precaution, the doors should only be opened or closed when the vehicle is stationary.

## SLIDING SIDE DOOR (2/2)



### Child locks

With the door open, turn lever **4** and close the door.

This means that the door is then locked from the inside.

The door can only be opened from the outside of the vehicle.




Recommendations concerning the sliding side door.

Care must be taken when opening or closing the sliding door, as is the case for any of the opening elements on the vehicle:

- Check that the door will not come into contact with any person, part of the body, animal or object.
- Only use the handles on the inside and outside of the door to operate it.
- Take care when opening and closing the door.
- Take particular care when the vehicle is parked on a slope: open or close the door fully until it latches into its locking position.
- Before moving off, always ensure that the sliding door is properly closed.

## REAR DOORS (1/2)



### Opening the doors from the outside

Unlock lock **1** using the key or, on equipped vehicles, use the remote control or the hands-free access remote control by pressing button **3**. Pull handle **2** towards you and open the door.




Do not leave the hinged rear doors open in case of strong winds. Risk of injury.



Lower lever **4** to open the door.



If the vehicle is parked on the hard shoulder with tailgate open, the rear lights may be obscured. You should make other road users aware of your vehicle by using a warning triangle or other equipment specified by the road traffic regulations of the country you are driving in.



### Opening the doors to 180°

Open the door, but not fully. Remove tie rod **7** from its housing **6**. Lock the tie rod on the hook **5**. Open the door as far as possible.



For your safety, check that all the vehicle's doors are properly closed before starting the engine.

## REAR DOORS (2/2)



### Opening the doors to 270°


Remove the check-strap from its housing as when opening to 180°. Open the door fully until the magnets **6** make contact.

### Closing from the outside

Partially close the left-hand door, then slam it shut.

Then repeat this with the right-hand door.


Lock.



### Opening from the inside

Lower lever **7** and push door **A**.

Pull lever **8** and open door **B**.



### Closing from the inside

Partially close door **B**, then slam it shut.

Do the same with door **A** using handle **9**.

### Locking/unlocking

Turn button **10**.



For your safety, check that all the vehicle's doors are properly closed before starting the engine.



# STEERING WHEEL/POWER-ASSISTED STEERING



## Steering wheel height adjustment

Pull lever **1** and move the steering wheel to the required position.

Then, push the lever back fully, beyond the point of resistance to lock the steering wheel.

Make sure that the steering wheel is correctly locked.



For safety reasons, only adjust the steering wheel when the vehicle is stationary.

## Power-assisted steering


With the engine running, do not leave the steering wheel at full lock while stationary as this may damage the power-assisted steering pump.

With the engine switched off, or if there is a system fault, it is still possible to turn the steering wheel. The force required will be greater.



Never switch off the ignition when travelling downhill, and avoid doing so in normal driving (assistance is not provided).

# HEADRESTS



## To raise the headrest

Simply slide it up.

## To lower the headrest

Press tab **1** and lower it at the same time.

## To remove the headrest

Raise the headrest then press tabs **1** and **2** to release it.



## To refit the headrest

Insert the rods into the holes, with the notches to the front, and lower the headrest to the desired height by pressing tab **1**.

## Adjusting the angle of the headrest


(depending on the vehicle)

Move section **B** towards or away from you to the required position.



The headrest is an important safety component: ensure that it is in place and in the correct position. The distance between your head and the headrest and the distance between the head and section **A** should be as small as possible.

## FRONT SEATS (1/3)




### Adjusting seat A

#### To move forwards or backwards

Lift handle **1** to release. Release the handle once the seat is in the correct position and ensure that the seat is locked.

#### To adjust the height of the seat base

Lower or pull lever **2** as many times as is necessary to raise or lower the seat base.



### Lumbar adjustment

(depending on the vehicle)

Turn control knob **3** to increase or decrease support.

#### To tilt the seatback

Move lever **4**.

### Heated seats

(depending on the vehicle)

**With the ignition on**, press switch **5**. The integrated indicator comes on.

The system, which has a thermostat, decides whether or not the heating is needed.




For safety reasons, carry out any adjustments when the vehicle is not being driven.

We would advise you not to recline the seatbacks too far to ensure that the effectiveness of the seat belts is not reduced.

Nothing should be placed on the floor (area in front of driver) as such objects may slide under the pedal during braking manoeuvres, thus obstructing its use.

## FRONT SEATS (2/3)



### Adjusting seat **B** with suspension

#### To move forwards or backwards

Lift handle **11** to release. Release the handle once the seat is in the correct position and ensure that the seat is locked.

#### To tilt the seatback

Lower or pull control **7** towards you.

#### To adjust the height of the seat base

Move control **9** to adjust the rear of the seat base or control **10** to adjust the front of the seat base.



### Lumbar adjustment

Activate bulb **12** to make it firmer.

Press switch **13** to make it less firm.

### To adjust the seat suspension

Turn control knob **6** to the right to stiffen the suspension and to the left to reduce it.


### Heated seats

(depending on the vehicle)

**With the ignition on**, press switch **8**. The integrated indicator comes on.

The system, which has a thermostat, decides whether or not the heating is needed.

## FRONT SEATS (3/3)



### Adjusting pivoting seats C

#### To move the seat forwards or back


Move handle **15** to unlock it. Release the handle once the seat is in the correct position and ensure that the seat is locked.

#### To move the seat forwards or back

Lift handle **18** to move the seat base forwards or back.

#### To tilt the seatback

Lower or pull handle **14** towards you.



### Adjusting the angle of the seat base

Move handle **16** to adjust the angle of the seat base.

### Adjusting the height of the armrests

Turn control knob **17** or **19**.

### Lumbar adjustment

Activate bulb **22** to make it firmer.

Press switch **21** to make it less firm.

### To pivot the seats

- Detach the seat belt buckle from its unit;
- raise the armrests;
- move the seat as far back as possible;
- adjust the seat base to its lowest position;
- adjust the seatback to the vertical position;
- open the door;
- lift handle **20** and pivot the seat to unlock it from its “forward-facing” position, then release handle **20**.

### Returning to the driving position

- Pivot the seat to the “forward facing” position;
- make sure the seat is correctly locked in position;
- adjust the seat to your driving position.



The “rear facing” seat position should only be used when the vehicle is stationary and the engine not running.

## SEAT BELTS (1/3)

Always wear your seat belt when travelling in your vehicle. You must also comply with the legislation of the particular country you are in.



Seat belts which are incorrectly adjusted or twisted may cause injuries in the event of an accident.

Use one seat belt per person, whether child or adult.

Even pregnant women should wear a seat belt. In this case, ensure that the lap belt is not exerting too much pressure on the abdomen, but do not allow any slack.

**Before starting, first adjust your driving position, then ask all occupants to adjust their seat belts to ensure optimum protection.**

### Adjusting your driving position

- **Sit well back in your seat** (having removed your coat or jacket etc.). This is essential to ensure your back is positioned correctly;
- **adjust the distance between the seat and the pedals.** Your seat should be as far back as possible while still allowing you to fully depress the clutch pedal. The seatback should be adjusted so that your arms are slightly bent when you hold the steering wheel;
- **adjust the position of your headrest.** For maximum safety, your head must be as close as possible to the headrest;
- **adjust the height of the seat.** This adjustment allows you to select the seat position which offers you the best possible view.
- **adjust the position of the steering wheel.**



### Adjusting the seat belts

Sit with your back firmly against the seatback.

Shoulder strap **1** should be as close as possible to the base of the neck but not on it.

Lap belt **2** should be worn flat over the thighs and against the pelvis.

The belt should be worn so that it is as close as possible to your body, i.e.: avoid wearing heavy clothing or keeping bulky objects under the belts, etc.

## SEAT BELTS (2/3)




### Locking

Unwind the belt **slowly and smoothly** and ensure that buckle **3** locks into catch **5** (check that it is locked by pulling on buckle **3**).

If the belt jams, allow it to return slightly before attempting to unwind it again.

If your seat belt is completely jammed, pull slowly, but firmly so that just over 3 cm unwinds. Allow it to return slightly before attempting to unwind it again.

If there is still a problem, contact an approved dealer.



### Seat with armrest(s)

Ensure the seat belt is passed underneath armrest **6**, check that buckle **3** is fastened in catch **5**.

Lower armrest **7** on the door side (movement **A**).

Unwind the belt **slowly and smoothly**. Pass the lap belt under armrest **7** and the shoulder strap over armrest **7**.

Make sure the buckle locks into the catch (check that it is locked by pulling on the buckle).



### Front seat belt reminder warning light


If the driver's seat belt is not fastened the light remains lit when the vehicle is started, then when the car reaches a speed of about 9.92 mph (16 km/h), it flashes and a beep sounds for about 90 seconds.

Depending on the vehicle, this flashes if the front passenger seat belt is not fastened.

### Unfastening

Press button **4** and the seat belt will be rewound by the inertia reel. Guide the belt.

## SEAT BELTS (3/3)



### Adjusting the height of the front seat belts

Press button **8** to adjust the seat belt height so that the shoulder strap **1** is worn as shown previously;

Press button **8** and raise or lower the seat belt.

Make sure that the seat belt is locked in position correctly after you have adjusted it.



- No modification may be made to the component parts of the originally fitted restraint system: belts, seats and their mountings. For special operations (e.g. fitting child seats), contact an authorised dealer.
- Do not use devices which allow any slack in the belts (e.g. clothes pegs, clips, etc.): a seat belt which is worn too loosely may cause injury in the event of an accident.
- Never wear the shoulder strap under your arm or behind your back.
- Never use the same belt for more than one person and never hold a baby or child on your lap with your seat belt around them.
- The belt should never be twisted.
- Following an accident, have the seat belts checked and replaced if necessary. Always replace your seat belts as soon as they show any signs of wear.
- Make sure that the buckle is inserted into the appropriate catch.
- Ensure that no objects are placed in the area around the seat belt catch as they could prevent it from being properly secured.
- Make sure the seat belt catch is properly positioned (it should not be hidden away, crushed or flattened by people or objects).




## REAR SEAT BELTS



### Rear seat belts with inertia reel 1

#### Locking

Unwind the belt **slowly and smoothly** and ensure that buckle **2** locks into catch **3** (check that it is locked by pulling on buckle **2**).



#### Unfastening

Press the button on catch **3** and the seat belt will be rewound by the inertia reel. Guide the belt.



Check that the rear seat belts are positioned and operating correctly each time the rear seats are moved.

### Lap belts with manual adjustment 5

The strap should be worn flat over your thighs and against your pelvis.

The belt should be worn so that it is as close as possible to your body, i.e. avoid wearing heavy clothing or keeping bulky objects under the belts, etc.

To tighten, pull on free section **6** of the belt.

To slacken, turn adjusting buckle **4** so it is at 90 degrees to the belt and press the buckle while pulling lap belt **5**.



Seat belts which are incorrectly adjusted or twisted may cause injuries in the event of an accident.

Use one seat belt per person, whether child or adult.

Even pregnant women should wear a seat belt. In this case, ensure that the lap belt is not exerting too much pressure on the abdomen, but do not allow any slack.

## METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (1/3)

Depending on the vehicle, they are composed of:

- **seat belt pretensioners;**
- **chest-level load limiters;**
- **air bags for driver and front passenger.**

These systems are designed to act independently or together when the vehicle is subjected to a frontal impact.

Depending on the severity of the impact, the system can trigger:

- seat belt locking;
- the seat belt seat belt pretensioner to hold the occupant in the seat, and the force limiter;
- the front air bag.

The passenger air bag protects the front passenger(s) (depending on whether there is a conventional seat or a bench seat in the front).

30054



### Pretensioners

The pretensioners hold the seat belt against the body, holding the occupant more securely against the seat, thus increasing the seat belt's efficiency.

With the ignition switched on, if the vehicle is subject to a significant frontal impact the system may, depending on the severity of the impact, trigger a piston which instantly retracts the belt.

### Load limiter

Above a certain level of impact force, this mechanism is used to limit the force of the belt against the body so that it is at an acceptable level.



– Have the entire restraint system checked following an accident.

– No operation whatsoever is permitted on any part of the system (pretensioners, air bags, computers, wiring) and the system components must not be reused on any other vehicle, even if identical.

– To avoid incorrect triggering of the system which may cause injury, only qualified personnel from an approved dealer may work on the pretensioner and air bag system.

– The electric trigger system may only be tested by a specially trained technician using special equipment.

– When the vehicle is scrapped, contact an approved dealer for disposal of the pretensioner and air bag gas generators.


## METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (2/3)

### Driver and passenger front airbags

It is fitted to the front seats on the driver's side and, depending on the vehicle, on the passenger's side as well.

Depending on the vehicle, an "air bag" marking on the steering wheel and the dashboard (air bag area **A**) indicates that this device is fitted.

Each air bag system consists of:

- an air bag and gas generator fitted on the steering wheel for the driver and in the dashboard for the front passenger;
- an electronic unit for system monitoring which controls the gas generator electrical trigger system;
- a special  tell-tale light;
- remote sensors.

### Operation

This system is only operational when the ignition is switched on.

If a severe **frontal** impact occurs, the air bag(s) inflate rapidly, thus cushioning the impact of the driver's head and chest on the steering wheel and those of the passenger on the dashboard; the air bag(s) then deflate immediately after the impact to prevent the occupants from being impeded in any way when leaving the vehicle.



The air bag system uses pyrotechnic principles. This explains why, when the air bag inflates, it will generate heat, produce smoke (this does not mean that a fire is about to start) and make a noise upon detonation. In a situation where an air bag is required, it will inflate immediately and this may cause some minor, superficial grazing to the skin or other problems.

## METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (3/3)

All of the warnings below are given so that the air bag is not obstructed in any way when it is deployed and also to prevent the risk of serious injuries caused by items which may be dislodged when the air bag deploys.



### **Warnings concerning the driver's air bag**

- Do not modify the steering wheel or the steering wheel boss.
- Do not cover the steering wheel boss under any circumstances.
- Do not attach any objects (badge, logo, clock, telephone holder, etc.) to the steering wheel boss.
- The steering wheel must not be removed (except by qualified personnel from our Network).
- When driving, do not sit too close to the steering wheel. Sit with your arms slightly bent (see the information on “Adjusting your driving position” in Section 1). This will allow sufficient space for the air bag to deploy correctly and be fully effective.

### **Warnings concerning the passenger air bag**

- Do not attach or glue any objects (badge, logo, clock, telephone holder, etc.) to the dashboard on or near the air bag.
- Do not place anything between the dashboard and the passenger (pet, umbrella, walking stick, parcels, etc.).
- The passenger must not put his or her feet on the dashboard or seat as there is a risk that serious injuries may occur. In general, parts of the body should be kept away from the dashboard (knees, hands, head, etc.).
- The devices in addition to the front passenger seat belt should be reactivated as soon as a child seat is removed, to ensure the protection of the passenger in the event of an impact.

**A CHILD SEAT MUST NOT BE FITTED TO THE FRONT PASSENGER SEAT UNLESS THE ADDITIONAL RESTRAINT SYSTEMS, I.E. THE PASSENGER AIR BAG, ARE DEACTIVATED.**

(refer to the information on “Child safety: deactivating/activating the front passenger air bag” in Section 1)

## SIDE PROTECTION DEVICES

### Side air bags

These air bags may be fitted to the front seats and are deployed at the sides of the seats (door side) to protect the occupants in the event of a severe side impact.



These air bags operate through slits in the front seatbacks (door side): never insert any objects in these slits.



#### Warnings concerning the side air bag

- **Fitting seat covers:** seats equipped with an air bag require covers specifically designed for your vehicle. Contact an approved Dealer to find out if these covers are available. The use of any covers other than those designed for your vehicle (and including those designed for another vehicle) may affect the operation of the air bags and reduce your protection.
- Do not place any accessories, objects or even pets between the seatback, the door and the internal fittings. Do not cover the seatback with any items such as clothes or accessories. This may prevent the air bag from operating correctly or cause injury when the air bag is deployed.
- No work or modification whatsoever may be carried out on the seat or internal fittings, except by qualified personnel from an approved Dealer.

## ADDITIONAL METHODS OF RESTRAINT

All of the warnings below are given so that the air bag is not obstructed in any way when it is inflated and also to prevent the risk of serious injuries caused by items which may be dislodged when the air bag inflates.




The air bag is designed to complement the action of the seat belt. Both the air bags and seat belts are integral parts of the same protection system. It is therefore essential to wear seat belts at all times. If seat belts are not worn, the occupants are exposed to the risk of serious injury in the event of an accident. It may also increase the risk of minor superficial injuries occurring when the air bag is deployed, although such minor injuries are always possible with air bags.

If the vehicle should overturn or suffer a rear impact, however severe, the pretensioners and air bags are not always triggered. Shocks to the underbody of the vehicle, e.g. from pavements, potholes or stones, can all trigger these systems.

- No work or modification **whatsoever** may be carried out on any part of the air bag system (air bags, pretensioners, computer, wiring harness, etc.), except by qualified personnel from an approved dealer.
- To ensure that the system is in good working order and to avoid accidental triggering of the system which may cause injury, only qualified Network personnel may work on the air bag system.
- As a safety precaution, have the air bag system checked if your vehicle has been involved in an accident, or is stolen or broken into.
- When selling or lending the vehicle, inform the user of these points and hand over this driver's handbook with the vehicle.
- When scrapping your vehicle, contact your approved dealer for disposal of the gas generator(s).



### Operating faults

Indicator light 1, , lights up when the ignition is switched on and goes out after a few seconds.

If it does not light up when the ignition is switched on, or comes on when the engine is running, there is a fault in the system.

Contact your approved dealer as soon as possible. Your protection will be reduced until this fault is rectified.

## CHILD SAFETY: General information (1/2)

### Carrying children

Children, and adults, must be correctly seated and strapped in for all journeys. The children being carried in your vehicle are your responsibility.

A child is not a miniature adult. Children are at risk of specific injuries as their muscles and bones have not yet finished growing. The seat belt alone would not provide suitable protection. Use an approved child seat and ensure you use it correctly.



To prevent the doors being opened, use the childproof locks (please refer to the information on "Locking/unlocking the doors" in Section 1).



A collision at 30 mph (50 km/h) is the same as falling a distance of 10 metres. Transporting a child without a restraint is the equivalent of allowing him or her to play on a fourth-floor balcony without railings.

Never travel with a child held in your arms. In the event of an accident, you will not be able to keep hold of the child, even if you yourself are wearing a seat belt.

If your vehicle has been involved in a road accident, replace the child seat and have the seat belts checked.



### Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or by locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**

## CHILD SAFETY: General information (2/2)

### Using a child seat

The level of protection offered by the child seat depends on its ability to restrain your child and on its installation. Incorrect installation compromises the protection it offers the child in the event of harsh braking or an impact.

Before purchasing a child seat, check that it complies with the regulations for the country you are in and that it can be fitted in your vehicle. Consult an approved dealer to find out which seats are recommended for your vehicle.

Before fitting a child seat, read the manual and respect its instructions. If you experience any difficulties during installation, contact the manufacturer of the equipment. Keep the instructions with the seat.

Set a good example by always fastening your seat belt and teaching your child:

- to strap themselves in correctly.
- to always get in and out of the car at the kerb, away from busy traffic.

Do not use a second-hand child seat or one without an instruction manual.

Check that there are no objects in the vicinity of the child seat which could impede its operation.



Never leave a child unattended in the vehicle.

Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted. Avoid wearing bulky clothing which could cause the belts to slacken.

Never let your child put their head or arms out of the window.

Check that the child is in the correct position for the entire journey, especially if asleep.



## CHILD SAFETY: choosing a child seat



### Rear-facing child seats

A baby's head is, proportionally, heavier than that of an adult and its neck is very fragile. Transport the child in this position for as long as possible (until the age of 2 at the very least). It supports both the head and the neck.

Choose a bucket type seat for best side protection and change it as soon as the child's head is higher than the shell.



### Forward-facing child seats

The child's head and abdomen need to be protected as a priority. A forward-facing child seat which is firmly attached to the vehicle will reduce the risk of impact to the head. Ensure your child travels in a forward-facing seat with a harness for as long as their size permits.

Choose a bucket type seat for optimum side protection.



### Booster cushions

From 15 kg or 4 years, the child can travel using a booster seat, which will enable the seat belt to be adapted to suit his/her size and shape. The booster seat cushion must be fitted with guides to position the seat belt on the child's thighs rather than the stomach. It is recommended that you use a seat-back fitted with a belt strap guide which can be adjusted in terms of height to position the seat belt in the centre of the shoulder. It must never rest on the neck or on the arm.

Choose a bucket type seat for optimum side protection.

## CHILD SAFETY: choosing a child, baby seat mounting (1/2)

There are two ways of attaching child seats: via the seat belt or using the ISOFIX system.

### Attachment via the seat belt

The seat belt must be adjusted to ensure that it is effective in the event of harsh braking or an impact.

Ensure that the strap paths indicated by the child seat manufacturer are respected.

Always check that the seat belt is correctly fastened by pulling it up, then pulling it out fully whilst pressing on the child seat.

Check that the seat is correctly held by moving it from side to side and back to front: the seat should remain firmly fixed.



Do not use the child seat if it may unfasten the seat belt restraining it: the base of the seat must not rest on the buckle and/or catch of the seat belt.

Check that the child seat has not been installed at an angle and that it is not resting against a window.



The seat belt must never be twisted or the tension relieved. Never pass the shoulder strap under the arm or behind the back.

Check that the seat belt has not been damaged by sharp edges.

If the seat belt does not operate normally, it will not protect the child. Consult an approved dealer. Do not use this seat until the seat belt has been repaired.



No modifications may be made to the component parts of the restraint system (ISOFIX seat belts, seats and their mountings) originally fitted.

### Attachment using the ISOFIX system

Authorised ISOFIX child seats are approved in accordance with regulation ECE-R44 in one of the three following scenarios:

- universal ISOFIX 3-point forward-facing seat;
- semi-universal ISOFIX 2-point seat;
- specific.


For the latter two, check that your child seat can be installed by consulting the list of compatible vehicles.

Attach the child seat with the ISOFIX locks, if these are provided. The ISOFIX system allows quick, easy, safe fitting. The ISOFIX system consists of 2 rings and, in some cases, a third ring.




Before using an ISOFIX child seat that you purchased for another vehicle, check that its installation is authorised. Consult the list of vehicles which can be fitted with the seat from the equipment manufacturer.

## CHILD SAFETY: choosing a child, baby seat mounting (2/2)



The two rings **1** are located between the seatback and the seat base of the seat and are identified by a marking.



The third ring is used to attach the upper strap on some child seats.

- Place the headrest in the top position or remove it;
- pass the belt **2** (supplied with the seat) between the two rear headrest rods;
- attach the hook **3** to ring **4** (**essential**) located in the luggage compartment;
- tighten the belt.



The ISOFIX anchorage points have been exclusively designed for child seats with the ISOFIX system. Never fit a different type of child seat, seat belt or other objects to these anchorage points.

Check that nothing is obstructing the anchorage points.

If your vehicle has been involved in a road accident, have the ISOFIX anchorage points checked and replace your child seat.

## CHILD SAFETY: fitting a child seat: general information (1/2)

Some seats are not suitable for fitting child seats. The diagrams on the following pages show you how to attach a child seat.

The types of child seats indicated may not be available. Before using a different child seat, check with the manufacturer that it can be fitted.



Fit the child seat in a rear seat wherever possible.

Check that when installing the child seat in the vehicle it is not at risk of coming loose from its base.

If you have to remove the headrest, check that it is correctly stored so that it does not come loose under harsh braking or impact.

Always attach the child seat to the vehicle even if it is not in use so that it does not come loose under harsh braking or impact.

### Front seats

The laws concerning children travelling in the front passenger seat differ in every country. Consult the legislation in force and follow the indications on the diagrams on the following pages.

Before fitting a child seat in this seat (if authorised):

- lower the seat belt as far as possible;
- on equipped vehicles, push the seat back as far as possible;
- on equipped vehicles, tilt the seat-back slightly (approximately 25°);
- on equipped vehicles, raise the seat base as far as possible.

Do not change these settings after the child seat is installed.



### **RISK OF DEATH OR SERIOUS INJURY:**

before installing a child seat on the front passenger seat, check that the air bag has been deactivated (refer to "Child safety: front passenger air bag deactivation/activation" Section 1).

## CHILD SAFETY: fitting a child seat, general information (2/2)

### In the rear seat

A carrycot can be installed across the vehicle and will take up at least two seats. Position the child with his or her feet nearest the door.

Move the front seat as far forward as possible to install a rear-facing child seat, then move back the seat in front as far as it will go, although without allowing it to come into contact with the child seat.

For the safety of the child in the forward-facing seat, do not move the seat in front back past the middle of the runner, do not tilt the seatback too far (maximum of 25°) and raise the seat as much as possible.

Check that the forward-facing child seat is resting against the back of the vehicle seat and that the headrest of the vehicle is not obstructing its use.



A child seat with a floor support must never be installed on the rear centre seat.

**RISK OF DEATH OR  
SERIOUS INJURY.**

# CHILD SEATS: attachment by seat belt (1/18)

Two-seat van version



Check the status of the air bag before fitting a child seat or allowing a passenger to use the seat.



Seat not suitable for fitting child seats.

## Child seat attached using the belt



Seat which allows a child seat with "Universal" approval to be attached by a seat belt.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.



**RISK OF DEATH OR SERIOUS INJURY:** before installing a child seat on the front passenger seat, check that the air bag has been deactivated (refer to "Child safety: front passenger air bag deactivation/activation" Section 1).

## CHILD SEATS: attachment by seat belt (2/18)

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

Two-seat van version		WITH PASSENGER AIR BAG	WITHOUT PASSENGER AIR BAG
Child seat group	Weight of the child	Front passenger seat	Front passenger seat
<b>Rear-facing shell seat</b> Group 0 or 0 +	< 13 kg	U (1)	U
<b>Rear-facing seat</b> Group 0+ and 1	< 13 kg and 9 to 18 kg	U (1)	U
<b>Forward-facing seat</b> Group 1	9 to 18 kg	U (1)	U
<b>Booster seat</b> Group 2 and 3	15 kg to 25 kg and 22 to 36 kg	U (1)	U


U = Seat allowing a child seat with "Universal" approval to be attached by seat belt; check that it can be fitted.



**(1) RISK OF DEATH OR SERIOUS INJURY:** before installing a child seat on the front passenger seat, check that the air bag has been deactivated (refer to "Child safety: front passenger air bag deactivation/activation" Section 1).

## CHILD SEATS: attachment by seat belt (3/18)

Three-seat van version



Check the status of the air bag before fitting a child seat or allowing a passenger to use the seat.



Seat not suitable for fitting child seats.

### Child seat attached using the belt

**U** Seat allowing a child seat with "Universal" approval to be attached by seat belt; check that it can be fitted.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.



**RISK OF DEATH OR SERIOUS INJURY:** before installing a child seat on the front passenger seat, check that the air bag has been deactivated (refer to "Child safety: front passenger air bag deactivation/activation" Section 1).



## CHILD SEATS: attachment by seat belt (4/18)

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

Three-seat van version		WITH PASSENGER AIR BAG		WITHOUT PASSENGER AIR BAG	
Child seat group	Weight of the child	Central front passenger seat	Side front passenger seat	Central front passenger seat	Side front passenger seat
<b>Rear-facing shell seat</b> Group 0 or 0 +	< 13 kg	U (1)	U (1)	U	U
<b>Rear-facing seat</b> Group 0+ and 1	< 13 kg and 9 to 18 kg	U (1)	U (1)	U	U
<b>Forward-facing seat</b> Group 1	9 to 18 kg	U (1)	U (1)	U	U
<b>Booster seat</b> Group 2 and 3	15 kg to 25 kg and 22 to 36 kg	U (1)	U (1)	U	U


U = Seat allowing a child seat with “Universal” approval to be attached by seat belt; check that it can be fitted.



**(1) RISK OF DEATH OR SERIOUS INJURY:** before fitting a rear-facing child seat in this position, check that the air bag has been deactivated (refer to the information on “Child safety: deactivating/activating the front passenger air bag” in Section 1).

# CHILD SEATS: attachment by seat belt (5/18)

Double cab version



Check the status of the air bag before fitting a child seat or allowing a passenger to use the seat.



Seat not suitable for fitting child seats.

## Child seat attached using the belt

**U** Seat allowing a child seat with “Universal” approval to be attached by seat belt; check that it can be fitted.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.



**RISK OF DEATH OR SERIOUS INJURY:** before fitting a rear-facing child seat in this position, check that the air bag has been deactivated (refer to the information on “Child safety: deactivating/activating the front passenger air bag” in Section 1).

## CHILD SEATS: attachment by seat belt (6/18)

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

Double cab version		WITH PASSENGER AIR BAG		WITHOUT PASSENGER AIR BAG		Rear side seats	Rear central seats
Child seat group	Weight of the child	Central front passenger seat	Side front passenger seat	Central front passenger seat	Side front passenger seat		
<b>Rear-facing shell seat</b> Group 0 or 0 +	< 13 kg	U (1)	U (1)	U	U	U	X
<b>Rear-facing seat</b> Group 0+ and 1	< 13 kg and 9 to 18 kg	U (1)	U (1)	U	U	U	X
<b>Forward-facing seat</b> Group 1	9 to 18 kg	U (1)	U (1)	U	U	U	X
<b>Booster seat</b> Group 2 and 3	15 kg to 25 kg and 22 to 36 kg	U (1)	U (1)	U	U	U	X

X = Seat not suitable for fitting child seats.

U = Seat allowing a child seat with “Universal” approval to be attached by seat belt; check that it can be fitted.



**(1) RISK OF DEATH OR SERIOUS INJURY:** before fitting a rear-facing child seat in this position, check that the air bag has been deactivated (refer to the information on “Child safety: deactivating/activating the front passenger air bag” in Section 1).

## CHILD SEATS: attachment by seat belt (7/18)

The table below summarises the information already shown on the diagram on the next page, to ensure the regulations in force are respected.

5-seater Combi version		Front seats		Rear seats		
Child seat group	Weight of the child	WITH PASSENGER AIRBAG (3)	WITHOUT PASSENGER AIR BAG	2nd row side seats		2nd row centre seat
				Behind driver	Behind front passenger	
<b>Carrycot fitted across the vehicle</b> Group 0	< 10 kg	X	X	X	X	X
<b>Rear-facing shell seat</b> Group 0 or 0 +	< 13 kg	U	U	U (1)	X	X
<b>Rear-facing seat</b> Group 0+ and 1	< 13 kg and 9 to 18 kg	U	U	U (1)	X	X
<b>Forward-facing seat</b> Group 1	9 to 18 kg	U	U (2)	U (2)	UF (2)	UF (2)
<b>Booster seat</b> Group 2 and 3	15 kg to 25 kg and 22 to 36 kg	U (2)	U (2)	U (2)	UF (2)	UF (2)

## CHILD SEATS: attachment by seat belt (8/18)

**X** = Seat not suitable for fitting child seats.

**U** = Seat which allows a child seat with “Universal” approval to be installed using a seat belt; check that it can be fitted.

**UF** = Seat which only allows a forward-facing seat with “Universal” approval to be attached with a seat belt; check that it can be fitted.


- (1) Move the front seat as far forward as possible to install a rear-facing child seat, then move back the seat in front as far as it will go, although without allowing it to come into contact with the child seat.
- (2) Forward-facing child seat; position the seatback of the child seat in contact with the seatback of the vehicle seat. Adjust the height of the headrest or remove it if necessary; do not push the seat in front of the child more than halfway back on its runners and do not recline the seatback more than 25°.



**(3) RISK OF DEATH OR SERIOUS INJURY:** before installing a child seat on the front passenger seat, check that the airbag has been deactivated (refer to “Child safety: front passenger airbag deactivation, activation” Section 1).

# CHILD SEATS: attachment by seat belt (9/18)

## 5-seater Combi version



### Child seat attached using the belt

**U** Seat which allows a child seat with “Universal” approval to be attached by a seat belt;

**⊘** Seat not suitable for fitting child seats.

**UF** Seat which **only** allows a **forward-facing seat** with “Universal” approval to be attached with a seat belt.

**⊘** Check the status of the air bag before fitting a child seat or allowing a passenger to use the seat.




**RISK OF DEATH OR SERIOUS INJURY:** before fitting a rear-facing child seat on the front passenger seat, check that the air bag has been deactivated (refer to the information on “Deactivating the front passenger air bag” in Section 1).



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.

# CHILD SEATS: attachment by seat belt (10/18)

## 6-seater Combi version



### Child seat attached using the belt

**U** Seat which allows a child seat with “Universal” approval to be attached by a seat belt;

**⊘** Seat not suitable for fitting child seats.

**UF** Seat which **only** allows a **forward-facing seat** with “Universal” approval to be attached with a seat belt.

**⊘** Check the status of the air bag before fitting a child seat or allowing a passenger to use the seat.



**RISK OF DEATH OR SERIOUS INJURY:** before fitting a rear-facing child seat on the front passenger seat, check that the air bag has been deactivated (refer to the information on “Deactivating the front passenger air bag” in Section 1).



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.

## CHILD SEATS: attachment by seat belt (11/18)

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

6-seater Combi version		Front seats				Rear seats		
Child seat group	Weight of the child	WITH PASSENGER AIRBAG (3)		WITHOUT PASSENGER AIR BAG		2nd row side seats		2nd row centre seat
		central	side	central	side	Behind driver	Behind front passenger	
<b>Carrycot fitted across the vehicle</b> Group 0	< 10 kg	X	X	X	X	X	X	X
<b>Rear-facing shell seat</b> Group 0 or 0 +	< 13 kg	U	U	U	U	U (1)	X	X
<b>Rear-facing seat</b> Group 0+ and 1	< 13 kg and 9 to 18 kg	U	U	U	U	U (1)	X	X
<b>Forward-facing seat</b> Group 1	9 to 18 kg	U (2)	U (2)	U (2)	U (2)	U (2)	UF (2)	UF (2)
<b>Booster seat</b> Group 2 and 3	15 kg to 25 kg and 22 to 36 kg	U (2)	U (2)	U (2)	U (2)	U (2)	UF (2)	UF (2)



## CHILD SEATS: attachment by seat belt (12/18)

**X** = Seat not suitable for fitting child seats.

**U** = Seat which allows a child seat with “Universal” approval to be installed using a seat belt; check that it can be fitted.

**UF** = Seat which only allows a forward-facing seat with “Universal” approval to be attached with a seat belt; check that it can be fitted.

- (1) Move the front seat as far forward as possible to install a rear-facing child seat, then move back the seat in front as far as it will go, although without allowing it to come into contact with the child seat.
- (2) Forward-facing child seat; position the seatback of the child seat in contact with the seatback of the vehicle seat. Adjust the height of the headrest or remove it if necessary; do not push the seat in front of the child more than halfway back on its runners and do not recline the seatback more than 25°.



**(3) RISK OF DEATH OR SERIOUS INJURY:** before installing a child seat on the front passenger seat, check that the airbag has been deactivated (refer to “Child safety: front passenger airbag deactivation, activation” Section 1).

## CHILD SEATS: attachment by seat belt (13/18)

The table below summarises the information already shown on the diagram on the next page, to ensure the regulations in force are respected.

8-seater Combi version		Front seats		Rear seats			
Child seat group	Weight of the child	WITH PASSENGER AIRBAG (1)	WITHOUT PASSENGER AIR BAG	2nd row side seats		2nd row centre seat	3rd row
		central	central	Behind driver	Behind front passenger		
<b>Carrycot fitted across the vehicle</b> Group 0	< 10 kg	X	X	X	X	X	X
<b>Rear-facing shell seat</b> Group 0 or 0 +	< 13 kg	U	U	U (1)	X	X	X
<b>Rear-facing seat</b> Group 0+ and 1	< 13 kg and 9 to 18 kg	U	U	U (2)	X	X	X
<b>Forward-facing seat</b> Group 1	9 to 18 kg	U (2)	U (2)	U (2)	UF (2)	UF (2)	X
<b>Booster seat</b> Group 2 and 3	15 kg to 25 kg and 22 to 36 kg	U (2)	U (2)	U (2)	UF (2)	UF (2)	X

## CHILD SEATS: attachment by seat belt (14/18)

**X** = Seat not suitable for fitting child seats.

**U** = Seat which allows a child seat with “Universal” approval to be installed using a seat belt; check that it can be fitted.

**UF** = Seat which only allows a forward-facing seat with “Universal” approval to be attached with a seat belt; check that it can be fitted.


- (1) Move the front seat as far forward as possible to install a rear-facing child seat, then move back the seat in front as far as it will go, although without allowing it to come into contact with the child seat.
- (2) Forward-facing child seat; position the seatback of the child seat in contact with the seatback of the vehicle seat. Adjust the height of the headrest or remove it if necessary; do not push the seat in front of the child more than halfway back on its runners and do not recline the seatback more than 25°.



**(3) RISK OF DEATH OR SERIOUS INJURY:** before installing a child seat on the front passenger seat, check that the airbag has been deactivated (refer to “Child safety: front passenger airbag deactivation, activation” Section 1).

# CHILD SEATS: attachment by seat belt (15/18)

## 8-seater Combi version



### Child seat attached using the belt

**U** Seat which allows a child seat with “Universal” approval to be attached by a seat belt;

**⊘** Seat not suitable for fitting child seats.

**UF** Seat which **only** allows a **forward-facing seat** with “Universal” approval to be attached with a seat belt.



Check the status of the air bag before fitting a child seat or allowing a passenger to use the seat.




**RISK OF DEATH OR SERIOUS INJURY:** before fitting a rear-facing child seat on the front passenger seat, check that the air bag has been deactivated (refer to the information on “Deactivating the front passenger air bag” in Section 1).



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.

# CHILD SEATS: attachment by seat belt (16/18)

## 9-seater Combi version



### Child seat attached using the belt

**U** Seat which allows a child seat with “Universal” approval to be attached by a seat belt;

**⊘** Seat not suitable for fitting child seats.

**UF** Seat which **only** allows a **forward-facing seat** with “Universal” approval to be attached with a seat belt.

**⊘** Check the status of the air bag before fitting a child seat or allowing a passenger to use the seat.



**RISK OF DEATH OR SERIOUS INJURY:** before fitting a rear-facing child seat on the front passenger seat, check that the air bag has been deactivated (refer to the information on “Deactivating the front passenger air bag” in Section 1).



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.

## CHILD SEATS: attachment by seat belt (17/18)

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

9-seater Combi version		Front seats				Rear seats			
Child seat group	Weight of the child	WITH PASSENGER AIRBAG (3)		WITHOUT PASSENGER AIR BAG		2nd row side seats		2nd row centre seat	3rd row
		central	side	central	side	Behind driver	Behind front passenger		
<b>Carrycot fitted across the vehicle</b> Group 0	< 10 kg	X	X	X	X	X	X	X	X
<b>Rear-facing shell seat</b> Group 0 or 0 +	< 13 kg	U	U	U	U	U (1)	X	X	X
<b>Rear-facing seat</b> Group 0+ and 1	< 13 kg and 9 to 18 kg	U	U	U	U	U (1)	X	X	X
<b>Forward-facing seat</b> Group 1	9 to 18 kg	U (2)	U (2)	U (2)	U (2)	U (2)	UF (2)	UF (2)	X
<b>Booster seat</b> Group 2 and 3	15 kg to 25 kg and 22 to 36 kg	U (2)	U (2)	U (2)	U (2)	U (2)	UF (2)	UF (2)	X

## CHILD SEATS: attachment by seat belt (18/18)

**X** = Seat not suitable for fitting child seats.

**U** = Seat which allows a child seat with “Universal” approval to be installed using a seat belt; check that it can be fitted.

**UF** = Seat which only allows a forward-facing seat with “Universal” approval to be attached with a seat belt; check that it can be fitted.

- (1) Move the front seat as far forward as possible to install a rear-facing child seat, then move back the seat in front as far as it will go, although without allowing it to come into contact with the child seat.
- (2) Forward-facing child seat; position the seatback of the child seat in contact with the seatback of the vehicle seat. Adjust the height of the headrest or remove it if necessary; do not push the seat in front of the child more than halfway back on its runners and do not recline the seatback more than 25°.



**(3) RISK OF DEATH OR SERIOUS INJURY:** before installing a child seat on the front passenger seat, check that the airbag has been deactivated (refer to “Child safety: front passenger airbag deactivation, activation” Section 1).

## CHILD SEATS: attachment using the ISOFIX system (1/12)

The table below summarises the information already shown in the diagram on the following pages, to ensure the applicable regulations are respected.

5-seater Combi version			Front seats	Rear seats		
Child seat group	Weight of the child	Size of Isofix seat		2nd row side seats		2nd row centre seat
				Behind driver	Behind front passenger	
<b>Carrycot fitted across the vehicle</b> Group 0	< 10 kg	F, G	X	X	X	X
<b>Rear-facing shell seat</b> Group 0 or 0 +	< 13 kg	E	X	IL (1)	X	X
<b>Rear-facing seat</b> Group 0+ and 1	< 13 kg and 9 to 18 kg	C, D	X	IL (1)	X	X
<b>Forward-facing seat</b> Group 1	9 to 18 kg	A, B, B1	X	IUF - IL (2)	X	IUF - IL (2)
<b>Booster seat</b> Group 2 and 3	15 kg to 25 kg and 22 to 36 kg		X	X	X	X



## **CHILD SEATS: attachment using the ISOFIX system (2/12)**

**X** = Seat not suitable for fitting child seats ISOFIX.

**IUF/IL** = On equipped vehicles, seat which allows an approved “Universal”/“semi-universal” or “vehicle specific” child seat to be attached using the ISOFIX system; check that it can be fitted.

- (1)** Move the front seat as far forward as possible to install a rear-facing child seat, then move back the seat in front as far as it will go, although without allowing it to come into contact with the child seat.
- (2)** Forward-facing child seat; position the seatback of the child seat in contact with the seatback of the vehicle seat. In all situations, remove the rear headrest of the seat on which the child seat is positioned. This must be done before fitting the child seat (please refer to the section entitled “Rear headrests” in Section 3). Do not push the seat in front of the child more than halfway back on its runners and do not recline the seatback more than 25°.

# CHILD SEATS: attachment using the ISOFIX system (3/12)

## 5-seater Combi



### Child seat attached using the ISOFIX mounting



Seat which allows an ISOFIX child seat to be fitted.



The rear seats are fitted with an anchorage point which allows a forward-facing ISOFIX child seat with universal approval to be fitted. The anchorage points are located in the luggage compartment and are visible.

The size of the ISOFIX child seat is indicated by a letter:

- A, B and B1: for forward-facing seats in group 1 (9 to 18 kg);
- C: rear-facing seats in group 1 (9 to 18 kg);
- D and E: shell seat or rear-facing seats in group 0 or 0+ (less than 13 kg);
- F and G: carrycots in group 0 (less than 10 kg).



Seat which does not allow a child seat to be fitted.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.

# CHILD SEATS: attachment using the ISOFIX system (4/12)

## 6-seater Combi



### Child seat attached using the ISOFIX mounting



Seat which allows an ISOFIX child seat to be fitted.



The rear seats are fitted with an anchorage point which allows a forward-facing ISOFIX child seat with universal approval to be fitted. The anchorage points are located in the luggage compartment and are visible.

The size of the ISOFIX child seat is indicated by a letter:

- A, B and B1: for forward-facing seats in group 1 (9 to 18 kg);
- C: rear-facing seats in group 1 (9 to 18 kg);
- D and E: shell seat or rear-facing seats in group 0 or 0+ (less than 13 kg);
- F and G: carrycots in group 0 (less than 10 kg).



Seat which does not allow a child seat to be fitted.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.

## CHILD SEATS: attachment using the ISOFIX system (5/12)

The table below summarises the information already shown on the diagram on the previous page, to ensure the applicable regulations are respected.

6-seater Combi version			Front seats		Rear seats		
Child seat group	Weight of the child	Size of Isofix seat	central	side	2nd row side seats		2nd row centre seat
					Behind driver	Behind front passenger	
<b>Carrycot fitted across the vehicle</b> Group 0	< 10 kg	F, G	X	X	X	X	X
<b>Rear-facing shell seat</b> Group 0 or 0 +	< 13 kg	E	X	X	IL (1)	X	X
<b>Rear-facing seat</b> Group 0+ and 1	< 13 kg and 9 to 18 kg	C, D	X	X	IL (1)	X	X
<b>Forward-facing seat</b> Group 1	9 to 18 kg	A, B, B1	X	X	IUF - IL (2)	X	IUF - IL (2)
<b>Booster seat</b> Group 2 and 3	15 kg to 25 kg and 22 to 36 kg		X	X	X	X	X

## **CHILD SEATS: attachment using the ISOFIX system (6/12)**

**X** = Seat not suitable for fitting child seats ISOFIX.

**IUF/IL** = On equipped vehicles, seat which allows an approved "Universal"/"semi-universal" or "vehicle specific" child seat to be attached using the ISOFIX system; check that it can be fitted.

- (1)** Move the front seat as far forward as possible to install a rear-facing child seat, then move back the seat in front as far as it will go, although without allowing it to come into contact with the child seat.
- (2)** Forward-facing child seat; position the seatback of the child seat in contact with the seatback of the vehicle seat. In all situations, remove the rear headrest of the seat on which the child seat is positioned. This must be done before fitting the child seat (please refer to the section entitled "Rear headrests" in Section 3). Do not push the seat in front of the child more than halfway back on its runners and do not recline the seatback more than 25°.

## CHILD SEATS: attachment using the ISOFIX system (7/12)

The table below summarises the information already shown on the diagram on the following pages, to ensure the applicable regulations are respected.

8-seater Combi version			Front seats	Rear seats			
Child seat group	Weight of the child	Size of Isofix seat	central	2nd row side seats		2nd row centre seat	3rd row
				Behind driver	Behind front passenger		
<b>Carrycot fitted across the vehicle</b> Group 0	< 10 kg	F, G	X	X	X	X	X
<b>Rear-facing shell seat</b> Group 0 or 0 +	< 13 kg	E	X	IL (1)	X	X	X
<b>Rear-facing seat</b> Group 0+ and 1	< 13 kg and 9 to 18 kg	C, D	X	IL (1)	X	X	X
<b>Forward-facing seat</b> Group 1	9 to 18 kg	A, B, B1	X	IUF - IL (2)	X	IUF - IL (2)	X
<b>Booster seat</b> Group 2 and 3	15 kg to 25 kg and 22 to 36 kg		X	X	X	X	X

## **CHILD SEATS: attachment using the ISOFIX system (8/12)**


**X** = Seat not suitable for fitting child seats ISOFIX.

**IUF/IL** = On equipped vehicles, seat which allows an approved “Universal”/“semi-universal” or “vehicle specific” child seat to be attached using the ISOFIX system; check that it can be fitted.

- (1)** Move the front seat as far forward as possible to install a rear-facing child seat, then move back the seat in front as far as it will go, although without allowing it to come into contact with the child seat.
- (2)** Forward-facing child seat; position the seatback of the child seat in contact with the seatback of the vehicle seat. In all situations, remove the rear headrest of the seat on which the child seat is positioned. This must be done before fitting the child seat (please refer to the section entitled “Rear headrests” in Section 3). Do not push the seat in front of the child more than halfway back on its runners and do not recline the seatback more than 25°.

# CHILD SEATS: attachment using the ISOFIX system (9/12)

## 8-seater Combi



### Child seat attached using the ISOFIX mounting



Seat which allows an ISOFIX child seat to be fitted.



The rear seats are fitted with an anchorage point which allows a forward-facing ISOFIX child seat with universal approval to be fitted. The anchorage points are located in the luggage compartment and are visible.

The size of the ISOFIX child seat is indicated by a letter:

- A, B and B1: for forward-facing seats in group 1 (9 to 18 kg);
- C: rear-facing seats in group 1 (9 to 18 kg);
- D and E: shell seat or rear-facing seats in group 0 or 0+ (less than 13 kg);
- F and G: carrycots in group 0 (less than 10 kg).



Seat which does not allow a child seat to be fitted.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.



# CHILD SEATS: attachment using the ISOFIX system (10/12)

## 9-seater Combi



### Child seat attached using the ISOFIX mounting



Seat which allows an ISOFIX child seat to be fitted.



The rear seats are fitted with an anchorage point which allows a forward-facing ISOFIX child seat with universal approval to be fitted. The anchorage points are located in the luggage compartment and are visible.

The size of the ISOFIX child seat is indicated by a letter:

- A, B and B1: for forward-facing seats in group 1 (9 to 18 kg);
- C: rear-facing seats in group 1 (9 to 18 kg);
- D and E: shell seat or rear-facing seats in group 0 or 0+ (less than 13 kg);
- F and G: carrycots in group 0 (less than 10 kg).



Seat which does not allow a child seat to be fitted.



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.

## CHILD SEATS: attachment using the ISOFIX system (11/12)

The table below summarises the information already shown on the diagram on the previous page, to ensure the applicable regulations are respected.

9-seater Combi version			Front seats		Rear seats			
Child seat group	Weight of the child	Size of Isofix seat	central	side	2nd row side seats		2nd row centre seat	3rd row
					Behind driver	Behind front passenger		
<b>Carrycot fitted across the vehicle</b> Group 0	< 10 kg	F, G	X	X	X	X	X	X
<b>Rear-facing shell seat</b> Group 0 or 0 +	< 13 kg	E	X	X	IL (1)	X	X	X
<b>Rear-facing seat</b> Group 0+ and 1	< 13 kg and 9 to 18 kg	C, D	X	X	IL (1)	X	X	X
<b>Forward-facing seat</b> Group 1	9 to 18 kg	A, B, B1	X	X	IUF - IL (2)	X	IUF - IL (2)	X
<b>Booster seat</b> Group 2 and 3	15 kg to 25 kg and 22 to 36 kg		X	X	X	X	X	X


## **CHILD SEATS: attachment using the ISOFIX system (12/12)**

**X** = Seat not suitable for fitting child seats ISOFIX.

**IUF/IL** = On equipped vehicles, seat which allows an approved "Universal"/"semi-universal" or "vehicle specific" child seat to be attached using the ISOFIX system; check that it can be fitted.

- (1)** Move the front seat as far forward as possible to install a rear-facing child seat, then move back the seat in front as far as it will go, although without allowing it to come into contact with the child seat.
- (2)** Forward-facing child seat; position the seatback of the child seat in contact with the seatback of the vehicle seat. In all situations, remove the rear headrest of the seat on which the child seat is positioned. This must be done before fitting the child seat (please refer to the section entitled "Rear headrests" in Section 3). Do not push the seat in front of the child more than halfway back on its runners and do not recline the seatback more than 25°.

## CHILD SAFETY: deactivating, activating the front passenger air bag (1/3)



### Front passenger air bag deactivation (depending on the vehicle)


Before installing a child seat on the front passenger seat:

- check that the child seat can be installed on this seat;
- it is essential **to deactivate** the air bag for a rear-facing child seat.

**To deactivate the air bag: with the vehicle stationary and the ignition off**, press and turn lock **2** to the **OFF** position.



With the ignition on, you **must check**

that the **1**  warning light is lit on the dashboard and, depending on the vehicle, that the message “PASSENGER AIRBAG OFF” is displayed.

**This light remains permanently lit to let you know that you can fit a child seat.**



The front passenger air bag must also be deactivated when a forward facing child seat is installed in the front passenger seat.



The passenger air bag must only be deactivated or activated when the **vehicle is stationary**.


If it is interfered with when the vehicle is being driven, indicator lights



and  will come on.

Switch the ignition off then on again to reset the air bag in accordance with the lock position.

## CHILD SAFETY: deactivating, activating the front passenger air bag (2/3)




### DANGER

Since operation of the front passenger airbag is not compatible with the position of a rear-facing child seat, **NEVER** fit a rear-facing child restraint system in a seat protected by an **ACTIVATED front AIRBAG**. This can lead to the **DEATH** of the **CHILD** or **SERIOUS INJURY**.

The markings on the dashboard and labels **A** on each side of the passenger sun visor **3** (for example, the labels shown above) will remind you of these instructions.


## CHILD SAFETY: deactivating, activating the front passenger air bag (3/3)



### Front passenger air bag activation

You should reactivate the air bag as soon as you remove the child seat from the front passenger seat to ensure the protection of the front passenger in the event of an impact.

**To reactivate the air bag :** with the vehicle stationary and the ignition off, press and turn the lock **2** to the **ON** position.

With the ignition on, you **must** check that the warning light **1**  is not lit up on the dashboard.



### Operating faults

In the event that the front passenger air bag activation/deactivation system is faulty, child seats must not be fitted to the front seat.

Allowing any other passenger to sit in that seat is not recommended.



Contact your approved Dealer as soon as possible.




### DANGER

Since operation of the front passenger air bag is not compatible with the position of a rear-facing child seat, **NEVER** fit a rear-facing child restraint system in a seat protected by an **ACTIVATED front AIRBAG**. This can lead to the **DEATH** of the **CHILD** or **SERIOUS INJURY**.




The passenger air bag must only be deactivated or activated when the **vehicle is stationary**. If it is interfered with when the vehicle is being driven, indicator lights  and  will come on. Switch the ignition off then on again to reset the air bag in accordance with the lock position.

## REAR-VIEW MIRRORS



### Interior rear view mirror

The interior rear-view mirror is adjustable. When driving at night, to avoid being dazzled by the headlights of the vehicle behind: tilt the small lever **1** located behind the rear-view mirror.




### Electrically-adjustable door mirrors

**With the ignition on**, position control **2** on:

**A** to adjust the left-hand door mirror,  
**C** to adjust the right-hand door mirror,  
**B** to deactivate it.

### Heated door mirrors

Depending on the vehicle, the mirrors are heated either alone or in conjunction with the rear windows.




### Additional rear-view mirror **4** (depending on the vehicle)

Lower the sun visor **3** to access the special mirror to increase lateral vision when manoeuvring.



For safety reasons, carry out any adjustments when the vehicle is stationary.

## DRIVER'S POSITION, LEFT-HAND DRIVE (1/2)



28714




## DRIVER'S POSITION: LEFT-HAND DRIVE (2/2)

The equipment fitted, described below, **DEPENDS ON THE VERSION AND COUNTRY.**

- |  |   |  |
|--|---|--|
| <p><b>1</b> Side window demister outlet.</p> <p><b>2</b> Side air vent.</p> <p><b>3</b> Stalk for:</p> <ul style="list-style-type: none"><li>– direction indicator lights;</li><li>– exterior lights;</li><li>– front fog lights;</li><li>– rear fog lights.</li></ul> <p><b>4</b> Instrument panel.</p> <p><b>5</b> Location for driver's air bag.</p> <p><b>6</b> – Windscreen wiper/washer stalk.<br/>– Information readout control.</p> <p><b>7</b> Accessories socket.</p> <p><b>8</b> Centre air vent.</p> | <p><b>9</b> Location for:</p> <ul style="list-style-type: none"><li>– radio;</li><li>– storage compartment.</li></ul> <p><b>10</b> Heating and ventilation controls.</p> <p><b>11</b> Centre air vent.</p> <p><b>12</b> Passenger airbag location.</p> <p><b>13</b> Side air vent.</p> <p><b>14</b> Side window demister.</p> <p><b>15</b> Storage compartments.</p> <p><b>16</b> Location for:</p> <ul style="list-style-type: none"><li>– storage compartment;</li><li>– audio connection socket;</li><li>– front passenger air bag deactivation warning light.</li></ul> <p><b>17</b> Cigar lighter or accessories socket.</p> | <p><b>18</b> Switches:</p> <ul style="list-style-type: none"><li>– cruise control/speed limiter;</li><li>– activation/deactivation of the Stop and Start function;</li><li>– activation/deactivation of ECO mode;</li><li>– fast idle speed;</li><li>– power take-off.</li></ul> <p><b>19</b> Steering wheel height adjustment control.</p> <p><b>20</b> Bonnet release.</p> <p><b>21</b> Fuse box.</p> <p><b>22</b> Controls for:</p> <ul style="list-style-type: none"><li>– electric beam height adjustment;</li><li>– activation/deactivation of the parking distance control;</li><li>– activating/deactivating the load position;</li><li>– activation/deactivation of the traction control.</li></ul> |
|--|---|--|

## DRIVER'S POSITION, RIGHT-HAND DRIVE (1/2)



30013

## DRIVER'S POSITION, RIGHT-HAND DRIVE (2/2)

The equipment fitted, described below, **DEPENDS ON THE VERSION AND COUNTRY.**


- 1** Side window demister outlet.
- 2** Side air vent.
- 3** Location for passenger air bag.
- 4** Centre air vent.
- 5** Heating and ventilation controls.
- 6** Location for:
  - radio;
  - storage compartment.
- 7** Centre air vent.
- 8** Accessories socket.
- 9** Stalk for:
  - direction indicator lights;
  - exterior lights;
  - front fog lights;
  - rear fog lights.
- 10** Instrument panel.
- 11** Driver airbag location.
- 12** – Windscreen wiper/washer stalk;
  - Information readout control.
- 13** Side air vent.
- 14** Side window demister.
- 15** Controls for:
  - electric beam height adjustment;
  - activation/deactivation of the parking distance control;
  - activating/deactivating the load position;
  - activation/deactivation of the traction control.
- 16** Steering wheel height adjustment control.
- 17** Switches:
  - cruise control/speed limiter;
  - activation/deactivation of the Stop and Start function;
  - activation/deactivation of ECO mode;
  - fast idle speed;
  - power take-off.
- 18** Cigar lighter or accessories socket.
- 19** Location for:
  - storage compartment;
  - audio connection socket;
  - front passenger air bag deactivation warning light.
- 20** Storage compartment.
- 21** Bonnet release.
- 22** Fuse box.

## WARNING LIGHTS (1/4)

The presence and operation of the warning lights **DEPEND ON THE EQUIPMENT AND COUNTRY.**



**Instrument panel A**

Warning light  means you should drive **very carefully to an authorised dealer as soon as possible**. Failure to follow this recommendation risks damaging your vehicle.



**Side light tell-tale light**



**Front fog light tell-tale**



**Rear fog light tell-tale light**



**Main beam headlight telltale**



**Dipped beam headlight tell-tale**



**Automatic main beam headlight indicator light**

Please refer to the information on “External signals and lights” in Section 1.



**Left-hand direction indicator tell-tale light**



**Right-hand direction indicator tell-tale light**



**Battery charge warning light**


It should go out as soon as the engine starts. If it comes on when you are driving, it indicates that the circuit has discharged. Stop as soon as traffic conditions allow and contact an approved dealer.



**Low fuel level warning light**

This goes out as soon as the engine starts. If it lights up or remains lit, fill up with fuel as soon as possible.



Warning light  requires you to stop immediately, for your own safety, as soon as traffic conditions allow. Switch off the engine and do not restart it. Contact an approved Dealer.



If no lights or sounds are apparent, this indicates a fault in the instrument panel. This indicates that it is essential to stop immediately (as soon as traffic conditions allow). Ensure that the vehicle is correctly immobilised and contact an approved Dealer.

## WARNING LIGHTS (2/4)

The presence and operation of the warning lights **DEPEND ON THE EQUIPMENT AND COUNTRY.**

### STOP light

This comes on when the ignition is switched on and goes out after about 3 seconds.

If it comes on, possibly accompanied by other warning lights, stop soon as traffic conditions allow. Contact an approved dealer as soon as possible.

Depending on the vehicle, this warning light is accompanied by a message on the instrument panel.

### Coolant temperature warning light

If this remains lit while driving accompanied by the **STOP** indicator light, it indicates engine overheating. Stop and allow the engine to run at idle speed for about a minute or two. The temperature should drop. Otherwise, stop the engine. Let the engine cool down, then check the coolant level. Contact an approved Dealer if necessary.

### Handbrake on and brake circuit incident warning light

This comes on when the ignition is switched on and goes out as soon as the handbrake is released. If it comes on during braking or when the vehicle is being driven, accompanied by the **STOP** indicator light, it means that one of the circuit levels is too low; it may be dangerous to continue driving. Consult an approved dealer.

### Tyre pressure loss warning


Please refer to the information on the "Tyre pressure loss warning" in Section 2.

### Warning light

This comes on when the ignition is switched on and goes out after about 3 seconds. If it comes on, possibly accompanied by other warning lights, you should visit an approved dealer as soon as possible. Depending on the vehicle, this warning light is accompanied by a message on the instrument panel.

### Toxic fume filter system warning light

On equipped vehicles, the light comes on when the ignition is switched on then goes out.

- If it lights up continuously accompanied by the  warning light, please consult an authorised dealer as soon as possible;
- if it flashes, reduce the engine speed until the light stops flashing. Contact an approved dealer as soon as possible.

Please refer to the information on "Maintenance and anti-pollution advice" in Section 2.

### Indicator light Airbag

This light comes on when the ignition is switched on and goes out within about 3 seconds. If it comes on, there is a fault in the system. Contact an approved dealer as soon as possible.

### Door status warning light

If it lights up when the ignition is switched on, it indicates that a door is not properly closed.

### Not used

## WARNING LIGHTS (3/4)

The presence and operation of the warning lights **DEPEND ON THE EQUIPMENT AND COUNTRY.**



### **Anti-lock braking warning light**

This light comes on when the ignition is switched on and goes out within about 3 seconds. If it comes on when you are driving, it indicates a fault on the anti-lock braking system. Braking will then occur normally without the anti-lock system.

Contact an approved dealer as soon as possible.

### **Emergency active brake assist**

Refer to the information on “Driving correction devices and aids” in Section 2.

### **Preheating warning light**

This should come on when the ignition is switched on. It indicates that the heater plugs are in operation. It goes out as soon as preheating is sufficient and the engine may be started.

### **T** **Digital tacograph warning light**

If it comes on, there is a fault in the system. Refer to the handbook for the equipment.

### **Engine standby warning light**

Please see information about “Stop and Start function” in Section 2.

### **Unavailability of engine standby warning light**

Please see information in the paragraph on “Stop and Start Function” in Section 2.

### **Water in the diesel filter warning light**

If it comes on when you are driving, it indicates the presence of water in the diesel. Contact your approved dealer as soon as possible.

### **Oil pressure warning light**

This light comes on when the ignition is switched on and goes out within about 3 seconds. If it lights up while you are driving, stop at once and switch off the ignition. Check the oil level. If the level is correct, the light has come on for another reason; contact an approved dealer.

### **Traction control warning light**

Refer to the information on “Driving correction devices and aids” in Section 2.

### **Brake pad wear warning light**

Depending on the vehicle, if the warning light comes on, you must have your brake pads checked as soon as possible.

## WARNING LIGHTS (4/4)

The presence and operation of the warning lights **DEPEND ON THE EQUIPMENT AND COUNTRY.**



### **Gear change indicator**

This lights up to advise you to change to a higher gear (up arrow) or, depending on the vehicle, a lower gear (down arrow).



### **Electronic Stability Control warning light (ESP).**

There are several reasons for the warning light to come on: please refer to information on “Driver correction devices and aids” in Section 2.



### **Cruise control and speed limiter indicator lights**

Refer to the information on the “Speed limiter” and “Cruise control” in Section 2.



### **Warning light for reagent level and faults in the exhaust gas reduction system**

Refer to the information on “Reagent tank” in Section 1.



### **Lane departure system warning light**

Please refer to the information on “Lane departure warning” in Section 2.

### **On display B**



### **Seat belt reminder light**

The light lights up constantly when the vehicle is started, then when the car reaches a speed of about 10 mph (16 km/h), if the driver's seat belt is not fastened, it flashes and a beep sounds for about 90 seconds.

Depending on the vehicle, this flashes if the front passenger seat belt is not fastened.



### **Passenger Airbag OFF**


Refer to the information on “Child safety: deactivating/activating the front passenger airbag” in section 1.

## DISPLAYS AND INDICATORS (1/2)

The presence and operation of the display and indicators **DEPENDS ON THE LEVEL OF EQUIPMENT AND THE COUNTRY.**



**Rev counter 1 (graduations  $\times 1000$ )**



**Speedometer 2 (mph or km/h)**

### **Overspeed buzzer**

Depending on the vehicle, a beep sounds for approximately 10 seconds every 40 seconds while the vehicle is travelling in excess of 74 mph (120 km/h).

### **Trip computer and warning system A**


Refer to the information on the “Trip computer and warning system” in Section 1.

### **Low engine oil level warning**

Depending on the vehicle, when the engine is started and for 30 seconds, display **A** alerts the driver when the minimum engine oil level is reached. Refer to the information on the “Engine oil level” in Section 4.

### **Fuel level gauge**

The number of lit squares on the display **A** shows the fuel level. When it is at the minimum level, the last square comes on, accompanied by a beep.

The  warning light will light up on the instrument panel.

Fill up as soon as possible.




## DISPLAYS AND INDICATORS (2/2)

The presence and operation of the display and indicators **DEPENDS ON THE LEVEL OF EQUIPMENT AND THE COUNTRY.**



### Fuel gauge 3

The needle shows the fuel level. When it is at the minimum level, the fuel warning light  comes on, accompanied by a beep.

Fill up as soon as possible.


### Coolant temperature indicator 4

In normal use, the needle should be positioned before zone **B**. Under “intensive” operating conditions, the needle may approach this zone. The driver is not alerted unless the indicator

light  comes on or the message “ENGINE OVERHEATING” appears.



### Reagent gauge 5

The needle shows the reagent level. When it is at the minimum level, the  warning light comes on, accompanied by a beep.


Refer to the information on “Reagent tank” in Section 1.

## TRIP COMPUTER: general information (1/2)



### Trip computer and warning system A

Depending on the vehicle, this includes the following functions:

- distance travelled;
- journey settings;
- information messages;
- operating fault messages (connected to the  warning light);
- warning messages (connected to the **STOP** warning light);
- setting the time.

All these functions are described on the following pages.



### Display selection keys 1 and 2

Scroll through the following information upwards (button 1) or downwards (button 2) by pressing briefly and successively (the display depends on the vehicle equipment and country).

- Total mileage and trip mileage recorder;
- journey parameters:
  - fuel consumed;
  - average fuel consumption;
  - current fuel consumption;
  - estimated range with remaining fuel;
  - distance travelled;
  - average speed;
- distance before service;
- Reset the tyre pressure
- cruise control and speed limiter programmed speed;
- trip log, operating faults and information message readout.

## TRIP COMPUTER: general information (2/2)

30363



### Trip mileage resetting

With "trip mileage recorder" selected on the display, press button **1** or **2** until the mileage recorder resets to zero.

### Resetting the journey parameters (reset button)

With one of the journey parameters selected on the display, press button **1** or **2** until the display resets.

### Interpreting some of the values displayed after resetting

The values showing average fuel consumption, range and average speed will become more stable and reliable the further you travel after pressing the reset button.

For the first few miles after pressing the reset key you will notice that the range increases as you travel. This range takes into account the average fuel consumption since the last time the reset button was pressed. Therefore, the average fuel consumption may decrease when:





- the vehicle stops accelerating;
- the engine reaches its operating temperature (if the engine was cold when the reset key was pressed);
- when driving from an urban area onto the open road.

### Automatic resetting of the journey parameters

Resetting occurs automatically when the maximum value of any of the parameters is exceeded.









# TRIP COMPUTER AND WARNING SYSTEM: journey parameters (1/4)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

Examples of selections	Interpreting the display selected	
<div data-bbox="92 331 399 460"><p>37360 KM 7080 KM</p></div> <div data-bbox="92 564 399 717"><p>FUEL USED 26.0 L</p></div> <div data-bbox="92 760 399 897"><p>AVERAGE 7.3 L/100</p></div>	<div data-bbox="424 239 731 376"></div> <div data-bbox="424 412 731 548"></div>	<p>a) Total mileage and trip mileage recorder</p> <p>b) Journey parameters</p> <p><b>Fuel consumed</b> since the last reset.</p> <p><b>Average fuel consumption</b> since the last reset.</p> <p>This value is displayed after driving 400 metres and takes into account the distance travelled and the fuel used since the last time the reset button was pressed.</p>





## TRIP COMPUTER: journey parameters (2/4)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

Examples of selections		Interpreting the display selected
<p>CURRENT <b>8.6 L/100</b></p> 		<p><b>Current fuel consumption</b></p> <p>This value is displayed after a speed of approximately 20 mph (30 km/h) is reached.</p>
<p>RANGE ----- <b>KM</b></p> 		<p><b>Estimated range with remaining fuel</b></p> <p>This range takes into account the average fuel consumption since the last time the reset button was pressed.</p> <p>The value is displayed after driving 400 metres.</p> <p>Several minutes after the reserve light has come on (refer to the information on the "Instrument panel"), the estimated range will no longer be displayed.</p>
<p>DISTANCE <b>0.0 KM</b></p> 		<p><b>Distance travelled</b> since the last reset.</p>
<p>AVERAGE <b>109.2 KM/H</b></p> 		<p><b>Average speed</b> since the last reset.</p> <p>The value is displayed after driving 400 metres.</p>

## TRIP COMPUTER: journey parameters (3/4)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

Examples of selections		Interpreting the display selected
		<p><b>c) Mileage before service</b> Distance remaining until the next service (displayed in miles/kilometres), then when the service time nears, several scenarios are possible:</p> <ul style="list-style-type: none"><li>– distance/time less than <b>1,800 miles</b> (3,000 km) or <b>two months</b>: depending on the vehicle, the message “SERVICE IN” is displayed;</li><li>– distance/time remaining <b>0 miles</b> or <b>service date reached</b>: depending on the vehicle, the message “SERVICE PROMPTLY” is displayed when the selected display is “mileage before service”, accompanied by the  symbol and the  warning light. The vehicle requires a service as soon as possible.</li></ul>
<p><b>NB:</b> depending on the vehicle, the mileage before service changes according to the driving style (frequent driving at low speed, door-to-door journeys, extensive use at idle speed, towing a trailer etc.). The distance remaining until the next service can therefore decrease more quickly in some cases than the actual distance travelled.</p> <p>The service intervals are independent of the vehicle’s maintenance schedule: please refer to your vehicle’s Maintenance Document.</p> <p><b>Resetting:</b> to reset the distance before service with the display selecting “service”, press and hold one of the display reset buttons for approximately 10 seconds until the display shows the mileage permanently.</p>		

## TRIP COMPUTER: journey parameters (4/4)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

Examples of selections	Interpreting the display selected
<div data-bbox="181 297 485 434" style="border: 1px solid black; padding: 10px; margin-bottom: 10px;">TYRE PRESSURE ACQUISITION</div> <div data-bbox="181 473 485 610" style="border: 1px solid black; padding: 10px; margin-bottom: 10px;">SPEED LIMITER <b>70 KM/H</b></div> <div data-bbox="181 649 485 786" style="border: 1px solid black; padding: 10px; margin-bottom: 10px;">CRUISE CONTROL <b>70 KM/H</b></div> <div data-bbox="181 825 485 962" style="border: 1px solid black; padding: 10px;">NO MESSAGE AVAILABLE</div>	<p><b>d) Reset the tyre pressures</b> Please refer to the information on the “Tyre pressure loss warning” in Section 2.</p> <p><b>e) Cruise control/speed limiter programmed speed</b> (depending on vehicle). Refer to the information on the “Cruise control/Speed limiter” in Section 2.</p> <p><b>f) Trip log</b> Successive display:</p> <ul style="list-style-type: none"><li>– of information messages (automatic lighting etc.);</li><li>– operating fault messages (Check injection system, etc.).</li></ul>


## TRIP COMPUTER: information messages


These can help in the vehicle starting phase, or give information about a selection or a driving status. Examples of information messages are given in the following pages.


<b>Examples of messages</b>	<b>Interpretation of messages</b>
TRACTION CONTROL OFF	Indicates that you have deactivated the traction control function.
BATTERY MODE: ECONOMY	Indicates that vehicle accessories have been switched off to preserve the battery.
OIL LEVEL CORRECT	Indicates that the oil level is correct when the ignition is switched on.



## TRIP COMPUTER: operating fault messages

These appear with the  warning light and mean that you should drive very carefully to an authorised dealer as soon as possible. If you fail to follow this recommendation, you risk damaging your vehicle.

They disappear when the display selection key is pressed or after several seconds and are stored in the computer log. The  warning light stays on. Examples of operating fault messages are given on the following pages.

Examples of messages	Interpretation of messages
CHECK ESC	Indicates a fault in the traction control system or in the Electronic Stability Program system (please refer to the information on “Driver correction devices and aids” in Section 2).
CHECK FUEL FILTER	Indicates that there is water present in the diesel fuel. Contact an approved Dealer as soon as possible.
CHECK GEARBOX	Indicates that a fault has occurred in the gearbox; contact an approved Dealer as soon as possible.
CHECK AUTO LIGHTS	Indicates a fault in the automatic lights operation. Consult an approved dealer.
CHECK ANTI- POLLUTION	– Indicates a fault in the vehicle's emission control system. – Indicates a fault in the emissions reduction system when it is accompanied by the  warning light. Refer to the information on “Reagent tank” in Section 1.

## TRIP COMPUTER: warning messages

These appear with the **STOP** warning light and require you to stop immediately, for your own safety, as soon as traffic conditions allow. Stop your engine and do not restart it. Contact an approved Dealer.

Examples of warning messages are given in the following pages. **Note:** the messages appear on the display either individually or alternately (when there are several messages to be displayed), and may be accompanied by a warning light and/or a beep.

Examples of messages	Interpretation of messages
INJECTION FAULT	Indicates that the vehicle has a serious engine fault.
ENGINE OVERHEATING	Indicates that the engine is overheating.
GEARBOX OVERHEATING	Indicates that the gearbox is overheating.
TYRE PUNCTURE	Indicates that at least one wheel is punctured or severely underinflated.

# CLOCK AND EXTERIOR TEMPERATURE



With the ignition on, the time and, depending on the vehicle, the exterior temperature, are displayed on the on-board computer **A**.

## Setting clock **A**

Display the “clock” page on the instrument panel by pressing one of the buttons on stalk **1**.

After 2 seconds, the hours and minutes start flashing.



Press and hold the bottom button to enter the hour setting mode. When they flash on their own, press the top button to scroll through them.

Press and hold the bottom button to enter the minute setting mode. When they flash on their own, press the top button to scroll through them.

Confirm by pressing and holding the bottom button on stalk **1**.

## Exterior temperature

When the temperature is between  $-3^{\circ}\text{C}$  and  $+3^{\circ}\text{C}$ , the  $^{\circ}\text{C}$  characters flash (indicates risk of ice formation).

If the electrical supply is cut (battery disconnected, broken supply wire, etc.), the clock will lose its time setting. The time must then be set.

For safety reasons, carry out any adjustments when the vehicle is not being driven.



## Exterior temperature indicator

As ice formation is related to climatic exposure, local air humidity and temperature, the external temperature alone is not sufficient to detect ice.

## SCREEN WASHER, WIPER (1/2)



### Vehicle fitted with intermittent windscreen wipers


#### A park

#### B intermittent wiping

The wipers will pause for several seconds between sweeps. It is possible to change the time between sweeps by turning ring 2.

#### C normal wiping speed

#### D fast wiping speed



### Special note

**When driving the vehicle**, the wiping speed slows down whenever the vehicle stops. For example, fast wiping speed will slow to normal wiping speed. As soon as the vehicle moves off, wiping will return to the speed originally selected.

If stalk 1 is operated, it overrides and cancels the automatic function.

**Note:** in the event of mechanical seizure, the system automatically cuts the power supply to the wipers.

### Vehicle fitted with windscreen wiper rain sensor

#### A park

#### B automatic wiper function.

When this position is selected, the system detects water on the windscreen and triggers the wipers at a suitable wiping speed. It is possible to change the triggering threshold and the time sweeps by turning ring 2:

- E: minimum sensitivity
- F: maximum sensitivity

**Note:** in foggy weather or during snowfalls, wiping is not automatically triggered and remains under the driver's control.

#### C normal wiping speed

#### D fast wiping speed

## SCREEN WASHER, WIPER (2/2)



### Windscreen washer

With the ignition on, pull stalk **1** then release.

A brief pull will trigger a single sweep of the wipers, in addition to the windscreen washer.

A longer pull will trigger three sweeps of the wipers followed, a few seconds later, by a fourth, in addition to the windscreen washer.

### Efficiency of a wiper blade

Check the condition of the wiper blades. How long they last depends on you:

- it must remain clean: clean the blade and the screen regularly with soapy water;
- do not use it when the screen is dry;
- free it from the screen when it has not been used for a long time.

In any event, replace them as soon as they begin to lose efficiency: approximately every year (refer to the information on “Wiper blades: replacement” in section 5).

### Precautions for using the wipers

- In freezing or snowy weather, clear the screen before starting the wipers (risk of motor overheating);
- ensure that no objects are obstructing the travel of the blade.



When working in the engine compartment, ensure that the windscreen wiper stalk is in position **A** (park).

**Risk of injury.**



Before any action involving the windscreen (washing the vehicle, de-icing, cleaning the windscreen, etc.) return stalk **1** to position **A** (park).

**Risk of injury and/or damage.**

## EXTERIOR LIGHTING AND SIGNALS (1/5)



### Side lights

Turn ring **3** until the symbol is opposite mark **2**.

The instrument panel will light up.

### Side position lights (depending on the vehicle)

These draw other road users' attention to the width of the vehicle.

They come on when the side lights are switched on.



### Dipped beam headlights

#### Manual operation

Turn ring **3** until the symbol is opposite mark **2**. This indicator light on the instrument panel comes on.

#### Automatic operation (depending on vehicle)

Turn ring **3** until the AUTO symbol is opposite mark **2**: with the engine running, the dipped beam headlights switch on or off automatically depending on the brightness of the light outside, without any action on stalk **1**.



If the vehicle is parked on the hard shoulder with the tailgate open, the rear lights may be obscured. You should make other road users aware of your vehicle by using a warning triangle or other equipment specified by the road traffic regulations of the country you are driving in.



Before driving at night, check that the electrical equipment is operating correctly and adjust the headlight beams (if your vehicle is not carrying its normal load). In general, check that the lights are not obscured (by dirt, mud, snow or objects which could cover them).

## EXTERIOR LIGHTING AND SIGNALS (2/5)

### Cornering lights

Depending on the vehicle, if the dipped beam headlights are on when cornering, and under certain driving conditions (speed, steering wheel angle, forwards gear selected, etc.), additional lights are switched on to light the inside of the bend.

**Note:** under certain conditions of prolonged use, this system will switch off automatically as it is intended for use over limited periods.

### “See-me-home lighting” function

This function allows you to briefly switch on the dipped beam headlights (to provide light when opening a gate, etc.).

**With the engine and lights off**, and ring **3** in position **0**, pull stalk **1** towards you: the dipped beam headlights come on for approximately one minute. To increase this duration, you may pull the stalk up to four times (total time limited to two minutes). To switch off the lights before they go out automatically, turn ring **3** to any position, then return it to position **0**.



### Main beam headlights

With stalk **1** in dipped beam headlights position, move the stalk towards you.

When the main beam headlights are lit up, an indicator light on the instrument panel lights up.

To return to the dipped headlight position, pull stalk **1** towards you again.

## EXTERIOR LIGHTING AND SIGNALS (3/5)



### Automatic main beam headlights

Depending on the vehicle, this system switches the main beam headlights on and off automatically. The function uses a camera located behind the interior rear-view mirror to detect vehicles that are following and coming in the opposite direction.

The main beam headlights come on automatically if:

- exterior light is weak;
- no other vehicles or lighting are detected;
- the vehicle speed is above approximately 30 mph (45 km/h).

If any of the above conditions are not fulfilled, the system switches to dipped beam headlights.



Using the portable navigation system at night in the windscreen area below the camera may disturb the operation of the “automatic main beam headlights” system (risk of reflection on the windscreen).

43006



The system may encounter difficulties under certain conditions, including:

- extreme weather conditions (rain, snow, fog, etc.);
- obstruction in front of the windscreen or camera;
- when a following or oncoming vehicle has weak or hidden lighting;
- incorrect settings for the front headlights;
- reflective systems;
- ...

### Activation/Deactivation

#### To activate automatic main beam headlights:

- Turn ring **3** until the AUTO symbol is opposite mark **2**;
- Pull the stalk **1** towards you.

Warning light  comes on the instrument panel.

#### To deactivate automatic main beam headlights:

- Pull the stalk **1** towards you again;
- or turn ring **3** to a position other than AUTO.

Warning light  goes out on the instrument panel.



The “automatic main beam headlights” system should under no circumstances be used to replace driver attention and responsibility with regard to vehicle lighting and adapting to light, visibility and traffic conditions.



## EXTERIOR LIGHTING AND SIGNALS (4/5)

### Automatic main beam headlights (continued)

#### Operating faults

When the message “CHECK LIGHTS” with warning light  is displayed

and warning light  flashes on the instrument panel, this indicates that there is a lighting fault.

Consult an approved dealer.

Each time you start the engine, pull the stalk **1** towards you to reactivate the system.

### Front fog lights

Turn the centre ring **4** of the stalk **1** until the symbol is opposite the **5** mark.

The front fog lights only work if the exterior lights have been activated. An indicator light on the instrument panel will come on.



### Rear fog lights

Turn the centre ring **4** of the stalk **1** until the symbol is opposite the **5** mark.

The rear fog lights only work if the exterior lights have been activated. An indicator light on the instrument panel will come on.

Do not forget to switch off the fog lights when they are no longer needed, to avoid inconveniencing other road users.

When the exterior vehicle lights are switched off, the rear fog lights switch off or the equipment returns to the front fog lights position (if they are fitted).

### Switching off the lights


There are two possibilities:

- manually, move ring **3** to position **0**;
- automatically, the lights will go out when the engine is switched off, the driver's door is opened or the vehicle is locked. In this case, the next time the engine is started the lights will be switched back on according to the position of the ring **3**.

### Lights-on warning buzzer

An audible warning sounds when the driver's door is opened to indicate that the lights have been left switched on after the ignition has been switched off (to prevent discharge of the battery).

## EXTERIOR LIGHTING AND SIGNALS (5/5)



### Electric beam height adjustment

Control **A** allows you to adjust the height of the headlight beams.

Turn control **A** to adjust the headlights according to the load.


This control only works when the lighting is in dipped beam headlight position.

Load status	Control position
Empty, driver only	0
Driver with passenger(s) and luggage compartment full (1)	2
Other cases	According to driver's judgement

The table below gives some examples. In all cases, adjust control **A** according to the vehicle load so that the road can be seen and other drivers are not dazzled.

(1) Load status at maximum permitted weight.

# AUDIBLE AND VISUAL SIGNALS



## Direction indicators

Move stalk **1** parallel to the steering wheel and in the direction you are going to turn it.

When driving on the motorway, the steering wheel is not usually turned sufficiently to return the stalk automatically to its starting position.

There is an intermediate position in which you should keep the stalk when the steering wheel is moved.



You can also briefly place stalk **1** in the intermediate position, causing the indicator light to flash three times.


When the stalk is released, it will automatically return to its starting position.

## Horn

Press on the sides **2** of the steering wheel boss.

## Headlight flasher

Pull stalk **1** towards you to flash the headlights.




## Hazard warning lights

Press switch **3**. This switch activates all four direction indicators and the side indicator lights simultaneously. It must only be used in an emergency to warn drivers of other vehicles that you have had to stop in an area where stopping is prohibited or unexpected, or that you are obliged to drive under special conditions.

Depending on the vehicle, the hazard warning lights may come on automatically under heavy deceleration. You can switch them off by pressing switch **3**.

## FUEL TANK (1/2)



### Filling the tank

Open the driver's door in order to open flap **1**.

Depending on the vehicle, unlock cap **2** using the key.

Remove cap **2** and attach it to flap **1**.

**Useful capacity of fuel tank: approximately 105 litres or 80 litres** (depending on the vehicle).

### Filling with fuel

When the pump cuts out automatically at the end of the filling procedure, a maximum of two further filling attempts may be made to maintain an expansion volume.

### Fuel grade

It is **essential** to use diesel. Make sure that no water enters the fuel tank accidentally during filling. The sealing system and its surrounding area must be dust-free.

**Use a high-grade fuel** that complies with the legislation in force in each country. It **must** comply with the specifications given on the label on the cover **1**. Refer to the information on "Engine specifications" in Section 6.

After filling, check that the cap and cover are closed.



Do not mix even small amounts of petrol (un-leaded or E85) with diesel.

Do not use ethanol-based fuel if your vehicle is not compatible with this fuel.

Do not add **anything** to the fuel (additive, reagent, etc.) to prevent the risk of damaging the engine.



**Fuel filler cap: this is of a special type.**

If you have to replace it, make sure it is identical to the original cap. Contact an approved Dealer.

Never place the cap near a source of heat or flame.

Do not wash the filler area with a high-pressure washer.

## FUEL TANK (2/2)



### Running out of fuel on diesel versions

After a breakdown caused by completely running out of fuel, the system must be reprimed before the engine is restarted:

Fill the tank on level ground with a minimum of 5 litres of diesel.

Press priming bulb **3** several times.

The engine can now be restarted.

If the engine does not start after several attempts, contact an approved Dealer.

### Vehicle fitted with the Stop and Start function

To fill up with fuel, the engine must be stopped (and not on standby): stop the engine (Please See "Starting, stopping the engine" in Section 2).



### Persistent smell of fuel

If you notice a persistent smell of fuel you should:

- stop the vehicle as soon as traffic conditions allow and switch off the ignition;
- switch on the hazard warning lights and ask your passengers to leave the vehicle and to keep away from traffic;
- contact an approved Dealer.

Fuel types that conform to European standards with which the engines of vehicles sold in Europe are compatible: refer to the "Engine specifications" in section 6.



No modifications whatsoever are permitted on any part of the fuel supply system (computers, wiring, fuel circuit, injector, protection covers, etc.) as this may be dangerous (such work must be undertaken by qualified Network personnel).

## REAGENT TANK (1/7)

Please ensure that you comply with the legislation of your country. It is important to remember that failure to respect regulations in force could lead to legal action being taken against the vehicle owner.

### Operating principle

The reagent is intended for diesel engines fitted with the SCR (selective catalytic reduction) system. Using the reagent reduces the quantity of nitrogen oxides in exhaust gases.


### Reagent quality

Use **only reagents which conform to standard ISO 22241** and in accordance with the mark on the tank filler cap.

### Average fuel consumption

**Approximately 0.77 gal/620 miles** (3.5 l/1000 km), depending on the vehicle.

Consumption in real time depends on vehicle usage conditions, the equipment fitted and the user's driving style.



### Topping up

**Capacity of the fuel tank: 4.4 gal (20 litres)** approximately.

Open the front passenger door to open the cover **2**. Unscrew the cap **1**.

**Note:** Ammonium hydroxide vapour may escape from the cap opening when the tank temperature is high.

### Vehicle fitted with the Stop and Start function

To fill up with reagent, the engine must be stopped (and not on standby): stop the engine (please see "Starting, stopping the engine" in Section 2).



**If the "XXX KM STOP ADD ADBLUE" message appears, fill the reagent tank and refer to the filling instructions.**

**Risk of immobilisation of the vehicle.**



**Fuel filler cap: this is specific.**

If you have to replace it, make sure it is identical to the original cap. Contact an approved Dealer. Do not wash the filler area with a high pressure washer.

## REAGENT TANK (2/7)

### Precautions for use

The tank can be filled at the pump. In other cases, it is essential to read the information shown on the reagent container (e.g. the can or bottle).

When filling, **handle the reagent carefully. They can damage clothes, shoes, bodywork components etc.**

If the reagent overflows, or contaminates any paintwork, clean the affected area quickly with plenty of cold water and a soft cloth.

**Note:** If the reagent crystallises, use a soft sponge.



The reagent must not come into contact with eyes or skin. If it does, wash the affected area with plenty of cold water. If necessary, consult a doctor.

### In extreme cold weather conditions

**In frosty weather conditions, the reagent tank should be refilled when the**




indicator and the message "Top Up AdBlue before 1500 km" appear on the instrument panel.

### Special cases

The reagent fluid freezes below about -10°C.

In these conditions, do not attempt filling when the fluid is frozen. In the event of needing to top up or fill the tank

with reagent () on), park the vehicle in a hotter location if possible so that the reagent becomes liquid again. Otherwise, have a qualified professional top up or fill up with reagent fluid.

After filling the reagent tank, check that the cap and cover are closed, start the engine and **WAIT 10 seconds with the vehicle stationary, engine running**, before setting off again.

If this operation is not carried out, the filling of the tank will not be taken into account automatically until after several dozens of minutes of driving.

The message "-- ADD ADBLUE" and/or the warning lights will continue to appear until the filling has been registered by the system.



No work whatsoever is permitted on any part of the system. To prevent damage, only qualified personnel from our network may work on the system.

## REAGENT TANK (3/7)



### Alert with message on the instrument panel on display 3

#### Front-wheel drive and van versions

Warning lights and the messages on the instrument panel **3** are displayed according to the estimated range of the remaining reagent.




Depending on how the vehicle is driven, **they may be displayed before the reagent gauge on the instrument panel is at minimum** (refer to the information on “Displays and indicators” in section 1).



# REAGENT TANK (4/7)

## Maintenance/Range







The information displayed on the instrument panel may be accompanied by a beep.

Indicator lights	Messages	What to do?
-	"ADBLUE LEVEL CORRECT"	-
-	"Top Up AdBlue before 2400 km"	If the message is displayed when the ignition is switched on, you have <b>less than 1,488 miles (2,400 km) range</b> . Fill or have an Approved Dealer <b>fill or top up the reagent</b> in the tank.
 comes on.	"Top Up AdBlue before 1500 km"	If the message is displayed when the ignition is switched on, you have <b>between 930 miles (1,500 km) and 620 miles (1000 km) range</b> . Fill or have an Approved Dealer <b>fill or top up the reagent</b> in the tank.
 comes on.	"XXX KM STOP ADD ADBLUE"	The message is displayed when the ignition is switched on and is repeated: – approximately every 62 miles (100 km), you have <b>between about 620 miles (1,000 km) and 124 miles (200 km) range</b> ; – approximately every 31 miles (50 km), you have <b>less than 124 miles (200 km) range</b> . In any event, you or an Approved Dealer should <b>fill the reagent tank as soon as possible</b> .
 comes on.	"0 KM STOP ADD ADBLUE"	<b>The engine will not start.</b> To restart, you must fill the reagent tank yourself.


## REAGENT TANK (5/7)

### System fault

When the indicator lights described light up, this may be accompanied by a beep.

Indicator lights	Message	Readings
 and  come on.	« CHECKANTI- POLLUTION SYSTEM »	Indicates a fault in the system. Contact your approved dealer as soon as possible.
 and  come on.	“ANTIPOLLUTION xxx KM FAIL”	Indicates a system fault and that in <b>less than 620 miles (1,000 km) it will become impossible to restart the vehicle.</b> These warnings are repeated: <ul style="list-style-type: none"><li>– every 62 miles (100 km) until there is <b>around 124 miles (200 km) left</b> before the vehicle cannot be restarted;</li><li>– every 31 miles (50 km) when there is <b>less than 124 miles (200 km) left</b> before the vehicle cannot be restarted.</li></ul> Contact your approved dealer as soon as possible.
 and  come on.	“ANTIPOLLUTION 0 KM FAILURE”	Indicates that after the ignition is switched off <b>the vehicle will not restart.</b> Call an approved Dealer.

## REAGENT TANK (6/7)







### Alert with no message on the instrument panel

#### Bus and rear-wheel drive versions

The warning light is displayed according to the level of reagent indicated by the needle **4** on the instrument panel.







### Maintenance/Range

Gauge level	Warnings	What to do?
Range <i>A</i>	–	–
Range <i>B</i>	 comes on.	You or an Approved Dealer should fill or top up the reagent tank.
Range <i>C</i>	 flashes for a few seconds at the start of the warning and each time the ignition is switched on, then stays on.	
Range <i>D</i>	 flashes for a few seconds at the start of the warning and each time the ignition is switched on, then stays on. It is accompanied by beeps.	<b>Loss of engine power.</b> You or an Approved Dealer should fill the reagent tank as soon as possible.
At <i>E</i>	<b>Empty tank.</b>  flashes accompanied by beeps and the message “CHECK ANTI-POLLUTION”.	In this case, at the next engine stop/start, <b>the vehicle speed is limited to approximately 12 mph (20 km/h)</b> until you fill the reagent tank or have it done by an Approved Dealer.

## REAGENT TANK (777)

### System fault

When the indicator lights described light up, this may be accompanied by a beep.

Indicator lights	Readings
 and  come on.	Indicates a fault in the system. Contact your approved dealer as soon as possible.
 and  flash when the engine is started then stay lit.	Indicates a system fault with <b>a loss of engine power</b> . Contact your approved dealer as soon as possible.
 and  flash.	Indicates a fault in the system. In this case, at the next engine stop/start, <b>the vehicle speed is limited to approximately 12 mph (20 km/h)</b> . Contact your approved dealer as soon as possible.

# **Section 2: Driving**

***(advice on use relating to fuel economy and the environment)***

Running in, ignition switch . . . . .	2.2
Starting, stopping the engine . . . . .	2.3
Stop and Start Function . . . . .	2.4
Special features of diesel versions . . . . .	2.7
Driving advice, Eco-driving . . . . .	2.8
Maintenance and antipollution advice . . . . .	2.12
Environment . . . . .	2.13
Gear lever . . . . .	2.14
Handbrake . . . . .	2.15
Driver correction devices/aids . . . . .	2.16
Tyre pressure loss warning . . . . .	2.24
Lane departure warning . . . . .	2.27
Speed limiter . . . . .	2.30
Cruise control . . . . .	2.33
Overspeed function . . . . .	2.37
Parking distance control . . . . .	2.38
Reversing camera . . . . .	2.40
Power take-off . . . . .	2.42
Fast idle speed . . . . .	2.43
Self-locking differential . . . . .	2.44
Sequential gearbox . . . . .	2.45

## RUNNING IN, IGNITION SWITCH

Up to **900 miles (1,500 km)**, do not exceed 2,500 rpm or approximately 54 mph (90 km/h) in the highest gear. After completing this mileage you may drive faster, although you may only expect top performance after approximately 3,600 miles (6,000 km).

During the running in period, do not accelerate hard while the engine is still cold and do not let the engine over-rev.

**Service intervals:** refer to the Maintenance Document for the vehicle.



### Ignition switch

#### Stop and steering lock position St

To lock: remove the key and turn the steering wheel until the steering column locks.

To unlock: turn the key and the steering wheel slightly.

#### Accessories position A

When the ignition is switched off, any accessories (radio, etc.) will continue to function.

#### Ignition on position M

With the ignition on, the engine will be preheating.

#### Start position D

If the engine fails to start at the first attempt, turn the key back before activating the starter again. Release the key as soon as the engine starts.

**Note:** several seconds may pass between turning the key and the engine starting to allow for engine preheating.

#### Special note on vehicles with a sequential gearbox

Press the brake pedal with the lever in the **N** position.

**Note:** If a gear other than neutral is displayed, it flashes; starting is not possible unless you depress the brake pedal, while holding the key in the starting position.

In the "Accessories" or "On" position, a system may automatically switch off your vehicle's accessories depending on the battery charge, to prevent it from discharging completely.

# STOPPING, STARTING THE ENGINE



## Starting the engine

Turn the ignition key to the "Ignition on" position **M** and hold this position until the engine preheating warning light

 goes out.



Never start your vehicle while freewheeling on a gradient. **Risk of non-activation of power-assisted steering.**  
There is a risk of accidents.

Depending on the vehicle, if a gear is engaged, the message "PRESS CLUTCH + START" is displayed on the instrument panel. Press the clutch pedal.

Turn the key to starter position **D** **without depressing the accelerator pedal.**

Release the key as soon as the engine starts.

## Starting the vehicle

For rear-wheel drive versions on level ground, with the vehicle unladen, we recommend that you start in second gear.



Never switch off the ignition before the vehicle has stopped completely. Once the engine has stopped, the brake servo, power-assisted steering, etc., and the passive safety devices such as the airbag and pretensioners will no longer operate.

## Stopping the engine

With the engine idling, turn the key to the "Stop" position **St**.



### Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**

## STOP AND START FUNCTION (1/3)

This system enables a reduced fuel consumption and lower greenhouse gas emissions.

The system is activated automatically when the vehicle is started.

While driving, the system stops the engine (standby) when the vehicle is at a standstill (traffic jam, traffic lights, etc).

### Conditions for engine standby

The vehicle has set off from where it was parked;

#### For sequential gearbox:

- the gearbox is in position A, Mor N; and
  - the brake pedal is depressed (sufficiently hard); and
  - the accelerator pedal is not depressed;
- and
- the speed is zero for around 1 second.

The engine remains on standby if position P is selected, or if position N is selected with the handbrake engaged and the brake pedal released.

#### For manual gearboxes:

- the gearbox is in neutral; and
- the clutch pedal is released.


If warning light  flashes, this means that the clutch pedal is not sufficiently released.

and

- the vehicle speed is less than approximately 2 mph (3 km/h).

The engine will restart when you press the clutch pedal and move into gear.

#### For all vehicles:


Warning light  on the instrument panel is lit when the engine is on standby.

The vehicle equipment remain operational while the engine is stopped.

If the engine stalls while the system is in operation, pressing the clutch pedal right down will start it again.

If you get out of the vehicle, a beep notifies you that the engine is on standby and has not been switched off.



Do not drive off when the engine is on standby (warning light  is displayed on the instrument panel).



Before leaving the vehicle, the engine must be stopped and not put on standby (please see the information on “Starting, stopping the engine” in Section 2).



## STOP AND START FUNCTION (2/3)

### Preventing the engine from standing by

In certain situations, such as negotiating a crossroads for instance, it is possible (with the system activated) to keep the engine running so as to be ready to move off quickly.

### SEQUENTIAL gearbox

Keep the vehicle stationary without pressing too hard on the brake pedal.

### Manual gearbox

Keep the clutch pedal pressed right down.

To fill up with fuel, the engine must be stopped (and not on standby): stop the engine (Please See "Starting, stopping the engine" in Section 2).

### Conditions for coming out of engine standby

#### For sequential gearbox:

- the brake pedal is released, position A or M engaged, or;
- the brake pedal is released, position N engaged and the handbrake off, or;
- or the brake pedal is pressed again, with position P engaged or position N engaged with the parking brake applied or;
- position R is engaged or;
- the accelerator pedal is pressed.

#### For manual gearboxes:

- the gearbox is in neutral and the clutch pedal is slightly depressed, or
- the engine is in gear and the clutch pedal is pressed right down.

### Conditions preventing the standby of the engine

Certain conditions prevent the system from using the engine standby function, including when:

- reverse gear is engaged;
- the bonnet is not locked;

- the outdoor temperature is too low or too high (less than around 0 °C or higher than around 35 °C);
- the battery is not sufficiently charged;
- the difference between the vehicle interior temperature and the automatic climate control instruction is too high;
- the "Clear View" function is activated (please see "Automatic Climate Control" in Section 3);
- the engine coolant temperature is too low;
- automatic particle filter cleaning is underway;
- the "Fast Idle Speed" function is activated (please refer to the information on "Fast Idle Speed" in section 2);
- ...

Warning light  is displayed on the instrument panel. This notifies you that the engine is on standby.

## STOP AND START FUNCTION (3/3)

### Special feature of the automatic engine re-start

Under certain conditions, the engine can restart on its own in order to guarantee your safety and comfort.

This can occur especially when:

- the outdoor temperature is too low or too high (less than around 0 °C or higher than around 35 °C);
- the “Clear View” function is activated (please see “Automatic Climate Control” in Section 3);
- the battery is not sufficiently charged;
- the vehicle speed is above 7 km/h (downhill slope, etc.);
- repeated pressing on the brake pedal or braking system requirement;
- on vehicles fitted with a manual gearbox, engine restarting may be interrupted if the clutch pedal is released too quickly while a gear is engaged;
- ...



**Special note:** depending on the vehicle, for some of these conditions the automatic restarting of the engine is inhibited if a door is open.

### Deactivating, activating the function

Press **1** to deactivate the function. Warning light **2** in the switch lights up.

Pressing this again will reactivate the system. Warning light **2** in switch **1** goes out.

The system is automatically reactivated each time the vehicle is started (see “Starting, stopping the engine” in Section 2).

### Operating faults

If warning light **2** lights up without pressing switch **1**, the system is deactivated.

Please consult an authorised dealer.





Before leaving the vehicle, the engine must be stopped and not put on standby (please see the information on “Starting, stopping the engine” in Section 2).

## SPECIAL FEATURES OF DIESEL VERSIONS

### Diesel engine speed

Diesel engines are fitted with an injection pump with an electronic regulator **which prevents overrevving of the engine** irrespective of the gear engaged.

If the  and  warning lights come on, consult an approved dealer as soon as possible.


When driving, depending on the fuel grade used, it is possible that white smoke may be emitted.

This is due to the exhaust particle filter being cleaned automatically, and does not affect the way the vehicle runs.

### Running out of fuel

You may start the engine normally after refilling the fuel tank **even if you have completely run out of fuel**, provided that the battery is well-charged.

However, if the engine does not start after a few seconds and several attempts, refer to the information on the "Fuel tank" in Section 1.



### Engine smoke opacity label

You will find **1** information on the **A** label stuck inside the engine compartment.

**1** Diesel exhaust emissions.

### Precautions to be taken in winter

To avoid any faults in icy weather:

- make sure that the battery is always fully charged;
- always keep the diesel tank relatively full to prevent water vapour condensing in it and accumulating at the bottom of the tank.



Do not park the vehicle or run the engine in locations where combustible substances or materials such as grass or leaves can come into contact with the hot exhaust system.


## DRIVING ADVICE, ECO-DRIVING (1/4)

Fuel consumption is accredited in accordance with a standard regulatory method. Identical for all manufacturers, this enables vehicles to be compared with one another. Consumption in real time depends on vehicle usage conditions, the equipment fitted and the user's driving style. To optimise fuel consumption, please refer to the following advice.

Depending on the vehicle, you will have various functions which enable you to lower your fuel consumption:

- the rev counter;
- gear change indicator;
- the journey record and eco-driving advice via the multimedia display;
- ECO mode – activated by the ECO button.

If fitted on the vehicle, the navigation system provides additional information.



### **Gear change indicator 1 and 2**

(depending on vehicle)

To obtain optimum consumption levels, a warning light on the instrument panel lets you know the best time to move up a gear, or down a gear for vehicles where this is fitted:




move up a gear;



move down a gear.



## DRIVING ADVICE, ECO-DRIVING (2/4)



### Journey record

Once the engine is switched off, you will see “Journey record” displayed on the screen **3**, enabling you to view information relating to your last journey.

This indicates:

- average fuel consumption;
- number of miles/kilometres travelled;
- number of miles/kilometres saved.



An overall rating from 0 to 100 is displayed to let you assess your eco driving performance. The higher the rating, the lower the fuel consumption.

Eco advice is given to help improve your performance.

With your favourite journeys saved, you can evaluate your performance.

For more information, please see the multimedia system instructions.

### ECO mode

ECO mode is a function which optimises fuel consumption. It acts on certain power consuming systems in the vehicle (heating, air conditioning, power-assisted steering, etc.) and on certain driving actions (acceleration, gear changing, cruise control, deceleration, etc.).

#### Activating the function

Press switch **4**.

The warning light in the **4** switch lights up.

While driving, it is possible to leave the ECO mode temporarily in order to improve engine performance.

Depress the accelerator pedal firmly and fully.

ECO mode is reactivated when you take pressure off the accelerator pedal.

#### Disabling the function

Press switch **4**.

The indicator light in the switch **4** goes out.

## DRIVING ADVICE, ECO-DRIVING (3/4)



### Driving advice, Eco-driving

#### Behaviour

- Drive carefully for the first few miles until the engine reaches its normal operating temperature, rather than let it warm up while the vehicle is stationary.
- Speed is expensive.
- Sporty driving uses a lot of fuel: drive with a light right foot.
- Do not overrev the engine in the intermediate gears.  
You should always use the highest gear possible.

- Avoid sudden acceleration.
- Brake as little as possible. If you anticipate an obstacle or bend in advance, you may then simply release the accelerator pedal.
- Do not try to maintain the same speed up a hill, accelerate no more than you would on the level. Keep your foot in the same position on the accelerator pedal.
- Double declutching and accelerating before switching off are unnecessary in modern vehicles.
- Bad weather, flooded roads:



Do not drive through floods if the water is above the lower edge of the wheel rims.




#### **Obstructions to the driver**

On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another.

**There is a risk of wedging the pedals**

## DRIVING ADVICE, ECO-DRIVING (4/4)



### Tyres

- An underinflated tyre increases fuel consumption.
- The use of non-recommended tyres can increase fuel consumption.



### Advice on use

- Favour ECO mode.
- Electricity is fuel; switch off all the electrical components which are not really needed. **However** (safety first), keep your lights on when the visibility is bad ("see and be seen").
- Use the air vents. Driving with the windows open at 60 mph (100 km/h) will increase fuel consumption by 4%.
- Never fill the fuel tank right to the brim to avoid overflow.

- In vehicles fitted with air conditioning, it is normal to observe an increase in fuel consumption (especially in urban conditions) when it is used. For vehicles fitted with manual air conditioning, switch off the system when it is not required.

### Advice for reducing consumption and therefore helping to preserve the environment:

If the vehicle has been parked in the sun, open the doors for a few moments to let the hot air escape before starting the engine.

- Do not leave an empty roof rack fitted to the vehicle.
- When towing a caravan, fit a wind deflector and adjust it carefully.

## MAINTENANCE AND ANTIPOLLUTION ADVICE

Your vehicle complies with criteria for recycling and recovering vehicles at the end of their service life, which entered into force in 2015.

Some parts of your vehicle have therefore been designed to facilitate future recycling.

These parts are easy to remove so that they can be recovered and reprocessed by recycling companies.

By virtue of its design, moderate fuel consumption and initial settings, your vehicle also conforms to current antipollution regulations. The manufacturer is actively striving to reduce pollutant exhaust gas emissions and to save energy. But the fuel consumption of your vehicle and the level of pollutant exhaust gas emissions are also your responsibility. Ensure that it is maintained and used correctly.

### Maintenance

It is important to remember that failure to respect antipollution regulations could lead to legal action being taken against the vehicle owner. In addition, replacing engine, fuel supply system and exhaust components with parts other than those originally recommended by the manufacturer may alter your vehicle so that it no longer complies with antipollution regulations.

Have your vehicle adjusted and checked by an approved Dealer, in accordance with the instructions given in your maintenance schedule: they will have all the equipment necessary for ensuring that your vehicle is maintained to its original standard.

### Engine adjustments

- **Air filter, diesel filter:** a choked element will reduce efficiency. It must be replaced.
- **Idle speed:** this does not require adjustment.

### Exhaust gas monitoring system

The exhaust gas monitoring system will detect any operating faults in the vehicle's antipollution system.

If this system malfunctions, toxic substances may be released into the atmosphere or damage may occur.



This warning light on the instrument panel will indicate if there are any faults in the system:

This lights up when the ignition is switched on and goes out when the engine is started.

- If it lights up continuously, consult an approved Dealer as soon as possible;
- if it flashes, reduce the engine speed until the light stops flashing. Contact your approved dealer as soon as possible.



Refer to the information on "Reagent tank" in Section 1.



## ENVIRONMENT

Your vehicle has been designed with respect for the **environment** in mind for its entire service life: during production, use and at the end of its life.

This commitment is illustrated by the of the manufacturer eco<sup>2</sup> signature.

### Manufacture

Your vehicle has been manufactured at a factory which complies with a policy to reduce the environmental impact on the surrounding areas (reduction of water and energy consumption, visual and noise pollution, atmospheric emissions and waste water; sorting and re-using waste).

### Emissions

Your vehicle has been designed to emit fewer greenhouse gases (CO<sub>2</sub>) while in use, and therefore to consume less fuel (eg. 140 g/km, equivalent to 5.3 l/100 km for a diesel vehicle).

Our vehicles are also equipped with a particle filter system including a catalytic converter, an oxygen sensor and an active carbon filter (the latter prevents vapour from the fuel tank being released into the open air).

For certain diesel vehicles, this system also has a particle filter to reduce the volume of soot particles emitted.

### Please make your own contribution towards protecting the environment too

- Worn parts replaced in the course of routine vehicle maintenance (vehicle battery, oil filter, air filter, batteries, etc.) and oil containers (empty or filled with used oil) must be disposed of through specialist organisations.

- At the end of the vehicle's service life, it should be sent to approved centres to ensure that it is recycled.
- In all cases, comply with local legislation.

### Recycling

Your vehicle is 85% recyclable and 95% recoverable.

To achieve these objectives, many of the vehicle components have been designed to enable them to be recycled. The materials and structures have been carefully designed to allow these components to be easily removed and reprocessed by specialist companies.

In order to preserve raw material resources, this vehicle incorporates numerous parts made from recycled plastics or renewable materials (vegetable or animal-derived materials such as cotton or wool).

## GEAR LEVER



### Gear lever

#### Selecting reverse gear

With the vehicle stationary, move the gear lever into neutral then into reverse. Follow the grid drawn on gear knob **1**, lift ring **2** against the gear knob to select reverse gear.

The reversing lights will come on as soon as reverse gear is selected (with the ignition on).


**Vehicles with sequential gearbox:** refer to the information on the “Sequential gearbox” in Section 2.



An impact to the underside of the vehicle (e.g.: striking a post, raised kerb or other street furniture) may result in damage to the vehicle (e.g.: deformation of an axle).

To avoid any risk of accident, have your vehicle checked by an approved Dealer.

# HANDBRAKE



## Handbrake

### To apply:

Pull upwards, check that the vehicle is properly immobilised.

### To release:

Pull the lever up slightly, press button 1 and then lower the lever to the floor.



Make sure that the handbrake is properly released when driving (red indicator light off), otherwise overheating, or even damage, may occur.




When the vehicle is stopped, depending on the gradient and/or the vehicle load, it may be necessary to apply the handbrake by at least two further notches and engage a gear (1<sup>st</sup> or reverse).



An impact to the underside of the vehicle (e.g.: striking a post, raised kerb or other street furniture) may result in damage to the vehicle (e.g.: deformation of an axle).

To avoid any risk of accident, have your vehicle checked by an approved Dealer.



## Pull-up handbrake

(depending on the vehicle)

### To release

Press button 3 and pull lever 2 upwards then place it in a horizontal position.

### To apply

Pull lever 2 upwards then release it. It returns to the horizontal position.

## DRIVING CORRECTION DEVICES AND AIDS (1/8)

Depending on the vehicle, this is composed of:

- **anti-lock braking system (ABS)**;
- **electronic stability program (ESC) with understeer control and traction control**;
- **driver assistance with a trailer**;
- **emergency brake assist**;
- **active emergency braking**;
- **grip control**;
- **hill start assistance**.

Other driving assistance systems are detailed on the following pages.

### Anti-lock braking system (ABS)







Under heavy braking, the ABS prevents the wheels from locking, allowing the stopping distance to be managed and keeping control of the vehicle.

Under these circumstances, the vehicle can be steered to avoid an obstacle whilst braking. In addition, this system can increase stopping distances, particularly on roads with low surface grip (wet ground etc.).

You will feel a pulsation through the brake pedal each time the system is activated. The ABS does not in any way improve the vehicle's physical performance relating to the road surface and road-holding. It is still **essential** to follow the rules of good driving practice (such as driving at a safe distance from the vehicle in front etc.).

In an emergency, apply **firm and continuous pressure** to the brake pedal. There is no need to pump it repeatedly. The ABS will modulate the force applied in the braking system.

### Operating faults:

-  and  lit up on the instrument panel accompanied by the messages "CHECK ABS" and "CHECK ESC": the ABS, ESC and emergency brake assist are disabled. **Braking is always enabled**;
- , ,  and  lit on the instrument panel accompanied by the message "BRAKING FAULT": **this indicates a fault with the braking system**.

In both cases, please consult an Authorised Dealer.



Your braking systems are partially operational. However, it is **dangerous to brake suddenly** and it is essential to stop immediately, as soon as traffic conditions allow. Contact an approved dealer.

## DRIVING CORRECTION DEVICES AND AIDS (2/8)

### Electronic stability program (ESC) with understeer control and traction control

#### Electronic stability control ESC

This system helps you to keep control of the vehicle in critical driving conditions (avoiding an obstacle, loss of grip on a bend, etc.).

#### Operating principle

A sensor in the steering wheel detects the direction selected by the driver.

Other sensors throughout the vehicle measure the actual direction.

The system compares driver input to the actual trajectory of the vehicle and corrects the trajectory if necessary by controlling the braking of certain wheels and/or engine power. In the event that the system is engaged, indicator light



flashes on the instrument panel.

#### Understeer control

This system optimises the action of the ESC in the case of pronounced understeer (loss of front axle road holding).

#### Traction control

This system helps to limit wheelspin of the drive wheels and to control the vehicle when pulling away accelerating or decelerating.



#### Operating principle

Using the wheel sensors, the system measures and compares the speed of the drive wheels at all times and slows down their over-rotation. If a wheel is starting to slip, the system brakes automatically until the drive supplied becomes compatible with the level of grip under the wheel again.

The system also adjusts the engine speed to the grip available under the wheels, independently of the pressure exerted on the accelerator pedal.

#### Operating faults

When the system detects an operating fault the message "CHECK ESC" and

warning light  and  appear on the instrument panel. In this case, the ESC and traction control system are deactivated.

Consult an approved dealer.



These functions are an additional aid in the event of critical driving conditions, enabling the vehicle behaviour to be adapted to suit the driving conditions.

The functions do not take the place of the driver. **They do not increase the vehicle's limits and should not encourage you to drive more quickly.** Therefore, they can under no circumstances replace the vigilance or responsibility of the driver when manoeuvring the vehicle (the driver must always be ready for sudden incidents which may occur when driving).

## DRIVING CORRECTION DEVICES AND AIDS (3/8)

### Driver assistance with a trailer

This system helps to maintain control over the vehicle while using a trailer. It detects shaking caused by towing a trailer under certain driving conditions.

#### Operating conditions

- The towbar must be approved by an authorised dealer;
- the harness must be approved by an authorised dealer;
- the towbar must be connected to the vehicle.

#### Operating principle

The function stabilises the vehicle by:

- asymmetric braking of the front wheels to reduce shaking caused by the trailer;
- braking of all four wheels and limitation on engine torque to reduce the vehicle speed until the shaking has stopped.

Warning light  flashes on the instrument panel to inform the driver.

### Emergency brake assist

This system supplements the ABS and helps reduce vehicle stopping distances.

#### Operating principle


The system is for detecting an emergency braking situation. In this case, the braking assistance immediately develops maximum power and may trigger ABS regulation.

ABS braking is maintained as long as the brake pedal is applied.


#### Hazard warning lights switching on

Depending on the vehicle, these may light up in the event of sudden deceleration.

#### Operating faults

When the system detects an operating fault the message “CHECK ABS” appears on the instrument panel along with the  warning light.

Consult an approved dealer.



### Active emergency braking


Using the sensor **1**, the system calculates the distance separating the vehicle from the one in front and alerts the driver if there is a risk of a front-end collision. The driver can then brake the vehicle to limit the damage arising from a collision.

**Note:** Make sure that the sensor **1** is not obscured (by dirt, mud, snow, etc.).


## DRIVER CORRECTION DEVICES AND AIDS (4/8)

### Operation

While driving (at speeds of between about 9 and 62 mph (15 and 100 km/h)), if there is a risk of collision with the


vehicle in front, the warning light  will flash on the instrument panel in red and a beep will sound.

If the driver depresses the brake pedal and the system still detects a collision

risk, the warning light  continues to flash on the instrument panel, accompanied by a beep, until the system no longer detects any risk of collision.

If the driver fails to react following an alert of an imminent collision, the system activates the brakes.

The system only detects vehicles driving in the same direction of traffic. The system cannot detect motorcycles because of the difficulty in forecasting their trajectory.




### Activating/deactivating the system

With the vehicle stationary and the ignition on:

- repeatedly press button **3** or **4** to select the “AEBS ACTIVE” function on the display **2**;
- press and hold button **3** or **4** for around 3 seconds to deactivate the system. The message “AEBS DEACTIVATED” will be displayed

and the  indicator light on the instrument panel will light up and stay on to confirm the deactivation of the system.

Pressing and holding one of the buttons **3** or **4** again will reactivate the system. The message “AEBS ACTIVE”

is displayed and the  indicator light goes out on the instrument panel.

This system is reactivated each time the ignition is switched on.

### Conditions for non-activation of the system


The system cannot be activated:

- when the gear lever is in neutral;
- when the parking brake is activated;
- while cornering.

# DRIVER CORRECTION DEVICES AND AIDS (5/8)

## Operating faults

The warning lights  and  lit up on the instrument panel accompanied by the message "WARNING AEBSCHECK" **indicate a system fault**. Consult an approved dealer.

When the system detects that the function is not available, the  warning light lights up on the instrument panel and stays on, with the message "WARNING AEBS DISABLED".

There are two possibilities:

- The system is temporarily disrupted (for example: radar obscured by dirt, mud, snow etc.). In this case, park the vehicle and switch off the engine. Clean the detection zone of the radar. When you next start the engine, the warning light and the message go out;
- If this is not the case, this may arise from another cause; contact an Approved Dealer.



### Active emergency braking

This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

### System servicing/repairs

- In the event of an impact, the sensor alignment may become changed, and its operation will consequently be affected. Deactivate the function, then consult an authorised dealer.
- Any work in the area where the radar is located (repairs, replacements, touching up of paintwork) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

### In the event of system disturbance

Some conditions can disturb or damage the operation of the system, such as:

- a complex environment (metal bridge, tunnel etc.) ;
- poor weather conditions (snow, hail, black ice, etc.).

### Risk of inadvertent braking.





### **Active emergency braking**

#### **Limitation of the system operation**

- A vehicle travelling in the opposite direction will not trigger any alert or any action on the system operation.
- The sensor area should be kept clean and free of any modifications in order to ensure the proper operation of the system.
- The system cannot respond to small vehicles such as motorbikes or bicycles as effectively as to other vehicles.

#### **Deactivating the function**

You must disable the function if:

- the brake lights are not functioning;
- the front of the vehicle has undergone an impact or been damaged;
- the vehicle is being towed (breakdowns).

#### **Halting the function**

You can halt the active braking function at any time by tapping the accelerator pedal or by turning the steering wheel in an avoidance manoeuvre.

In the event of the system behaving abnormally, deactivate it and consult an authorised dealer.

# DRIVER CORRECTION DEVICES AND AIDS (7/8)

## Grip control

If fitted on the vehicle, grip control makes it easier to control the vehicle on low grip surfaces (soft ground, etc.).



These functions are an additional aid in the event of critical driving conditions, enabling the vehicle behaviour to be adapted to suit the driving conditions.

The functions do not take the place of the driver. **They do not increase the vehicle's limits and should not encourage you to drive more quickly.** Therefore, they can under no circumstances replace the vigilance or responsibility of the driver when manoeuvring the vehicle (the driver must always be ready for sudden incidents which may occur when driving).



### “Road” mode

When the vehicle starts, the “STANDARD HIGHWAY MODE” message is displayed on the instrument panel. Depending on the vehicle the

warning light  on the instrument panel is out.

This position enables optimal usage under normal driving conditions (dryness, humidity, light snow, etc.). “Road” mode uses traction control functions.

### “Soft ground” mode

Press switch 5: the message “VARIABLE HIGHWAY MODE” lights up on the instrument panel, accompanied

by the warning light , depending on the vehicle.

This position enables optimal usage on soft ground (mud, sand, dead leaves, etc.). In this position, engine speed is left under the driver's control. The system automatically switches to “Road” mode at speeds above about 31 mph (50 km/h). The message “STANDARD HIGHWAY MODE” is displayed on the instrument panel and depending on the

vehicle, the  warning light on the instrument panel goes out.



### Tyres

When they need to be replaced, only tyres of the same make, size, type and profile should be used.

**Tyres fitted to the vehicle should either be identical to those fitted originally or conform to those recommended by your approved dealer.**

## DRIVING CORRECTION DEVICES AND AIDS (8/8)

### Hill start assistance

Depending on the gradient of the incline, this system assists the driver when starting on a hill. It prevents the vehicle from rolling backwards, depending on the slope, by automatically applying the brakes when the driver lifts his/her foot off the brake pedal to depress the accelerator pedal.

#### System operation

It only operates when the gear lever is in a position other than neutral and the vehicle is completely stationary (brake pedal depressed).

The system holds the vehicle for approximately **2 seconds**. The brakes are then gradually released (the vehicle will move according to the slope).



The hill start assistance system cannot completely prevent the vehicle from rolling backwards in all situations (extremely steep gradients etc.).

In all cases, the driver may depress the brake pedal to prevent the vehicle from rolling backwards.

The hill start assistance function should not be used for prolonged stops: use the brake pedal.

This function is not designed to immobilise the vehicle permanently.

If necessary, use the brake pedal to stop the vehicle.

The driver must remain particularly vigilant when driving on slippery or low-grip surfaces.

**Risk of serious injury.**


## TYRE PRESSURE LOSS WARNING (1/3)



When fitted to the vehicle, this system notifies the driver if one or more tyres lose pressure.

### Operating principle

Each wheel (except for the emergency spare wheel) has a sensor in the inflation valve which periodically measures the tyre pressure while driving.

Warning light  1 comes on to alert the driver in the event of insufficient pressure (deflated wheel, punctured tyre, etc.).

### Resetting the standard level for the tyre pressures

This should be done:

- when the standard tyre pressure needs to be changed to adapt to usage conditions (empty, carrying a load, motorway driving, etc.);
- after swapping a wheel (however this practice is not recommended);
- after changing a wheel.

It should always be done after checking the tyre pressure of all four tyres when cold.

Tyre pressures must correspond to the current usage of the vehicle (empty, carrying a load, motorway driving, etc.).




This function is an additional driving aid.

However, the function does not take the place of the driver. It cannot, therefore, under any circumstances replace the vigilance or the responsibility of the driver.

Check the tyre pressures, including the emergency spare wheel, once a month.

## TYRE PRESSURE LOSS WARNING (2/3)



### Resetting procedure

With the ignition on:

- repeatedly press button **3** or **4** to select the “TYRE PRESSURE ACQUISITION” function on the display **2**;
- press and hold (around 3 seconds) button **3** or **4** to start initialisation. Display of the message “TP ACQUISITION LAUNCHED” indicates that the reset request for the tyre pressure reference value has been taken into account.

Reinitialisation is carried out after a few minutes' driving.


### Note:

The standard tyre pressure cannot be less than that recommended and indicated on the door frame.

### Display

Display **2** on the instrument panel informs you of any tyre pressure faults (flat tyre, punctured tyre, etc.).

### “CHECK TYRE PRESSURES”

Warning light  comes on, along with the message “CHECK TYRE PRESSURES”.

These indicate that at least one tyre is flat.

Check and, if necessary, readjust the pressures of the four wheels when cold.

The warning light  goes off after a few minutes' driving.

The sudden loss of pressure in a tyre (burst tyre, etc.) cannot be detected by the system.

### “TYRE PUNCTURE”

The warning light  comes on steady, accompanied by the message “TYRE PUNCTURE” and a beep.

This message appears along with the **STOP** warning light.

They indicate that at least one wheel is punctured or severely underinflated. Replace it or contact an approved dealer if it is punctured. Top up the tyre pressure if the wheel is deflated.





allow.

Warning light **STOP** requires you to stop immediately, for your own safety, as soon as traffic conditions

## TYRE PRESSURE LOSS WARNING (3/3)

### “CHECK TYRE SENSORS”

The warning light  flashes for several seconds, then stays on, along with the message “CHECK TYRE SENSORS”.

This message appears along with the  warning light.

They indicate that at least one tyre is not fitted with sensors (e.g. emergency spare wheel). Otherwise, consult an authorised dealer.

### Readjustment of tyre pressures

**The tyre pressures must be adjusted when cold** (please refer to the label located on the edge of the driver’s door). If tyre pressures cannot be checked when the tyres are **cold**, the recommended pressures must be increased by **0.2 to 0.3 bar (3 PSI)**.

**Never deflate a hot tyre.**



### Replacing wheels/tyres

This system requires specific equipment (wheels, tyres, hubcaps, etc.). Please see the information on “Tyres” in Section 5.

Contact an approved Dealer to fit new tyres and to find out about available accessories compatible with the system and available from your dealer network: the use of any other accessory could affect the correct operation of the system or damage a sensor.

### Emergency spare wheel

If the vehicle is equipped with an emergency spare wheel, it will not have a sensor. When it is fitted on the vehicle,

the warning light  flashes for several seconds, then stays on, together with the warning light  and the message “CHECK TYRE SENSORS” appears on the instrument panel.

### Tyre repair product and inflation kit


Because the valves are specially designed, only use equipment approved by the approved network. Please refer to “Tyre inflation kit” in Section 5.



#### Changing a wheel

The system may take several minutes depending on use for the new wheel pressures to be recognised; check the tyre pressures after all operations.

## LANE DEPARTURE WARNING (1/3)



Using information from the camera **1**, the function warns the driver if he crosses a continuous or broken line without activating the direction indicator lights.


**Note:** make sure the windscreen is not obscured (dirt, mud, snow, condensation, etc.).



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

**The lane departure warning function does not correct the vehicle's trajectory.**

## LANE DEPARTURE WARNING (2/3)



With the ignition on, the function is active by default.

### Deactivating/Activating the function

To deactivate it, press button **2**. The indicator light on button **2** comes on, accompanied by a message on the instrument panel "LANE DEPARTURE WARNING OFF".


To activate it, press button **2**. The warning light on button **2** goes out, accompanied by a message on the instrument panel "LANE DEPARTURE WARNING ON".

#### The function is set to notify the driver if:

- the indicator light on button **2** is off; and
- the vehicle speed is greater than approximately 37.2 mph (60 km/h); and
- lines are detected.

Warning light  comes on on the instrument panel to notify the driver.


#### The function sounds the alarm if:

a line is crossed without activating the indicator lights. The function alerts the driver through a warning light  on the instrument panel, along with a beep.

### Conditions for non-activation of alerts

- Indicators activated or having been activated less than approximately four seconds prior to departing from the lane;
- Very fast lane departure;
- Driving continuously on a line;
- ...

### Operating faults

In the event of a malfunction, a message "LANE DEPARTURE CHECK" is displayed on the instrument panel accompanied by the warning light . Consult an approved dealer.





This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

### **System servicing/repairs**

- In the event of an impact, the camera alignment may be changed, and its operation may consequently be affected. Deactivate the function, then consult an authorised dealer.
- Any work in the area where the camera is located (repairs, replacements, windscreen modifications etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

### **In the event of system disturbance**

Some conditions can disturb or damage the operation of the system, such as:

- a complex environment (tunnel etc.);
- poor weather conditions (snow, hail, black ice etc.);
- poor visibility (night, fog etc.);
- road markings which are worn, lacking in contrast or very widely spaced from one another (lines partially erased etc);
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction etc.);
- the road is narrow, winding or undulating (tight bends etc.);
- closely following a vehicle travelling in the same lane.

### **Risk of false alarms or absence of warnings**

## SPEED LIMITER (1/3)

The speed limiter function helps you stay within the driving speed limit that you choose, known as the **limit speed**.




### Controls

- 1 Limit speed activation, memorisation and increase switch (+).
- 2 Decrease limit speed (-).
- 3 Switch the function to standby (with limit speed memorisation (O)).
- 4 Activation and recall of memorised limit speed (R).
- 5 Main "On/Off" switch.



### Switching on

Press the side switch **5** . The warning light **6** comes on, lit orange, and the message "SPEED LIMITER" appears on the instrument panel, accompanied by dashes to indicate that the speed limiter is activated and waiting to store a speed limit.

To memorise the current speed, press switch **1** (+): the minimum speed which can be memorised is 20 mph (30 km/h).

## SPEED LIMITER (2/3)



### Driving

When a limited speed has been stored and this speed is not reached, driving is similar to driving a vehicle without the speed limiter function.

Once you have reached the stored speed, no effort on the accelerator pedal will allow you to exceed the programmed speed except in an emergency (refer to information on “Exceeding the limit speed”).

### Varying the limit speed

The limit speed may be changed by repeatedly pressing:

- switch 1 (+) to increase speed;
- switch 2 (-) to reduce speed.

### Exceeding the limit speed

It is possible to exceed the limit speed at any moment. To do this: press the accelerator pedal **firmly and fully** (beyond the kickdown point).

Whilst the speed is being exceeded, the limit speed displayed on the instrument panel flashes.

Then, as far as is possible, release the accelerator pedal: the speed limiter function will return as soon as you reach a speed lower than the memorised speed.

### Limited speed cannot be maintained

When driving down a steep gradient, the system is unable to maintain the limit speed: the memorised speed will flash on the instrument panel information display to inform you of this situation.



The speed limiter function is in no way linked to the braking system.

## SPEED LIMITER (3/3)



### Putting the function on standby

The speed limiter function is deactivated when you press switch **3** (O). In this case, the speed limit remains stored and the message “SPEED MEMORY”, accompanied by this speed, appears on the instrument panel.

### Recalling the limit speed

If a speed has been memorised, it can be recalled by pressing switch **4** (R).

### Switching off the function

The speed limiter function is deactivated when you press switch **5**. In this case, the speed is no longer memorised. The instrument panel orange indicator light (S) goes out, confirming that the function is deactivated.

When the speed limiter is set to standby, pressing switch **1** (+) reactivates the function without taking into account the memorised speed: it is the speed at which the vehicle is moving that is taken into account.

## CRUISE CONTROL (1/4)

The cruise control function helps you to maintain your driving speed at a speed that you choose, called the **cruising speed**.

This cruising speed may be set at any speed above 20 mph (30 km/h).



### Controls

- 1 Cruising speed activation, storage and increase switch (+).
- 2 Cruising speed decrease switch (-).
- 3 Switch the function to standby (with stored cruising speed) (O).
- 4 Activation with recall of stored governed cruising speed (R).
- 5 Main "On/Off" switch.



The cruise control function is in no way linked to the braking system.



This function is an additional driving aid. The function does not take the place of the driver.

Therefore, it can under no circumstances replace the driver's responsibility to respect speed limits and to be vigilant (the driver must always be ready to brake).


Cruise control must not be used in heavy traffic, on undulating or slippery roads (black ice, aquaplaning, gravel) and during bad weather (fog, rain, side winds etc.).

**There is a risk of accidents.**

## CRUISE CONTROL (2/4)



### Switching on

Press switch **5** on the side showing .

Indicator light **6** comes on, lit green, and the message "CRUISE CONTROL" appears on the instrument panel, accompanied by dashes to indicate that the cruise control function is activated and waiting to store a cruising speed.



### Activating cruise control

At a steady speed (above 20 mph (30 km/h) approximately) press switch **1 (+)** or **2 (-)**: the function is activated and the current speed is memorised.

Cruise control activation is confirmed when indicator light **7** is lit up in green in addition to indicator light **6**.

## Driving

Once a cruising speed is memorised and the cruise control function is active, you may lift your foot off the accelerator pedal.



Please note that you must keep your feet close to the pedals in order to react in an emergency.

## CRUISE CONTROL (3/4)



### Adjusting the cruising speed

The cruising speed may be changed by pressing the following repeatedly:

- switch **1** (+) to increase speed;
- switch **2** (-) to decrease the speed.



The cruise control function is in no way linked to the braking system.

### Exceeding the cruising speed


The cruising speed may be exceeded at any time by depressing the accelerator pedal. While it is being exceeded, the cruising speed flashes on the instrument panel.

Then, release the accelerator pedal: after a few seconds, the vehicle will automatically return to its set cruising speed.

### Cruising speed cannot be maintained

When driving down a steep gradient, the system is unable to maintain the cruising speed: the stored speed will flash on the instrument panel information display to inform you of this situation.

## CRUISE CONTROL (4/4)




### Putting the function on standby

The function is set to standby if you:

- press button **3** (O);
- the brake pedal;
- depress the clutch pedal or shift into neutral if the vehicle has an automatic gearbox.

In all three cases, the cruising speed remains stored and the message “SPEED MEMORY” appears on the instrument panel.

Standby is confirmed when the green  indicator light goes out.

### Recalling the cruising speed

If a speed is memorised, it can be recalled, once you are sure that the road conditions are suitable (traffic, road surface, weather conditions, etc.).



With a vehicle speed above 20 mph (30 km/h), press switch **4** (R).

**Note:** if the speed previously stored is much higher than the current speed, the vehicle will accelerate more rapidly to reach this threshold.

When the cruise control is set to standby, pressing switch **1** (+) reactivates the cruise control function without taking into account the stored speed: it is the speed at which the vehicle is moving that is taken into account.

### Switching off the function

The cruise control function is deactivated if you press switch **5**: in this case a speed is no longer memorised.

The  and  indicator lights on the instrument panel go out, confirming that the function is deactivated.



Putting the cruise control on standby or switching it off does not cause a rapid reduction in speed: you must brake by depressing the brake pedal.



## VEHICLE WITH OVERSPEED FUNCTION



The vehicle speed may be permanently set at a fixed value depending on the vehicle or on local legislation.

To adjust the value or activate/deactivate the function, consult an approved dealer.

In the event of statutory limits (depending on the vehicle), this function may not be deactivated.

Label **1** attached to the dashboard shows the speed limit.

**Special case:** if your vehicle is fitted with the Cruise control/Speed limiter, fully depressing the accelerator pedal (beyond the kickdown point) will not allow you to exceed the overspeed function set speed (refer to the information on the “Speed limiter” in Section 2).

In exceptional circumstances (e.g. steep gradient), the overspeed function speed may be exceeded slightly as the function does not affect the braking system.



The function does not take the place of the driver. Under no circumstances should it replace observation of speed limits nor vigilance and responsibility on the part of the driver.

## PARKING DISTANCE CONTROL (1/2)

### Operating principle

Ultrasonic sensors, fitted in the vehicle's rear bumper, measure the distance between the vehicle and an obstacle when reversing.

This measurement is indicated by beeps which become more frequent the closer you come to the obstacle, until they become a continuous beep when the vehicle is approximately 25 centimetres from the obstacle.

There is a beep when reverse gear is engaged. If the beep sounds for a long time (about 3 seconds), this signals an operating fault.

The parking distance control system does not take into account towing and load carrying systems etc.

**Note:** make sure that the ultrasonic sensors are not obscured (by dirt, mud, snow, etc.).



An impact to the underside of the vehicle (eg. striking a post, raised kerb or other street furniture) may result in damage to the vehicle (eg. deformation of an axle).

To avoid any risk of accident, have your vehicle checked by an approved Dealer.



This function is an additional aid that indicates the distance between the vehicle and an obstacle whilst reversing, using sound signals.

Under no circumstances should it replace the driver's care or responsibility whilst reversing.

The driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post, etc.) in the blind spot when manoeuvring.

## PARKING DISTANCE CONTROL (2/2)



### Temporary deactivation of the system

Press switch **1** to deactivate the system.

The indicator light built into the switch lights up to remind you that the system is deactivated.

Pressing the switch again will reactivate the system and switch off the indicator light.

The system is automatically reactivated after the ignition is switched off and the engine restarted.

### Prolonged deactivation of the system

You can deactivate the system permanently by pressing and holding switch **1**.

The warning light built into the switch remains lit constantly.

The deactivated system can be reactivated by pressing and holding the switch again.

### Operating faults


When the system detects an operating fault, a beep sounds for about 3 seconds as a warning. Consult an approved dealer

## REVERSING CAMERA (1/2)



### Operation

Moving into reverse gear, the camera **1** located on the tailgate or, depending on the vehicle, on the rear hinged door, provides a view of the area behind the vehicle on the rear-view mirror **2** or, depending on the vehicle, on the multimedia display **3**, accompanied by two moving or fixed guide lines **4** and **5**.



**Note:** make sure that the reversing camera is not obscured (by dirt, mud, snow, condensation, etc.).




**Note:** depending on the vehicle, you can adjust certain settings from the multimedia display **3**. Refer to the handbook for the equipment.



This function is an additional aid. It cannot, therefore, under any circumstances replace the vigilance or the responsibility of the driver.

The driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post, etc.) in the blind spot when manoeuvring.

## REVERSING CAMERA (2/2)



### Dynamic gauge 4 (depending on the vehicle)

This is shown in blue on the multimedia display 3. It indicates the vehicle trajectory according to the position of the steering wheel.

### Static guide line 5:

The fixed clearance gauge comprises coloured markers **A**, **B** and **C**, indicating the distance behind the vehicle:

- **A** (red) approximately 30 centimetres from the vehicle;
- **B** (yellow) approximately 70 centimetres from the vehicle;
- **C** (green) approximately 150 centimetres from the vehicle.

This gauge remains fixed and indicates the vehicle trajectory if the wheels are in line with the vehicle.

This system is initially used with the aid of several gauges (mobile for trajectory and fixed for distance). When the red zone is reached, use the bumper image to stop accurately.

The screen shows a reverse image.

The frames are a representation projected on a flat surface. This information is to not be taken into account when superimposed on a vertical object or an object on the ground.

Objects which appear on the edge of the screen may be deformed.

In very bright light (snow, vehicle in sunshine etc.), the camera vision may be adversely affected.

If the rear doors are open or poorly closed, the camera display disappears and, depending on the vehicle, the message "BOOT OPEN" appears.

## POWER TAKE-OFF



### Operating the function

With the vehicle stopped, the engine idling, the gearbox in neutral:

- depress the clutch pedal;
- press switch **1**. The indicator light integrated in the switch comes on after about 2 seconds;
- release the clutch pedal. The idle speed increases to 1,200 rpm.

### Operating faults

When the indicator light integrated into switch **1** does not come on or the power take-off is not triggered:

- with the clutch pedal depressed, press switch **1** and release the clutch pedal then repeat the procedure;
- or gradually release the clutch pedal.

### Switching off the function

- Depress the clutch pedal;
- press switch **1**. The indicator light integrated in the switch goes out after about 2 seconds.

When the power take-off is engaged, do not change gear. If it becomes necessary to change gear, you must first disconnect the power take-off.

## FAST IDLE SPEED





Press control **1**, and the function will be activated after a few seconds.

### Modifying fast idle speed

To increase or reduce the speed, contact an approved dealer.

### Switching off the function

The function is interrupted when:

- you depress the clutch pedal and/or accelerator pedal;
- the sequential gearbox is not in neutral;
- the vehicle speed is above 0 mph;
- the **STOP** indicator light is lit up on the instrument panel;
- the  indicator light is lit up on the instrument panel;
- the  indicator light is lit up on the instrument panel.

**Special feature relating to the Stop and Start** function: activation of the “Fast Idle Speed” function stops the engine going into standby (refer to the information on “Stop and Start” in section 2).

## SELF-LOCKING DIFFERENTIAL

The self-locking differential controls the torque transmitted to each rear wheel.

Depending on the grip conditions on the road surface, and at low speeds (under 20 mph/30 kph), this device enables wheel torque to move automatically, thereby providing increased grip. This enables the grip potential of each wheel to be used to the fullest possible extent, thereby enabling the vehicle to run over areas with decreased grip (e.g.: work sites, muddy ground, etc.).

Once the rear wheels return to surfaces with normal grip (eg: return to paved roads), the self-locking differential device will be deactivated, sometimes accompanied by a noise (with no consequence to vehicle behaviour). You have the option of turning this device off yourself, once normal grip conditions have resumed, by briefly releasing the accelerator



This function is an additional driving aid.

**However, it does not increase the vehicle's limits and should not encourage you to drive more quickly.**

It cannot, therefore, under any circumstances replace the vigilance or the responsibility of the driver.




## SEQUENTIAL GEARBOX (1/5)



### Selector lever 1

- This allows you to shift directly from first gear to reverse gear, to select reverse gear and neutral and to change gear in manual mode.
- It also allows you to switch between manual and automatic modes at any time, with the engine switched on and reverse gear engaged, by moving the lever to the left.

**Note:** the selector lever automatically returns to the centre position after each use.



### Display

- 2 Load mode
- 3 Automatic mode
- 4 Gear display
- 5 Brake pedal depressed indicator light

The gear selected (1, 2..., 6, N, R) is displayed on the instrument panel. In automatic mode, (A) is displayed.

### Operation

Switch on the ignition.

The display on the instrument panel switches on.

If neutral (N) is displayed and is accompanied (depending on the vehicle), by the 5 warning light; press the brake pedal and start the engine but do not accelerate.

If a gear other than neutral is engaged, N flashes on the display accompanied by the 5 warning light; press the brake pedal and place the lever in position N. Start the engine.

**Note:** do not attempt to start the engine by pushing the vehicle if the battery is flat (the display remains off when the ignition is switched on).

## SEQUENTIAL GEARBOX (2/5)

### Starting

**Moving forwards** (starting in neutral)

**The display indicates gears N and A.**


- With the brake pedal depressed, push the selector lever forwards then release it.
- Release the brake pedal and accelerate gently to move forwards.

**Reverse gear** (vehicle stationary)

- **Brake pedal depressed.** Push the selector lever towards the right and to the rear as shown on the base of the lever, and then release it. Reverse gear is engaged and the letter **R** appears on the display.
- Release the brake pedal:
  - the engine's idle speed is sufficient for parking manoeuvres;
  - accelerate gently to reverse.

You may shift from reverse gear to a forwards gear by pushing the lever forwards once the vehicle is stationary.

**Note:** When the vehicle is stationary, you must depress the brake pedal to engage or disengage a gear. Otherwise, warning light **5** will come on.



### Gear shift pattern

(see the marking on the lever base)

- + To move up through the gears
- To move down through the gears

**N** Neutral

**R** Reverse

- Only stable position of the lever

**A/M** To switch from automatic mode to manual mode and vice versa



Exactly like a vehicle equipped with a manual gearbox, a vehicle equipped with a sequential gearbox is unable to prevent the vehicle from rolling on a slope if the handbrake is not applied or the brake pedal constantly depressed.

## SEQUENTIAL GEARBOX (3/5)

### Operation in semiautomatic mode (manual)

This mode can be activated at any time when driving by pushing the lever to the left. The mode is switched without shifting up a gear.

You can initiate gear changes using the selector lever.

To shift up a gear, push the selector lever forwards; the accelerator pedal does not have to be lifted.

To shift down a gear, push the selector lever backwards; the accelerator pedal does not have to be lifted.

The system will not tolerate a series of up or down changes that cause the engine to underrev or overrev.

By pushing the lever forwards twice you can move up two gears at a time (except if underrevving). By pushing the lever backwards twice you can move down two gears at a time (unless this causes overrevving).

When decelerating with the foot off the pedal, the gears will automatically drop to the low engine speed limit to avoid stalling. First gear automatically shifts below a certain speed limit. You can stop the vehicle at red lights or junctions etc. by depressing the brake pedal; there is no need to change to neutral (**N**).

The vehicle will move off again:

- either slowly, if you release the brake without accelerating (e.g. when in a traffic jam);
- or quickly, if you release the brake and accelerate.

**Note:** neutral may only be selected when the vehicle is being driven or is stationary when **the brake pedal is depressed (if you forget, warning light 5 will come on)**.

Push the gear selector lever to the right to engage neutral.

If the engine speed is too high or too low, the system will choose the optimum gear.

Semiautomatic mode can be deactivated and reactivated at any time when the engine is running by pushing the lever to the left.

## SEQUENTIAL GEARBOX (4/5)

### Operation in automatic mode

Automatic mode is selected by default every time the ignition is switched on.

The letter **A** appears on the display. The vehicle is controlled using the accelerator and the brake. Gears will change automatically at the correct moment and at a suitable engine speed because the automatic mode takes the road surface and the chosen driving style into consideration.

Gears may be shifted manually in this mode. Pushing the lever forwards or backwards shifts a gear upwards (except if there is a risk of underrevving) or downwards (except if there is a risk of overrevving).

The oil level in the automatic gearbox system reservoir varies depending on use. Adding oil is **strictly forbidden** (except by qualified approved network personnel).

**Note:** automatic mode takes account of:

- the position and speed of depression of the accelerator pedal to assess driving style and select the optimum gear;
- action on the brake pedal, to commence engine braking in preparation for a downshift.

You can stop the vehicle at red lights, with the gear engaged, by depressing the brake pedal; there is no need to change to neutral (**N**).

The vehicle will move off again:

- either slowly, if you release the brake without accelerating (e.g. when in a traffic jam);
- or quickly, if you release the brake and accelerate.

### Accelerating and overtaking

- Slowly depress the accelerator pedal to accelerate gradually;

- **to obtain maximum vehicle performance regardless of the mode selected (automatic or manual), quickly depress the accelerator pedal beyond the kickdown point.**

The speed with which you depress the pedal will allow you to downshift according to the vehicle's capabilities.

### Parking the vehicle

It is possible to park in gear (for example, on a slope):

- with the ignition on, select a gear **with your foot on the brake**;
- check that a gear other than **N** is displayed on the instrument panel, then remove the ignition key;
- **apply the handbrake.**

To disengage the gear, switch on the ignition without starting the engine and shift the selector lever to neutral **with the brake pedal depressed**. Check that **N** is displayed on the instrument panel.

## SEQUENTIAL GEARBOX (5/5)

### Bleep

- If you hold the vehicle on a slope for too long without applying the brakes or handbrake, you will strain the system (risk of overheating the clutch).


In this case, an intermittent beeping sound will remind you that you should put your foot on the brake pedal or apply the handbrake.

- Never leave the vehicle with the engine running when in gear. For safety reasons you will hear an intermittent beeping sound when you open the door if you have not shifted into neutral or you have not switched off the ignition or depressed the brake pedal.

### Special circumstances

On a slippery surface or surface with little grip, change to manual mode (A/M) and select second gear before accelerating to avoid wheelspin.

### Operating faults

 If this warning light comes on when the **vehicle is in motion**, it indicates a fault in the system. In most cases, you may still drive the vehicle, although it will not function perfectly. Contact an approved dealer as soon as possible.

### Towing a vehicle with a sequential gearbox

If the gearbox is stuck in a gear:

- switch on the ignition;
- select neutral **with the brake pedal depressed**;
- check that the gearbox is in neutral (by pushing the vehicle, for example).

If you cannot find neutral you must tow the vehicle with the front wheels raised.

**The vehicle should always be towed with the ignition switched off.**



### Load position

When the vehicle is driven loaded, press the **6** switch on the dashboard. The indicator light **kg** on the instrument panel will light up.

Load mode is deselected every time the engine is switched off. It will be necessary to select it again.

Load mode may be used to equal effect in both automatic and manual modes.




# Section 3: Your comfort

Air Vents . . . . .	3.2
Manual air conditioning/heating system . . . . .	3.4
Automatic climate control . . . . .	3.7
Air conditioning: information and advice on use . . . . .	3.13
Windows . . . . .	3.15
Interior lighting . . . . .	3.17
Sun visor, grab handle . . . . .	3.18
Ashtrays, Cigarette lighter, Accessories socket . . . . .	3.19
Passenger compartment storage, fittings . . . . .	3.20
Rear bench seats . . . . .	3.26
Multimedia equipment . . . . .	3.28
Transporting objects . . . . .	3.29

## AIR VENTS, air outlets (1/2)

209952



- 1 Side window demister outlet.
- 2 Side air vent.
- 3 Windscreen demisting vents.
- 4 Centre air vents.

- 5 Side air vent.
- 6 Side window demister outlet.
- 7 Passenger footwell heater outlets.
- 8 Control panel.



## AIR VENTS, air outlets (2/2)



### Air vent 1 or 2

To open, press on the air vent.

To direct, take hold of the air vent and turn it to the required position.




To remove bad odours from your vehicles, only use the systems designed for this purpose. Consult an approved Dealer.



Do not add anything to the vehicle's ventilation circuit (for example, to remove bad odours).

**There is a risk of damage or of fire.**

# MANUAL AIR CONDITIONING, HEATING SYSTEM (1/3)



## Controls

- A** Adjusting the amount of air blown into the passenger compartment.
- B** Air recirculation operation (isolation of the passenger compartment)
- C** Adjusting the air temperature.
- D** Activating air conditioning (depending on the vehicle).
- E** Rear screen and/or door mirror de-icing/demisting.
- F** Air distribution.

## Information and advice for use

Refer to information on “Air conditioning: information and advice on use”.

## Distribution of air in the passenger compartment

Turn control **F**.



All the air flow is directed to the dashboard vents.

This selection is not appropriate if all the air vents are closed.



The air flow is directed to the dashboard vents and the footwells.



The air flow is directed mainly towards the footwells.



The air flow is distributed between all the air vents, the front side window demisting vents, the windscreen demisting vents and the footwells.



The air flow is directed to the windscreen demisting/outlets and the side windows. This position prevents the formation of condensation. Use at the highest temperature.




## Rear screen and/or door mirror de-icing/demisting.

Press button **E**: the integrated indicator light comes on. This function demists the rear screen and/or the heated door mirrors quickly.

To exit this function, press the button again; the integrated indicator goes out. Demisting automatically stops by default.

## MANUAL AIR CONDITIONING, HEATING SYSTEM (2/3)



### Adjusting the air temperature

Turn control **C**.

Turning the control to the right increases the temperature.

### Air recirculation operation (isolation of the passenger compartment)

Normal operation of the heating and ventilation system is obtained using air from outside.

Recirculation of air allows the external atmosphere to be isolated (driving in polluted areas, etc.).

Press button **B** to switch to isolation mode.


This function also allows the desired comfort level to be achieved as quickly as possible.

This starts or stops air recirculation. Operating tell-tale lights up when the function is operational. In this position the air is taken from inside the passenger compartment and is recycled without letting air in from outside.

Prolonged use of this position can lead to condensation forming on the side windows and windscreen and problems due to the use of non-renewed air in the passenger compartment.

We therefore advise you to return to normal mode (external air) as soon as the air recirculation function is no longer required, by pressing button **B** again.

## MANUAL AIR CONDITIONING, HEATING SYSTEM (3/3)



### Adjusting the amount of air blown into the passenger compartment

Turn control **A** from **0** to **4**.

The passenger compartment is ventilated by blown air.

The blower determines how much air enters but vehicle speed also has some influence on this.

The further the control is positioned to the right, the greater the amount of air blown into the passenger compartment.

### Switching air conditioning on or off

(depending on the vehicle)


The air conditioning is switched on (indicator light lit) or off (indicator light off) using button **D**.

The air conditioning system is used for:

- lowering the temperature inside the passenger compartment;
- eliminating condensation more quickly.

**Note:** the air conditioning does not operate if the exterior temperature is low or the ventilation speed is less than 1.

## AUTOMATIC CLIMATE CONTROL (1/6)



### Controls (depending on vehicle)

- 1 - "Clear View" button to demist and de-ice the windows.
- 2 - Air conditioning off button.
- 3 - Automatic mode.
- 4 - Display.
- 5 and 7 - Adjusting the ventilation speed.
- 6 and 8 - Passenger compartment air distribution adjustment.

9 and 10 - Adjusting the air temperature.


11 - Heated rear screen and/or heated door mirror de-icing.

12 - Air recirculation control.

### Information and advice for use

Refer to information on "Air conditioning: information and advice on use".

## AUTOMATIC CLIMATE CONTROL (2/6)



### Automatic mode

Press button **3**. AUTO lights up on display **4**.

In most cases, the automatic climate control system ensures a comfortable temperature in the passenger compartment, while maintaining good visibility and optimising fuel consumption.

**This is the recommended mode of use.**

To reach and keep the chosen comfort level and to maintain good visibility, the system controls:

- ventilation speed;
- air distribution;
- air recirculation management;
- air conditioning start/stop;
- the air temperature.

**Only the temperature and the AUTO symbol are displayed**

Functions managed in automatic mode are not displayed.

- press button **9** to increase the temperature;
- press button **10** to decrease the temperature.

**Note:** The maximum and minimum settings of 15°C and 27°C allow the system to produce a minimum or maximum temperature, whatever the ambient conditions.

In automatic mode (AUTO lit on the display), all heating and air conditioning functions are controlled by the system.

When you modify certain functions, AUTO goes out. Only the modified function stops being controlled by the system.

## AUTOMATIC CLIMATE CONTROL (3/6)

### Adjusting automatic mode

The system normally operates in automatic mode but you can alter the standard settings used by the system (air distribution, etc.). These options are explained on the following pages.

#### **Automatic mode is the recommended mode of use**

In most cases, the automatic climate control system ensures a comfortable temperature in the passenger compartment, while maintaining good visibility and optimising fuel consumption.

The types of adjustments that can be made are described in the following pages.


Return to automatic mode as soon as possible.

The displayed temperature values show a comfort level.

When starting the engine, increasing or decreasing the value displayed will not allow the comfort level to be reached any more quickly. The system will always optimise the temperature increase or decrease (the ventilation system does not start instantly at maximum speed: it gradually increases). This may take several minutes.

Generally speaking, unless there is a particular reason not to, the dashboard air vents should remain open.

## AUTOMATIC CLIMATE CONTROL (4/6)



### Distribution of air in the passenger compartment

There are five possible combinations for air distribution, which may be selected by pressing buttons **6** and **8** repeatedly. The arrows on display **4** indicate the setting selected:



The air flow is directed to the windscreen demisting vents and the side windows.



The air flow is directed to the windscreen and side window demisting vents, and the passenger footwells.



The air flow is directed mainly to the dashboard air vents.



The air flow is directed towards all the air vents and the passenger footwells.




The air flow is directed mainly towards the footwells.

The manual air distribution option causes the operating tell-tale light on display **4** to go out (automatic mode), but only air distribution is no longer controlled automatically by the system.

Press button **3** to return to automatic mode.



## AUTOMATIC CLIMATE CONTROL (5/6)



### Switching air conditioning on or off

In automatic mode, the system switches the air conditioning system on or off, depending on the climate conditions.

Exit automatic mode by pressing button **2**: AUTO goes out on display **4** and AC OFF lights up.

**Note:** the "Clear View" function automatically activates the air conditioning. Press button **3** to return to automatic mode.

### Varying the ventilation speed

In automatic mode, the system uses the most suitable amount of air to reach and maintain the desired comfort level.

Exit automatic mode by pressing buttons **5** and **7**.

These buttons allow you to increase or decrease ventilation speed.

### Rear screen and/or door mirror de-icing/demisting.


Press button **11**: the integrated indicator light comes on.

This function allows electric demisting of the rear screen and/or the electric heated door mirrors, depending on the vehicle.

**To exit this function**, press button **11** again. Demisting automatically stops by default.

In automatic mode, depending on the outside air conditions, the ventilation may not start immediately at maximum power but will increase progressively until the engine temperature is warm enough to heat the passenger compartment air. This may take from a few seconds to several minutes.

## AUTOMATIC CLIMATE CONTROL (6/6)



### Clear View function

Press button **1**; the indicator lights in buttons **1** and **11** come on.

AUTO goes out on display **4**.

This function rapidly demists/de-ices the windscreen, the front side windows and the door mirrors.

It imposes automatic operation of the air conditioning and heating of the rear screen and/or heated door mirrors, and inhibits air recirculation.

Press button **11** if you do not wish to switch on the heated rear screen and/or heated door mirrors.

**Note:** if you wish to reduce the air flow (which may produce a certain amount of noise in the passenger compartment), press button **5**.

**To exit this function**, press:

- button **1** again;
- button **3** (AUTO lights up on the display).

### Air recirculation

Pressing button **12** activates air recirculation (the symbol lights up on the display).

During recirculation, air is taken from the passenger compartment and is recycled, with no air being taken from outside the vehicle.

Air recirculation allows the external atmosphere to be cut off (when driving in polluted areas, etc.).

Prolonged use of the air recirculation mode may cause the windows to mist up or lead to odours, as the air is not renewed.

We therefore advise you to return to normal mode (external air) as soon as the air recirculation function is no longer required, by pressing button **12** again.

# AIR CONDITIONING: information and operating instructions (1/2)

## Advice on use

In some situations (air conditioning off, air recirculation activated, ventilation speed at zero or low etc.), you may notice that condensation starts to form on the windows and windscreen.

If there is condensation, use the “**Clear View**” function to remove it, then use the air conditioning in automatic mode to stop it forming again.

### Vehicles equipped with modeECO

Once activated, ECO mode may reduce air conditioning performance. Please refer to the information on “Driving advice, Eco-driving” in Section 2.



Do not add anything to the vehicle's ventilation circuit (for example, to remove bad odours).

**There is a risk of damage or of fire.**

## Fuel consumption

You will normally notice an increase in fuel consumption (especially in town) when the air conditioning is operating. For vehicles fitted with air conditioning with no automatic mode, switch off the system when it is not required.

### Advice for reducing consumption and helping to preserve the environment

Drive with the air vents open and the windows closed. If the vehicle has been parked in the sun, open the doors for a few moments to let the hot air escape before starting the engine.

## Maintenance

Refer to the Maintenance Document for your vehicle for the inspection frequency.

Use the air conditioning system regularly, even in cold weather, running it at least once a month for approximately 5 minutes.

## Operating faults

As a general rule, contact your approved dealer in the event of an operating fault.

### – Reduction in de-icing, demisting or air conditioning performance.

This may be caused by the passenger compartment filter cartridge becoming clogged.

### – No cold air is being produced.

Check that the controls are set correctly and that the fuses are sound. Otherwise, switch off the system.


## Presence of water under the vehicle

After prolonged use of the air conditioning system, it is normal for water to be present under the vehicle. This is caused by condensation.



**Do not open the refrigerant fluid circuit.** The fluid may damage eyes or skin.


# AIR CONDITIONING: information and operating instructions (2/2)









The refrigerant circuit may contain fluorinated greenhouse gases.

Depending on the vehicle, you will find the following information on label **A** affixed inside the engine compartment.

The presence and location of the information on label **A** depends on the vehicle.

 **Do not open the refrigerant circuit.** The fluid may damage eyes or skin.

 Before performing any action in the engine compartment, the ignition must be switched off (please see the information on “Starting, stopping the engine” in section 2).


-  Type of refrigerant fluid
-  Type of oil in the air conditioning circuit
-  Inflammable product
-  Consult the driver’s handbook
-  Maintenance

x.xxx kg Quantity of refrigerant fluid present in the vehicle.

GWP xxxxx Global Warming Potential (CO<sub>2</sub> equivalent).

CO<sub>2</sub> eq  
x.xx t Quantity in weight and in CO<sub>2</sub> equivalent.

## WINDOWS (1/2)



### Electric windows


#### With the ignition on:

- press the switch for the window concerned to lower it to the desired height;
- lift the switch for the window concerned to raise it to the desired height.

#### From the driver's seat

Operate the switches as follows:

- **1** for the driver's side;
- **2** for the front passenger side.



#### From the front passenger seat

Press switch **3**.

Avoid resting any objects against a half-open window: there is a risk that the electric window winder could be damaged.



#### Driver's responsibility

Never leave your vehicle with the key, remote control or transmitter-receiver inside, and never leave a child, adult who is not self-sufficient or a pet, even for a short while. They may pose a risk to themselves or to others by starting the engine or activating equipment (such as the gear lever or electric windows). If any part of the body becomes trapped, reverse the direction of the window immediately by pressing the relevant switch.

**Risk of serious injury.**

## WINDOWS (2/2)



### One-touch electric window

The one-touch mode works in addition to the operation of the electric windows described previously.

**It is fitted to the driver's window and is used for lowering only.**


**Briefly press** switch **1**: the window lowers completely.

Pressing the switch again while the window is moving will stop its movement.



When closing the windows, ensure that no part of the body (arm, hand, etc.) is protruding from the vehicle.


**Risk of serious injury.**



### Sliding rear windows

Press the tab **4** and slide the window.

# INTERIOR LIGHTING



## Courtesy light


Use switch **1** to:

- permanent lighting;
- intermittent lighting, which comes on when a door is opened. It goes out when the doors concerned are properly closed;
- immediate switching off.

## Map reading lights

(depending on the vehicle)

Move switch **2**.



## Rear light 3

Turn switch **4** to:

- switch on continuous lighting;
- switch on intermittent lighting when one of the rear doors is opened. The lights only go out when the doors are correctly closed;
- force the lights off.

## Note


Remote unlocking of the doors triggers timed lighting of the passenger compartment.

If one of the front or rear doors is opened, the timed lighting will start again.

Then the courtesy light and the luggage compartment light dim and go out. The lighting timer will cut out for various reasons:

- if a door has been open for 15 minutes;
- if all the doors have been closed for 15 seconds;
- when the ignition is switched on.

## SUN VISOR, GRAB HANDLE



### Sun visor

Lower sun visor **1**.

The sun visor can be swung round against the door window.



### Courtesy mirror or additional rear-view mirror **2**

(depending on the vehicle)

Lower the sun visor to access the mirror.

### Special feature of the additional rear-view mirror

See "Rear view mirrors" in Section 1.




### Grab handle **3**

This offers support and can be held when the vehicle is being driven.

Do not use it for getting into or out of the vehicle.



# ASHTRAY, CIGAR LIGHTER, ACCESSORIES SOCKET



## Ashtray 2

(depending on vehicle)

This is a removable ashtray which can be placed in the cup holders.

Lift the cover to open.

To empty it, pull the assembly. The ashtray will come out of its housing.

## Cigar lighter 1

(depending on vehicle)

With the ignition on, push in cigar lighter 1, it will spring back with a click when it is ready. Pull it out to use. After use, replace it without pushing it all the way in.




## Accessories socket 1 and 3

(depending on vehicle)

They are designed for connecting accessories with a maximum power rating of 120 Watts (voltage: 12V) which have been approved by our Technical Department.

If your vehicle is not fitted with a cigar lighter and an ashtray, these can be obtained from an approved Dealer.



## Accessories socket 4 (in the luggage compartment)




Connect accessories with a maximum power of 120 watts (12 V) only.

When several accessory sockets are used at the same time, the total power of the connected accessories must not exceed 180 watts.

**Fire hazard.**

## PASSENGER COMPARTMENT STORAGE, FITTINGS (1/6)



### Front door storage compartments

#### Storage compartment 1


#### Storage compartment 2

Do not use it as a handle to close the door.

#### Storage compartment 3

It can hold a 1.5 litre bottle.

#### Storage compartment 4



### Sun visor storage 5

This can be used for storing motorway tickets, cards, etc.




Nothing should be placed on the floor area in front of the driver as such objects may slide under the pedal during braking manoeuvres, thus obstructing its use.




Ensure that no hard, heavy or pointed objects are placed in the open storage compartments in such a way that they may fall on any passengers during sudden turning, braking or in the event of an accident.

## PASSENGER COMPARTMENT STORAGE, FITTINGS (2/6)



### Cup holder 6, 13 and 17

These can be used to hold cups or the ashtray.



### Dashboard storage compartments 7, 8, 9, 11, 14, 16 and 18

### Location for storage compartment or radio 10



When turning corners, accelerating or braking, ensure that the receptacle being held by the cup holder is not dislodged.

There is a risk of burning if hot liquid escapes.



Ensure that no hard, heavy or pointed objects are placed in the open storage compartments in such a way that they may fall on any passengers during sudden turning, braking or in the event of an accident.

### Location for storage compartment or passenger air bag 12

### Glove compartment 15

Pull the handle to open it.

It can hold A4 size documents, a 2 litre bottle of water etc.


Depending on the vehicle, it may be ventilated and refrigerated.



Always leave the storage compartment cover closed when you are driving:

- there is a risk of injury when braking suddenly or in the event of an accident;
- there is a risk of objects being hurled through the passenger compartment.

## PASSENGER COMPARTMENT STORAGE, FITTINGS (3/6)




**Token holder and card holder 19**

### **Token holder A**

### **Card holder B**

This can be used for storing motorway tickets, cards, etc.



**Location for storage compartment or tray 20**

**Location for storage compartment or sockets for audio multiconnection unit 21**

**Location for storage compartment or switches 22**




**Dashboard upper storage compartment 23**

To open it, lift the handle.



Nothing should be placed on the floor area in front of the driver as such objects may slide under the pedal during braking manoeuvres, thus obstructing its use.

## PASSENGER COMPARTMENT STORAGE, FITTINGS (4/6)




### Tray 25

Pull tray **25** fully towards you.

Turn it and push it fully.

You can use clip **24** to attach A5 format documents.

To refit it, pull the table tray fully towards you, lift it up until it is horizontal and push it in fully.



### Upper cab storage compartment 26 and 27

Reserved for the transport of objects only.

The total weight of upper cab storage compartment **27** must not exceed 5 kg.



Do not hang any heavy and/or sharp objects which may fall whilst driving. Risk of injury.



Nothing should be placed on the floor area in front of the driver as such objects may slide under the pedal during braking manoeuvres, thus obstructing its use.

## PASSENGER COMPARTMENT STORAGE, FITTINGS (5/6)



### Tray

On equipped vehicles, lower the back of the centre seat by lifting control **31**.

The back of the centre seat has the following features:

- a tray **28** which can be turned only to the driver's side (depending on the vehicle);
- a cup holder **30**;
- storage compartment **29**.



It is forbidden to sit in the centre seat if its seatback is folded down.

**Note:** make sure the tray is put back in place correctly before lifting the back of the centre seat. Check that the back of the centre seat is properly locked.

Ensure that nothing is obstructing the operation of the folding tray.




When turning corners, accelerating or braking, ensure that the receptacle being held by the cup holder is not dislodged.

There is a risk of burning if hot liquid escapes.




Ensure that no hard, heavy or pointed objects are placed in the open storage compartments in such a way that they may fall on any passengers during sudden turning, braking or in the event of an accident.




### Clothes hooks **32**

## PASSENGER COMPARTMENT STORAGE, FITTINGS (6/6)



### Storage compartment 34 underneath front bench seat

To access, pull tabs **33**.



### Storage compartment underneath rear bench seat

Seat base **35** lifts up to give access to a storage compartment underneath the bench seat.



### Rear load area storage compartment 36

Reserved for the transport of objects only.

The total weight of rear load area upper storage compartment must not exceed 35 kg.



Always close the seat base when driving:

- there is a risk of injury when braking suddenly or in the event of an accident;
- there is a risk of objects being hurled through the passenger compartment.



Check that the rear seat belts are positioned and operating correctly each time the rear seats are moved.



Do not hang any heavy and/or sharp objects which may fall while you are driving. Risk of injury.

## REAR BENCH SEATS (1/2)




### Access to the rear seats

Move the handle **1** backwards to lower the seat back.

To return the seat to its original position, bring the seatback back into position.



For safety reasons, carry out any adjustments when the vehicle is not being driven.



### Removing the bench seat

Lift levers **2** situated behind each bench seat. The spigots **3** protrude to indicate that the bench seat is unlocked.

Pull the bench seat backwards to release the anchoring points, then lift it to remove it.



Removing the anchoring points is prohibited.




The bench seat is rather heavy (approximately 65 kg). For your own safety, please handle it carefully.

Risk of injury.



## REAR BENCH SEATS (2/2)




### Refitting the rear bench seat

- Position the guides **4** on the rails set back in relation to the anchorage points;
- slide the bench seat forwards.

The bench seat will lock automatically.

Check that the red spigots **3** can no longer be seen.



The rear bench seats must be placed on their original anchorage points.

Driving with the bench seat in a rear-facing position is prohibited.




When moving the rear bench seat, check that the bench seat anchorage points are clean (they should be free from grit, cloths or any other item which may prevent the bench seat from locking securely).

The row bench seats in rows 2 and 3 are not interchangeable. Do not force them into position.

Risk of damage.



# MULTIMEDIA EQUIPMENT



The presence and location of this equipment depends on the vehicle's multimedia equipment.


- 1 Radio;
- 2 Multimedia sockets;
- 3 steering column control;
- 4 multimedia touchscreen;
- 5 microphone.

To operate this equipment: please refer to the driver's handbook.




## Using the telephone

We remind you of the need to conform to the legislation in force concerning the use of such equipment.




## TRANSPORTING OBJECTS (1/2)




### Transporting objects in the rear load area

Depending on the vehicle, securing rings **1** and **2** can be used to stop transported objects from moving. The number of rings and their position may vary depending on the vehicle.

The sole purpose of rings **2** is to prevent transported objects from moving. The objects must be secured to mounting rings **1** on the vehicle floor beforehand.




Always position the heaviest items directly on the floor. Use the lashing points on the floor of the luggage compartment, if these are fitted to the vehicle. The luggage should be loaded in such a way that no items will be thrown forward and strike the occupants if the driver has to brake suddenly. Fasten the rear seat belts, even if the seats are not occupied.



F max: 625 daN

## TRANSPORTING OBJECTS (2/2)



Front-wheel drive, standard wheels


**C = 1,110 mm.**

Rear-wheel drive, standard wheels

**C = 1,760 mm.**

Rear-wheel drive, dual wheels

**C = 1,753 mm.**



### Towing

#### Fitting the towing ball

Position the ball within the range of height **D**, which must be between 350 and 420 mm, with the vehicle laden. Tighten bolts **3**, observing a tightening torque of 196 Nm (Newton metres).

**Permissible nose weight, maximum permissible towing weight, braked and unbraked:** refer to the information on “Weights” in Section 6.

#### Choice and fitting of towing equipment

Maximum weight of towing equipment: 26 kg

For fitting and conditions of use, refer to the equipment’s fitting instructions.

Please keep these instructions with the rest of the vehicle documentation.

If the towbar ball obscures the registration plate or the rear fog lights, it should be removed when not in use.

In all cases, comply with local legislation.

# Section 4: Maintenance

Bonnet . . . . .	4.2
Engine oil level . . . . .	4.4
Engine oil level: topping up/filling . . . . .	4.6
Levels . . . . .	4.8
brake fluid. . . . .	4.8
coolant . . . . .	4.9
power-assisted steering pump . . . . .	4.10
windscreen washer reservoir . . . . .	4.10
Filters. . . . .	4.10
Tyre Pressure . . . . .	4.11
Battery . . . . .	4.13
Bodywork maintenance . . . . .	4.14
Interior trim maintenance. . . . .	4.17


## BONNET (1/2)



To open the bonnet, pull handle **1**.

### Unlocking the bonnet catch

To unlock, pull control **2**.



Before performing any action in the engine compartment, the ignition must be switched off (please see the information on “Starting, stopping the engine” in Section 2).



In the event of even a slight impact involving the radiator grille or bonnet, have the bonnet lock checked by an authorised dealer as soon as possible.




Please note when working close to the engine that it may be hot. In addition, the engine cooling fan may



start at any moment. The warning light in the engine compartment reminds you of this.

**Risk of injury.**

## BONNET (2/2)



### Opening the bonnet

Lift the bonnet and release stay **4** from its holders **5**. For your own safety, it is **essential** to fix the stay into retainer **3** in the bonnet.



After any procedure in the engine compartment, make sure that you do not forget anything (cloth, tools, etc.).

Otherwise, this may lead to engine damage or cause a fire.

### Closing the bonnet

Ensure that the windscreen wiper blades are correctly positioned.

Place stay **4** back into its holders **5**, hold the bonnet in the middle and lower it to about 20 cm above the closed position, then release it. It will latch automatically under its own weight.



Ensure that the bonnet is properly locked.

Check that nothing is preventing the catch from locking (gravel, cloth, etc.).

## ENGINE OIL LEVEL: general information (1/2)

It is normal for an engine to use oil for lubrication and cooling of moving parts and it is normal to top up the level between oil changes.

However, contact an approved Dealer if more than 0.5 litres is being consumed every 600 miles (1,000 km) after the running in period.

**Oil change frequency: check the oil level from time to time and certainly before any long journey to avoid the risk of damaging your engine.**

### Reading the oil level

The oil level should be read with the vehicle on level ground, after the engine has been switched off for some time.

**The dipstick must be used to read the exact oil level and make sure that the maximum level has not been exceeded (risk of engine damage).** Refer to the following pages.

The instrument panel display only alerts the driver when the oil level is at its minimum.



### Minimum oil level display A


#### If the level is above the minimum level

The "OIL LEVEL" message appears on the display, accompanied by squares indicating the level. These squares disappear as the level drops and they are replaced by dashes.

To switch to trip computer reading, press button **1** or **2** again.



#### If the level is at the minimum

The "TOP-UP OIL LEVEL" message and warning light  are displayed on the instrument panel.


**It is vital to top up the oil as soon as possible.**



The display only warns the driver if the oil level is at the minimum level. It does not inform the driver that the oil level has exceeded the maximum level as this can only be measured using a dipstick.



## ENGINE OIL LEVEL: general information (2/2)



### Reading the level using the dipstick

Engine switched off:

- remove the dipstick and wipe with a clean, lint-free cloth;
- push the dipstick in as far as it will go;
- take out the dipstick again; read the level: it should never fall below minimum mark **C** or exceed maximum mark **B**.

Once the level has been read, push the dipstick in as far as it will go.

### Maximum engine oil level exceeded.

The oil level should only be read with the dipstick as explained above.

If the level exceeds the maximum level, **do not start your vehicle** and contact an authorised dealer.



Before performing any action in the engine compartment, the ignition must be switched off (please see the information on “Starting, stopping the engine” in Section 2).




Under no circumstances should maximum filling level **B** be exceeded: this could damage the engine and the catalytic converter.

Consult your approved Dealer at once if you notice an abnormal or repeated drop in any of the fluid levels.

In order to prevent splashback, it is recommended that a funnel be used when topping up/filling with oil.



Please note when working close to the engine that it may be hot. In addition, the engine cooling fan may

start at any moment. The  warning light in the engine compartment reminds you of this.

**Risk of injury.**

## ENGINE OIL LEVEL : topping up, filling (1/2)




### Topping up/filling

The vehicle must be parked on level ground and the engine should be cold (for instance, before the engine is started up for the first time in the day).

### Engine oil grade

Refer to the Maintenance Document for your vehicle.

Do not exceed the **MAX** level and do not forget to refit cap **1** and dipstick **2**.



- Unscrew cap **1**;
- top up the level (as a guide, the capacity between the minimum and maximum reading on the dipstick **2** is between 1.5 and 2 litres, depending on the engine);
- wait for approximately 10 minutes to allow the oil to drain;
- check the level using the dipstick **2** (as described above).

Once the level is read, ensure that the dipstick is pushed in as far as it will go and the cap is completely screwed in.

### Oil change

**Service interval:** refer to the Maintenance Service Booklet for your vehicle.

### Oil change capacity

Please refer to the maintenance document for your vehicle, or contact an authorised dealer.

Always check the engine oil level using the dipstick, as explained previously (it should never fall below the minimum level, or be over the maximum level on the dipstick).

### Engine oil grade

Refer to the Maintenance Service Booklet for your vehicle.

In order to prevent splashback, it is recommended that a funnel be used when topping up/filling with oil.

## ENGINE OIL LEVEL : topping up, filling (2/2)



### Exceeding the maximum engine oil level

Under no circumstances must the maximum fill level be exceeded: risk of damage to the engine and catalytic converter. If the oil level exceeds the maximum level, **do not start your vehicle** and contact an approved Dealer.



Before performing any action in the engine compartment, the ignition must be switched off (please see the information on "Starting, stopping the engine" in Section 2).



**Engine oil change:** if you are changing the oil when the engine is hot, be careful not to scald yourself if the oil overflows.


Consult your approved Dealer at once if you notice an abnormal or repeated drop in any of the fluid levels.



Never run the engine in an enclosed space as exhaust gases are poisonous.



Please note when working close to the engine that it may be hot. In addition, the engine cooling fan may

start at any moment. The  warning light in the engine compartment reminds you of this.

**Risk of injury.**



**Filling:** take care when topping up the oil that no oil drips onto engine components - risk of fire. Remember to refit the cap securely as there is a risk of fire if oil splashes onto hot engine components.



When working in the engine compartment, ensure that the windscreen wiper stalk is in the park position.

**Risk of injury.**

## LEVELS (1/3)



### Brake fluid

This should be checked frequently, and immediately if you notice even the slightest loss in braking efficiency.

The level should be read with the engine switched off and on level ground.

### Level 1

It is normal for the level to drop as the brake shoes become worn, but it must never drop lower than the “MINI” warning line.

If you wish to check the disc and drum wear yourself, you should obtain the document explaining the checking procedure from our network or from the manufacturer's website.

### Filling

After any operation on the hydraulic circuit, a specialist must replace the fluid.

Only use fluids approved by our Technical Department (and taken from a sealed container).


### Replacement intervals

Refer to the Maintenance Document for your vehicle.

Consult your approved dealer at once if you notice an abnormal or repeated drop in any of the fluid levels.



Please note when working close to the engine that it may be hot. In addition, the engine cooling fan may

start at any moment. The  warning light in the engine compartment reminds you of this.

**Risk of injury.**



Before performing any action in the engine compartment, the ignition must be switched off (please see the information on “Starting, stopping the engine” in Section 2).

## LEVELS (2/3)



### Coolant

With the engine switched off and on level ground, the level **when cold** must be between the “MINI” and “MAXI” marks on the coolant reservoir **2**.

Top this level up **when cold** before it reaches the “MINI” mark.

### Frequency of checking coolant level

**Check the coolant level regularly** (very severe damage is likely to be caused to the engine if it runs out of coolant).

If the level needs to be topped up, only use products approved by our Technical Department which ensure:

- protection against freezing;
- anticorrosion protection of the cooling system.

### Replacement intervals


Refer to the Maintenance Document for your vehicle.

Consult your approved dealer at once if you notice an abnormal or repeated drop in any of the fluid levels.



No operations should be carried out on the cooling circuit when the engine is hot.

**Risk of burns.**



### Windscreen washer reservoir **4**

#### Filling

With the engine switched off, open cap **3**, fill until you can see the fluid, then refit the cap.

#### Fluid

Special windscreen washer fluid (product with antifreeze in winter).



Before performing any action in the engine compartment, the ignition must be switched off (please see the information on “Starting, stopping the engine” in Section 2).


## LEVELS (3/3)/FILTERS



### Power-assisted steering pump

**Level:** the correct level **when cold**, with the engine switched off and on level ground, should be visible between the “MINI” and “MAXI” levels on the reservoir **5**.

For topping up or refilling with oil, use products approved by our Technical Department.




### Special feature on vehicles fitted with a tank **6**

Access to the filler cap is not accessible. Contact an approved dealer for topping up or filling.



Please note when working close to the engine that it may be hot. In addition, the engine cooling fan may

start at any moment. The  warning light in the engine compartment reminds you of this.

**Risk of injury.**



### Filters

The filter elements (air filter, diesel filter, etc.) should be replaced during the maintenance operations carried out on your vehicle.

**Replacement intervals for filter elements:** refer to the Maintenance Document for your vehicle.

On equipped vehicles, if warning light **7** turns red, it indicates that the air filter is clogged.

Consult your approved dealer as soon as possible.

## TYRE PRESSURE (1/2)




### Label A

Open the driver's door to read it.

Tyre pressures should be checked when the tyres are cold.

If the tyre pressures cannot be checked when the tyres are **cold**, increase the pressures from **0.2 to 0.3 bar (or 3 PSI)**.  
**Never deflate a hot tyre.**

### Vehicle fitted with a tyre pressure loss warning system

In the event of underinflation (punctures, underinflation etc.), the  warning light on the instrument panel comes on. Please refer to the information on the "Tyre pressure loss warning" in Section 2.



For your safety, please respect the speed limit.


When they need to be replaced, only tyres of the same make, size, type and profile should be used on a single axle.

**They must: either have a load capacity and speed rating at least equal to those of the original tyres, or conform to those recommended by an authorised dealer.**

Failure to heed these instructions could endanger your safety and affect your vehicle's roadworthiness.

**Risk of loss of control of the vehicle.**

## TYRE PRESSURE (2/2)



Zone **B**: tyre pressures for the front wheels (non-motorway).

Zone **C**: tyre pressures for the rear wheels (non-motorway).

Zone **D**: tyre pressures for the front wheels (motorway).

Zone **E**: tyre pressures for the rear wheels (motorway).

Zone **F**: tyre pressure for the emergency spare wheel.

**Tyre safety and the use of chains:** please refer to the information on “Tyres” in Section 5 for servicing conditions and, depending on the version, the use of chains.



**Vehicle used fully laden  
(Maximum Permissible  
All-up Weight) and  
towing a trailer**

The maximum speed must be limited to **60 mph (100 km/h)** and the tyre pressure increased by **0.2 bar**.

Refer to the information on “Weights” in Section 6.

**Risk of tyre blowouts.**



# BATTERY



This is located behind step **A** and does not require maintenance. **You should not open it or add any fluid.**

Depending on the vehicle, a system continuously checks the battery charge status.


When the ignition is off, some consumers may also be switched off (dipped beam headlights, radio, ventilation, etc.). On the instrument panel, the message "BATTERY MODE: ECONOMY" appears when switched off. When the level is extremely low, the message "BATTERY LOW START ENGINE" is displayed.

The charge status of the battery can decrease, especially if you use your vehicle:

- for short journeys;
- for driving in town;
- when the temperature drops;
- with the vehicle stopped and the engine off.

## Replacing the battery

As this operation is complex, we advise you to contact an approved Dealer.



## Label B

Observe the indications on the battery:

- **1** naked flames and smoking are forbidden;
- **2** eye protection required;
- **3** keep away from children;
- **4** explosive materials;
- **5** refer to the handbook;
- **6** corrosive materials.



Handle the battery with care as it contains sulphuric acid, which must not come into contact with eyes or skin. If it does, wash the affected area with plenty of cold water. If necessary, consult a doctor.

Ensure that naked flames, red hot objects and sparks do not come into contact with the battery as there is a risk of explosion.



The battery is a **specific type**, please ensure it is replaced with the same type. Consult an approved dealer.

## BODYWORK MAINTENANCE (1/3)

A well-maintained vehicle will last longer. It is therefore recommended to maintain the exterior of the vehicle regularly.

Your vehicle has been treated with very effective anti-corrosion products. It is nevertheless subject to various outside influences.

### Corrosive agents in the atmosphere

- atmospheric pollution (built-up and industrial areas);
- saline atmospheres (near the sea, particularly in hot weather);
- seasonal and damp weather conditions (e.g. road salt in winter, water from road cleaners, etc.).

### Minor impacts

#### Abrasive action

Dust and sand in the air, mud, road grit thrown up by other vehicles, etc.

You should take a number of minor precautions in order to safeguard your vehicle against such risks.

### You should

Wash your car frequently, **with the engine off**, with cleaning products recommended by the manufacturer (never use abrasive products). Rinse thoroughly beforehand with a jet:

- spots of tree resin and industrial grime;
  - mud in the wheel arches and underneath the body which forms damp patches;
  - **bird droppings**, which cause a chemical reaction with the paint that **rapidly discolours paintwork and may even cause the paint to peel off**;
- wash the vehicle **immediately** to remove these marks since it is impossible to remove them by polishing;
- salt, particularly in the wheel arches and underneath the body after driving in areas where the roads have been gritted.

Remove any plant matter (resin, leaves, etc.) from the vehicle regularly.

Respect local regulations about washing vehicles (e.g. do not wash your vehicle on a public highway).

Observe the vehicle stopping distances when driving on gravelled surfaces to prevent paint damage.

Repair, or have repaired quickly, areas where the paint has been damaged, to prevent corrosion spreading.

Remember to visit the body shop periodically in order to maintain your anti-corrosion warranty. Refer to the Maintenance Document.

If it is necessary to clean mechanical components, hinges, etc., spray them with products approved by our Technical Department to protect them after they have been cleaned.

We have selected special products to care for your vehicle and you can obtain these from the manufacturer's accessory outlets.

## BODYWORK MAINTENANCE (2/3)

### What you should not do

Wash the vehicle in bright sunlight or freezing temperatures.

Do not scrape off mud or dirt without pre-wetting.

Allow dirt to accumulate on the exterior.

Allow rust to form following minor impacts.

Do not use solvents not approved by our Technical Department to remove stains as this could damage the paintwork.

Do not drive in snow or muddy conditions without washing the vehicle, particularly under the wheel arches and body.



Degrease or clean using high-pressure cleaning equipment or by spraying on products not approved by our Technical Department:

- mechanical components (e.g.: engine compartment);
- underbody;
- parts with hinges (e.g.: inside the doors);
- painted plastic external fittings (e.g.: bumpers).

Doing this could give rise to corrosion or operational faults.

## BODYWORK MAINTENANCE (3/3)

### Vehicles with a matte paint finish

This type of paint requires certain precautions.

#### You should do the following

Wash the vehicle by hand using plenty of water, using a soft cloth or a gentle sponge.

#### Do not do the following

Use wax-based products (polishing).

Rub too hard.

Wash the vehicle in a roller-type car wash.

Attach stickers to the paintwork (risk of leaving marks).



Wash the vehicle using a high-pressure cleaning device.

### Using a roller type car wash

Return the windscreen wiper stalk to the Park position (refer to the information on the “Windscreen washer, wiper” in Section 1). Check the mounting of external accessories, additional lights and mirrors, and ensure that the wiper blades are secured with adhesive tape.

Remove the radio aerial mast if your vehicle is fitted with this equipment.

Remember to remove the tape and refit the antenna after washing.

### Cleaning the headlights

As the headlights are made of plastic “glass”, use a soft cloth or cotton wool to clean them. If this does not clean them properly, moisten the cloth with soapy water, then wipe clean with a soft damp cloth or cotton wool. Finally, carefully dry off with a soft dry cloth.

**Do not use cleaning products containing alcohol or utensils (e.g.: a scraper).**

## INTERIOR TRIM MAINTENANCE (1/2)

A well-maintained vehicle will last longer. It is therefore recommended to maintain the interior of the vehicle regularly.

A stain should always be dealt with swiftly.

Whatever type of stain is on the trim, use **cold** (or warm) **soapy water with natural soap**.

**Detergents (washing-up liquid, powdered products, alcohol-based products) should not be used.**

Use a soft cloth.

Rinse and soak up the excess.

### Glass instrument panel

(e.g. instrument panel, clock, exterior temperature display, radio display, etc.)

Use a soft cloth (or cotton wool).

If this does not clean them properly, use a soft cloth (or cotton wool) slightly moistened with soapy water and then wipe clean with another soft damp cloth or cotton wool.

Finally, **carefully** dry off with a soft dry cloth.

**Do not use products containing alcohol and/or spray fluids on the area.**

### Seat belts

These must be kept clean.

Use products selected by our Technical Department (Approved outlets) or warm, soapy water and a sponge and wipe with a dry cloth.

**Detergents or dyes must not be used under any circumstances.**

### Textiles (seats, door trim, etc)

Vacuum-clean the textiles **regularly**.

#### Liquid stain

Use soapy water.

Dab lightly (never rub) with a soft cloth, rinse and remove the excess.

#### Solid or pasty stain

Carefully remove the excess solid or pasty material **immediately** with a spatula (working from the edges to the centre to avoid spreading the stain).

Clean as for a liquid stain.

#### Special instructions for sweets or chewing gum

Put an ice cube on the stain to solidify it, then proceed as for a solid stain.

For further recommendations for maintaining the interior, and/or for any unsatisfactory results, please see an authorised dealer.

## INTERIOR TRIM MAINTENANCE (2/2)

### Removal/replacing removable equipment originally fitted in the vehicle

If you need to remove equipment in order to clean the passenger compartment (for example, mats), always ensure that they are correctly refitted and are the right way around (the driver's mat should be fitted on the driver's side, etc.) and fit them with the components supplied with the equipment (for example, the driver mat should always be fixed using the pre-fitted mounting components).

With the vehicle stationary, always ensure that nothing will impede driving (anything obstructing the pedals, heel wedged by the mat etc.).

### You should not:

Position objects such as deodorants, scents etc. near air vents as this could damage your dashboard trim.



Use high-pressure cleaning equipment or sprays inside the passenger compartment:

without careful use, this equipment could impair the correct functioning of the electrical or electronic components in the vehicle, or have other detrimental effects.



# Section 5: Practical advice

Puncture . . . . .	5.2
Emergency spare wheel . . . . .	5.2
Tool kit . . . . .	5.4
Tyre inflation kit . . . . .	5.5
Wheel trims . . . . .	5.11
Changing a wheel: hydraulic jack . . . . .	5.13
Changing a wheel: jack . . . . .	5.16
Tyres . . . . .	5.18
Headlights (changing bulbs) . . . . .	5.21
front fog lights. . . . .	5.23
side lights . . . . .	5.24
rear lights . . . . .	5.25
interior lighting . . . . .	5.27
Fuses. . . . .	5.28
Battery: troubleshooting. . . . .	5.33
Key, radio frequency remote control: battery. . . . .	5.35
Hands-free access transmitter/receiver: battery . . . . .	5.36
Replacing wiper blades . . . . .	5.37
Towing . . . . .	5.38
Fitting a radio. . . . .	5.40
Accessories . . . . .	5.41
Operating faults . . . . .	5.42

## PUNCTURE, EMERGENCY SPARE WHEEL (1/2)



On equipped vehicles, this is located underneath the chassis.



### To remove the emergency spare wheel

- Insert the end of the unlocking key **3** extended (depending on the vehicle) by the hexagonal extension piece **5** and the wheelbrace **6** in location **1** or **4** (the use of other tools could damage the mechanism);
- lower the emergency spare wheel fully;
- unclip the component **2** on the wheel rim;
- thread the component **2** through the wheel rim (as shown in **A**) to release the wheel.




If the emergency spare wheel has been stored for several years, have it checked by your dealer to ensure that it is safe to use.

In some cases (puncture at the rear, vehicle with towing equipment, etc.) it may be necessary to lift the vehicle beforehand (via the lifting point closest to the affected wheel) to provide access to the emergency spare wheel (please refer to the information on "changing a wheel: vehicle with standard wheels" in Section 5).



## PUNCTURE, EMERGENCY SPARE WHEEL (2/2)




### To fit a wheel

Proceed in the reverse order.

- place the wheel flat underneath the vehicle. The **valve 7 must be facing you**. Risk of losing the wheel if the correct direction for refitting the wheel is not observed;



Place the punctured wheel flat on the ground. The **valve 7 must be facing you**. Risk of losing the wheel.



- thread the cable and the component **2** through the wheel rim;
- centre the component **2** in the middle of the wheel and clip it to the wheel rim;
- lift the retaining cable up as far as it will go and check the wheel is completely secure.

**Note:** do not place a punctured wheel with aluminium wheel rims in the emergency spare wheel winch. Ensure the winch is refitted correctly.



Do not touch the exhaust system.  
**Risk of burns.**

## TOOL KIT




### Location of the tool kit

Tool kit **1** is located under the driver's seat.

To remove the tools, move the seat forward and fold down the seatback (please refer to the information on the "Front seats" in Section 1).




Nothing should be placed on the floor area in front of the driver as such objects may slide under the pedal during braking manoeuvres, thus obstructing its use.



### Contents of the tool kit (depending on the vehicle)

- hydraulic jack **2**;
- towing hitch **3**;
- hubcap tool **4**;



- wheelbrace **5**;
- winch unlocking key **6**;
- hexagonal extension piece **7**;
- extension pieces **8**;
- jack **9**.



Do not leave the tools unsecured inside the vehicle as they may come loose under braking. After use, check that all the tools are correctly clipped into the tool kit, then position it correctly in its housing: risk of injury.

If wheel bolts are supplied in the tool kit, you must only use these bolts for the emergency spare wheel: refer to the label affixed to the emergency spare wheel. The jack is designed for wheel changing purposes only. Under no circumstances should it be used for carrying out repairs underneath the vehicle or to gain access to the underside of the vehicle.

## TYRE INFLATION KIT (1/6)

30748



The kit repairs tyres when tread **A** has been damaged by objects smaller than **4 mm**. It cannot repair all types of puncture, such as cuts larger than **4 mm**, or cuts in tyre sidewall **B**.

Ensure also that the wheel rim is in good condition.



Do not attempt to use the inflation kit if the tyre has been damaged as a result of driving with a puncture.

You should therefore carefully check the condition of the tyre sidewalls before any operation.

Driving with underinflated, flat or punctured tyres can be dangerous and may make the tyre impossible to repair.

### **This repair is temporary.**

A tyre which has been punctured should always be inspected (and repaired, where possible) by a specialist.

When taking a tyre which has been repaired using this kit to be replaced, you must inform the specialist.

When driving, vibration may be felt due to the presence of the repair product injected into the tyre.



The kit is only approved for inflating the tyres of the vehicle originally equipped with the kit.

It must never be used to inflate the tyres of another vehicle, or any other inflatable object (rubber ring, rubber boat, etc.).

Avoid spillage on skin when handling the repair product bottle. If droplets do leak out, rinse them off with plenty of water.

Keep the repair kit away from children.

Do not dispose of the empty bottle in the countryside. Return it to your approved dealer or to a recycling organisation.

The bottle has a limited service life which is indicated on its label. Check the expiry date.

Contact an approved dealer to replace the inflation tube and repair product bottle.

## TYRE INFLATION KIT (2/6)



### Inflation kit C

Depending on the vehicle, in the event of a puncture, use inflation kit **1** located underneath the driver's seat.

Move the driver's seat forward and fold down the seatback to access the inflation kit.

Open it.



Screw compressor adapter **3** to container **2** and clip onto compressor **D**.

The bottle must remain in an upright position.

Unscrew the valve cap on the tyre concerned.

Screw inflation adapter **4** onto the valve.




Before using this kit, park the vehicle at a sufficient distance from traffic, switch on the hazard warning lights, apply the handbrake, ask all passengers to leave the vehicle and keep them away from traffic.



Do not pull out the foreign body causing the puncture if it is still in the tyre.


## TYRE INFLATION KIT (3/6)



To connect the compressor, open the bonnet and connect black clamp **10** to earth **6** (refer to the information on “Battery: troubleshooting” in Section 5). Then connect red clamp **11** to terminal **5**.



Before starting the engine, check that the handbrake is applied and the gear lever is in neutral or in position **N** for sequential gearboxes.




With the engine running, press switch **7** to start inflating.

After a maximum of **15** minutes, stop inflating and read the pressure on pressure gauge **9**.

A pressure of at least **4.7** bar must be reached.

**Note:** while the bottle is emptying (approximately 30 seconds), the pressure gauge **9** will indicate briefly a pressure of up to 6 bars, then the pressure drops.



**If the correct pressure cannot be achieved, repair is impossible. Do not drive the vehicle. Consult an approved dealer.**

**If the pressure is too high, press button 8 to lower the pressure.**

## TYRE INFLATION KIT (4/6)



Once the tyre is correctly inflated, remove the kit: slowly unscrew the inflation adapter **3** to prevent any product spatter and screw the tyre inflation hose **4** to the bottle opening **2** to prevent the product from escaping.



Nothing should be placed around the driver's feet as such objects may slide under the pedals during sudden braking manoeuvres and obstruct their use.

Affix the driving recommendation label to the dashboard where it can easily be seen by the driver;

Store the kit underneath the driver's seat.

Start the vehicle immediately in order to distribute the product in the tyre and, after **6 miles (10 km)** or **10 minutes** driving, stop to check the pressure. To do this, fit adapter **3** onto the tyre valve. If the pressure is less than the recommended pressure, adjust it (refer to the information on "Tyre pressures"), otherwise contact an approved dealer: repair is not possible.



Please be aware that a poorly tightened or missing valve cap can make the tyres less airtight and lead to pressure loss.

Always use valve caps identical to those fitted originally and tighten them fully.

## Precautions when using the kit


- the kit should not be operated for more than 15 consecutive minutes;
- when driving, vibration may be felt due to the presence of the repair product injected into the tyre.



Following repair with the kit, do not travel further than 120 miles (200 km). In addition, reduce your speed and under no circumstances exceed 48 mph (80 km/h). The sticker, which you must affix in a prominent position on the dashboard, reminds you of this.

Depending on the country or local legislation, a tyre repaired with the inflation kit may need to be replaced.

## TYRE INFLATION KIT (5/6)



### Inflation kit E

Depending on the vehicle, in the event of a puncture, use the inflation kit located underneath the driver's seat.



Before using this kit, park the vehicle at a sufficient distance from traffic, switch on the hazard warning lights, apply the handbrake, ask all passengers to leave the vehicle and keep them away from traffic.

### With the engine running and the parking brake applied,

- unroll the hose from the container;
- connect the compressor hose **14** to the container's inlet **19**;
- depending on the vehicle, connect the container **19** to the compressor from the container recess **18**;
- unscrew the valve cap on the relevant wheel and screw on the container's inflation adapter **12**;
- disconnect any accessories previously connected to the vehicle's accessories sockets;
- adapter **13** **must** be connected to the vehicle accessories socket;
- press switch **15** to inflate the tyre to the recommended pressure (please refer to the information in the section on "Tyre pressure");

- after a maximum of **15** minutes, stop inflating and read the pressure (on pressure gauge **16**).

**Note:** while the bottle is emptying (approximately 30 seconds), the pressure gauge **16** will indicate briefly a pressure of up to **6** bars, then the pressure drops.


- adjust the pressure: to increase it, continue inflation with the kit; to reduce it, press button **17**.

**If a minimum pressure of 1.8 bar is not reached after 15 minutes, repair is not possible; do not drive the vehicle but contact an approved dealer.**



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.

## TYRE INFLATION KIT (6/6)



Once the tyre is correctly inflated, remove the kit: slowly unscrew the inflation adapter **12** to prevent any product spatter and store the container in plastic packaging to prevent product leaks.



Nothing should be placed around the driver's feet as such objects may slide under the pedals during sudden braking manoeuvres and obstruct their use.

- Affix the driving recommendation label to the dashboard where it can easily be seen by the driver;
- Put the kit away.
- At the end of this initial inflation operation, air will still escape from the tyre. You must drive a short distance in order to seal the hole.
- Start immediately and drive at between 12 and 40 mph (20 and 60 km/h) in order to distribute the product evenly in the tyre and, after driving for 2 miles (3 km), stop and check the pressure.
- If the pressure is greater than 1.3 bar but less than the recommended pressure (refer to the label affixed to the edge of the driver's door), readjust it. Otherwise, please contact an authorised dealer: the tyre cannot be repaired.

### Precautions when using the kit

The kit should not be operated for more than 15 consecutive minutes.



Please be aware that a poorly tightened or missing valve cap can make the tyres less airtight and may lead to pressure loss.


Always use valve caps identical to those fitted originally and tighten them fully.



Following repair with the kit, do not travel further than 120 miles (200 km). In addition, reduce your speed and under no circumstances exceed 48 mph (80 km/h). The sticker, which you must affix in a prominent position on the dashboard, reminds you of this. Depending on the country or local legislation, a tyre repaired with the inflation kit may need to be replaced.




## WHEEL TRIMS (1/2)



### Wheel trim 2 (concealed wheel bolts)

Remove it using hubcap tool **1** (found in the tool kit), by pushing the hook into the opening located near the valve (to reach the metal retaining wire located behind the wheel trim).

To refit it, align it with the valve. Push the retaining hooks, starting with side **A** on the valve side, then **B** and **C** and finish with the side opposite the valve **D**.




### Central wheel trim 4 (concealed wheel bolts)

Remove it using hubcap tool **1**, inserting the tool into the recesses **3** provided.

To refit it, align it with the wheel bolts, clip it in and check it is securely locked.

## WHEEL TRIMS (2/2)



### Wheel trim 5 (exposed wheel bolts)

To remove it without removing the wheel, press it at the points indicated by the arrows.

Turn it so that the retaining brackets holding it in place behind the wheel bolts are released.


To refit the hubcap, proceed in reverse order.



### Wheel trim 6 (front wheel only for vehicles equipped with dual wheels)

Remove the nut covers **6** by hand, then remove the wheel trim.

## CHANGING A WHEEL: hydraulic jack (1/3)



When removing dual wheels, unscrew inflating extension piece 1.

**Do not forget to reattach it when refitting.**

Undo the wheel bolts by fitting the wheel spanner 3 extended using the hexagonal extension piece 2 (supplied in the tool kit) and pressing down.

### Anti-theft bolt

If you use anti-theft bolts, fit these nearest the valve (otherwise it may not be possible to fit the wheel trim).



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.



Switch on the hazard warning lights.

Keep the vehicle away from traffic and on a level surface where it will not slip.

Apply the parking brake and engage a gear (first or reverse, or **N** for sequential gearboxes).

Ask all the passengers to leave the vehicle and keep them away from traffic.

## CHANGING A WHEEL: hydraulic jack (2/3)




Take the jack **3** out of the tool kit. Familiarise yourself with the jack arrangement prior to using it.

### Using the jack

Position the head of the jack on the contact points **2** close to the wheel concerned.

Place the jack **3** horizontally. The jack head must line up with the point **2** provided.



Begin to pump using the three extension pieces **4** available in the tool kit placed end-to-end (refer to the information on the "Tool kit" in section 5).

Free the wheel from the ground.

**Note:** the use of the three extension pieces **4** prevents you having to go under the vehicle to operate the jack **3** when raising the vehicle.

Remove the screws, then remove the wheel (take off the central wheel trim if necessary).


Fit the emergency spare wheel on the central hub and, depending on the vehicle, turn it to align the mounting holes in the wheel and the hub.

If bolts are supplied with the emergency spare wheel, only use these bolts for the emergency spare wheel.



To prevent any risk of injury or damage to the vehicle, raise the jack until the wheel you are replacing is a maximum of 3 centimetres off the ground.


## CHANGING A WHEEL: hydraulic jack (3/3)



Tighten the nuts and lower the jack.

With the wheel on the ground, tighten the bolts completely, following the order of tightening below:

**Wheel with 6 holes:** start with screw **A**, then **D**, **B**, **E**, **C** and finish with **F**.



**Wheel with 5 holes:** start with screw **G**, then **J**, **H**, **K** and finish with **I**.

Have the tightening and the pressure of the spare wheel checked as soon as possible.

## CHANGING A WHEEL: jack (1/2)



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.




Switch on the hazard warning lights.

Keep the vehicle away from traffic and on a level surface where it will not slip.

Apply the parking brake and engage a gear (first or reverse, or **N** for sequential gearboxes).


Ask all the passengers to leave the vehicle and keep them away from traffic.



### Vehicle equipped with a jack with a heightener

When changing a front wheel, use the heightener **1** (figure **A**).

When changing a rear wheel, remove the heightener **1** (figure **B**).




If necessary, remove the wheel trim.

Use the wheelbrace **2** to slacken off the wheel bolts. Position it so as to be able to push from above.




To prevent any risk of injury or damage to the vehicle, raise the jack until the wheel you are replacing is a maximum of 3 centimetres off the ground.

## CHANGING A WHEEL: jack (2/2)



Position jack **4** horizontally. Jack head **3** **must** be positioned level with the reinforcement panel closest to the wheel in question or the contact points **5**; start cranking the jack up by hand to align the base plate (which should be pushed slightly under the vehicle). Turn the wheelbrace a few times using the wheel spanner **2** until the wheel is lifted off the ground. Remove the bolts and take off the wheel; fit the emergency spare wheel on the central hub and turn it to locate the mounting holes in the wheel and the hub.




If bolts are supplied with the emergency spare wheel, only use these bolts for the emergency spare wheel. Tighten the bolts, checking that the wheel is correctly positioned on its hub and unscrew the jack.

**Note:** do not lubricate the wheel bolts.

### Anti-theft bolt

If you use anti-theft bolts, fit these nearest the valve (otherwise it may not be possible to fit the wheel trim).



With the wheel on the ground, tighten the bolts firmly, starting on side **C**, then **E**, **G**, **D** and ending with **F**. Check the tightness and the tyre pressure on the emergency spare wheel as soon as possible.




If you have a puncture, replace the wheel as soon as possible.

A tyre which has been punctured should always be inspected (and repaired, where possible) by a specialist.

## TYRES (1/3)

The tyres are the only contact between the vehicle and the road, so it is essential to keep them in good condition.

You must make sure that your tyres conform to local road traffic regulations.



### Maintaining the tyres

The tyres must be in good condition and the tread form must have sufficient depth; tyres approved by our Technical Department have tread wear indicators **1** which are **indicators moulded into the tread at several points**.

When the tyre tread has been worn to the level of the wear indicators, **they become visible 2**: it is **then** necessary to replace your tyres because the tread rubber is **no more than 1.6 mm deep, resulting in poor roadholding on wet roads**.

An overloaded vehicle, long journeys by motorway, particularly in very hot weather, or continual driving on poorly surfaced minor roads will lead to more rapid tyre wear and affect safety.



Incidents which occur when driving, such as striking the kerb, may damage the tyres and wheel rims, and could also lead to misalignment of the front or rear axle geometry. In this case, have the condition of these checked by an approved dealer.



## TYRES (2/3)

### Tyre pressures

Adhere to the tyre pressures (including the emergency spare wheel). The tyre pressures should be checked at least once a month and additionally before any long journey (refer to the label affixed to the edge of the driver's door).



#### **Incorrect tyre pressures**

lead to abnormal tyre wear and unusually hot running.

These are factors which may seriously affect safety and lead to:

- poor road holding,
- risk of bursting or tread separation.

The pressure depends on the load and the speed of use. Adjust the pressure according to the conditions of use (refer to the label affixed to the edge of the driver's door).

Pressures should be checked when the tyres are cold; ignore higher pressures which may be reached in hot weather or following a fast journey.

If tyre pressures cannot be checked when the tyres are **cold**, the normal pressures must be increased by **0.2** to **0.3** bar (or **3 PSI**).

**Never deflate a hot tyre.**

#### **Dual wheel versions**


To inflate the outer wheel, it is recommended that the inflation tube is passed between the two wheels.



Please be aware that a poorly tightened or missing valve cap can make the tyres less airtight and lead to pressure loss.

Always use valve caps identical to those fitted originally and tighten them fully.

### **Vehicle fitted with a tyre pressure loss warning system**

If underinflated (puncture, low pressure, etc.), the warning light  on the instrument panel comes on, see "Tyre pressure loss warning system" in Section 2.

### **Changing wheels around**

This practice is not recommended.

### **Emergency spare wheel**

Refer to the information on the "Emergency spare wheel" and "Changing a wheel" in Section 5.

## TYRES (3/3)

### Fitting new tyres



For your safety, please respect the speed limit.

When they need to be replaced, only tyres of the same make, size, type and profile should be used on a single axle.

**They must: either have a load capacity and speed rating at least equal to those of the original tyres, or conform to those recommended by an authorised dealer.**

Failure to heed these instructions could endanger your safety and affect your vehicle's roadworthiness.

**Risk of loss of control of the vehicle.**



Chains may only be fitted to tyres of the same size as those originally fitted to **your vehicle**.

Only certain chains can be fitted to tyres. Consult an approved Dealer.

### Use in winter

#### Chains

**Chains must not be fitted** to tyres which are larger than those originally fitted to the vehicle.

#### Front wheel drive versions

**For safety reasons, fitting snow chains to the rear axle is strictly forbidden.**

#### Rear wheel drive versions

**For safety reasons, only fit chains on the rear axle.**

**Note:** for rear wheel drive, dual wheel versions, fit chains on the outer rear wheels.

#### Snow or winter tyres

We would recommend that these be fitted to **all four wheels** to ensure that your vehicle retains maximum grip.

**Note:** be aware that these tyres may sometimes have:

- a direction of travel;
- a maximum speed index which may be lower than the maximum speed of your vehicle.

#### Studded tyres

This type of equipment may only be used for a limited period and as laid down by local legislation.


It is necessary to observe the speed specified by current legislation.

These tyres must, as a minimum, be fitted to the two wheels on the front axle for front wheel drive versions and all the rear wheels for rear wheel drive versions.

In all cases, we would recommend that you contact an approved Dealer who will be able to advise you on the choice of equipment which is most suitable for your vehicle.

## HEADLIGHTS: changing bulbs (1/2)

20603



### Front side lights

Remove cover **B** and pull bulb holder **2**.


**Bulb type: W5W.**

**Note:** once the bulb has been replaced, ensure the cover is refitted correctly.



Before performing any action in the engine compartment, the ignition must be switched off (please see the information on "Starting, stopping the engine" in Section 2).

3045T



### Direction indicators

Remove cover **A** and turn bulb holder **1** a quarter turn.

To refit the bulb holder, position it correctly, as determined by the foolproofing device.

**Bulb type: PY21W.**

**Note:** once the bulb has been replaced, ensure the cover is refitted correctly.

To comply with current legislation, or as a precaution, you can obtain an emergency kit from an approved dealer containing a set of spare bulbs and fuses.



The bulbs are under pressure and can break when replaced.

**Risk of injury.**




Please note when working close to the engine that it may be hot. In addition, the engine cooling fan may



start at any moment. The warning light in the engine compartment reminds you of this.

**Risk of injury.**

## HEADLIGHTS: changing bulbs (2/2)



### Dipped beam headlights

Remove cover **E** and turn bulb holder **6** a quarter turn.


**Bulb type: H7LL.**

**Do not touch the bulb glass. Hold it by its base.**

**Note:** once the bulb has been replaced, ensure the cover is refitted correctly.



Before performing any action in the engine compartment, the ignition must be switched off (please see the information on "Starting, stopping the engine" in Section 2).



### Cornering lights

(depending on the vehicle)

Remove cover **D** and turn bulb holder **5** a quarter turn.

**Bulb type: H7.**

**Note:** once the bulb has been replaced, ensure the cover is refitted correctly.



The bulbs are under pressure and can break when replaced.

**Risk of injury.**

### Main beam headlights

Remove cover **C**.

Unclip the springs **4** and remove the bulb holder **3**.

**Bulb type: H1.**

**Note:** once the bulb has been replaced, ensure the cover is refitted correctly.

To comply with current legislation, or as a precaution, you can obtain an emergency kit from an approved dealer containing a set of spare bulbs and fuses.



Please note when working close to the engine that it may be hot. In addition, the engine cooling fan may



start at any moment. The warning light in the engine compartment reminds you of this.

**Risk of injury.**

## HEADLIGHTS: front fog lights



### Fog lights 1

Consult an approved dealer.




The bulbs are under pressure and can break when replaced.

Risk of injury.



Any operation on (or modification to) the electrical system must be performed by an approved dealer since an incorrect connection might damage the electrical equipment (harness, components and in particular the alternator). In addition, your Dealer has all the parts required for fitting these units.

## SIDE LIGHTS: changing bulbs



### Side indicator lights

Move mirror **1** to access the bolt.

Undo the bolt using a Torx screwdriver.

Take out the indicator light and replace bulb **2**.

**Bulb type, depending on vehicle: WY5W or P21W.**




To comply with current legislation, or as a precaution, you can obtain an emergency kit from an approved dealer containing a set of spare bulbs and fuses.



The bulbs are under pressure and can break when replaced.

Risk of injury.




### Clearance lights

Push light **3** (movement **A**) and press at **B** to release the light.

Turn the bulb holder a quarter of a turn and replace the bulb.


**Bulb type: W5W.**

## REAR LIGHTS: changing bulbs (1/2)




### Rear lights

Depending on the vehicle, remove the protective grilles. Unscrew the two nuts **1** and pull rear light unit **A**.



Unscrew the bolt **2** using a flat-blade screwdriver or similar to remove the bulb holder **3**.



### 4 Side lights and brake lights

Pear-shaped, bayonet type **P21/5W** bulb with two filaments.

### 5 Indicator

Orange pear-shaped, bayonet type **PY21W** bulb.

### 6 Reversing light

Pear-shaped, bayonet type bulb **P21W**.

### 7 Fog light


Pear-shaped, bayonet type bulb **P21W**.



The bulbs are under pressure and can break when replaced.


Risk of injury.

## REAR LIGHTS: changing bulbs (2/2)




### High-level brake light

Remove cover **8**.  
Unscrew the nut.



Remove the unit, from outside the vehicle, to gain access to bulb **9**.

**Bulb type: W16W.**



### Number plate lights


Unclip light **10** (using a flat-blade screwdriver or similar).

Remove the light cover to gain access to the bulb.

**Bulb type: W5W.**



## INTERIOR LIGHTING: changing bulbs




### Courtesy light

Unclip the ceiling light diffuser **1** using a flat blade screwdriver or similar.

Pull the bulb to remove it from its housing.

**Bulb type: W6W**


Replace the bulb and refit the lens.



**Special features for vehicles fitted with a reading lamp**

**Type of bulb 2: festoon 10W**

**Type of reading lamp 3: W5W**



### Rear lights


Unclip the ceiling light diffuser using a flat blade screwdriver or similar.

Pull the bulb to remove it from its housing.

**Type of bulb 4 : W6W**

Replace the bulb and refit the lens.

## FUSES (1/5)



If any electrical component does not work, check the condition of the fuses. Remove the fuse using tweezers **1**, located at the back of flap **A**.

To remove the fuse from the tweezers, slide the fuse to the side.

It is not advisable to use the free fuse locations.


To comply with legislation, or as a precaution, you can obtain an emergency kit containing a set of spare bulbs and fuses from an approved dealer.

Your vehicle is equipped with two fuse boxes: in the passenger compartment and in the engine compartment.



Check the fuse in question and **replace it**, if necessary, **by a fuse of the same rating**.

If a fuse is fitted where the rating is too high, it may cause the electrical circuit to overheat (risk of fire) in the event of an item of equipment using an excessive amount of current.




















### Fuses in the passenger compartment

Unclip flap **A** using notch **B** to help you.


To identify the fuses, refer to the fuse allocation label (see the next page for details), located on the rear of flap **A**.

# FUSES (2/5)

## Allocation of fuses (DEPENDING ON THE EQUIPMENT LEVEL)

Numbers	Allocation	Numbers	Allocation	Numbers	Allocation
	Radio, heated seats, multi-function display, sockets for audio and alarm connections.		Brake lights, interior lighting.	<b>FBL</b>	Cornering lights.
	Accessories sockets.		Passenger compartment ECU.		Hands-free access.
	Cigar lighter.	<b>STOP</b>	Brake lights.	<b>T</b>	Tachograph.
	Instrument panel.	<b>ALIM UCH</b>	Electric windows, heating and air conditioning system and passenger compartment ECU.		Heating and air conditioning system fan.
	Central door control.		Left-hand heated rear screen.	<b>ADP</b>	Additional adaptations.
	Passenger compartment ECU, direction indicator lights and rear fog lights.		Right-hand heated rear screen.		Electric windows and passenger compartment ECU.
<b>DIAG</b>	Diagnostic socket.		Windscreen washer.		
	ABS/ESC		Engine immobiliser.		
			Heated seats.		

## FUSES (3/5)



### Fuses in the engine compartment


#### Removing fuse box C

Remove screw **2** and remove coolant reservoir **3**.



No operations should be carried out on the cooling circuit when the engine is hot.


**Risk of burns.**



Unscrew the four screws **4**.



Please note when working close to the engine that it may be hot. The engine cooling fan may also start

at any moment. The  warning light in the engine compartment reminds you of this.

**Risk of injury.**



Turn unit **5** over to access the fuses in the engine compartment.


To identify the fuses, refer to the fuse allocation label (see the next page for details), located on unit **5**.

Check that no water or dust enters unit **5** when it is being removed/re-fitted.




Deactivate the Stop and Start function for any operation performed in the engine compartment.

## FUSES (4/5)




### Refitting fuse box C

Clip the mountings 7, then clip mounting 6.



Screw the four screws 4 to ensure that unit 5 is completely sealed.












Check that no water or dust enters unit 5 when it is being removed/refitted.



Position coolant reservoir 3, then screw bolt 2.

## FUSES (5/5)

### Allocation of fuses (DEPENDING ON THE EQUIPMENT LEVEL)

Symbol	Allocation	Symbol	Allocation
	Right-hand side light.		Right-hand main beam headlight.
	Left-hand side light.		ABS
	Right-hand dipped beam headlight.		Windscreen wiper.
	Left-hand dipped beam headlight.		Heating and air conditioning system.
	Fog light		De-icing.
	Left-hand main beam headlight.		

## BATTERY: troubleshooting (1/2)

### To avoid all risk of sparks:

- Ensure that any consumers (courtesy lights, etc.) are switched off before disconnecting or reconnecting the battery;
- when charging, stop the charger before connecting or disconnecting the battery;
- to avoid creating a short circuit between the terminals, do not place metal objects on the battery;
- always wait at least one minute after the engine has been switched off before disconnecting a battery;
- make sure that you reconnect the battery terminals after refitting.



Special procedures may be required to charge some batteries. Contact your approved dealer.

Avoid all risk of sparks which may cause an immediate explosion, and charge the battery in a well ventilated area. **Risk of serious injury.**

### Connecting a battery charger

**The battery charger must be compatible with a battery with nominal voltage of 12 volts.**

Do not disconnect the battery when the engine is running. **Follow the instructions given by the manufacturer of the battery charger you are using.**

When many accessories are fitted to the vehicle, have them connected to the **+ after ignition feed.**



Handle the battery with care as it contains sulphuric acid, which must not come into contact with eyes or skin. If it does, wash the affected area with plenty of cold water. If necessary, consult a doctor.

Ensure that naked flames, red hot objects and sparks do not come into contact with the battery as there is a risk of explosion.

Please note when working close to the engine that it may be hot. In addition, the engine cooling fan may



start at any moment. The warning light in the engine compartment reminds you of this.

**Risk of injury.**

## BATTERY: troubleshooting (2/2)


### Starting the vehicle using the battery from another vehicle

If you have to use the battery from another vehicle to start, obtain suitable jump leads (with a large cross section) from an approved dealer or, if you already have jump leads, ensure that they are in perfect condition.

**The two batteries must have an identical nominal voltage of 12 volts.** The battery supplying the current should have a capacity (amp-hours, Ah) which is at least the same as that of the discharged battery.

Ensure that there is no risk of contact between the two vehicles (risk of short circuiting when the positive terminals are connected). Switch off your vehicle ignition.


Start the engine of the vehicle supplying the current and run it at a moderate speed.



Attach the positive lead (+) **A** to terminal **3**, then to terminal **2** (+) of the battery supplying the current.

Attach negative lead (-) **B** to terminal **1** (-) of the battery supplying the current, then to earth **4** (-).

Start the engine as normal. As soon as it is running, disconnect leads **A** and **B** in the reverse order (**4-3-2-1**).




Check that there is no contact between leads **A** and **B** and that the positive lead **A** is not touching any metal parts on the vehicle supplying the current.

**Risk of injury and/or damage to the vehicle.**



# RADIO FREQUENCY REMOTE CONTROL: battery

27416




## Replacing the battery

Open the case at slot **1** using a flat-blade screwdriver or similar and replace the battery **2**, observing the type and polarity shown on the back of the cover.

**Note:** It is not advisable to touch the electrical circuit in the key cover when replacing the battery.

Do not dispose of your used batteries in the countryside. Give them to an organisation that collects and recycles used batteries.

522A



## Special feature of key A

Undo screw **3** to remove the remote control cover.

When refitting, ensure that the cover is correctly clipped on and the screw tightened.

The batteries are available from approved Dealers, and their service life approximately two years. Check that there is no dye on the battery: risk of an incorrect electrical contact.

522B



20810



# HANDS-FREE ACCESS TRANSMITTER, RECEIVER: battery

31505



## Replacing the battery

Use a coin to open the unit via slot 1.

The batteries are available from approved Dealers, and their service life approximately two years.

Check that there is no dye on the battery: risk of an incorrect electrical contact.



Replace battery 2 according to the direction marked on the cover.

**Note:** it is not advisable to touch the electronic circuit in the cover when replacing the battery.

When refitting, ensure that the cover is correctly clipped into place.


30410

20510



Do not dispose of your used batteries in the countryside. Give them to an organisation that collects and recycles used batteries.

# WIPER BLADES




To access the wiper blades, stand on step 1.

**Note:** the step may be slippery.

## Replacing windscreen wiper blades 2

- Lift wiper arm 4;
- move the blade into a horizontal position;



- press tab 3 and slide the wiper blade downwards to release hook 5 from the wiper arm;
- slide the blade (A) then lift it (B) to release it.

## Refitting

To refit the wiper blade, proceed in the reverse order to removal. Make sure that the blade is correctly locked in position.

Check the condition of the wiper blades. You are responsible for their service life:

- clean the blades and the windscreen regularly with soapy water;
- do not use them when the windscreen is dry;
- free them from the windscreen when they have not been used for a long time.



- In frosty weather, make sure that the wiper blades are not stuck by ice (to avoid the risk of the motor overheating).
- Check the condition of the wiper blades.  
Replace the wiper blades as soon as they begin to lose efficiency (approximately once a year).

Whilst changing the blade, take care not to drop the arm onto the window after it has been removed as this may break the window.

## TOWING: breakdown (1/2)

The steering wheel must be unlocked and the ignition key must be in position M (ignition on) to provide brake lights and hazard warning lights on the towed vehicle. At night the vehicle must have its lights on.

Unhitch the trailer, etc., if one is being towed.

You must observe the towing regulations which apply in the country in which you are driving: do not exceed the towing weight for your vehicle.

Contact an approved dealer.



Do not remove the key from the ignition when the vehicle is being towed.



When the engine is stopped, steering and braking assistance are not operational.

### Towing a vehicle with a sequential gearbox

If the gearbox is stuck in a gear:

- switch on the ignition;
- select neutral with the brake pedal depressed;
- check that the gearbox is in neutral (by pushing the vehicle for example).

If you cannot find neutral you must tow the vehicle with the front wheels raised.


**The vehicle should always be towed with the ignition switched off.**



– Use a rigid towing bar. If a rope or cable is used (where the law allows this), the vehicle being towed must be able to brake.

- A vehicle must not be towed if it is not fit to be driven.
- Avoid accelerating or braking suddenly when towing, as this may result in damage being caused to the vehicle.
- When towing a vehicle, it is advisable not to exceed **15 mph (25 km/h)**.

## TOWING: breakdown (2/2)



### Only use:

- At the rear left, towing point 1.
- At the front, towing hitch 4 (from the tool kit) and towing point 2.

These towing points may only be used for pulling the vehicle, never for lifting it either directly or indirectly.

### Rear towing point 1




### Front towing point 2

#### Accessing towing hitch 4

Move the driver's seat forward and recline the seatback so that tool kit 3 can be removed.

#### Access to front towing point 2

Unclip cover 5 by inserting a flat-blade screwdriver or similar under the cover.



First screw in towing hitch 4 as far as it will go by hand, then finish tightening it fully using the wheelbrace stored in tool kit 3.



When storing the tools, ensure that they are correctly replaced in unit 3, in their original positions and store the unit under the driver's seat. Do not leave the tools unsecured inside the vehicle as they may come loose under braking.

## FITTING THE RADIO



If your vehicle is not fitted with an audio system, one can be fitted and locations have been provided for:

- radio **1**;
- front speakers **2** (depending on the vehicle).

To install any equipment, please consult an approved dealer.

### Radio location 1

Unclip the blanking cover. The aerial, + and – supply and speaker wire connections are located behind it.



- In all cases, it is very important to follow the manufacturer's instructions carefully.
- The specifications of the brackets and wires (available from our network) vary depending on the equipment level of your vehicle and the type of radio.  
Consult an approved Dealer to find out the correct part number.
- No work may be carried out on the vehicle's electrical or radio circuits, except by approved dealers: an incorrectly connected system may result in damage being caused to the electrical equipment and/or the components connected to it.

## ACCESSORIES



### **Electrical and electronic accessories**

Before installing this type of accessory (particularly for transmitters/receivers: frequency bandwidth, power level, position of the aerial, etc.), make sure it is compatible with your vehicle. You can get advice from an authorised dealer.

Connect accessories with a maximum power of 120 Watts only. **Fire hazard.** When several accessory sockets are used at the same time, the total power of the connected accessories must not exceed 180 watts.

No work may be carried out on the vehicle's electrical or radio circuits, except by authorised dealers: an incorrectly connected system may result in damage being caused to the electrical equipment and/or the components connected to it.

If the vehicle is fitted with any aftermarket electrical equipment, make sure that the installation is correctly protected by a fuse.

Establish the rating and position of this fuse.

### **Using the diagnostic socket**

The use of electronic accessories on the diagnostic socket may cause serious disturbance to the vehicle's electronic systems.

For your safety we recommend that you use only electronic accessories approved by the manufacturer, consult an Approved Dealer. **Serious accident risk.**

### **Use of transmitting/receiving devices (telephones, CB equipment etc.).**

Telephones and CB equipment with integrated aerials may cause interference to the electronic systems originally fitted to the vehicle: it is advisable only to use equipment with an external aerial. **Furthermore, we remind you of the need to conform to the legislation in force concerning the use of such equipment.**

### **Fitting aftermarket accessories**

If you wish to install accessories on the vehicle: please contact an authorised dealer. Also, to ensure the correct operation of your vehicle, and to avoid any risk to your safety, we recommend that you use only accessories specifically designed for your vehicle, which are the only accessories for which the manufacturer will provide a warranty.

If you are using an anti-theft device, only attach it to the brake pedal.

### **Obstructions to the driver**

On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another. **There is a risk of wedging the pedals.**

## OPERATING FAULTS (1/5)

The following advice will enable you to carry out quick, temporary repairs. For safety reasons you should always contact an approved dealer as soon as possible.

The starter is activated	POSSIBLE CAUSES	WHAT TO DO
Warning lights dim or fail to come on; the starter does not run.	Battery terminals disconnected, oxidised or incorrectly secured.	Contact an approved Dealer.
	Battery discharged or worn.	Connect another battery to the faulty battery. Refer to the paragraph "Battery: troubleshooting" in Section 5 or replace the battery if necessary. Do not push the vehicle if the steering column is locked.
The engine will not start.	Starting conditions are not fulfilled.	Refer to the information on "Starting/stopping the engine" in Section 2.
The steering column remains locked.	Steering wheel locked.	To unlock, move the key and the steering wheel (refer to the information on the "Ignition switch" in Section 2).



## OPERATING FAULTS (2/5)

On the road	POSSIBLE CAUSES	WHAT TO DO
Vibrations.	Tyres not inflated to the correct pressure, incorrectly balanced or damaged.	Check the tyre pressures: if this is not the problem, have them checked by an approved dealer.
Coolant boiling in the coolant reservoir.	Mechanical fault: damaged cylinder head gasket.	Stop the engine. Contact an approved Dealer.
Smoke under the bonnet.	Short circuit or cooling system leak.	Stop, switch off the ignition, stand away from the vehicle and contact an approved dealer.
The oil pressure warning light comes on:		
while cornering or braking	The level is too low.	Top up the engine oil (refer to the information on "Engine oil level – Topping up/refilling" in Section 4).
is slow to go out or remains lit under acceleration	Loss of oil pressure.	Stop the vehicle and contact an approved Dealer.
White smoke from the exhaust.	This is not necessarily a fault. Smoke may be caused by regeneration of the particle filter.	Refer to the information on "Special features of diesel versions" in Section 2.

## OPERATING FAULTS (3/5)

### On the road

### POSSIBLE CAUSES

### WHAT TO DO

Steering becomes heavy.

Assistance overheating.  
Fault with the electric assistance motor.  
Fault in the assistance system.

Drive carefully at reduced speed, be aware of the level of force in the steering wheel needed to turn the wheels. Consult an approved dealer

The engine is overheating. The coolant temperature warning light and the STOP warning light come on.

Engine cooling fan not working.

Stop the vehicle, switch off the engine and contact an approved Dealer.

Coolant leaks.

Check the coolant reservoir: it should contain fluid. If there is no coolant, consult an approved Dealer as soon as possible.



**Radiator:** If there is a significant lack of coolant, remember that it must never be topped up using cold coolant while the engine is very warm. After any procedure on the vehicle which has involved even partial draining of the cooling system, it must be refilled with a new mixture prepared in the correct proportions. Reminder: only products approved by our Technical Department may be used for this purpose.

## OPERATING FAULTS (4/5)

<b>Electrical equipment</b>	<b>POSSIBLE CAUSES</b>	<b>WHAT TO DO</b>
The wipers do not work.	Wiper blades stuck.	Free the blades before using the wipers.
	Faulty electrical circuit.	Consult an approved dealer.
	Fuse damaged.	Replace the fuse or have it replaced; refer to the information on "Fuses" in section 5.
The wiper does not stop.	Faulty electrical controls.	Consult an approved dealer.
Direction indicators flashing more quickly.	Blown bulb.	See the information on "Headlights: changing bulbs" or "Rear lights: changing bulbs" in Section 5.
	Fuse damaged.	Replace the fuse or have it replaced; refer to the information on "Fuses" in section 5.
The direction indicators do not work.	Faulty electrical circuit.	Consult an approved dealer.
	Fuse damaged.	Replace the fuse or have it replaced; refer to the information on "Fuses" in section 5.


## OPERATING FAULTS (5/5)

<b>Electrical equipment</b>	<b>POSSIBLE CAUSES</b>	<b>WHAT TO DO</b>
The lights do not come on or go off.	Faulty electrical circuit or control.  Fuse damaged.	Consult an approved dealer.  Replace the fuse or have it replaced; refer to the information on "Fuses" in section 5.
Traces of condensation in the head-lights or rear lights.	Traces of condensation may be a natural phenomenon caused by variations in temperature and humidity.  In this situation, these traces soon disappear when the lights are switched on.	

# ***Section 6: Technical specifications***

Vehicle identification plates . . . . .	6.2
Engine specifications . . . . .	6.5
Dimensions . . . . .	6.6
Weights . . . . .	6.8
Replacement parts and repairs . . . . .	6.9
Service sheets . . . . .	6.10
Anticorrosion check . . . . .	6.16

## VEHICLE IDENTIFICATION PLATES (1/2)




The information shown on the vehicle identification plate should be quoted on all correspondence or orders.

### Vehicle identification plate A

- 1 Manufacturer name.
- 2 EC design number or approval number.
- 3 Identification number.  
**Depending on the vehicle, this information is also given on marking B.**
- 4 MAM (Maximum Authorised Mass).


- 5 GTW (Gross train weight: vehicle fully loaded, with trailer).
- 6 MPAW (Maximum Permissible Weight) for front axle.
- 7 MPAW on rear axle.
- 8 Reserved for related or additional entries.
- 9 Not used.
- 10 Paint reference (colour code).

## VEHICLE IDENTIFICATION PLATES (2/2)



To access the vehicle type and chassis number, unclip the covers **C** using a flat-blade screwdriver or similar.

# ENGINE IDENTIFICATION PLATES



**The information on the engine plate or label A should be quoted on all your correspondence or orders.**



(Location varies depending on engine)

- 1 Engine type.
- 2 Engine suffix.
- 3 Engine number.








## ENGINE SPECIFICATIONS

<b>Versions</b>	<b>2.3 dCi</b>	
<b>Engine type</b> (see engine plate)	M9T	
<b>Cubic capacity (cc)</b>	2299	
<b>Injection</b>	Diesel	
<b>Type of fuel</b> <b>Octane rating</b>	Diesel The label located in the fuel filler flap indicates the authorised fuels.	
<b>Fuel types that meet European standards and are compatible with the engines of vehicles sold in Europe</b> (in any other case, contact an Approved Dealer).		Diesel fuel compliant with standard <b>EN 590</b> contains up to 7 % fatty acid methyl ester in volume.
		Diesel fuel compliant with standard <b>EN 16734</b> contains up to 10 % fatty acid methyl ester in volume.
<b>Spark plugs</b>	-	

## DIMENSIONS (in metres) (1/2)

6208



## DIMENSIONS (in metres) (2/2)

Complete vehicles without recent alterations

	Short (L1)	Average (L2)	Medium (L2.5)	Long (L3)	Long (L4)
<b>A</b>	3,182	3,682	4,006	3,682 → 4,332	4,332
<b>B</b>	5,048	5,548	5,967	6,198	6,848
<b>C</b>	0,842				
<b>D</b>	1,024			1,024 → 1,674	1,575 → 1,674
<b>E</b>	1,750				
<b>F</b>	1,730	1,730 → 1,860		1,612 → 1,730	1,612
<b>G</b>	2,470				
<b>H</b>	2,222 → 2,500	2,256 → 2,745	2,256 → 2,261	2,270 → 2,815	2,267 → 2,808
<b>J</b>	0,546 → 0,560	0,543 → 0,787	0,735 → 0,740	0,542 → 0,775	0,700 → 0,789
<b>K</b>	0,189 → 0,196	0,166 → 0,185	0,166	0,166 → 0,208	0,166 → 0,178
<b>Q</b>	1,700 → 1,894	1,894 → 2,144	-	1,798 → 2,048	
<b>Y</b>	1,580		-	1,580	
<b>Z</b>	1,627	1,820	-	1,724 → 1,820	1,724
<b>Z1</b>	2,583	3,083	-	3,733	4,383

## WEIGHTS (in kg)

The weights indicated are for a basic vehicle without options: they vary depending on the your vehicle's equipment. Contact an approved dealer.

Versions	Up to 3.5 tonnes			from 3.5 to 4.5 tonnes
<b>Maximum permissible all-up weight (MMAC)</b> <b>Total train weight</b>	Weights indicated on the identification plate (refer to the information on "Vehicle identification plates" in Section 6)			
<b>Braked Trailer Weight* (Masse Remorque Freinée/MRF)</b>	obtained by calculating: <b>MTR - MMAC</b>			
<b>Unbraked Trailer Weight*</b>	750			
<b>Permissible nose weight*</b>	Front wheel drive versions	Rear wheel drive versions with MRF of up to 3 tonnes	Rear wheel drive versions with MRF of between 3 and 3.5 tonnes	-
	100	120	140	120
<b>Maximum permissible load on roof</b>	Standard version: 200 Raised version: prohibited			

### \* Towing weight (Towing a caravan, boat, etc.)

Towing is prohibited when the GTW - MAM calculation is equal to zero, or when the GTW is equal to zero (or is not listed) on the identification plate.

- It is important to comply with the towing weights, governed by local legislation in each country and, in particular, laid down in the Road Traffic Regulations. Contact an approved Dealer about any towing equipment.
- When towing, under no circumstances may **the total train weight (vehicle + trailer) be exceeded**. However the following is permitted:
  - the Maximum permissible weight at the rear may be exceeded by no more than 15%,
  - the maximum permissible all-up weight may be exceeded by no more than 10% or 100 kg (whichever occurs first).
 In either case, the maximum speed of the vehicle and trailer must not exceed 48 mph (80 kph), depending on local legislation, and the tyre pressure must be increased by 0.2 bar (3 PSI).
- The engine output and climbing capability are reduced with altitude. We recommend that the maximum load be reduced by 10% at an altitude of 1,000 metres and by an additional 10% for each 1,000 metres thereafter.

## REPLACEMENT PARTS AND REPAIRS

Original parts are based on strict specifications and are subject to highly-specialised tests. Therefore, they are of at least the same level of quality as the parts fitted originally.

If you always fit genuine replacement parts to your vehicle, you will ensure that it performs well. Furthermore, repairs carried out within the manufacturer's Network using original parts are guaranteed according to the conditions set out on the reverse of the repair order.

# SERVICE SHEETS (1/6)

VIN: .....

Date: _____ Miles (km): _____ Invoice number: _____		Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>	<b>Stamp</b>	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page		

Date: _____ Miles (km): _____ Invoice number: _____		Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>	<b>Stamp</b>	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page		

Date: _____ Miles (km): _____ Invoice number: _____		Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>	<b>Stamp</b>	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page		

# SERVICE SHEETS (2/6)

VIN: .....

Date: _____ Miles (km): _____		Invoice number: _____	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		Stamp	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page			
Date: _____ Miles (km): _____		Invoice number: _____	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		Stamp	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page			
Date: _____ Miles (km): _____		Invoice number: _____	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		Stamp	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page			

# SERVICE SHEETS (3/6)

VIN: .....

Date: _____ Miles (km): _____ Invoice number: _____		Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>	<b>Stamp</b>	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page		

Date: _____ Miles (km): _____ Invoice number: _____		Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>	<b>Stamp</b>	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page		

Date: _____ Miles (km): _____ Invoice number: _____		Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>	<b>Stamp</b>	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page		



# SERVICE SHEETS (4/6)

VIN: .....

Date: _____ Miles (km): _____		Invoice number: _____	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		Stamp	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page			
Date: _____ Miles (km): _____		Invoice number: _____	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		Stamp	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page			
Date: _____ Miles (km): _____		Invoice number: _____	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		Stamp	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page			

# SERVICE SHEETS (5/6)

VIN: .....

Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		<b>Stamp</b>	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page			

Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		<b>Stamp</b>	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page			

Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		<b>Stamp</b>	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page			

# SERVICE SHEETS (6/6)




VIN: .....

Date: _____ Miles (km): _____		Invoice number: _____	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		Stamp	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page			
Date: _____ Miles (km): _____		Invoice number: _____	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		Stamp	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page			
Date: _____ Miles (km): _____		Invoice number: _____	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		Stamp	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/> *See specific page			

# ANTICORROSION CHECK (1/6)

If the continuation of the warranty is subject to repair, it is indicated below.




VIN: .....

Corrosion repair operation to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		

# ANTICORROSION CHECK (2/6)

If the continuation of the warranty is subject to repair, it is indicated below.




VIN: .....

Corrosion repair operation to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		

# ANTICORROSION CHECK (3/6)

If the continuation of the warranty is subject to repair, it is indicated below.




VIN: .....

Corrosion repair operation to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		

# ANTICORROSION CHECK (4/6)

If the continuation of the warranty is subject to repair, it is indicated below.




VIN: .....

Corrosion repair operation to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		

# ANTICORROSION CHECK (5/6)

If the continuation of the warranty is subject to repair, it is indicated below.

VIN: .....




Corrosion repair operation to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		



# ANTICORROSION CHECK (6/6)

If the continuation of the warranty is subject to repair, it is indicated below.

VIN: .....

Corrosion repair operation to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		



# ALPHABETICAL INDEX (1/5)

## A

ABS .....	2.16 → 2.23
accessories.....	5.41
accessories socket .....	3.19
additional systems to the seat belts.....	1.31
adjusting the seats.....	1.24
adjusting your driving position .....	1.24
advice on antipollution.....	2.12
air bag.....	1.28 → 1.31
activating the front passenger air bags.....	1.70 → 1.72
deactivating the front passenger air bags.....	1.70 → 1.72
air conditioning .....	3.2 → 3.14
air vents.....	3.2 – 3.3
anti-corrosion check .....	6.16 → 6.21
anti-corrosion protection.....	4.14
anti-lock braking system: ABS.....	2.16 → 2.23
antipollution	
advice .....	2.12
ashtrays.....	3.19
audible and visual signals.....	1.101
automatic gearbox selector lever.....	2.45 → 2.49

## B

battery.....	4.13
troubleshooting .....	5.33 – 5.34
bonnet.....	4.2
brake fluid.....	4.8
bulbs	
changing .....	5.21 – 5.22, 5.25 → 5.27

## C

capacity of mechanical components.....	4.8 → 4.10
central door locking .....	1.2 → 1.12, 1.15 → 1.18
changing a bulb .....	5.21 – 5.22, 5.25 → 5.27
changing a wheel.....	5.2 → 5.4, 5.11 → 5.15, 5.17
changing gear.....	2.14

child restraint/seat.....	1.30, 1.33 – 1.34, 1.38 → 1.57, 1.70 → 1.72
child safety.....	1.33 – 1.34, 1.38 → 1.57, 1.70 → 1.72
child seats.....	1.33 – 1.34, 1.38 → 1.57
children.....	1.33 – 1.34
cigar lighter .....	3.19
cleaning:	
inside the vehicle .....	4.17 – 4.18
clock .....	1.93
control instruments .....	1.78 → 1.89, 1.91
coolant.....	1.83
courtesy light .....	3.17, 5.27
cruise control .....	1.89, 2.33 → 2.36
cruise control-speed limiter.....	1.89, 2.30 → 2.36

## D

deadlocking the doors .....	1.7
demisting	
windscreen.....	3.4, 3.7 → 3.12
dimensions .....	6.6 – 6.7
dipstick.....	4.4 – 4.5
display .....	1.84 → 1.89, 1.91
doors.....	1.13 – 1.14, 1.17 – 1.18
driver's position .....	1.74 → 1.77
driving.....	2.2, 2.10, 2.16 → 2.26, 2.37
driving recommendations .....	2.8 → 2.11

## E

ECO driving .....	2.8 → 2.11
ECO mode.....	2.9
electric beam height adjustment.....	1.100
electric windows .....	3.15 – 3.16
electronic stability control: ESC.....	2.16 → 2.23
emergency active braking.....	2.16 → 2.23
emergency brake assist.....	2.16 → 2.23
emergency braking.....	2.16 → 2.23
emergency spare wheel .....	5.2 – 5.3

## ALPHABETICAL INDEX (2/5)

engine	
technical specifications .....	6.5
engine coolant .....	4.9
engine oil .....	4.4 → 4.7
engine oil level .....	1.83, 4.4 → 4.7
engine specifications .....	6.5
environment .....	2.13
ESC: electronic stability control .....	2.16 → 2.23
external lights and signals .....	1.96 → 1.100
external temperature .....	1.93

### F

faults	
operating faults .....	1.89

### F

filling with reagent .....	1.104 → 1.110
----------------------------	---------------

### F

filter .....	4.10
fitting a radio .....	5.40
foot panel .....	5.37
front passenger air bag deactivation .....	1.70 → 1.72
front seat adjustment .....	1.21
front seats .....	1.21
fuel	
advice on fuel economy .....	2.8 → 2.11
consumption .....	2.8 → 2.11
filling .....	1.102 – 1.103
grade .....	1.102
fuel consumption .....	2.8 → 2.11
fuel filler cap .....	1.102 – 1.103
fuel grade .....	1.103
fuel level .....	1.83
fuel repriming .....	1.102 – 1.103
fuel tank .....	1.102 – 1.103

fuel tank capacity .....	1.102
fuses .....	5.28 → 5.32

### G

gear lever .....	2.14, 2.45 → 2.49
grab handle .....	3.18
grip control .....	2.22
ground clearance .....	6.6 – 6.7

### H

handbrake .....	2.15
handsfree .....	1.8 – 1.9
hazard warning lights signal .....	1.101
headrest .....	1.20
heated seats .....	1.21
heating and air conditioning system .....	3.2 – 3.3, 3.7 → 3.13
heating system .....	3.2 → 3.6, 3.13 – 3.14
Hill Start Assist .....	2.16 → 2.23
HSA: Hill Start Assistance .....	2.23
hubcap tool .....	5.4, 5.11 – 5.12

### I

idle speed .....	2.43
ignition switch .....	2.2
indicators .....	1.101
indicators:	
direction indicators .....	1.101
instrument panel .....	1.78 → 1.83, 1.86 → 1.89, 1.91
instrument panel .....	1.78 → 1.89, 1.91
instrument panel messages .....	1.86 → 1.89, 1.91
interior lighting:	
changing bulbs .....	5.27
interior trim	
maintenance .....	4.17 – 4.18

## ALPHABETICAL INDEX (3/5)

- J**  
jack ..... 5.4
- K**  
keys ..... 1.2 → 1.6
- L**  
lane departure warning ..... 2.27 → 2.29  
levels:  
    brake fluid ..... 4.8  
    coolant ..... 4.9  
    power-assisted steering pump ..... 4.10  
lifting the vehicle  
    changing a wheel ..... 5.4, 5.13 → 5.15, 5.17  
lighting:  
    interior ..... 3.17  
lights:  
    adjustment of headlight beam height ..... 1.100  
    brake lights ..... 5.25 – 5.26  
    daytime running lights ..... 5.21 – 5.22  
    dipped beam headlights ..... 1.96, 5.21 – 5.22, 5.25  
    direction indicators ..... 5.21 – 5.22  
    fog lights ..... 5.25  
    hazard warning ..... 5.25  
    main beam headlights ..... 1.97, 5.21 – 5.22  
    reversing lights ..... 5.25  
    side lights ..... 1.96, 5.21 – 5.22  
lights-on warning buzzer ..... 1.97  
locking the doors ..... 1.2 → 1.9, 1.12, 1.15 – 1.16
- M**  
maintenance ..... 2.12  
maintenance:  
    bodywork ..... 4.14 → 4.16  
    interior trim ..... 4.17 – 4.18  
    mechanical ..... 6.10 → 6.15  
    mileage before service ..... 1.88, 6.10 → 6.15  
    manufacturer's plates ..... 6.2  
    methods of restraint in addition to the front seat belts ..... 1.28 → 1.30  
    mileage before service ..... 1.88
- N**  
navigation system ..... 1.93, 3.28
- O**  
oil change ..... 1.88, 4.6 – 4.7  
operating faults ..... 1.89, 5.42 → 5.46
- P**  
paintwork  
    maintenance ..... 4.14 → 4.16  
    reference ..... 6.2  
parking distance control ..... 2.38 – 2.39  
power-assisted steering ..... 1.19  
puncture ..... 5.2 → 5.10, 5.13 → 5.15, 5.17
- R**  
radio  
    fitting a radio ..... 5.40  
radio frequency remote control/key  
    use ..... 1.5 – 1.6
- R**  
reagent (tank) ..... 1.83, 1.91, 1.104 → 1.110  
reagent tank ..... 1.83, 1.91, 1.104 → 1.110
- R**  
rear bench seat ..... 3.26 – 3.27  
rear view camera ..... 2.40 – 2.41  
rear view mirrors ..... 1.73

## ALPHABETICAL INDEX (4/5)

remote control door locking	
batteries .....	5.35
remote control door locking unit .....	1.2 → 1.6
RENAULT ANTI-INTRUDER DEVICE (RAID) .....	1.12
replacement parts .....	6.9
reverse gear	
selecting .....	2.14, 2.46
running in .....	2.2

### S

screen wash/wipe .....	1.94 – 1.95
seat belt pretensioners	
front seat belt .....	1.28 → 1.30
seat belts .....	1.24 → 1.26, 1.31
see-me-home lighting .....	1.97
sequential gearbox .....	2.45 → 2.49
service sheets .....	6.10 → 6.15
signals and lights .....	1.96 → 1.100
speakers	
location .....	5.40
special features of diesel versions .....	2.7
speed limiter .....	1.89, 2.30 → 2.32
starting the engine .....	2.3
steering wheel	
adjustment .....	1.19
Stop & Start .....	2.4 → 2.6
Stop & Start function .....	2.4 → 2.6
stopping the engine .....	2.3
storage compartment .....	3.20 → 3.25
storage compartments .....	3.20 → 3.25
sun visor .....	3.18

### T

tailgate .....	3.29
tanks and reservoirs:	
windscreen washer .....	4.10

technical specifications .....	6.2 – 6.3, 6.6 → 6.9
temperature regulation .....	3.13 – 3.14
tool kit .....	5.4
towing .....	3.29
driving .....	2.18
breakdown .....	5.38 – 5.39
towing a caravan .....	6.8
towing hitch .....	5.4
towing rings .....	3.29 – 3.30
towing weights .....	6.8
traction control .....	2.16 → 2.23
transporting children ....	1.33 – 1.34, 1.38 → 1.57, 1.70 → 1.72
transporting objects	
in the luggage compartment .....	3.29 – 3.30
trims .....	5.11 – 5.12
trip computer and warning system .....	1.84 → 1.89, 1.91
turning circle .....	6.6 – 6.7
tyre inflation kit .....	5.5 → 5.10
tyre pressure .....	1.89, 2.24 → 2.26, 4.11 – 4.12
tyre pressure loss warning .....	2.24 → 2.26
tyre pressures .....	4.11 – 4.12
tyres .....	2.24 → 2.26, 4.11 – 4.12, 5.18 → 5.20

### U

unlocking the doors .....	1.8 → 1.11
use in winter .....	5.20

### V

vehicle identification .....	6.2 – 6.3
vehicle identification plates .....	6.2 – 6.3
vehicle range .....	1.87
ventilation .....	3.13 – 3.14
air conditioning .....	3.2 – 3.3

### W

warning buzzer .....	1.13 – 1.14
----------------------	-------------

## ALPHABETICAL INDEX (5/5)

warning lights.....	1.78 → 1.83, 1.86 → 1.89, 1.91
washing .....	4.14 → 4.16
weights .....	6.8
wheelbrace .....	5.4
wheels (safety) .....	5.18 → 5.20
windows.....	3.15 – 3.16
wiper blades .....	5.37





<https://www.truck-manuals.net/>



XJ

9 9 9 1 0 4 9 2 8 S