

# Workshop Service Manual

# EEBRO

## TRACTORS

### 350 AND 460 MODELS



# DAVID MCNEILL

## SECTION 1:

## GENERAL INFORMATION

### CONTENTS

	PAGE
Identification	1
Specifications	2
Pre-delivery inspection	3
Maintenance	4



Publication DP 808 EXP 1  
1st Edition 1-75

## IDENTIFICATION

The identification of the ECRS 350 and 400 tractors is provided by the unit serial number and the engine serial number.

## Unit Serial number (Fig. 1)

The unit number is stamped on the edge of the left side of the rear axle cover, adjacent to the back stop.

8TXL97498



Fig. 1 - Unit serial number

## Engine Serial number (Fig. 2)

The 3.150 engine of Model 350 tractors has serial number stamped exactly in the upper middle part of the left side of the block.

152NE  
2125ODL



Fig. 2 - Engine serial number of Model 350

## Engine Serial number (Fig. 3)

The 4.200 engine of the Model 400 has its serial number in the upper rear part of the left cylinder head.



Fig. 3 - Engine serial number of Model 400

NOTE. - When making any repairs, check or request for information with respect to other tractor

models, always check the model, serial number and engine number.

### Identification of the Instruments and Controls

In Figure 4 the different instruments and controls found on each instrument panel.




Fig. 4 - Instruments and controls

- |                                  |                                        |
|----------------------------------|----------------------------------------|
| A - Temperature gauge            | K - Reduction gear lever               |
| B - Tachometer                   | L - Primary starting pedal             |
| C - Fuel gauge                   | M - Auxiliary starting pedal           |
| D - Throttle control lever       | N - Auxiliary over-boost control lever |
| E - Battery charge control light | O - Gear shift lever                   |
| F - Oil pressure                 | P - Clutch pedal                       |
| G - Engine alarm                 | Q - Parking brake lever                |
| H - Power take-off lever         |                                        |
| I - Right taillight              |                                        |
| J - Left taillight               |                                        |

## SPECIFICATIONS

The specifications of the different surfaces, which have not been included in their corresponding group, are set out below:

## Rear axle

## - Gear ratios

$$1st \quad \frac{35}{32} \times \frac{18}{38} \times \frac{12}{20} = 8,26 : 1$$

$$2nd \quad \frac{35}{32} \times \frac{18}{38} \times \frac{17}{20} = 8,18 : 1$$

$$3rd \quad \frac{35}{32} \times \frac{18}{38} \times \frac{20}{21} = 8,02 : 1$$

$$4th \quad \frac{35}{32} \times \frac{18}{38} \times \frac{25}{19} = 8,04 : 1$$

$$5th \quad \frac{15}{16} = 2,25 : 1$$

$$6th \quad \frac{17}{16} = 1,02 : 1$$

$$7th \quad \frac{22}{21} = 8,96 : 1$$

$$8th \quad \frac{20}{19} = 8,95 : 1$$

$$\text{Low reverse} \quad \frac{35}{32} \times \frac{18}{38} \times \frac{15}{20} = 8,08 : 1$$

$$\text{High reverse} \quad \frac{35}{32} = 2,15 : 1$$

## Rear axle

- Differential reduction
- Pinion-crown wheel reduction
- Total rear axle reduction

4,6 - 1 (20 pinion teeth - 46 crown wheel teeth)

7,225 : 1 (7 pinion teeth - 51 crown wheel teeth)

33,01 : 1




Fig. 2 - Transmission diagram

**Power take-off**

- Position: Rear
- Dimensions: 34,5 mm in diameter
- Number of splines: 8 (conforming to ISO recommendations)
- Height above the ground:
  - Model 280: 330 mm
  - Model 480: 740 mm
- Distance to the tractor's vertical main rotary phase: 0 mm
- Direction of revolution: To the right
- Reduction:  $\frac{16}{41} \times \frac{20}{28} = 4,1:1$
- Speed: 544 rpm, at 2000 rpm, of the engine

**Weight of the tractor in operating conditions (without the tillage and main fuel tank full)**

- Without ballasting
  - Model 280:
    - Over the front axle: 700 kg
    - Over the rear axle: 1,220 kg
    - Total weight: 1,920 kg
  - Model 380:
    - Over the front axle: 700 kg
    - Over the rear axle: 1,300 kg
    - Total weight: 2,100 kg
- With ballasting and counterweights
  - Model 380:
    - Over the front axle: 1,000 kg
    - Over the rear axle: 1,400 kg
    - Total weight: 2,400 kg
  - Model 480:
    - Over the front axle: 1,300 kg
    - Over the rear axle: 2,000 kg
    - Total weight: 3,300 kg



## Clearances

Foot lock	0.02 mm
Crankcase	
Model 300	0.2 mm
Model 400	0.25 mm
Oil filter	0.8 mm
Engine cooling system	
Model 300	0.5 mm
Model 400	1.0 mm
Air cleaner	1.0 mm
Draining hole	1.0 mm
Oil box, rear axle and hydraulic oil	20.0 mm

## LUBRICATION

The quality of the lubricant to be used for each part is indicated in the lubrication schedule. In using only good quality lubricants, the tractor will be maintained in perfect working order.

APPROVED LUBRICANTS - ALL TERRITORIES

Category	Grade	Brand	SAE	ISO-VG	AGMA	AGMA	AGMA	AGMA	AGMA
Engine	SAE 15W-40	Shell	Shell Multigrade 15W-40	Shell Multigrade 15W-40	Shell Multigrade 15W-40	Shell Multigrade 15W-40	Shell Multigrade 15W-40	Shell Multigrade 15W-40	Shell Multigrade 15W-40
			Shell Multigrade 15W-40	Shell Multigrade 15W-40	Shell Multigrade 15W-40	Shell Multigrade 15W-40	Shell Multigrade 15W-40	Shell Multigrade 15W-40	Shell Multigrade 15W-40
			Shell Multigrade 15W-40	Shell Multigrade 15W-40	Shell Multigrade 15W-40	Shell Multigrade 15W-40	Shell Multigrade 15W-40	Shell Multigrade 15W-40	Shell Multigrade 15W-40
Gearbox	SAE 90	Shell	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90
			Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90
			Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90
Rear Axle	SAE 90	Shell	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90
			Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90
			Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90	Shell Gear Oil 90
Hydraulic Oil	SAE 46	Shell	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46
			Shell Hydraulic Oil 46	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46
			Shell Hydraulic Oil 46	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46	Shell Hydraulic Oil 46
Fuel System	SAE 30	Shell	Shell Fuel System Oil 30	Shell Fuel System Oil 30	Shell Fuel System Oil 30	Shell Fuel System Oil 30	Shell Fuel System Oil 30	Shell Fuel System Oil 30	Shell Fuel System Oil 30
			Shell Fuel System Oil 30	Shell Fuel System Oil 30	Shell Fuel System Oil 30	Shell Fuel System Oil 30	Shell Fuel System Oil 30	Shell Fuel System Oil 30	Shell Fuel System Oil 30
			Shell Fuel System Oil 30	Shell Fuel System Oil 30	Shell Fuel System Oil 30	Shell Fuel System Oil 30	Shell Fuel System Oil 30	Shell Fuel System Oil 30	Shell Fuel System Oil 30

\*Trademark and design.



**PRE-DELIVERY INSPECTION**

Before delivering the tractor to the customer, the pre-delivery operations described as follows shall be carried out:

- Check engine oil level.
- Check oil level of the gear box, rear axle and hydraulics etc.
- Check steering box oil level.
- Check radiator water level level and bleed if necessary.
- Check oil pressure oil level and fan belt assembly.
- Check tension of the fan belt/serpentine belt.
- Check electrolyte level of the battery.
- Check operation of the engine, exhaust system and PTO-shifting.
- Check condition of the controls and instrument panel.
- Check tire and full inflate (a.p.m. without engine load).
- Check operation of the clutch free travel and maximum disengagement travel.
- Check operation of the power take-off.

- Check tire level of the brake and parking brake pedals.
- Raise ball ball and show point linkage in working position.
- Check electrical connections and condition of wiring.
- Tighten up nuts and bolts if general.
- Check operation of the hydraulic lift.
- Check tightness of wheel nuts and air pressure of the tires.
- Start up tractor and observe its behavior, checking the following:
  - a) Operation of the gears.
  - b) Operation of the clutch.
  - c) Operation of the brakes and uniformity of braking.
  - d) Operation of differential locking.
  - e) Operation of the steering.

**MAINTENANCE**

The good running of the tractor depends on its maintenance. In this chapter all the necessary formalities is given for performing the maintenance

operations on the different components of the tractor.

**MAINTENANCE SCHEDULE****General check every**

- Check the paraffin/oil level of the oil storage.

**Every 50 hours or daily**

- Check engine instrument oil level.
- Check radiator water level.
- Check temperature of the fuel filter.
- Clean the air cleaner (in normal conditions).
- Check the belt wear after changing a wheel.

**Every 100 hours or weekly**

- Clean the air cleaner (in normal conditions).
- Check oil level of the gear box, rear axle and hydraulic oil.
- Check electrolyte level of the battery.
- Remove impurities from the fuel sediment cup.
- General lubrication in the following points:
  - a) Front axle gear pin.
  - b) Brake and clutch pedal shaft.
  - c) King pin bolts.
  - d) Drag link.
  - e) Ball joints of the steering track rod to the steering arms.
  - f) Landing gear.

**Every 150 hours or monthly**

- Test brake efficiency and free travel of the pedals.
- Test clutch pedal free travel.
- Check or adjust alternator belt tension.
- Check tightness of wheel nuts.
- Check or clean and grease front wheel axle splines/bearings.
- Clean and oil accelerator and cut-out (steep terrain) linkage.

**Every 200 hours**

- Change capricious of air engine filter.
- Check working level of level.
- Clean the outside of the radiator fan/cores.
- Clean the two lift flaps.
- Tighten up nuts and bolts in general.

**Every 300 hours**

- Change fuel filter.
- Clean and test injection.
- Tighten up cylinder head and manifold.
- Test and adjust the motor parts and clean the engine or adjusting table.
- Clean the cooling system internally.
- Clean the rear axle/differential.
- Test the adjustment of the steering linkage.

**Every 1000 hours**

- Change the hydraulic oil, greases and seal with oil.
- Clean the hydraulic system filters.

The maintenance operations listed are made regularly.

**BLADE, SHEET METAL AND BODY (Item 2)**

- Always keep body parts clean and repair them as soon as they become damaged or weakened to

**FRONT AXLE AND STEERING (Item 3)**

- Grease the ball joint pin (Fig. 7).
- Grease king pin bolt (Fig. 8).
- Grease the drag link.
- Grease ball joints of steering knuckle to steering arms (Fig. 9).

which are grouped together in each section, are as follows:

- Inspect and clean the fuel tank.
- Check the alternator and electrical system.

avoid rust and maintain the good appearance of the tractor.

- Check or clean and grease the wheel spindle bearings (Fig. 10).
- Test the adjustment of steering linkage.
- Check steering toe of wheel (Fig. 10).



Fig. 7



Fig. 8



Fig. 9



Fig. 10

**ENGINE (Series 4)**

- Check operation of fuel Fig. 13.
- Change operation of fuel if starting Fig. 14.
- Tighten cylinder head and manifold.
- Check and adjust the rocker arm lock Fig. 15.



Fig. 13



Fig. 14

The adjustment of the rocker arm lock when done with a cold engine, is 0.30 mm for both valves. With the engine warm it is 0.25 mm for both intake and exhaust.

- Clean the engine air entering hole.



Fig. 15



Fig. 16

**FUEL FEED SYSTEM (Series 4)**

- Close the air cleaner filter Fig. 17.
- Check the fuel filter sediment cup Fig. 18.
- Clean the air cleaner.
- Remove impurities from the fuel filter sediment cup.

- Clean and oil the watermeter and valve seat (keep correct leakage) Fig. 19.
- Change the fuel filter element.
- Clean and test the injectors.
- Drain and clean the fuel tank.



Fig. 8



Fig. 9

**COOLING SYSTEM (Section 8)**

- Check radiator water level.
- Clean the outside of the radiator grille (Fig. 10).



Fig. 10



Fig. 11



Fig. 12

- Flush out the cooling system (Fig. 13) (Work with plug for the Model 460 the plug is located behind the water intake) (Fig. 13) (Use the drain plug).



Fig. 13

**CLUTCH (Section 1)**

— Grease ball and clutch pedal shaft (Fig. 28).

— Test clutch pedal free travel.

**GEARBOX (Section 2)**

— Check the oil level of the gearbox, rear axle and 8th (Fig. 23). The oil should come up to the level of the plug hole situated on the right side base of the gearbox, behind the float-valve.

— Change the gearbox, rear axle and 8th oil (Fig. 23) using special (Fig. 23) filling hole.



Fig. 28



Fig. 29



Fig. 22



Fig. 30

**HYDRAULIC SYSTEM (Section 3)**

— Check the oil level of the 8th, rear axle and gearbox (Fig. 22).

— Grease 8th axle, right and left (Figs. 28 and 29).

— Change 8th, rear axle and gearbox oil (Figs. 22 and 23).

— Clean the two 8th flares (Figs. 26 and 27). These two flares are to be cleaned with clean gas oil and dried with air.

— Grease the leveling feet (Fig. 24).



Fig. 25



Fig. 27



Fig. 26



Fig. 28

**REAR AXLE (Section 10)**

- Check oil level of the rear axle, gearbox and DR (Fig. 27).
- Clean rear axle bracket located above DR DR (2004).

**BRAKES (Section 11)**

- Inspect the brake and check pedal drift (Fig. 28).

**WHEELS AND TIRES (Section 12)**

- After a wheel change, test the wheel lock nuts.
- Test the tire pressure.

- Change the rear axle, gearbox and DR of (Figs. 27 and 28).

- Test brake efficiency and pedal travel.

- Check the tightness of the wheel nuts.

## ELECTRICAL EQUIPMENT AND INSTRUMENTS

(Section 10)

- Check battery electrolyte level.
- Check or adjust alternator drive belt tension (Fig. 20).
- Inspect alternator and motor BRUSHES.



Fig. 20



**SECTION 2:****SEAT SHEET METAL  
AND BODY****CONTENTS****PAGE**

Seat	1
Specifications	1
Description	1
Removing and installing the seat	1
Disassembly and assembly of the operator's seat	2
Facile-mounted seat	4
Sheet metal and bodywork	6
Specifications	6
Description	6
Removing and installing the front grille	7
Removing and installing the hood	7
Removing and installing exhaust venting	7
Removing and installing the instrument panel	10
Removing and installing the fenders	10
Removing and installing the step plates	11



## SEAT

## SPECIFICATIONS

Type of seat

SINGLE SEAT

Suspension

Hydro springs.

Type of shock absorber

Controlled by shock absorber

## DESCRIPTION (Figs. 1 and 2)

The seat is designed to provide comfort and reduce fatigue of the operator, thereby increasing his work performance. The seat conforms to 4- of plastic foam. The height of the seat back can be adjusted by the wing nuts (A). Control (B) enables the position of the springs to be regulated (C). In accordance with the driver's weight and the irregularities of the ground. The shock absorber (D) softens the return of the springs (C), eliminating any backlash and harshness of the suspension, thereby for the operator to have the pedals and other controls at a distance most in keeping with his own personal stature. The seat is also adjustable laterally. For this purpose the tubes (E) of the seat holder attached to the 10" cross bar elongated. Locken and tighten the set screws into the seat base when set in the most convenient position.



Fig. 1 - Seat

## TO REMOVE AND INSTALL THE SEAT

To remove the tractor seat, procedure is follow:

- Loosen the two screws and the lock nut (A, Fig. 2) and slide the seat forward in the way the head of the lock nut screw is marked.
- Withdraw the two screws and the nut and fit the seat (Fig. 2).

To install the seat, carry out the above operations in reverse.



Fig. 2 - Securing of the seat



Fig. 4 - Removal of the seat.

#### DISASSEMBLY AND ASSEMBLY OF THE SEAT (Fig. 4)

The seat does not require maintenance. If damaged, for any reason, it is necessary to disassemble it, proceed as follows:

Disassemble the following:

- The seat lock (A) by taking off the wing nuts (B).
- The seat lock (C) by loosening its set screws.
- The wing nuts (E) of the springs (D) and their adjuster (F).
- The set screw (G).
- The lock support (H) of the springs (D).
- The bracket adjustment rod (I) and the guide slip (L) of the upper fixate of the shock absorber (P).

- The set screws (O) of the seat (K).
- The lock bolt (M) and its adjuster (N).
- The lock bolt (K).

Once the seat has been taken apart, check the condition of the plastic bearings, rubber strips and other parts, replacing any component found to be defective or which does not offer complete security.

To assemble the seat, carry out the above disassembly procedure in reverse.

Note: - Lubricate the wing nuts (B) with oil or graphite grease.




Fig. 4 - Exploded view of the seat

**SEATER MOUNTED SEAT (Fig. 8)**

The seater mounted seat consists of a safety designed front rail attached to the left handle. To remove or install the seat, it is only necessary to loosen or tighten the nuts which secure it to the upper surface of the handle from the inside.



Fig. 8 — Seater-mounted seat

## SHEET METAL AND BODYWORK

## SPECIFICATIONS

Type of toolwork:

Work with flat hammers and hammers.

## DESCRIPTION (Fig. 8)

The plate shows the assembly of the hood (A), front grille (B), front window (C), instrument panel (D) and the two fenders (E) which are equipped with a coil box.

These parts, which can be very easily removed and installed in a short time, afford protection to both

the operator and the engine. Under no circumstances should the hood be used without these parts in place. Always keep them clean and repair them as soon as they are scratched or damaged to prevent rust and maintain the good appearance of the motor.




Fig. 8—Tractor bodywork




Fig. 7 - Exploded view of the front left seat assembly.

### TO REMOVE AND INSTALL THE FRONT GRILLE (Fig. 2)

To remove the front grille, proceed as follows:

- Remove the two screws (A).
- Pull the front grille (B) forwards and upwards to separate the two guides (C) from their housing in the nose member.

To install the front grille, reverse the above operations.



Fig. 2 - Removing the front grille.

### TO REMOVE AND INSTALL THE HOOD

To remove the hood, proceed as follows:

- Raise the right-hand side of the hood.
- Remove the four screws from both guides.

- Remove the hood assembly. To install hood, reverse the above procedure.



Fig. 3 - Hood attachment screws and guides.





Fig. 10—Removed air filter hood

#### TO REMOVE AND INSTALL THE FRONT DOWNPIPE

To remove the front casing, proceed as follows:

- Remove the front grille.
  - Remove the hood.
  - Disconnect the air cleaner-to-intake hose (A, Fig. 10).
  - Disconnect electrical connections of the following:
    - a) the regulator
    - b) the fans, as well as its earth wire
    - c) the front right headlight
  - Remove the air pre-filter (Fig. 10).
  - Remove the cleaner intake elbow (Fig. 10).
  - Remove the fan side seal-to-radiator seal around (Fig. 10) be careful with the two rubbers, which act as plastic absorbent.
  - Remove the fan cover to check set screws (Fig. 10).
  - Partially loosen the two radiator set screws.
  - Pull the cover forwards, disengaging it from the radiator (Fig. 10).
- Once the casing has been separated from the radiator, remove the following:
- a) the regulator
  - b) the air cleaner
  - c) the fan
  - d) the right and left headlights and their earth brackets.

To install the front casing, carry out the above procedure in reverse order. Do not forget to tighten the radiator set screws and to place the two rubber washers in the side bolt points between cover and radiator.



Fig. 17 - Removal of brake shoe with tool



Fig. 18 - Removal of seat or modification with set of tools



Fig. 19 - Removal of seat to chassis with tool



Fig. 20 - Taking off the front seat

### TO REMOVE AND INSTALL THE INSTRUMENT PANEL

To remove the instrument panel, proceed as follows:

- Remove the bezel.
- Loosen the handle control lever.



Fig. 15 - View of instrument panel

- Remove the instrument panel and fasten all screws (Fig. 16).

- Pull the panel forward while sliding it out (Fig. 16).

To install the panel, carry out the above procedure in reverse order.



Fig. 16 - Removal of panel

### TO REMOVE AND INSTALL THE FENDERS

To remove the fenders, proceed as follows:

- Disconnect the wiring of the lights in the recess for box (Fig. 17), located on the left side of the rear axle.
- Remove the fender-to-frame set screws (Fig. 18).
- Remove the two set screws of each fender, located inside of the rear frame (Fig. 18).
- Take off the fenders (Fig. 20).

To install the fenders, carry out the above procedure in reverse.



Fig. 17 - Connections



Fig. 11 - Remove stop plate and screws



Fig. 12 - Remove and remove



Fig. 13 - Trimming off the fender

**TO REMOVE AND INSTALL THE STOP PLATE**

To remove the stop plate, carry out the following procedure:

- Remove the stop plate-to-fender set screws (Fig. 11).
- Remove the stop plate-to-trunk set screws.
- Remove the stop plate.

To install the stop plate, carry out the above procedure in reverse order.




Fig. 27 — Panels and seat plates

## SECTION 3:

# FRONT AXLE AND STEERING

### CONTENTS

	PAGE
Front axle	1
Specifications	1
Description	1
Front end adjustment	1
Tire fit	2
Removal and installing the front coil-over steering assembly	2
Removal the front wheel hub assembly	3
Installing the front wheel hub assembly	4
Removal and installing a shock absorber	5
Removal and installing the center beam of the front axle	6
Steering	9
Specifications	9
Description	11
Removal and installing the tractor steering box	12
Disassembling the steering box	12
Assembling the steering box	14



Publication SP-500-6-87  
See Bulletin 7-78

## FRONT AXLE

## SPECIFICATIONS

Swivel angle	0°
Castor angle	30° 30'
King-pin inclination angle	11°
Toe-in	0 to 6,35 mm
King-pin diameter	27,30 to 28,25 mm
King-pin bushing inside diameter	30,00 to 30,50 mm
Stem of center pivot pin	47,00 to 47,60 mm
Center pivot pin bushing inside diameter	47,00 to 47,60 mm

## DESCRIPTION

The front axle is of the floating type and is mounted over the cross member with a pivot pin.

The cross member is joined to the rear axle tube and is mounted in the engine with four bolts in each rail and six bolts in the cross member itself.

The front axle is made up of a steering knuckle (see of quadrangular cross-section and individual side members, joined to the housings of the shingles. The side members can be locked to the center beam in different positions, thus making it possible to obtain different track widths.

## ADJUSTMENT OF THE FRONT TRACK

(Figs. 1 and 2)

The side axle extensions can be moved in graduation steps of 61 mm per side, which provides the following track bread widths: 1,29 m, 1,38 m, 1,46 m, 1,55 m, 1,63 m, 1,71 m and 1,80 m.

To adjust the front track proceed as follows:

- Raise the front end of the tractor.
- Loosen the two straps (2) which secure the ends of the lead rods (1) to the lock bolts (3) of

the drag links (2). These clamps have a lock, a shoulder nut and a safety cotter pin.

- Take out the bolts which secured these their respective nuts (1), move each extension (2) to the center beam (3).
- Place the side extensions at the desired track spacing at the same time as the necessary adjustments are made on the track rods. For this purpose, the lock bolts (3) have machined grooves

to the different road conditions. These grooves fit into the sleep holes and provide for self-alignment of the track coils.



Fig. 1 - Front track adjustment

— Since the track adjustment has been worked out, freely tighten all nuts and bolts and cover the tractor to the ground.




Fig. 2 - Front track adjustment

## NOTE

The wear of the track wheels of the SP122-200 and 400 tractors, complies with a permanent pre-arranged/construction standard, according to the design characteristics of both units. Its specific value is

from 0 to 0.20 mm. An can be gathered from the foregoing, the toe-in is not altered by the different track adjustments since there is a different track coil length for each model setting.

## TO REMOVE AND INSTALL THE FRONT AXLE CROSS MEMBER ASSEMBLY (Figs. 3 and 4)

(Figs. 3 and 4)

The operations involved in removing and installing the front axle-cross member assembly should be carried out in the following order:

- Place a chock under the tractor engine.
- Place a wedge between the front axle control beam and the oil on both sides.
- Remove the hood.
- Disconnect the steering shaft at its connection with the drag link.
- Drain water from engine and radiator.
- Remove upper and lower radiator-to-engine hoses.

- Remove all clearance-angle intake manifold hoses.
- Take the front grill off the tractor.
- Disconnect the battery terminals.
- Take out the eight bolts that secure the top side to the engine.
- Take out the six bolts that secure the cross member to the engine.
- Pull the front sub-frame assembly forward to disengage it from the engine.
- Check up the assembly compatibility and remove



- a) The rollers.
- b) The battery, brackets moving the front head-light brackets backwards.
- c) The radiator cover, air blower and fan assembly.

To install the front axle-ross member assembly, follow the above procedure in reverse order.



Fig. 3 - To remove the front axle-ross member assembly.




Fig. 4 - Front axle-ross member assembly.

### DISASSEMBLY OF THE FRONT WHEEL HUB ASSEMBLY (Fig. 8)

To carry out this operation, proceed as follows:

- Take the front of the tractor and remove the wheel from the hub.
- Remove the hub cap (M).
- Pull out the outer pin (K).
- Remove the sealbed nut (C) and the washer (D).
- Disassemble the following from steering column: The hub (F) together with the bearings (E) and (G) and the retainer (L).
- Remove the following from the hub: the ball races (I) and (J) of both bearings.



Fig. 8 - Front hub assembly

### ASSEMBLY OF THE FRONT WHEEL HUB ASSEMBLY

- Place the ball races in the hub.
- Set the inner bearing in place (E).
- Fit back the retainer (L) with the ball race towards the inside of the hub, fitting it onto the step located inside of it.
- Partly fill the hub with grease and mount it on the steering column.
- Assemble the outer bearing (G), the washer (H) and the sealbed nut (I). Tighten the sealbed nut to 8.5 kg and then loosen it approximately half a turn so that the hub has an axial play of 0 to 0.25 mm.
- Coat a new outer pin (K).
- Fit the hub cap with grease, set it in place and mount the wheel.

### TO REMOVE AND INSTALL A SIDE EXTENSION OF THE FRONT AXLE (Figs. 6, 7 and 8)

The same procedure that is followed when removing a side extension may also be used to install when changing a steering wheel.

The procedure is as follows:

- Slide the front of the tractor and remove the wheel.

The following applies when changing a steering wheel (Fig. 6):

- Remove the hub assembly as described on page 4.
- Put chocks under the steering wheel or steering wheel hub assembly to prevent them from falling to the ground while carrying out the following operation.
- Remove the nut and bolt (A) which secure the drag link (B) to the kingpin and disengage both parts.
- Take out the king pin nut (C).



Fig. 6 - Removing a steering wheel

- Remove the disks from under the steering wheel or steering wheel-hub assembly and their own weight will cause them to slide out of their housing in the side extension. Take out the bearing (D).

At this point the steering wheel is left free. To install it, carry out the above procedure in reverse order.

When removing the side extension, the trouble of separating the hub from the steering wheel can be avoided by disengaging them together and proceeding as follows:

- Remove the three bolts (E) which secure the beam side extension.
- Take out the side extension.

**NOTE:** - Before mounting a side extension, make sure the inside bushings of the king pin housing and the grease cup are in good condition, replacing them if necessary. To install the side extension, mount the procedure described above.



Fig. 7 - Removing a steering wheel-hub assembly




Fig. 7 - Removing side spring

**TO REMOVE AND INSTALL THE FRONT JOCKEY CENTER BEAM (Fig. 8)**

To remove and install the center beam of the front axle, proceed as follows:

— Raise the front part of the tractor and shock up the center beam, under both chassis rails.




Fig. 8 - Removing and installing the front axle center beam

- Disconnect the steering arm at the drag link.
- Disconnect the track rod at both ends.
- Remove ball's wheels.
- Take out the air side extension and wheel.
- Remove both of the side extensions together with their steering knuckle and hubs.
- Loosen the nut and set screw of the center beam pivot pin.
- Withdraw the pivot pin bearing vertically upwards for center beam and disengage it.

**NOTE.** - Before removing the center beam, check the pivot pin bearing loading and the grease cap, refilling them if necessary.

To install the center beam, follow the above procedure in reverse order.

**NOTE.** - When installing the pivot pin (Fig. 3-16), leave a clearance in IM of 0.079 to 0.254 mm. Tighten the nut IM to a torque of 2.7 to 3.5 kg. The thread of the screw IM must be completely free of grease and be given a coating of vasoline before assembly, applying a torque of 3 to 4 kg.




Fig. 3-16 - Shrouding of pivot pin.

## STEERING

## SPECIFICATIONS

Type	Steer and run self-aligning ball system
Center	20:1:1
Oil capacity	1.8
Lubricant	SAE 90 EP
Worm machining	Right-hand thread
Worm bearings	Two radial ball bearings
Number of upper worm bearing balls	18 (8.82 mm (3/16"))
Number of lower worm bearing balls	18 (8.82 mm (3/16"))
Number of axle worm nut balls	36 (7.92 mm (5/16"))
Worm adjusting washers	Steel of 4.1 (5/16) and 5.25 mm
Steer nut travel	30"
Steer rack travel	30"
Steering column gear	Paper of 8.1 mm
Steering wheel turn from lock to lock	6.8

DESCRIPTION Fig. 10




Fig. 10 - Steering assembly

The steering mechanism is of the high performance recirculating ball type and requires very little attention aside from normal maintenance.

Two ball bearings (A) support the shaft. They are located at the upper and lower ends of the worm shaft (B). The adjustment of these bearings is by means of adjuster (C), located between the steering column flange (D) and the cover (E). At the upper end of the steering column a bearing (F) is used, not only as bearing neck for the worm shaft.

The worm shaft drives the steering rack (G), which consists of the rack itself and the transfer tube, held together by the transfer tube lock. The helical grooves in the steering rack and worm worm together to form a guide. The ends of the guide are connected by means of the transfer tube, providing a connection that is subject to very low belt stresses.

When the worm shaft turns the balls in the guide are displaced by its movement, passing through the transfer tube and entering the other end of the guide. Only the balls are in contact with the worm.

The lock (H) of the worm (I) is coupled to the control end of the steering rack. The control end which stands out from the steering rack, actuates the roller (L) which moves longitudinally along the groove in the lower face of the side cover (J).

The function of the roller is to ensure that the steering rack recirculates recirculating rollers in a straight line, parallel to the worm shaft, and for the effect of increasing the steering ratio when the steering rack moves away from the position in which the wheels are steered to the tractor.

The loading of the worm with the steering rack is required by means of the adjusting screw (K) to maintain the outside of the steering rack side cover.

### TO REMOVE AND REINSTALL THE TRACTOR STEERING BOX

To remove the steering box, proceed as follows:

#### Remove:

- The hood.
- The clutch lever.
- The steering wheel, after that working its position.
- The rubber seal and indicator panel, when

removing the electrical connections and the brake-water cable.

- The fuel tank.
- The throttle linkage.
- The steering gear tube (part A2-P 102/11).
- The steering box.

To install the steering box in the tractor, carry out the above procedure in reverse order.

### DISASSEMBLING THE STEERING BOX

Once the steering box has been placed on the bench and its accessories disassembled, disassemble it as follows:

#### Remove:

- The side cover and its gasket (Fig. 11).

- The steering sector and roller through the side cover housing (Fig. 12).

- The steering rollers and its gasket (Fig. 13) in well extreme adjustment slots. They will be needed when installing the steering box again.

- The worm shaft, raising it high enough to be able



Fig. 11 - Removing the side cover



Fig. 12 - Removing the worm



To remove the thrust washer, the upper bearing race and the tie balls. Withdraw the worm shaft through the axle cover housing (Fig. 14) together with the steering nut and the tie balls of the lower bearing.

- The worm shaft steering nut (Fig. 15), loosening it completely. Be careful with the tie balls housed in the guide and transfer ribs.

Once the steering box has been disassembled, check the plastic bearing in the upper part of the steering column, the bushing in the lower shaft housing, the rollers on the same side and the other components of the assembly. Replace all parts which are defective or wear with new ones.



Fig. 15 — Removing the worm shaft



Fig. 14 — Removing the column



Fig. 16 — Removing the steering nut

## ASSEMBLY OF THE STEERING BOX

Once all parts of the assembly have been inspected and cleaned, the steering box should be assembled as follows:

- Fit the steering nut on the worm, introducing the balls into the guide and wedge slots (Fig. 16).



Fig. 16 - Fitting the steering nut on the worm.

- Place the balls in the bearing case. A thin coating of clean grease will help to maintain the balls in the correct position.
- Insert the worm shaft with the steering nut through the side cover housing, seeing it in such a way that the lower end of the worm shaft is placed between the balls of the lower bearing.

Taking care not to move the worm shaft so that the balls of the lower bearing are not displaced, proceed as follows:

- Set the upper ball race onto the worm shaft with the ball guide downwards, and fit it in place in the box. After the application of a thin coating of clean grease, place the balls in the race guide and insert it into the housing.

- Set the thrust washers on to the worm shaft and locate in the upper ball race.

- Set the piston gasket on the worm shaft and assemble the adjustment spring and steering return, securing it to the box cover with its screws.

While tightening the steering column set screws, take the worm shaft by hand. If it is too soft, put in low resistance grease. If, on the other hand, the worm shaft is too free, increase some adjustment slots.

After the steering column is fully tightened, the worm shaft should turn quite freely.

- Mount the center at a 90° angle with respect to the worm, so that the center line bisects the vertical end of the steering rack.
- Fit the roller on the vertical edge of the steering nut, which extends out from the bottom fork.
- Adjust the side wear, ensuring that the roller fits into the longitudinal groove on the inside face of the cover.

Once the cover has been assembled, run the worm shaft so that the water is in a straight position, that is, in the middle of its travel. Check to see if there is any play in the sector shaft end. If there is any play, or if it is too soft, adjustment is necessary. The adjusting screws and its counter nut are located on the outside face of the side cover.

- Fit the steering box with the correct amount of oil at the recommended viscosity.

**SECTION 3:****FRONT AXLE AND  
STEERING****CONTENTS**

	<b>PAGE</b>
Front axle	1
Specifications	1
Description	1
Front wheel adjustment	1
Trails	2
Removing and installing the front axle cross member assembly	2
Removing the front wheel hub assembly	4
Installing the front wheel hub assembly	4
Removing and installing a side extension	5
Removing and installing the center beam of the front axle	6
Marking/steering	9
Specifications	9
Description	11
Removing and installing the tractor steering box	12
Disassembling the steering box	12
Assembling the steering box	14
Hydraulic steering system	15



Publication SP 322-EXP 1  
2nd Edition 01.78

## HYDROSTATIC STEERING SYSTEM

## CONTENTS

Item	Page
Specifications	17
General description	20
Operation	23
Maintenance (200 tractor)	25
Maintenance (400 tractor)	26
Washing the system	27
Removing and refitting the hydraulic pump (200 tractor)	27
Disassembling the hydraulic pump (200 tractor)	28
Assembling the hydraulic pump (200 tractor)	29
Removing and refitting the hydraulic pump (400 tractor)	30
Checking the safety valve setting pressure	31
Disassembling, checking and assembling the hydraulic pump (400 tractor)	31
Disassembling the hydraulic oil reservoir (200 tractor)	34
Disassembling and assembling the safety valve (200 tractor)	34
Removing and refitting the hydraulic unit (200 and 400 tractor)	35
Disassembling the hydraulic unit (200 and 400 tractor)	38
Assembling the hydraulic unit (200 and 400 tractor)	39
Disassembling the steering arm	41
Assembling the steering arm	43
Fault finding chart	46

## HYDROSTATIC STEERING SYSTEM

## SPECIFICATIONS

## Hydraulic line

Outer hydraulic length	476.5 mm
Dial	57 mm
Outer diameter	32 mm
Inner hydraulic length	276.6 mm
Dial	35 mm
Outer diameter	35 mm
Outer seal-off length	541.6 mm
Stroke	228 mm
Diameter	26 mm
Front and ball joint threaded length	30 mm
Flange diameter	55 mm
Collar - rear end securing ball joint	41 ± 0.05 mm
Collar - rear to rear thread	107 mm
Rear end, working pressure	100 kg/cm <sup>2</sup>

## Steering column

Dial length	476 mm
Diameter	36 mm

## Hydrostatic unit

Hydrostatic unit output (steering)	30 L/min (flow, localized area for 120 and 170 cc/L)
Stroke (steering)	3.4" (88 mm)
Leakage control valve (steering)	MA-301 (300-900-100)
Hydrostatic unit connecting column fastening	300-10 LINC
Torque (steering)	15.7 mm (min.)

## Steering wheel

Diameter	300 mm
----------	--------

1" of torque from stop to stop (steering with 30-cc/min flow, unit)

8 towards the left	8 towards the right
1" of torque from stop to stop (steering with 120-cc/min flow, unit)	8 towards the left
	3.5 towards straight

## Hydraulic oil reservoir capacity

300 Tractor	1.0 liter
400 Tractor	1.0 liter

## Steering pump flow output

300 Tractor	30 L per minute
400 Tractor	12 L per minute at 1,000 r.p.m.

## Safety valve setting pressures

300 Tractor	30 kg/cm <sup>2</sup>
400 Tractor	30 kg/cm <sup>2</sup>

## Recommended hydraulic oils

Brand	Company
-------	---------

Hydraulic HLP-45	BP
Tellus 27	Shell
Isdath 28	BP
OTI 26	BP
SAE 10	BP
	Green (this is the type of oil used to reactivate an assembly line)

## Tightening torques

Physical securing nut	17 N·m
Steering arm rear support bracket securing balls	11.5 to 13.0
Collar - rear to steering column screws	4.0 to 5.0
Hydrostatic unit to tractor frame securing screws	5.5 to 7
Hydraulic oil reservoir support bracket fastening screws	5 to 6




Fig. 37 - Hydraulic steering system arrangement - 00 1131010




Fig. 20 - Hydroassist steering system arrangement - 600 Trucks

## GENERAL DESCRIPTION

## 300 Tractor

The hydraulic steering system fitted to 300 model tractor comprises the following components:

1. Gear type hydraulic pump (A), located at the engine right hand side towards the front end, it is driven by a gear in the timing case.
2. Oil reservoir (B), containing the hydraulic oil (or synthetic oil) in the steering circuit, incorporating a safety valve (C).  
This reservoir is fitted at the engine right hand side, towards the rear and top part, in front of the fuel tank.  
The oil filter is also located in this reservoir. The oil level indicator is located in the oil filler cap (D).
3. Hydraulic unit (E) attached to the bottom end of the steering column and secured to the frame body by means of a support bracket.  
The hydraulic unit, the hydraulic pump and the steering arm are lubricated with hydraulic oil.



Fig. 30 - Hydraulic unit arrangement - 300 Tractor



4. Dual action steering ram (P) with a single stem, fitted on the tractor L.H. side.  
The ram rear ball joint is attached to the gearbox housing by means of a bracket (Q). The front end ball joint is secured to the steering arm.  
The ram houses two oil inlet hydraulic pipe unions coming from the hydrostatic unit which will determine the steering towards either side.

#### 460-Tractors:

The hydrostatic steering system fitted to 460 tractors comprises the following components:

1. Gear type hydraulic pump (A), incorporating the hydraulic oil reservoir (B), located at the engine L.H. side front end. It is driven by a gear in the timing case.
2. The oil reservoir (B) incorporates an oil filter and a safety valve. The oil filler plug (C) is also used to check the oil level in the reservoir.
3. Hydrostatic unit (F), attached to the steering column bottom end and secured to the tractor frame by means of a bracket. Hydraulic pipes connect the hydraulic oil pump to the steering ram.
4. Dual action steering ram (D) with a single stem. Its rear end ball joint is attached to a bracket (E) and the front end ball joint is secured to the steering arm.




Fig. 20 — Location of the steering ram fitted to 350 Tractors




Fig. 21 — Hydrostatic unit arrangement - 460 Tractors

The basic hydrostatic steering unit is a set of gears the function of which is to provide a steady constant oil flow to the steering rack and, in the case of an emergency, to act as a hand pump.

The unit consists of:

- A rotary motor containing a fixed outer ring (B) with seven loxes, and an inner rotor (C) with eight loxes.
- A two-element, four-way rotary distributor valve: the two elements are an inner sleeve (D) and an outer sleeve (E). The inner sleeve is connected directly to the steering wheel.
- A valve shaft (F) that mechanically connects the inner sleeve (D) to the outer sleeve (E), thus providing internal recirculation.
- A check valve (G) to prevent reverse flow when oil pressure connections.





Fig. 22 - Cross-section view of hydrostatic steering unit

- Locking nut
- Distributor unit body
- Inner rotor
- Rotary valve inner sleeve
- Rotary valve body
- Valve shaft
- Check valve
- Rotor

Fig. 23 - Hydraulic steering unit components

- Return nut
- Nut for lock ring
- Lock ring
- Inner sleeve
- Outer sleeve
- Valve shaft
- Check valve
- Inner rotor
- Rotor
- Rotary valve inner sleeve
- Distributor valve inner sleeve
- Rotary valve body
- Valve shaft
- Check valve
- Rotary valve body



## OPERATION

1. The DPF0-360 and 480 tractors equipped with the hydraulic Steering Unit, have an independent hydraulic circuit fitted with an oil reservoir.
2. 400 DPF0 Tractors incorporate the hydraulic oil reservoir on the hydraulic pump.

On 200 6000 Tractors, the hydraulic oil reservoir is located on the engine right hand side towards the rear lap-end. Connection from the reservoir to the pump is achieved through hydraulic pipes.

3. Safety valve setting pressure must be of 50 kg/cm<sup>2</sup> for both tractors models.
4. The uncontrolled oil supplied by the pump through the safety valve freely goes to the hydraulic unit by means of two steel pipes, i.e. a return pipe and a pressure pipe.
5. When the steering wheel is inoperative and the control valve is in neutral position, the small control valve on the lower sleeve connects with the steel tubes on the rotor device, thus allowing a free circulation of oil through said tubes, returning to the reservoir under action.




Fig. 26 - Oil circulation in steering

- A - Oil supply line
- B - Leak return
- C - Oil return line
- D - Oil suction line

8. When turning the steering wheel the valve ports and cone sleeves turn the one in respect of the other. The cone sleeves leading to the cylinder ports progressively open by an approximate rotation of  $15^\circ$ . These sleeves are fully open by an approximate rotation of  $90^\circ$ . After a rotation of approximately  $90^\circ$  the conical ports are closed.

Oil circulation through gear will cease.

9. After gear rotation.
10. A flow volume will directly proportional to the steering wheel angular movement on the steering cylinder, to turn the front wheels in the desired direction.
11. The force resistance load from the rear gear in the valve outer sleeve is such that the rigid service valve ports of steering gear are closed when the angular movement of the steering gear coincides with that of the steering wheel.




Fig. 21 - Hydraulic power steering of steering gear (right hand turn)

- 1 - Oil pressure line to pump  
 2 - Oil pressure line to cylinder  
 3 - Oil pressure line  
 4 - Oil pressure line




Fig. 22 - Hydraulic power steering of steering gear (left hand turn)

- 1 - Oil pressure line to pump  
 2 - Oil pressure line to cylinder  
 3 - Oil pressure line  
 4 - Oil pressure line

## MAINTENANCE

## 800 Tractor

1. Every 30 hours of operation at 800, lubricate the rear end ball joint with an adequate multi-purpose grease, through nipple (A).

Fig. 27 - Hydraulic cylinder rear axle/steering  
800 Tractor

- A - Cylindrical
- B - 5/16" nut and grease nipple



2. Every 200 hours of operation, check oil level in the steering oil reservoir. Whenever necessary, refill with good quality oil, see Specifications on Page 15.

Fig. 28 - Checking oil level - 800 Tractor

- C - Dipstick
- D - Cover and oil filling screw
- E - Oil reservoir



3. Every 1000 hours of operation or when fabricating the spring, flush the entire steering circuit and refill with new oil.

Also change the hydraulic filter 800 filter inside the reservoir. Filter oil must be of an adequate quality, see SPECIFICATIONS on page 15.

**NOTE:** When adding oil to the reservoir or changing filter check oil and examine steering lines. Stay alert for the usual road wear conditions/straps.

Fig. 29 - Changing oil filter - 800 Tractor

- F - Reservoir lid
- G - Filter housing
- H - O-ring seal
- I - 1/2" nut




## MAINTENANCE

## Oil Tankers:

1. Every 10 hours or daily, lubricate the steering gear and ball joint through nipple (2). Use multi-purpose grease.
2. Every 200 hours of operation, check the hydraulic pump oil reservoir (3) level, by following the procedure outlined below:
  - Shut the engine and turn the steering wheel and turn towards the L.H. side.

Fig. 21 - Hydraulic oil reservoir and venting

- A - Cylinder body  
B - Fan belt and power chain



- Keep the engine running for 20 seconds.
- Remove the filler plug (2). The oil level must reach up to the filler mouth lower limit (1) or 2 and be checked.
- Refill the filler plug. Start the engine and keep it running for several three minutes.
- Remove the filler plug again and check the oil level until it is up to the required to reach the correct level.
- Refill the filler plug once more and tighten to 1.5 kgf torque.

Fig. 20 - Checking operating reservoir oil level

## Oil Tankers:

- 1 - Oil reservoir  
2 - Oil filler and breathing

2. Every 1000 hours of operation, change the oil separator oil filter element as per the following instructions (Fig. 22):
  - Place indicator steel container under the reservoir.
  - Remove the nut (3).
  - Remove the separator (4).
  - Remove the element (5).
  - Remove the collar pin (6).
  - Remove the washer (7).
  - Remove the spring (8).
  - Remove the washer (11).
  - Remove the nut (9).
  - Remove the filter element (10) and discard. Clean all components in petrol and dry them.
  - Remove the "O" ring (12).
  - Assemble the elements by reversing the above procedure except for:
    - a) Fit a new "O" ring and a new filter element.
    - b) Reservoir nut must be tightened to 3 kgf ft.
    - c) Fill the reservoir and check that level is correct.



Fig. 22 - Exploded view of reservoir and filter

**BLEEDING THE STEERING SYSTEM****400-Tractor**

1. Remove the filler plug.
2. Fill the pump reservoir with fluid all up to the filler tube lower limit.
3. Refill the filler plug and tighten to 1.0 kgf m.
4. Start the engine and keep it at 800 r.p.m. for 30 sec. approx.
5. Turn the steering wheel from stop to stop and from left to right and from right to left.
6. Stop the engine and refill the reservoir.
7. Start the engine and keep it at 1,200 r.p.m. approx.
8. Repeat operation 5 above.
9. Turn the steering wheel at the L.H. stop and keep it there for about 10 sec. Repeat the operation with the steering wheel turned to the R.H. stop stop (When the steering wheel is held against either stop the safety valve cut off fluid while in operation).
10. Repeat the operation under 5, above, three times.
11. Stop the engine, check for leaks at all unions and repeat the sequence from 1 to 10.
12. Loosen the unions on the steering ram slightly to permit oil to rise right from ball joints the top. Turn the steering wheel from stop to stop while the engine is running and tighten the unions completely.

**300-Tractor**

1. To bleed the steering system on 300 tractors follow the procedure outlined in item 12, above.

**REMOVING AND REFITTING THE STEERING PUMP ON 300-TRACTORS**

1. Loosen out the pressure outlet pipe union (B).
2. Loosen out the suction pipe union (C) letting the oil drip into an adequate container.
3. Disconnect the retaining screws (M) and pull out the pump assembly (E) from its housing in the steering case.
4. Refit the pump by reversing the above stated procedures and brush the oil suction pipe and outlet pipe being not to change their original fitting profiles.



Fig. 12 - Bleeding the steering system




Fig. 14 - Removing the steering pump from 300 - Tractor

### DISASSEMBLING THE SPINNING PUMP ON TO INDICATORS

1. Strip the locking washer (4) and remove the nut (2) and locking wash (3) securing the radial gear (2) to the pump pressure driving gear shaft (3).
2. Detach the radial gear from the gear shaft. Tap the gear base with a plastic hammer or use a suitable puller if required.
3. Remove the woodruff key (5) from the shaft.
4. Remove the right vertical head seal screws (6) and washers securing the pump cover (8) to the pump body (4).
5. Separate the cover from the body. Where necessary the oil seal can be removed from the cover by carefully driving it out with a suitable steel brush etc.
6. Extract the tapered V-ring (9) from its bearing groove in the pump body, and withdraw the rubber O-ring (1) and rubber O-ring washers (2) from the front bronze bearing (10). Separate the latter from the gear, taking care not to turn the shaft beyond cover (8).
7. Withdraw the pump gears (11 and 12) and the rear bronze bearing (1).
8. Examine the bearings for signs of seizure or scoring on the face or journals. Light wear scoring can be removed by careful lapping on a surface plate, using V-grade emery paper and suitable lubricant.
9. Examine the teeth for wear in the gear mating zone. If the wear is more than 0.1 mm on the addendum, the teeth must be replaced.
10. Examine the gears for excessive wear or damage on journals, flats or both. Run out across the gear face to the tooth edge should not exceed 0.025 mm. The gear journals can, if required, be lightly polished with V-grade emery paper to remove wear marks. The gear face may be polished by sandblasting the emery paper between the gear and a steel bearing and rotating the gear.
11. All rubber seals, oil seal washers and V-rings should be replaced when assembling the pump.



Fig. 11 - Exploded view of spinning gear drive hydraulically operating points

- |                           |                            |
|---------------------------|----------------------------|
| A - Pump body             | I - Rear bearing           |
| B - Pressure driving gear | J - Pressure driving gear  |
| C - Rear bearing          | K - Oil seal O-ring washer |
| D - Pressure oil seal     | L - Tapered washer V-ring  |
| E - Tapered V-ring        | M - Pump cover             |
| F - Intermediate washer   | N - Locking washer         |
| G - Woodruff key          | O - O-ring seal            |
| H - Radial gear           |                            |



### ASSEMBLING THE STEERING PUMP 320 TRACTOR

The steering bearing must be assembled in exact relationship to the gear and to the housing in the pump body or body. To this end, when disassembling the pump the components should be arranged on the work bench in accordance with their original mounting position (see Fig. 35).

Carry out a thorough check with tolerance or permit (specified) when reassembling the pump.

1. If the oil seal has been retained previously, insert a new double lip oil seal in the pump cover. The oil seal can be driven in by using a suitable sized bronze drift.
2. Fit the rear bearing (2) into the pump body (A). Care should be taken to distinguish these bearings from the front ones, which are identified by the small steps in the front edge of their flaps, mounted to locate the rubber seal on the shaft (2).
3. Assemble the pressure driving gear (3) and driven gear (4) into their respective bearing in mesh with each other. Be careful not to lower the original mounting position of the driven gear, so as to avoid interference of tooth drive sides.
4. Fit the front bearing (5) onto the gear journal and insert the rubber sleeve (6) between them.
5. Fit two rubber brush washers (7) and rubber rings (8) on the front bearing, ensuring that the rubber rings seal correctly around the washers.
6. Fit a new S-shaped (9) ring (9) into the groove in the pump body (A).
7. Assemble the pump cover (B) to the pump body (A) taking care not to damage the oil seal when passing the driving shaft (10) through. Fit the eight screws and washers (11) and tighten evenly to 2.8 kg (28 lbs. ft.). An accurate torque wrench must be used for this operation, to ensure that this torque figure is not exceeded.
8. Replace the endshaft key (12) in the pressure driving gear shaft and assemble the ball race (13) to the shaft.

9. Place a locking washer (14) onto the shaft and insert the single roll into the groove in the gear. Turn on the steering oil K2, tighten fully and lock the nut with the main lock of the locking washer.

2

**REMOVING AND FITTING THE STEERING PUMP, 400-TRACTORS**

1. Place a suitable steel container beneath the tractor to collect the oil from the steering circuit.
2. Loosen nut (1) before and nut (2) after (3) and (4), respectively.
3. Loosen nut (5) across (6) securing the pump body to the timing gear.



Fig. 20 - Removing the steering pump - 400 Tractor

- 1 - Securing nut
- 2 - Nut after nut
- 3 - Pressure plate nut

4. Release the pump (7) and remove (8) steering (9) from the tractor.
5. Carry on removing the steering procedure correct for
  - Fit a new sealing gasket between pump flange and timing case cover.
  - Fill the reservoir (10) with oil.
  - Bleed the system (see page 27).
  - Check the whole system for leak-proof mounting.



Fig. 21 - Removing the pump and oil reservoir assembly from 400 Tractor

### CHECKING THE SAFETY VALVE SETTING PRESSURE AND FUNCTIONING

1. Start the engine and leave it running at 1,500 r.p.m. with the steering wheel turned right to stop, until the oil temperature reaches 50° C. Stop the engine.
2. Increase the pressure until just after off the pump and tighten a pressure gauge close before to its housing.
3. Start the engine.  
The safety valve must release pressure and show a pressure reading of 50 kg/cm<sup>2</sup> on the gauge with the engine at 1,500 r.p.m. speed.
4. If the pressure reading is other than the specified check the system as follows:
  - Drain the system.
  - Remove the reservoir.
  - With a screwdriver drive the regulating screw in or out to increase or decrease the pressure, respectively.

**Remarks.** - Normally the regulating screw is adjusted by a welding spot to prevent pressure setting alteration.

- Refill the reservoir.
- Refill with oil through in the pressure gauge connection.
- Start the engine and check that the pressure reading is 50 kg/cm<sup>2</sup>.



Fig. 28 - Drawing safety valve pressure setting



Fig. 29 - Safety valve pressure setting regulating screw

- A - Oil filter housing guide
- B - Safety valve spring




Fig. 30 - The inner view of the reservoir, safety valve and pump

- 1 - Pinion drive gear
- 2 - Drive gear
- 3 - Crown gear
- 4 - Safety valve
- 5 - Oil filter
- 6 - Oil reservoir

**DISASSEMBLY, INSPECTION AND REASSEMBLY OF STEERING PUMP, 485 TRACTOR**

**Tools/Items:**

1. Remove the screws and filler assembly from the pump body (see Item 3 on page 30) and place the pump body in a suitable vice.
2. Loosen and fit safety valve plug (2) along with its sealing washer.
2. Loosen and fit filler bearing guide (2) along with its sealing washer.
4. Remove the "O" ring (3) sealing the pump to eccentric mounting from the body (3).
5. Turn the pump mounting position on the workbench vice.
6. Straighten out the washer (4) holding the nut (5).
7. Loosen and fit the nut (5) and remove along with washer (4).  
**Remark:** - Lock the gear in order to loosen the nut.
8. Remove the input gear (6) with a standard gear puller.
9. Remove the gear (6) and the washers (4) (5).
10. Drill a fitting mark on the pump body (1) and the eccentric (8) to make the re-assembly operation easier.
11. Loosen and fit around the (9) "Wiper" screw (10) and washers, securing the end plate (11) to the pump body (3).
12. Remove the long ring (12).

12. Remove the "O" rings (13) and the O-ring washers (14).
13. Remove the eccentric cover (15).
13. Remove the bearing (16) from the shaft gear shaft.
16. Remove the bearing (16) from the driver gear.
17. Remove both the drive (17) and the idler (18) gears.
18. Remove the oil seal from the end plate (19) and fit a new one.

**Checks:**

Check the bearing for wear. Carefully inspect the lubrication grooves and fit of the lip(s) between the two shaft holes. Any scoring or damage to the shaft may cause important leaks.

Usually on servicing, the bearings must be pulled out and inspected by run ones. However, if run bearings are not available, the sealing ones may be re-used, fitted loosely if minor scoring are observed. Follow them as per the following instructions: Place grade "O" emery paper soaked in paraffin on a flat surface. Polish the surface by sliding the bearing in a circular pattern. Check that the bearings can move freely inside the pump housing. If so needed, polish the bearing polishing surface.

After polishing, thoroughly clean the bearings to prevent re-contamination.

Fig. 4 - Steering pump components - 485 Tractor

- 1 - Pump body
- 2 - End plate
- 3 - Eccentric eccentric mounting "O" ring
- 4 - Oil bearing seal
- 5 - Safety valve plug
- 6 - Input gear
- 7 - "O" ring
- 8 - Eccentric "O" ring
- 9 - Eccentric cover
- 10 - Wiper screw
- 11 - Drive gear bearing
- 12 - Output gear bearing
- 13 - Drive gear
- 14 - Output gear
- 15 - Eccentric cover
- 16 - Drive gear bearing
- 17 - Drive gear eccentric hole
- 18 - Idler gear
- 19 - End plate
- 20 - Oil seal



Visually check for wear, scoring or cracks in the pump body and end plate. Due to air pressure, the gears normally sit in grooves in the pump body. If it does, this groove should never exceed 0.1 mm. If it does the pump body must be changed.

The only repair that can be performed on the pump body is to carefully grind all any burrs at the groove edge with a very fine oil emery paper. Be sure always to damage the gear teeth or gear shaft. If gear shaft wear or scoring are of minor importance, they can be eliminated with profiles soaked grade 17 emery paper.

Gears bearing small wearings on the top face can be reconditioned with profile soaked grade 17 emery paper.

Check gear backlash, which cannot be greater than 0.25 mm. If gears cannot be polished after scoring are of greater importance, a new set must be used. Gears are only supplied in sets of one, i.e. drive and driven gear.

Inspect the assembly, especially the bearing remove face since it may get scraped if the set is over-tightened.

Also check the O ring sealing surface for condition.

Finally, examine the labels drive and coast for corrosion. If so required, slightly smear the rear end coat with adequate grease. Then, clean carefully.

**Notes.** — The groove is cut out by the oil under pressure forcing the gears on to the pump body wall. If the bearings are worn, this groove will be cut deeper.



Fig. 42 — Assembling the bearings with the eccentric shaft removed there.

#### Assembly

1. Fit the drive (K) and driven (L) gear shafts into the pump housing.
2. Fit the bearing J, and M on to the corresponding shaft using care that they have the corresponding fitting position.
3. Fit the eccentric shaft (E) between the inner side journal and drive the bearing on to that shaft.
4. Place the O ring (R) round the bearing surface with the corresponding thrust washer L1, as shown in fig. 42.
5. Place the "B" shaped O ring (S).
6. Fit the end plate on to the pump body, using care to damage the O ring seal when fitting it to the drive shaft.
7. Cover the end plate by means of 8 screws. Tighten down diagonally.
8. Fit the ring (T).
9. Place the eccentric (U) on to the drive shaft (E) by using end plate, the pump failure also gear (K).
10. Insert the oil washer (V) and adjust the nut. Then bend the lock up the washer on to the nut faces.
11. Insert the mounting position of the pump and fit the filter (bearing opposite screw (Z) with its washer.
12. Drive the safety-wire clip (G) into its housing.
13. Mount the assembly, O ring and filter.



Fig. 43 — Fitting the ball thrust washers and O ring.

**REMOVING THE OIL RESERVOIR FROM THE TRACTOR AND DISASSEMBLING AND ASSEMBLING THE SAFETY VALVE**

1. Flush the reservoir.
2. Remove the rods from the four clips A, B, C and D.
3. Uncover the reservoir to engage support headed fastening screws.
4. Remove the reservoir and safety valve assembly from tractor.



Fig. 10 - Removing the reservoir - 50 Tractor

- A - Remove clip to hydraulics unit
- B - Remove clip to reservoir
- C - Remove the spring support clip
- D - Remove pipe from spring to hydraulics unit on the safety valve.

**Disassembling and assembling the safety valve**

1. Place the reservoir and valve assembly on a work bench vice.

**NOTE:** The valve can also be disassembled with reservoir fixed to tractor.

2. Loosen the screw W and remove along with the spring H.
3. Loosen and remove the screw B. Remove the spring G.
4. Clean all components carefully. Check the spool H and using 60/70 perfect condition.
5. Insert the spool (H) in its housing. The fitted part of the spool (H) must be on the side of the larger end H.
6. Tighten the screw (E) equipped with a sealing washer (F). On the other side, tighten the screw (I) equipped with the spring G and the sealing washer (L).
7. Fasten the assembly to the tractor by means of the screws. Apply grease with 3 mg.
8. Connect the pipes M, N, O and D.
9. Fill the reservoir with good quality tractor oil as indicated under SPECIFICATIONS.



Fig. 11 - Disassembling the safety valve

- E - Safety valve screw cover
- F - Sealing washer
- G - Safety valve spring
- H - Safety valve spool
- I - Water spring support screw
- L - Sealing washer
- M - Safety hose

### REMOVING AND RESETTING THE HYDROSTATIC UNIT.

500 and 600 Tractors

Remove:

1. Turn the steering wheel (B) by means of a puller (A).

**Remark.** — This occurs easily with.

Fig. 10 — Removing the steering wheel

2. Remove the hand throttle lever (C).

**Remark.** — Care not to lose the woodruff key securing the hand throttle lever (C) to the shaft (D).

3. Pull out the dust cover (E).
4. Loosen and fit the axle across (F) ensuring the instrument panel cover the wheel.

Fig. 11 — Removing the instrument panel and hand throttle lever

5. Unscrew the instrument shroud (F) out of the engine socket.

Fig. 12 — Instrument shroud



5. Release the ball joint (B) from the front steering knuckle (A).

Fig. 18 - Removing the ball joint from the front steering knuckle



6. Loosen and the four corners (D) from the front axle (C).



Fig. 19 - Removing the hydroboost unit

7. Place the instrument panel (M) in the corner (D).
8. Through the hole (N) in the front fork, insert the four screws securing the steering column (O) to the hydroboost unit. Use a new screw with an expansion sleeve (L).




Fig. 21 - Removing the steering column and hydroboost unit from corner



10. Slide the steering column (1) away from its housing.

Fig. 10 - Sliding the steering column through the bottom speed to the hub nuts.



11. Slightly push open the flow control valve (1) and remove the hydraulic lock from the master cylinder.

Fig. 11 - Removing the hydraulic lock from the master.



**Warning:** Remove the steering column to roll the hydraulic system back to the master, leaving the following in mind:

- Steering column is hydraulic lock support after steering wheel must be turned to 45 to 60 deg.
- Tighten the steering wheel to column following up to 3 to 4 kg m.


### DISMANTLING THE CENTRAL STEERING UNIT - 2H and 2H Tractors

To dismantle the hydraulic steering unit, please refer to an amount bench vice with the T-allow base specially then proceed as follows.

1. Unscrew and remove the T screw (C) with the washer (D).
- NOTE. — One of the screws is equipped with the check valve stop (A).
2. Remove the cover (E) along with the O-ring (B).
3. Remove the water take ring (K) along with the valve stop and the O-ring (H).
4. Remove the spacer washer (I).
5. Remove the valve plate (L) and O-ring (J).
6. Remove the control shaft (N).
7. With the aid of an adequate screwdriver, loosen the check valve stop (M) in the hydraulic unit.
8. Turn the hydrocylinder nut and remove the ball (O), which will come out easily.
9. With a (3000) ratchet, tap the valve sleeve end (P) and it comes out through the other end.
10. Remove the pin (Q) from the outer sleeve (P).
11. Oppose the outer sleeve (P) from the spacer (S).
12. Remove the following parts from the hydraulic unit:
  - a) Ball stop (O)
  - b) Check valve stop (A)
  - c) Outer bearing (L)
  - d) End washer (V)
  - e) O-ring (J)
  - f) Carefully remove the rubber seal with the steel ring (U).
13. With the aid of a ground tool, apply pressure to the 6 pressure springs (R) until returning them from spot (Z).

Fig. 30 — Exploded view of truck steering unit

- |                                  |                          |
|----------------------------------|--------------------------|
| A — Check valve stop             | H — O-ring               |
| B — End washer                   | I — Spacer washer        |
| C — T screw (with base provided) | J — Valve plate          |
| D — Washer                       | K — Water take ring      |
| E — Cover                        | L — O-ring               |
| F — Cover stop                   | M — Check valve stop     |
| G — O-ring                       | N — Control shaft        |
| H — O-ring                       | O — Ball stop            |
| I — Spacer washer                | P — Outer sleeve         |
| J — Valve plate                  | Q — Pin                  |
| K — Water take ring              | R — Pressure springs     |
| L — O-ring                       | S — Spacer               |
| M — Check valve stop             | T — Ball stop            |
| N — Control shaft                | U — Rubber retainer ring |
| O — Ball stop                    | V — End washer           |
| P — Outer sleeve                 | W — O-ring               |
| Q — Pin                          | X — Accumulator body     |
| R — Pressure springs             | Y — O-ring               |
| S — Spacer                       | Z — Check valve stop     |
| T — Ball stop                    |                          |
| U — Rubber retainer ring         |                          |
| V — End washer                   |                          |
| W — O-ring                       |                          |
| X — Accumulator body             |                          |
| Y — O-ring                       |                          |
| Z — Check valve stop             |                          |



### ASSEMBLING HYDRAULIC STEERING UNIT 30 and 30T Tractors

Before assembling the steering unit, proceed as follows:

- a) Clean all components carefully with petrol.
  - b) Examine all parts for signs of wear or damage.
  - c) Should either the outer sleeve (F), the inner spool (X) or the body (Y) appear to be damaged, change the entire hydraulic unit as a whole, except for the O-ring.
1. Fasten the body (Y) to a work bench and lubricate all parts with clean oil. Carry out the subsequent assembly with absolute cleanliness.
  2. Insert the inner sleeve (X) in the outer sleeve (F).
  3. Insert the pin (K) through the tubes in both sleeves.
  4. Place the 8 springs (R) opposite each other, on either side. The two smallest springs are fitted internally and opposite the other.
  5. If previously removed, fit the rubber seal and steel ring (J).
  6. Insert the O-ring (G), making sure it seats properly.
  7. Place the washer (D) over the ring (K).
  8. Insert the roller bearing (S).
  9. Place the fan washer (T) with the lower chamfered radius opposite the bearing.
  10. Insert the inner ring (L).
  11. Insert the outer and inner sleeves assembly into the hydraulic steering unit and make sure that all previously assembled parts are in their respective housings.
  12. Insert the lead (H) in the larger threaded hole and tighten the nut (M).
  13. Place the O-ring (B) in the hydraulic unit body groove.
  14. Fit the plate (I) making sure the holes are correctly aligned.
  15. Place the O-ring (N) over the plate (I).
  16. Place the outer leg (E) with the outer (F) over the O-ring (B). The outer leg chamfers should be downwards, opposite the holes.



Fig. 18 — Assembling the hydraulic steering unit

- B — O-ring outer sleeve
- F — Outer sleeve
- X — Hydraulic unit body



Fig. 19 — Fitting the outer shell

- E — Outer leg
- G — Outer inner ring
- L — Inner ring
- N — O-ring shell

## 17. Make the center-shaft as follows:

- a) The fork end (A) of the center shaft (S) must be aligned between the holes (M) on the rotor (R).
  - b) Once well aligned, insert cone in the assembly until its points engage with those of the rotor, and the fork end (A) engages the pin (D).
- NOTE:** — It is important that the fork (A) is perfectly aligned with cone. Should this not be the case, the hydrostatic unit will not operate correctly.

## 18. Place the O-ring (E) (Fig. 54)

19. Place the spacer washer (F) (Fig. 55) over the center shaft.
20. Place the end plate (G) (Fig. 56) over the entire assembly, making sure that the hole housing the check valve (A) stop screw (C) is correctly aligned.
21. Tighten the 4 screws with final operation (H) evenly and alternately. Tighten to 5 to 3.4 kg/m.




Fig. 55 — Alignment of center shaft with rotor

- F — Spacer
- A — Check valve
- M — Holes for alignment
- D — Pin
- R — Rotor
- G — End plate of the center shaft

Fig. 56 — Assembling the hydrostatic assembly unit

- A — Check valve stop
- E — O-ring
- C — Hydrostatic unit stop screw



**DISMANTLE THE REAR HUB AND BALL JOINT 200 and 800 Tractors**

Pushing the pin from the inner rear wheel joint

1. Place the cylinder on a workbench vice.
2. Remove nut (L), washer (H), outer cap (K) and steel shim (I).
3. With an adequate sized punch (M), remove the shaft lock pin (F) securing the ball joint (B) to the cylinder rod.
4. Unmount the ball joint (B) from the rod.
5. Pushing the inner cap (C) with the screw (D) and replace the rubber dust cone (N).

To assemble the rear ball joint, invert the dismantling procedure.

After assembling the ball joint, apply multi-purpose grease through the grease nipple (E).

Fig. 10 - Exploded view of rear ball joint components

- A - Grease dust cone
- B - Ball joint or support mounting arm
- C - Steel cap
- D - Steel pin
- E - Grease nipple
- F - Shaft lock pin
- G - Outer cap
- H - Spring washer
- I - Washer to support mounting arm
- J - Rear ball joint grease nipple

**Mount and ball joint****Removal**

1. Loosen the nut (H).
2. Unmount the ball joint body (I).

**Refitment**

1. Screw the ball joint (J) on the nut (H) to a maximum.
2. Tighten the nut (H) until the ball joint is snug with the rod.

**Remark.** - This ball joint is not equipped with a grease nipple because it is self-lubricating.



Fig. 10 - Dismantling the rear ball joint

- A - Ball joint or support mounting arm
- B - Ball joint body
- C - Steel cap
- D - Steel pin
- E - Grease nipple
- F - Shaft lock pin
- G - Outer cap
- H - Spring washer
- I - Washer to support mounting arm
- J - Rear ball joint grease nipple




Fig. 11 - Mounting the front ball joint on the axle

- K - Hub nut
- L - Ball joint body
- M - Spring washer
- N - Ball joint to rod securing nut
- O - Tyrode rod

**HYDRAULIC RAM****Reel number**

1. Place the cylinder on a clean bench vice.
2. Remove the cylinder rear plug nut lock split pin (JL).
3. With the front (CC) plug (20) loosen nut (FL).
4. Remove the rear plug (2L), pulling some outward.

**NOTE 340504**

1. Remove from ball joint (see DAC 20).
2. Remove the nut (L) lock split pin (JL).
3. With the nut (CC) plug (20), unscrew the nut (L).

4. Pull out the rod (W) along with front plug (2C) piston (TL) and rear cylinder (2L).
5. Separate the front cylinder (2C) from the front plug (2C) and piston (TL).
6. Disassemble the rear piston assembly as follows:
  - a) Place the rod (W) on a clean vice.
  - b) Loosen the nut (L).
  - c) Remove the nut (L) and piston (TL).
7. Remove the front plug (2C) from the rod (W) through the piston side. Do not attempt to remove same from the opposite side, as this would damage the seal and the front ball joint thread.




Fig. 25 - Showing the hydraulic cylinder components

- |                                      |                                           |
|--------------------------------------|-------------------------------------------|
| A - Rear ball joint lock nut         | F - Rear ball joint lock pin              |
| B - Ball joint (20) split pin        | G - Front up and lowering rod             |
| C - Rear ball joint nut              | H - Front plug                            |
| D - Ball joint to rod lock split pin | I - Ball joint screw spring washer        |
| E - Rear ball joint lower side       | J - Pinion                                |
| F - Rear plug nut                    | K - Pin nut                               |
| G - Rear plug nut front pin          | L - Rear cylinder                         |
| H - Rear plug spring                 | M - Front ball joint to rod anchoring nut |
| I - Rear plug                        | N - Spring washer                         |
| J - Drive cylinder                   | OL - Front ball joint to anchoring lock   |
| K - Front plug lock split pin        | OM - Rear ball joint body                 |
| L - Front plug pin                   | ON - Cylinder housing                     |
| M - Front plug spring                |                                           |
| N - Pinion                           |                                           |
| O - Rear ball joint lock nut         |                                           |

**ASSEMBLING THE HYDRAULIC RAM**

(Figs. 94C-DI-20 to 26)

Carefully clean all cylinder components and change the front and rear O-rings.  
Change the piston rings.  
Check the remaining components and change same wherever necessary.

1. Insert the front plug (AD) on the rod (RV) on the piston thrust side.
2. Place the piston (D) on the rod (RV), with the lower seal assembly.
3. Place the fat washer (A) against the rod (D). To tighten the nut properly, place the nut in a soft vice and hold the vice by placing a wedge in the fat groove provided for this purpose in the bolt section.
4. Insert the sleeve (TI) in the lower cylinder (D), using a ring compressor. This nut also fit flush to head, making sure that the ring gaps are opposite each other.
5. Engage the front plug (AC) in the lower cylinder (D).
6. Insert the entire lower cylinder assembly (D) in the outer cylinder (L), as shown in Fig. 94.
- Be careful not to damage the front plug (D) or (AC).
7. Insert the rod (RV) as far as is possible in the cylinder.
8. Place the nut (E) end, by means of the bolt (CC), tighten nut properly.
9. By means of the pin (X), block the nut (E) in the outer cylinder (L).

Fig. 94 - Tightening cylinder front assembly

- D - Outer cylinder
- E - Nut
- CC - 10.00 nut



Fig. 93 - Assembly of the rear plug, nut and piston assembly

- D - Outer cylinder
- E - Nut
- CC - 10.00 nut
- AC - Front plug



Fig. 94 - Bathing the lower cylinder assembly into the outer cylinder

- D - Outer cylinder
- E - Nut
- X - Pin
- AC - Front plug



10. In the upper end of the cylinder liner assembly, insert the rear plug (E), as shown in Fig. 86.

Fig. 86 - Assembling rear plug of cylinder

- E - Rear plug
- F - Shim ring
- G - Piston pin



11. Place the rear plug nut (F) and tighten same properly with the nut CO.
12. With the pin (G) slide the nut (F) on the outer cylinder L.L.

Fig. 87 - Tightening rear plug nut

- F - Rear plug nut
- G - Shim pin
- CO - Torque wrench



13. Fit the cylinder rear tail joint.



## TROUBLE SHOOTING TABLE

PROBLEM	CAUSE	REMEDY
STEERING SYSTEM VIBES HARD WHEN TURNING (STEERING WHEEL)	<ol style="list-style-type: none"> <li>1. Faulty pump.</li> <li>2. A leak at the hydrostatic unit. Check valves or valve ball seating.</li> <li>3. Pressure relief valve is faulty (does not lock in open position).</li> <li>4. Broken or pressed steering column bearing.</li> </ol>	<ol style="list-style-type: none"> <li>1. Repair the pump.</li> <li>2. Mount the ball with a metal spring, so an emergency unit assembly can be checked properly.</li> <li>3. Repair the relief valve assembly.</li> <li>4. Change steering column, if the bearing can be removed, change valve.</li> </ol>
STEERING WHEEL TURNS CONTINUOUSLY WITHOUT HOLDING NEUTRAL POSITION	<ol style="list-style-type: none"> <li>1. The 2 pressure springs do not hold the cylinder in the lock position.</li> </ol>	<ol style="list-style-type: none"> <li>1. Disassemble the hydrostatic unit and change the 2 pressure springs.</li> </ol>
VIBRATION BY THE DRIVE WHEELS	<ol style="list-style-type: none"> <li>1. Air in hydrostatic cylinder.</li> <li>2. Wear on steering linkage.</li> </ol>	<ol style="list-style-type: none"> <li>1. Bleed the circuit and eliminate the noise of air inside.</li> <li>2. Change defective parts.</li> </ol>
STEERING WHEEL CAN BE TURNED INDISTINCTLY	<ol style="list-style-type: none"> <li>1. Lack of oil in reservoir.</li> <li>2. Faulty hydrostatic cylinder.</li> <li>3. Faulty hydrostatic unit.</li> <li>4. Irregular leaks between hydrostatic unit and water supply hose.</li> </ol>	<ol style="list-style-type: none"> <li>1. Fill it with oil.</li> <li>2. Change or repair cylinder.</li> <li>3. Service, dress and repair or change circuit.</li> <li>4. Change Circuit assembly.</li> </ol>
THE DRIVE WHEELS ARE TURNED IN JERKS	<ol style="list-style-type: none"> <li>1. Insured fitting of carrier shaft and hydrostatic unit.</li> </ol>	<ol style="list-style-type: none"> <li>1. Disassemble the unit and assemble properly.</li> </ol>

PROBLEM	CAUSE	REMEDY
WHEELS TURN TOO SLOWLY	<ol style="list-style-type: none"> <li>Insufficient amount of oil in shock.</li> <li>Faulty Greaseball unit.</li> </ol>	<ol style="list-style-type: none"> <li>Increase pump supply level.</li> <li>Change or repair hydrostatic unit.</li> </ol>
DRIVE/WHEELS DO NOT RETURN TO HELPFUL POSITION. HYDROSTATIC UNIT TENDS TO ACT AS AN ENGINE	<ol style="list-style-type: none"> <li>All parts of impeller between the cover and inner casing.</li> <li>Unacceptable axial tolerance cover and inner casing, due to excessive pressure.</li> </ol>	<ol style="list-style-type: none"> <li>Remove hydrostatic unit from chain both covers or change them along with the hydrostatic unit. Clean circuit completely and add new oil.</li> <li>Place a pressure gauge on supply circuit and check pressure. Change relief valve if amount increases.</li> </ol>
WHEELS TURN POSITIVELY. WHEELS TURN ONLY IN ONE DIRECTION	<ol style="list-style-type: none"> <li>Throttle valve in hydrostatic unit.</li> <li>Unfavorable axial position within the hydrostatic unit.</li> </ol>	<ol style="list-style-type: none"> <li>Repair or change hydrostatic unit.</li> <li>Repair or change cylinder.</li> </ol>
OIL LEAKS IN UPPER OR LOWER SECTION OF HYDROSTATIC UNIT	<ol style="list-style-type: none"> <li>Damaged sealing ring at lower side of hydrostatic unit.</li> <li>Hydrostatic base screw loose.</li> <li>Defective washers and O-rings.</li> </ol>	<ol style="list-style-type: none"> <li>Disassemble hydrostatic unit and change ring.</li> <li>Adjust the lock to a torque of 8 to 12 Nm.</li> <li>Change washers and O-rings.</li> </ol>

**SECTION 4:****ENGINE  
D3.152****INDEX**

Specifications	1
Descriptions	2
Trouble-shooting chart	3
Rocker cover	4
Valve lash adjustment	4
Rocker arm shaft	4
Servicing rocker arm shaft	5
Intake manifold	5
Exhaust manifold	6
Valve springs	6
Cylinder head	6
Servicing cylinder head	7
Replenishable valve seats	9
Timing case cover	10
Timing gear	10
Camshaft	12
Timing case	12
Flywheel	13
Flywheel ring gear	13
Flywheel housing	13
Crankshaft rear mainseal	14
Engine crankcase	15
Oil pump	16
Servicing oil pump	16
Connecting rod big end bearings	17
Pistons and connecting rods	18
Servicing pistons and connecting rods	19
Cylinder liners	20
Crankshaft thrust ball bearings	21
Crankshaft	22



Publication 900-2-0014  
1st edition 83-92

## SPECIFICATIONS

## ENGINE

Make and type	Fujitsu four stroke, direct-acted injection
Model	03.102
Number of cylinders	Three
Distance of cylinders	81.66 mm
Stroke	121 mm
Displacement	2,100 c.c.m.
Compression ratio	16.5 : 1
Power	674.8 P. at 2,200 r.p.m. of engine.
Maximum torque	17.5 kg/m at 1,300 r.p.m. of engine.
Maximum speed	2,200 r.p.m. under load; 2,280 r.p.m. no load and 50 ± 50 r.p.m. idling
Firing system	By gear.
Cylinder block	Built of a single high strength grey-iron casting.
Type of crank	Thin wall casting.
Crankcase	Cast iron.
Cylinder head	Cast iron with extensive water-cooling channels.
Camshaft	Cast iron with hardened cams. Located in the top right-hand part of the block.
Camshaft	Machinable chrome forged steel with high frequency inductively treated overlays.
Connecting rods	Heat-treated forged steel.
Pistons	Aluminum alloy with extensive oxidized bore. Pro- vided with one oil control and three compression rings.
Valves	In cylinder head, actuated by camshaft by means of push rods and collar rods.
Lubrication system	
Type	Low pressure through-valve direct oil pump.
Oil flow	Full flow, restricted on block with knagged body and element.
Oil pump capacity	0.3 liter.
Minimum pressure in oil line	2.01 kg/cm <sup>2</sup> at 2,200 r.p.m. of engine and 1.2 kg/cm <sup>2</sup> idling with oil temperature in limit of 70 to 80° C.
Pump cover pressure valve	Platen type.
Valve opening pressure	3.8 to 4.0 kg/cm <sup>2</sup> .
Flow to case valve	Ball type.
Valve opening differential pressure	0.01 to 1.2 kg/cm <sup>2</sup> .
Lubricant	See general information.

**DESCRIPTION**

The Perkins D2.102 engine is of the three cylinder, water-cooled, direct diesel injection type. The total bore diameter of the cylinders is 29.44 mm and the stroke is 127 mm.

The engine has overhead valve in-cylinder assembly in the cylinder head. The camshaft, located in the right hand part of the cylinder block, is driven by a timing gear. The camshaft, in turn, actuates the valves by way of the tappets and rocker arms.

The cylinder block is a single piece of grey-iron casting of high strength.

The aluminium pistons have skirted heads and four rings. The pistons are cooled by their recessing into the cylinder liner covered with shrapnel. The connecting rod big end bearings are replaceable and are made up of a sleeve of steel covered with a tin and aluminium alloy.

The engine has force feed lubrication. The oil is sucked up from the sump through the screen filter by means of a rotary pump driven by the crankshaft. The oil passes through the filter before circulating under pressure through the engine.

The crankshaft has five bearing journals with their corresponding bearings. It is supported by bearings top and bottom. Lubrication is controlled by three ball valves housed in the rear bearing.

## TROUBLE-SHOOTING CHART

Trouble	Possible cause
Insufficient cranking speed	1, 3, 5, 6,
The engine does not start	5, 6, 7, 8, 9, 10, 11, 13, 14, 16, 18, 17, 18, 19, 20, 21, 22,
Difficult starting	6, 7, 8, 10, 11, 13, 14, 15, 16, 18, 19, 20, 21, 22, 28, 21, 33, 33,
Loss of power	12, 13, 22, 14, 16, 18, 20, 21, 22, 23, 24, 26, 27, 29, 32, 33,
Continuation failure	15, 16, 14, 18, 18, 32,
Excessive fuel consumption	10, 16,
Black exhaust smoke	17, 13, 14, 16, 18, 19, 20, 24, 27, 32,
Blue-white exhaust smoke	4, 23, 25, 24, 25, 30,
Loss of pressure	4, 20, 27, 28, 30, 40, 42, 43, 44,
Engine knocking	6, 14, 15, 16, 18, 22, 23, 28, 29, 30, 40, 40,
Uneven running	1, 5, 9, 16, 11, 12, 13, 14, 15, 17, 22, 28, 29, 30, 32, 40, 40,
Vibrations	13, 14, 22, 25, 30, 40, 47, 48,
Excessive oil pressure	4, 41,
Engine overloading	28, 19, 20, 28, 40, 30, 31, 32, 33, 34, 37,
Excessive pressure in oil passage	28, 31, 32, 34, 40, 40,
Low compression	16, 20, 31, 32, 33, 40,
Engine starts at and stops	10, 11, 12,

## Trouble-shooting list

1. Battery charge low.
2. Fuel delivery contamination.
3. Starter motor faulty.
4. Wrong grade of oil.
5. Inefficient cranking speed.
6. Fuel tank empty.
7. Cut-out control opening.
8. Fuel feed pipe blocked.
9. Faulty air pump operation.
10. Fuel filter blocked.
11. Air cleaner blocked.
12. Air to fuel system.
13. Faulty injection pump operation.
14. Injection fault.
15. Incorrect use of oil-inject system.
16. Failure in cold-start system.
17. Injection pump control failure.
18. Injection pump setting incorrect.
19. Valve adjustment incorrect.
20. Low compression.
21. Tank breather blocked.
22. Wrong type or grade of fuel.
23. Accelerator linkage sticking.
24. Release pin too tight blocked.
25. Leaks in cylinder head gasket.
26. Overheating.
27. Operating temperature incorrect.
28. Exhaust pipe partly blocked.
29. Sticky valves.
30. High pressure pipes blocked.
31. Worn cylinders.
32. Worn-out seats fitted.
33. Piston-rings broken, worn or seized.
34. Valve stems and guides worn.
35. Clevis insufficient or wrong grade of oil.
36. Bearings worn or damaged.
37. Distilled oil blocked.
38. Oil pump worn.
39. Pressure relief valve stuck open.
40. Pressure relief valve stuck closed.
41. Relief valve spring broken.
42. Oil pump breather pipe blocked.
43. Oil filter blocked.
44. Pistons bent or stick.
45. Incorrect piston height.
46. Piston damaged.
47. Valve spring broken.
48. Flanged bolts loosened or wrongly assembled.
49. Torque-wrench faulty.
50. Blockage in the cylinder block and/or cylinder head water jackets.
51. Piston skirt.
52. Piston blocked.
53. Water pump faulty.
54. Breather pipe blocked.
55. Water pump malfunctions.
56. Coolant level too low.

**ROCKER COVER****Disassembly**

1. Place hood.
2. Disconnect breather pipe.
3. Remove rocker cover fitting nuts and washers.
4. Take off rocker cover.
5. Remove gasket.


**Assembly**

6. Reverse operations 1 to 5, except:
  - a) Tighten gasket lightly with suitable sealing grease before assembling rocker cover.
  - b) Do not over-tighten rocker cover fitting nuts.

**LASH ADJUSTMENT VALVE**

The valve lash is measured between the rocker arm and tappet and has to be adjusted to 0.254 mm (0.010 in) with cold. For this, carry out the following operations:

1. Disassemble rocker cover.
2. Turn camshaft until number 1 piston is at T.D.C. and the valve of this cylinder is closed.
3. Adjust clearance of number 1, 2, 3 and 5 valves.
4. Turn camshaft 200° (two full turns).
5. Adjust clearance of number 4 and 6 valves.
6. Assemble rocker cover.

**ROCKER ARM SHFT****Disassembly**

1. Disassemble rocker cover.
2. Disconnect intake shaft oil feed line union.
3. Remove intake shaft fitting nuts and washers.
4. Withdraw complete rocker shaft.

**Assembly**

5. Reverse operation 2 to 4.
6. Adjust valve clearances.
7. Assemble rocker cover.



**SERVISING ROCKER ARM SHAFT****Disassembly**

1. Disassemble rocker arm shaft.
2. Remove shaft from front end of shaft.
3. Remove shaft support.
4. Remove rocker arm.
5. Remove long spring.
6. Remove rocker arm.
7. Remove spring.
8. Remove shaft support.
9. Remove spring.
10. Remove roller arm.
11. Remove stem spring.
12. Repeat operations 2 to 11 to complete disassembly of roller shaft.
13. Remove all fuel pipes and valves from rocker shaft.

Check for wear or damage to shaft and rocker arm bushes. If rocker arm bushes are worn, replace roller arm.

**Assembly**

14. Reverse operations 1 to 13, EXCEPT:
  - a. Check that all parts are clean and lubricated with engine oil before assembling.
  - b. The front end of the rocker arm shaft has a slot; install it as shown in diagram 140.

**INTAKE MANIFOLD****Disassembly**

1. Take apart.
2. Disconnect additional fuel pipe.
3. Disconnect cold-start heater fuel pipe.
4. Remove intake pipe clips.
5. Remove flange bolts and washers.
6. Take off manifold, or the same time separating it from the air intake tube.
7. Remove and discard gaskets.

**Assembly**



8. Install a new gasket.
9. Reverse operations 1 to 7.

**EXHAUST MANIFOLD****Disassembly**

1. Raise hood.
2. Remove exhaust pipe flange nuts.
3. Remove the floor rods and rebar.
4. Withdraw exhaust manifold.
5. Remove and discard gaskets.

**Assembly**

6. Install new gaskets.
7. Reverse operations 1 to 4.





### VALVE SPRINGS

#### Disassembly and assembly

1. Disassemble rocker arm shaft.
2. Turn crankshaft until number 1 piston is at its T.D.C.
3. Compress valve springs 1 and 2 in line with tools KT3B-0 and KT3B-1.
4. Remove valves.

**NOTE:** - Do not turn the crankshaft again until the valves have been re-assembled and secured with their collars.

5. Remove caps from springs.
6. Remove springs.
7. Remove spring seats.
8. Check free length of springs. This must be between 19.02 and 20.04 mm.
9. Set seats 1 and 2 in place and assemble or replace springs, as required.
10. Reverse operations 4 and 5.
11. Turn crankshaft until piston number 2 is at its T.D.C.
12. Repeat operations 2 to 8 for valves numbers 3 and 4.
13. Turn crankshaft until number 3 piston is at its T.D.C.
14. Repeat operations 2 to 8 for valves numbers 5 and 6.
15. Assemble rocker arm shaft.

### CRANKSHAFT BARS

#### Disassembly

1. Drain cooling system.
2. Disassemble head.
3. Disassemble rocker arm shaft.
4. Disassemble exhaust and inlet manifolds.
5. Disassemble high pressure injection pump.
6. Disassemble injectors and washers.
7. Disconnect rubber tap hose and separate hose between the thermostat housing and water pump.
8. Disconnect external oil feed pipe.
9. Remove cylinder head nuts and timing belts in reverse order to the tightening sequence.
10. Take off cylinder head.
11. If necessary, remove thermostat casing.

#### Assembly

12. Reverse operations 1 to 11, except:
  - a) Install a new gasket on the cylinder head with the rest of sealing parts.
  - b) Install a new gasket on the thermostat casing if it has been disassembled.



- 4) Tighten up the cylinder head fixing bolts and nuts in the correct order, in three uniform stages, to a torque of 30 kg m. 
12. Bleed fuel system.
13. Start up engine and run it at approximately 1,200 r.p.m. for ten minutes until normal working temperature is reached. Stop engine.
14. Disassemble rocker shaft.
15. Tighten up cylinder head fixing bolts and nuts in correct sequence to a torque of 10 kg m.
17. Assemble rocker shaft.
18. Start up engine and check that there are no leaks.



### SERVICING CYLINDER HEAD

#### Disassembly and assembly

1. Disassemble cylinder head.
2. Disassemble valve springs.
3. Place cylinder head on its side and remove valves.

**NOTE.** — Keep valves in order in which they were removed.

4. Loosen counter-sunk.
5. Remove left and innermost.
6. Remove push rod.
7. Repeat operations 4 to 6 for the remaining push rods.
8. Disassemble rear plate and its gasket from cylinder head.
9. Clean all cylinder head openings, leaving them free of carbon or other deposits.
10. If there are excessive deposits in the cylinder head water passages, the use of cleaner (BRO) Sol. A-20 is recommended.
11. Check for wear on inside diameter of valve guides.
12. If necessary, disassemble valve guides with tool PD 1 C.
13. Install new guides with tools PD 1 C and PD 1 C-4. Make sure guides are assembled correctly. Both ends are beveled out to 45° and the other to 20° (the 20° end is also chamfered). The 20° end must be inserted into the cylinder head through the top until the opposite end (45° bevel) stands out 14.30 to 15.00 mm above the top surface.
14. Check for excessive pitting or wear on valve seats.
15. If necessary, grind valve seats with the following tools: milling tool, profile cutter for exhaust valve seats, another one for those of inlet valves and the center head. Work in as little time as possible, polish well and ensure perfect seating.



16. Carefully clean all valves and check that they are not bent, worn or leaky.
17. If necessary, polish the valve stems with a grinder to an angle of 30°, making off as little metal as possible and providing a satisfactory smooth finish.
18. Carefully clean valves and lubricate stems with engine oil.
19. If necessary, lath grind valves and reposition stem and oil fitting is removed and a good working lubricated.
20. Carefully wash cylinder head and when valve clean profiles and dry.
21. Check depth of valve face with respect to cylinder head surface. This depth must be between 1.261 and 1.328 mm for inlet valves and between 1.328 and 1.108 mm for exhaust valves.
22. If a valve exceeds these limits, it must be replaced. Check valve face depth again and if it will seat correctly within the specified limits, a replaceable seat must be installed only for exhaust valves; if it is an inlet valve which does not comply with the limits, the cylinder head has to be replaced.
23. Check that cylinder head surface is level and, if necessary, plane it to a maximum of 0.02 mm, bearing in mind that the intake is not to stand out more than 0.07 mm. The intake seat must not be strained by using additional washers.
24. Carefully clean cylinder head.
25. Remove components 1 to 6, except:
  - a) Assemble valves in their correct positions.
  - b) Lightly coat the plate gasket with suitable sealing paste, as well as threads of the plate fixing bolts.



## REPLACIBLE VALVE SEATS

## Assembly procedure

Replaceable valve seats may only be assembled to DRAKUT valves and only as a last resort to extend cylinder head service life.

The assembly of replaceable valve seats is a precision operation and should therefore only be carried out by specialist personnel.

This operation must never be performed with a worn valve guide to fit assembled.

1. Service cylinder head.
2. Using a valve guide housing as center, machine cylinder head surface that adjoining to intake bore given.

**NOTE.** — Work as close as possible to minimum machining dimensions to allow for a possible later re-working.

3. Remove machining flange and clean replaceable seat housing.
4. Using valve guide housing, set valve seat in place by means of an insertion tool made to the given measurements.

**NOTE.** — Replaceable valve seats must not be removed into glass or lubricated.




5. Check that the replaceable valve seat is fully inserted into its housing and is on a level with the lower part of the cylinder head cast.
6. Remove machining overfl and flange and, if necessary, machine valve head surface.
7. Grind valve seat at a vertical angle of  $15^\circ$ , so that after grinding the depth of the valve head below the cylinder head surface lies between 1.00 and 1.22 mm (production limit), for exhaust valves.

## KEY TO FIGURE 2

- A. 1.37 to 1.50 mm.  
B. 41.00 to 42.54 mm.  
C. 0.50 mm max. value.

## KEY TO FIGURE 4

- A. 86.00 mm.  
B. 88.00 mm.  
C. 93.00 mm.  
D. 1.30 to 1.50 mm.  
E. 1.5 mm at  $45^\circ$ .  
F. 1.0 mm at  $45^\circ$ .  
G. 0.8 mm.  
H. 30.00 to 30.30 mm.  
J. 5.30 to 5.40 mm.  
K. 40.77 to 41.00 mm.



## TIMING CASE COVER

## Disassembly

1. Disconnect hoses between front outward engine and intermediate water pump.
2. Remove belt and washers.
3. Remove crankshaft pulley.
4. Disconnect alternator cables.
5. Disconnect alternator and its support brackets.
6. Remove timing chain.
7. Remove bolts securing timing case cover.
8. Remove timing case cover.
9. Remove oil filter gasket.
10. Remove valves.

## Assembly

11. Assemble system.
12. Install cover with a new gasket coated with anti-rusting paste.
13. Place pulley on crankshaft (assembly is held during installation) to set its center relative and pin.
14. Pull in and tighten timing bolts so as to secure cover and remove pulley.
15. Install remaining bolts and washers in cover.
16. Reverse operations 1 to 8, except:
  - a) Tighten pulley fixing bolt to a torque of 15 kg m.

## TIMING GEAR


## Intermediate gear and belt

## Disassembly

1. Disconnect timing case cover.
2. Turn crankshaft until the marks on the interior pump, crankshaft and intermediate gear are lined up with those of the intermediate gear.
3. Remove lock plate.
4. Remove belt.
5. Remove lock plate.
6. Remove lock washer.
7. Remove intermediate gear.
8. If necessary, disassemble intermediate gear hub.

## Assembly

9. Assemble gear hub, making sure the sleeve is fitted into the hub fixing hole.
10. Assemble gear, making sure that gear marks are lined up.
11. Reverse operations 4 to 8, except:
  - a) Tighten lock eye a torque of 7 kg m.
12. Check intermediate gear total play, which should be between 0.11 and 0.28 mm.
13. Tight lock plate over one of the valve flats.
14. Assemble timing case cover.



**Camshaft gear****Disassembly**

1. Disconnect intermediate gear.
2. Remove timing bolts and washers.
3. Remove gear.

**Assembly**

4. Reverse operations 2 and 3, except:
  - a) Make sure that bottom on gear and end of camshaft are in line.
5. Assemble intermediate gear.

**Injection pump gear****Disassembly**

1. Disconnect intermediate gear.
2. Remove timing bolts and washers.
3. Remove gear.

**Assembly**


4. Reverse operations 2 and 3, except:
  - a) Make sure that gear flange is forced in pump hub slot.
  - b) Tighten bolts to a torque of 2 Kg m.
5. Assemble intermediate gear.

**Crankshaft gear****Disassembly**

1. Disconnect intermediate gear.
2. Remove pinion.
3. Remove crankshaft gear.
4. Remove key, if necessary.
5. Take out spacer, if necessary.

**Assembly**

6. Reverse operations 2 to 5.
7. Assemble intermediate gear.



**CRANKSHAFT****Disassembly**

1. Disconnect cranker arm shaft.
2. Disconnect intermediate gear.
3. Disconnect fuel lift pump.
4. Roll topers.
5. Disconnect camshaft and gear through front of engine, taking care that the cam is not damaged the bearings.
6. Remove bolts and washers.
7. Remove gear.

**Assembly**


8. Reverse operations 1 to 7, except: at times assembling, make sure the holes in the gear and shaft match up.
9. Assemble intermediate gear.
10. Assemble cranker arm shaft.

**THIRD CASE****Disassembly**

1. Disconnect camshaft.
2. Disconnect injection pump gear.
3. Disconnect engine overtones.
4. Remove the two bolts and washers.
5. Remove bottom cover of case.
6. Remove timing case.
7. Remove timing case.
8. Remove intermediate gear hub.
9. Remove and adjust gears.

**Assembly**

11. Assemble intermediate gear hub.
12. Install a new gasket, lightly coated with white sealing paste.
13. Reverse operations 7 and 8.
14. Install bottom cover, making sure that the two holes of the cover and timing case are lined up.
15. Reverse operations 3 and 4.
16. Assemble injection pump gear.
17. Assemble camshaft.



**FLYWHEEL****Disassembly**

1. Disconnect clutch.
2. Remove fly (in bolts and lock plates).
3. Remove flywheel.

**Assembly**


4. Reverse operations 1 and 2, except:
  - a. Loosen flywheel on crankshaft flange so that the protruded hole of flange fits into the flywheel hole with no ball.
  - b. Tighten flywheel bolts to a torque of 50 kg-m and secure them with new lock plates.
5. Assemble clutch.

**FLYWHEEL RING GEAR****Disassembly**

1. Disconnect flywheel.
2. Drill a hole 5 mm in diameter and up to a depth of only 10 mm. Be careful the flywheel could be damaged at midway point between inner diameters of ring gear and base of one of its teeth.
3. Place a cold chisel at base of teeth, above drill hole.
4. Cover flywheel and cutting point with a lead coat as a preventive blow fragment that might fly off.
5. Hold flywheel and remove cold chisel firmly to split ring gear.

**Replacement**

6. Hold over ring gear to a thickness of approx. 0.05 mm (0.002 in) (0.0004 in) (0.0004 in).
7. Place ring gear on flywheel with tooth entry guide towards top of flywheel, quickly fit ring gear into its housing section. It cool slowly.
8. Assemble flywheel.

**FLYWHEEL HOUSING****Disassembly**

1. Disconnect flywheel.
2. Remove belt and washers.
3. Remove screws.
4. Straighten housing from top.

**Assembly**

5. Reverse operations 1 to 4, except:
  - a. Make sure that flywheel housing and engine block surfaces are individually clean.
  - b. Lightly coat both surfaces with an appropriate coating paste.
6. Assemble flywheel.






## CRANKSHAFT BEAR RETAINER

## Disassembly

1. Disassemble flywheel housing.
2. Remove bolts and washers.
3. Remove retainer housing together with seal.
4. Remove seal oilseal gasket.
5. Extract retainer from fly housing.

## Replacement

6. In replacement, the fly retainer is assembled with fly face aligned with the rear surface of fly housing. Inspect crankshaft flange end, if it is correct, the new retainer must be inserted further into the housing that it should be inserted 3.2 mm and, if necessary, a further 3.2 mm, making 6.4 mm in all. If these operations should not be sufficient, the crankshaft flange contact surface has to be machined.
7. Lubricate retainer and fly housing with clean engine oil. Press retainer in fly housing in the required depth with tool PD 185.1.
8. Install a new gasket tightly secured with suitable sealing paste.
9. Lubricate retainer, crankshaft flange and tool PD 185.2 with clean engine oil.
10. Using tool PD 185.2, install retainer assembly and fly housing. Make sure that it is properly engaged on the crank hub.
11. Remove tool PD 185.2.
12. Reverse operations 1 and 2.




**ENGINE CRANKCASE****Disassembly**

1. Disconnect bracket between front axle and engine.
2. Remove plug from oilpan and drain oil. Cut out if it is suitable container.
3. Remove belts and washers.
4. Remove nuts and washers.
5. Support crankcase and remove belts and washers.
6. Separate crankcase from block.
7. Remove and discard gasket.

**Assembly**

8. Reverse operations 1 to 7, except:
  - a) Check that contact surfaces are clean.
  - b) Fit new gaskets, lightly smeared with suitable mating paste.
  - c) Fill crankcase to the correct level with specified engine oil.

**OIL PUMP****Disassembly**

1. Disconnect engine crankcase.
2. Disconnect timing case cover.
3. Remove timing case bottom cover.
4. Disconnect pump pressure pipe.
5. Remove studs and intermediate gasket.
6. Remove timing bolts and washers.
7. Withdraw cover.

**Assembly**

8. Reverse operations 1 to 7.



## SERVICING OIL PUMP

## Disassembly

1. Disassemble oil pump.
2. Take out piston.
3. Remove cover.
4. Remove Drive shaft.
5. Check clearance at all points between maximum diameter of internal wear and minimum diameter of external shaft. If clearance exceeds 0.100 mm, a new oil pump should be installed.
6. Check clearance between external rotor and pump body. If clearance exceeds 0.075 mm, a new pump must be fitted.
7. Check clearance between top of rotor and pump body. If clearance exceeds 0.150 mm, a new oil pump must be installed.
8. If necessary, take out rotor pin.
9. Remove plug.
10. Remove spring.
11. Remove safety valve.
12. If necessary, disassemble gear with tools FD 1000 and FD 150-4K.  
Check for wear or damage to parts and replace if necessary.

## Assembly

12. Reverse operations 8 to 12 and 1 to 5, except at least primary gear with flat face schmirid sand it is fixed up with end of shaft. Then use shaft key fit into gear keyway.  
H. Install a new ring.



## CONNECTING ROD BIG END BEARINGS

## Disassembly

1. Disassemble all pumps.
2. Turn crankshaft until bearing to be disassembled is at 6 O'Clock.
3. Remove nuts free big end bolts.
4. Remove big end cap together with half bearing.
5. Remove half bearing from cap.
6. Take out big end bolts.
7. Turn crankshaft and upper half bearing can be removed.
8. Repeat operations 1 to 7 to disassemble remaining bearings.


Inspect half bearings for wear or scoring. If any should be found, replace complete set.

Check for wear on crankshaft crankpins with a micrometer. The diameter of crankpins should be checked both on a horizontal and vertical plane and at both ends.

Wear and ovalization must not exceed 0.0021 inch. If above this limit, the crankshaft must be ground or replaced.

## Assembly

9. Reverse operations 1 to 8, except:
  - a) Check that all components are meticulously clean and lubricated with clean engine oil prior to fit.
  - b) Make sure half bearing has fit in connecting rod slot and that they are correctly assembled in their original positions.
  - c) The connecting rod nuts and bolts are special and wherever they are replaced this must be duly noted supplied by the engine manufacturer.
  - d) Make sure that base of bolt heads is seated correctly on connecting rod shoulder.
  - e) Check that connecting cap and big end cover cap are assembled with matching identification marks and in left side of engine.
10. Tighten big end nuts to a torque of 7 kg-m (50 lbf-ft).



## PISTONS AND CONNECTING RODS

## Disassembly

1. Disconnect cylinder head.
2. Disconnect big end bearings.
3. Withdraw piston and connecting rods through top of cylinder.

## Assembly

Check condition of pistons, rings and liners and if in doubt of suspect replace them.

4. Clean all parts carefully and lubricate them with clean engine oil specified.

**NOTE:** Place rings on pistons in such a way that gap in each ring is at 180° in relation to the previous one.

5. With tool 3813, insert each piston and connect rod into the top part of its respective cylinder. Make sure that the rod **SPRON'S** is towards front of engine.
5. Assemble big end bearings but without assembly of pump.
7. Check height of each piston with tool 3048. At 1st V. S. C. the piston must be 8.650 (+0.012) mm below top surface of block.
8. Assemble oil pump.
9. Assemble cylinder head.



### SERVISING PISTONS AND CONNECTING RODS

#### Disassembly

1. Disassemble pistons and rods.
2. Remove rings from each piston.
3. Remove skives from each piston.
4. Heat pistons in a steam liquid to a temperature of 26 to 50°.
5. Carefully extract piston pins.
6. Remove carbon deposits from piston pin special attention to ring grooves.
7. Inspect pistons for scoring.
8. Check piston pin adjustment.
9. If necessary, extract brass and bushes.

10. Place legs to steel, examine part at top of cylinder and check gap.

The gap must be between:

For piston rings:

1st ring 0.26 to 0.40 mm.

2nd, 3rd and 4th rings 0.26 to 0.40 mm.

Topmost piston rings:

1st, 2nd and 3rd rings 0.25 to 0.50 mm.

4th ring 0.25 to 0.40 mm.

11. After handling new rings, check vertical clearance of grooves. This clearance must be between:

For piston rings:

1st and 4th rings 0.07 to 0.102 mm.

2nd ring 0.04 to 0.068 mm.

3rd ring 0.034 to 0.052 mm.

Topmost piston rings:

1st and 2nd rings 0.08 to 0.091 mm.

3rd ring 0.068 to 0.097 mm.

4th ring 0.026 to 0.030 mm.

#### Assembly


12. If necessary, install new small end bushes, bring up both lubrication holes with connecting rod small end.

13. With rod 356, check that each rod is perpendicular and parallel. If there is any distortion, it must be repaired.

14. Heat pistons in a clean liquid, assemble connecting rods in their respective pistons and insert pins.

**NOTE:** The piston head cavity is offset towards towards one of its sides. Join up pistons to connecting rods with cavity towards connecting rod and big end cap like clockwise marks.

15. Install new circlips on each piston pin.



16. Starting from the top, install rings in the following order:
- Oil ring
  - Internally stepped compression ring
  - Externally stepped compression ring
  - Adjustable scraper ring

**NOTE:** The internally stepped compression rings must be placed with step towards piston head. Place rings in each piston so that the gap of one ring is at 180° in relation to the previous one.

17. Assemble piston and connecting rods.



## CYLINDER LINING

### Disassembly

- Disassemble pistons and rods.
- Remove studs from cylinder block.
- With tool FD 180 suitable sizer and hollow hydraulic cylinder, extract liner from cylinder through top of block.

### Reassembly

- Reverse operations 1 to 3, except:
  - Cylinder liner should be handled and stored with care. The slightest defect or burr could cause considerable damage when assembled in block.
  - Gas Test liner with flange should not be ground but have to be replaced by new semi-finished liner.
  - Before inserting a new liner, lube this and the corresponding cylinder should be carefully cleaned, especially the groove at top of cylinder where flap flange is located.
  - All parts should be copiously lubricated before assembly with clean engine oil.
  - Check that flange of each liner does not get its leading edge at top of cylinder out of shape.
  - When it is completely in place, the top of each liner must be between 0.000 and 0.302 mm below top face of block.
  - Check condition of pistons and if it is all right, replace them.
  - Install a set of new rings.
  - Allow a seating in center before checking inside diameter of liner.
  - Each liner must be checked in three positions: open, middle and closed; the readings must be taken both transversely and parallel to center line of block.



## CRANKSHAFT THRUST HALF WASHERS

## Disassembly and replacement

1. Disassemble pistons.
2. Push crankshaft backwards and check side play between these half washers and crankshaft. The clearance should be between 0.150 and 0.200 mm.
3. If side play does not fit within these limits, proceed as follows:
4. Disassemble crankshaft rear section.
5. Take out the two timing belts.
6. Remove the crankcase cap together with two lower thrust ball washers.
7. Push the two upper half washers with a wire and they can be withdrawn.
8. Reface the two washers.
9. Before re-assembly, lubricate all components with clean engine oil.
10. Place the two new upper thrust half washers in deck housing with the low crankshaft half timing.
11. Place the two new lower thrust half washers in rear crankcase cap and assemble it.
12. Put in timing belts and adjust them to a tension of 18 kg m.
13. Check crankshaft side play again, operation 2.
14. If side play is still not correct, larger size thrust half washers may be needed. Repeat operations 5 to 13.

**NOTE:** Both upper and lower thrust half washers have to be of the same thickness.

15. Reassemble rear section.
16. Assemble pistons.





## CRANKSHAFT

## Disassembly

1. Drain engine oil.
2. Support engine on a suitable stand.
3. Remove bearing between front axle and engine and between engine and gearbox.
4. Disassemble timing case.
5. Disassemble big end bearings.
6. Disassemble thrust ball washers.
7. Disassemble crankshaft pin.
8. Take out the six timing bolts from the other three bearing caps.
9. Remove the three bearing caps with their respective ball bearings.
10. Withdraw crankshaft.
11. Remove upper ball bearings from crankshaft supports.
12. Clean all components carefully.

Check with a micrometer for wear of journals on crankshaft located at crankpins. The diameter of journals and crankpins should be checked both horizontally and vertically and at both ends. Your own micrometer must not exceed 0.0251 mm. Diameter of crankpins and rods and see journals may be ground to the following measurements:

- a) Stroke 3.254 mm.
- b) Journals 5.528 mm.
- c) Rods 3.762 mm.


If crankshaft requires grinding below 0.752 mm, total a new crankshaft. The width of the crankpin edges be increased when grinding, but it is so circumstances must be ground 33.02 mm.

It is important to keep journal and crankpin well lubricated. After grinding, rough edges should be removed from lubrication holes.

Tuffloded crankshaft must be removed with the Tuffloding process after grinding. If this treatment can not be carried out, a new crankshaft must be ordered.

If the three assembly positions of the crankshaft pin support have been used, the crankshaft flange should be ground.

Remove only the minimum amount of metal from the flange to eliminate scoring. The flange should not be machined below a minimum diameter of 11.17 mm. It is not necessary to apply Tuffloding process to flange. Remove crankshaft for cracks and elongation.



## Assembly

13. Reverse operations 7 to 12, except:
  - a) Check that cylinder block and crankshaft lubrication lines are not blocked.
  - b) Check that timing cap firing belts are not stretched. Only belts supplied by engine manufacturer should be used.
  - c) Make sure all components are vertically clean and properly lubricated with engine oil.
  - d) The bearing caps are numbered starting from front of engine. Each bearing cap is also stamped with the same serial number as it stamped on bottom face of block and they must be matched up.
  - e) Tighten bolts to a torque of 15 kg m.
14. Assemble crankshaft thrust ball washers.
15. Assemble connecting rod big end bearings.
16. Assemble timing case.
17. Reverse operation 3.
18. Fit engine with specified oil.

## SECTION 4:

## ENGINE D4.203

INDEX

	Page
Specifications	22
Description	24
Tractor charging sheet	25
Rocker cover	26
Valve lash adjustment	26
Rocker arm shaft	26
Scrubbing rocker arm shaft	27
Intake manifold	27
Exhaust manifold	27
Valve springs	28
Cylinder head	28
Scrubbing cylinder head	28
Hydraulic valve seats	31
Timing seat cover	32
Timing gear	32
Crankshaft	34
Timing case	34
Flange	35
Flange ring gear	35
Flange housing	35
Crankshaft rear retainer	37
Engine crankcase	38
Oil pump	38
Scrubbing oil pump	38
Connecting rod big end bearings	44
Pinion and connecting rods	41
Scrubbing pinion and connecting rods	42
Cylinder liners	42
Crankshaft thrust half washers	44
Crankshaft	45



Publication 100-EMP-1  
See index 61-76

## SPECIFICATIONS

## Engine

Make and type	Porsche two-cylinder, direct-inject injection.
Model	04.205
Number of cylinders	Two
Cylinder bore	51.44 mm
Stroke	107 mm
Displacement	1,000 c.c.
Compression ratio	10.5:1
Power	33.0/4.7 at 2,200 r.p.m. of engine.
Maximum torque	21.8/3.9 at 1,300 r.p.m. of engine.
Maximum speed	2,200 r.p.m. under load, 3,375 r.p.m. no load and 400 ± 10 r.p.m. idling.
Timing system	By gear.
Cylinder block	Both of a single, high strength grey-iron casting.
Type of liner	Thin-wall casting.
Carburetor	Cast iron.
Cylinder head	Cast iron with extensive water cooling channels.
Crankshaft	Cast iron with horizontal pins. Located in top right-hand end of cylinder block.
Connecting rods	Magnesium chrome-niobium steel with high frequency induction treated crankpins.
Pistons	Stainless forged steel.
Valves	Aluminum alloy with concave machining in head. Provided with one of casted and three compressive rings.
	In cylinder head, driven by camshaft through push rods and rocker arms.

## Lubrication system

Type	Low pressure through rotor driven oil pump.
Oil filter	Full flow, mounted on block with integral body and element.
Oil pump capacity	7 liters.
Minimum pressure in oil line	2.21 kg/cm <sup>2</sup> at 2,200 r.p.m. of engine and 1.2 kg/cm <sup>2</sup> at idling speed with oil temperature in the 0° to 70 to 80° C.
Purge excess pressure valve	Flapper type.
Valve opening pressure	0.2 to 0.3 kg/cm <sup>2</sup> .
Filter by-pass valve	Ball type.
Valve opening differential pressure	0.05 to 1.2 kg/cm <sup>2</sup> .
Lubricant	See general information.

**DESCRIPTION**

The Perkins 34.300 engine is of the four-cylinder, water-cooled, direct-drive injection type. The rated cylinder bore is 31.50 mm and the stroke is 127 mm.

The engine has overhead valves mounted vertically in the cylinder head. The overhead, located in the right-hand part of the cylinder block, is driven by a timing gear. The overhead, in turn, actuates the valves by way of the tappets and rocker arms.

The cylinder block is a single piece of high strength grey-iron casting.

The piston rings have slanted heads and four rings. The pistons are coupled to their connecting rods by piston pins secured with shanks. The connecting rod big-end bearings are replaceable and are made up of a steel shell covered with a tin anti-stressman alloy.

The engine has force-feed lubrication. The oil is sucked up from the sump through the screen filter by means of a rotary pump driven by the crankshaft. The oil passes through the filter before circulating under pressure through the engine.

The crankshaft has five bearing points with their corresponding bearings. It is supported by bearing caps and its axial location is controlled by thrust ball bearings located on the rear bearing.

TROUBLE SHOOTING CHART

Trouble	Possible cause
Low/No fuel reaching speed	1, 2, 3, 4,
Engine does not start	6, 5, 7, 8, 9, 10, 11, 12, 14, 15, 16, 17, 18, 19, 20, 21, 22,
Difficult starting	6, 7, 8, 10, 11, 12, 14, 15, 16, 19, 20, 21, 22, 25, 27, 30, 33,
Loss of power	10, 11, 13, 14, 15, 19, 20, 21, 22, 24, 25, 27, 28, 30,
Compression failure	11, 13, 14, 15, 19,
Excessive fuel consumption	15, 16,
Black exhaust smoke	11, 12, 14, 15, 19, 20, 24, 27, 33,
Blue/white exhaust smoke	4, 20, 23, 24, 25, 33,
Low oil pressure	4, 20, 27, 28, 29, 40, 42, 43, 44,
Engine knocking	5, 14, 16, 18, 19, 20, 22, 23, 25, 26, 40, 45, 46,
Unusual working	7, 8, 9, 10, 11, 12, 13, 14, 16, 21, 22, 23, 24, 30, 33, 45, 46,
Vibrations	12, 14, 20, 26, 30, 45, 47, 49,
Excessive oil pressure	4, 11,
Engine over heating	10, 13, 24, 25, 40, 43, 45, 50, 51, 52, 53, 54, 57,
Excessive pressure in circulation	26, 27, 28, 29, 30, 33,
Low compression	10, 25, 27, 30, 33, 40,
Engine start-up and stop	10, 11, 12,

## Trouble shooting key


1. Battery charge low.
2. Poor electrical connections.
3. Starter motor faulty.
4. Wrong grade of oil.
5. Insufficient cranking speed.
6. Fuel tank empty.
7. Cut-out control operating.
8. Fuel feed pipe blocked.
9. Faulty 25 pump operation.
10. Fuel filter blocked.
11. Air cleaner blocked.
12. Air in fuel system.
13. Faulty injection pump operation.
14. Injection faulty.
15. Incorrect use of relief inlet system.
16. Failure in cold-start system.
17. Injection pump control broken.
18. Injection pump setting incorrect.
19. Valve adjustment incorrect.
20. Low compression.
21. First breather blocked.
22. Wrong type or grade of oil.
23. Accumulator linkage sticking.
24. Shut-off valve wrongly blocked.
25. Gaskets in cylinder head gasket.
26. Overheating.
27. Operating temperature incorrect.
28. Exhaust pipe partly blocked.
29. Safety valves.
30. High pressure pipes blocked.
31. Valve syphoning.
32. Valves and seats pitted.
33. Piston rings broken, worn or seized.
34. Valve stems and guides worn.
35. Discard, overhaul or wrong grade of oil.
36. Bushings worn or damaged.
37. Crankcase oil level low.
38. Crankcase filter blocked.
39. Oil pump worn.
40. Pressure relief valve open/closed.
41. Pressure relief valve clogged.
42. Relief valve spring broken.
43. Oil pump injection pipe defective.
44. Oil filter blocked.
45. Piston land to ring.
46. Incorrect piston height.
47. Fan damaged.
48. Valve spring broken.
49. Flywheel body balance/color wrongly assembled.
50. Thermostat faulty.
51. Leakage in the cylinder block and/or cylinder head water joints.
52. Fan belt slack.
53. Radiator blocked.
54. Water pump faulty.
55. Breather pipe blocked.
56. Valve stem retained broken.
57. Coolant level too low.

**ROCKER COVER****Disassembly**

1. Remove bolt.
2. Disconnect bracket pipe.
3. Remove oil feeding nut, washer and retainer.
4. Take off rocker cover.
5. Remove and discard gasket.

**Assembly**

6. Reverse operations 1 to 5, except:
  - a) Install a new oil gasket.

**VALVE LASH ADJUSTMENT**

The valve lash is measured between the rocker arm and tip of the valve. It is adjusted to 0.283 mm (0.011 in) or 0.30 mm (0.012 in). The procedure is as follows:

1. Disconnect valve cover.
2. With #1 cylinder valve in cross-over position, adjust #1 cylinder valve.  
With #2 cylinder valve in cross-over position, adjust #2 cylinder valve.  
With #3 cylinder valve in cross-over position, adjust #3 cylinder valve.
3. Assemble rocker cover.

**ROCKER ARM SHAFT****Disassembly**

1. Disconnect rocker cover.
2. Disconnect oil feed pipe.
3. Remove valve shaft, timing nuts and washers.
4. Withdraw complete rocker shaft.

**Assembly**

5. Reverse operations 2 to 4.
6. Adjust valve clearances.
7. Assemble rocker cover.



**REPLACE ROCKER ARM SHAFT**

1. Disconnect rocker arm shaft.
2. Remove shims from base end of rocker shaft.
3. Remove shaft support.
4. Remove "1" valve rocker arm.
5. Remove spring.
6. Remove "2" valve rocker arm.
7. Remove washer.
8. Remove shaft support.
9. Remove valve.
10. Remove "3" valve rocker arm.
11. Remove shaft support.
12. Remove "4" valve rocker arm.
13. Remove valve and oil feed pipe.
14. Remove shaft support.
15. Remove spacer.
16. Repeat operations 2 to 15 for other end of rocker shaft, which is identical.

Check for wear in storage to rocker arms or shaft. The rocker arms should be able to be assembled fully on the shaft, without excessive side play.

**Assembly**

17. Repeat operations 1 to 16, except:
  - a) The base end of the rocker arm shaft has a slot and it has to be assembled as is shown in Diagram 17-A.
  - b) Lubricate all parts with clean engine oil before assembly.

**INTAKE MANIFOLD****Disassembly**

1. Raise hood.
2. Disconnect cold-start heater cable.
3. Disconnect cold-start heater fuel pipe.
4. Loosen inlet pipe clamp.
5. Remove fitting bolts and washers.
6. Take off manifold, at the same time separating it from intake base.
7. Remove and discard gasket.

**Assembly**



8. Install new gasket.
9. Reverse operations 1 to 7.

**EXHAUST MANIFOLD****Disassembly**

1. Raise hood.
2. Remove the four nuts and washers.
3. Withdraw manifold.
4. Remove and discard gaskets.

**Assembly**

5. Install new gaskets.
6. Reverse operations 1 to 4.



**VALVE SPRINGS**


Disassembly and assembly (with cylinder head in place)

1. Disconnect rocker shaft.
2. Turn crankshaft until #1 and 4 pistons are at Top D.C.
3. Compress cylinder #1 and 4 valve springs with tools PD 8788 and PD 8784.
4. Remove coils.
5. Slowly release tools PD 8788 and PD 8784.
6. Remove spring tops.
7. Remove springs and seats.

**NOTE:** a) Do not turn crankshaft again until the valves have been reassembled and secured with lock washers.

b) If a valve spring requires replacement, a complete set should be assembled.


8. Reverse operations 3 to 7.
9. Turn crankshaft until #2 and 3 pistons are at Top D.C.
10. Repeat operations 3 to 7 for #2 and 3 cylinder valves.
11. Reverse operations 1 and 2 to 5.

**CYLINDER HEAD****Disassembly**

1. Disconnect hood.
2. Remove control plate.
3. Disconnect battery leads.
4. Drain cooling system.
5. Disconnect pressure manifold.
6. Disconnect fuel manifold.
7. Disconnect radiator top hose and connection hose between thermostat housing and water pump.
8. Disconnect thermostat cover.
9. Remove high pressure fuel pipe.
10. Disconnect heater.
11. Disconnect temperature gauge sender.
12. Disconnect all fuel pipe from cylinder head.
13. Remove cylinder head firing pins and bolts in reverse order to tightening sequence.
14. Remove cylinder head.
15. If necessary, disconnect thermostat housing and pump.
16. Remove cylinder head gasket.


**Assembly**

17. Make sure that all components are thoroughly clean and that contact surfaces are free of grease.





16. Reverse operations 1 to 15, except:
  - a) Place a new cylinder head gasket with a fine coat of sealing paste.
  - b) Tighten up cylinder head flange nuts and bolts in the correct order, in three equal stages, to a torque of 10 kg/m.
  - c) Apply a thin coat of sealing paste to inner-most housing gasket if disassembled.
20. Bleed fuel system.
21. Start up engine and run it at approximately 1,200 r.p.m. for ten minutes until normal working temperature is reached. Stop engine.
22. Disassemble motor and shaft.
23. Tighten cylinder head flange nuts and bolts in correct order to a torque of 10 kg/m.
24. Assemble motor and shaft.
25. Start engine and check that there are no leaks.



### SERVISING CYLINDER HEAD

#### Disassembly and assembly

1. Disassemble cylinder head.
2. Disassemble valve matrix.
3. Place cylinder head on its side and remove valves.

**NOTE:** Keep valves in same order in which they were extracted.

4. Loosen counter-bolt.
5. Remove bolt and nut/washer.
6. Remove push rod.
7. Repeat operations 4 to 6 for remaining push rods.
8. Disassemble thermostat housing and gasket.
9. Disassemble sea plate and gasket from cylinder head.
10. Check all cylinder head coverings, tearing them free of carbon or other deposits.
11. If there are excessive deposits in the cylinder head water passages, the use of Deasol (BORG) Sol. 3.281-A is recommended.
12. Check for wear in both diameter of valve guide.
13. If necessary, extract valve guides with tool FD, B.
14. Install new guides with tools FD 1C and FC, 33.1A. Make two guides pre-assembled in correct direction. Both ends are beveled, one to 80° and the other to 20° like 20° and is also round.



out. The 2P end must be inserted into the roller head through the top until the opposite end (M7) stops at 15.83 to 15.88 mm above the top face.

18. Check for excessive pitting or wear on valve seats.
19. If necessary, grind valve seats with the following tools: grinding cylinder tool, valve seat profile cutter, touchbar and center bit. Remove as little metal as possible and ensure a fine, tight finish.
20. Carefully fit valves stems and check that they are not pitted, worn or bent.
21. If necessary, machine grind valve stem ends to a 45° angle. Remove as little metal as possible to achieve a fine finish.
22. Clean valves carefully.
23. Lubricate valve stems with clean engine oil.
24. If necessary, sand grind valves and their respective seats until all pitting is removed and a good seating is obtained.
25. Carefully seat cylinder head and valves with clean profile and then dry.
26. Lightly lubricate valve stems and head them in cylinder head.
27. Check depth of valve head in relation to cylinder head surface. This depth must be between 1.02 and 2.0 mm.
28. If a valve exceeds this limit, it must be replaced. Measure valve depth again and if it still does not conform to the limits stated, a replaceable valve seat must be installed first on exhaust valves. In the case of an intake valve, the cylinder head has to be replaced.
29. Check the cylinder head surface is flat and, if necessary, grind surface up to a maximum of 0.30 mm, bearing in mind that the inspector is not to stand out more than 4.00 mm. This measurement must not be obtained by adding extra washers.
30. Carefully clean cylinder head.
31. Reverse operations 1 to 8, steps:
  - a) Place valves in correct position.
  - b) Lightly smear each part and threaded bearing points with suitable sealing paste.



## REPLACIBLE VALVE SEATS

## Assembly procedure

Replaceable valve seats may only be assembled to DISELUST valves and only as a last resort to extend cylinder head service life.

The assembly of replaceable valve seats is a precision operation and should therefore only be performed by specialised personnel.

This operation must never be performed while a worn valve guide is still mounted.

1. Service cylinder head.
2. Using a valve guide housing as centre, machine cylinder head surface into conformity to instructions given.

**NOTE:** Work as close as possible to minimum machining dimensions to allow for a possible later reworking.

3. Remove machining flaps and clean replaceable seat housing.
4. Using valve guide housing, set valve seat in place to verify if an insertion and in accordance to the specified dimensions.


**NOTE:** Replaceable valve seats must not be hammered into place or lubricated.

5. Check that replaceable valve seat is fully inserted into its housing and is in a seat with the outer part of cylinder head intact.
6. Remove machining swarf and flaps and, if necessary, machine cylinder head surface.
7. Grind valve seat at a normal angle of 90°, so that after grinding the depth of the valve seat circle the cylinder head surface lies between 1.50 and 1.60 mm (precision limit) for exhaust valves.




REF TO FIGURE 3

A: 2.30 to 2.50 mm



REF TO FIGURE 2

A: 2.37 to 2.52 mm  
B: 44.07 to 45.34 mm  
C: 2.48 mm max. (0.98 in)



REF TO FIGURE 4

A: 1.25 mm ± 0.07  
B: 10.00 mm  
C: 6.90 mm  
D: 50.00 mm  
E: 20.00 to 22.50 mm  
F: 42.24 to 43.50 mm  
G: 0.75 mm (0.03 in)  
H: 1.25 mm (0.05 in)  
I: 1.75 mm (0.07 in)  
K: 1.25 to 1.47 mm

## TIMING CASE COVER

## Disassembly

1. Disconnect tractor between engine and load pin.
2. Remove bolt and washer securing crankshaft pulley.
3. Take off crankshaft pulley.
4. Remove water pump.
5. Remove engine breather pipe.
6. Remove accelerator return spring from injector pump.
7. Remove the four lockwire bolts.
8. Disconnect alternator security support bracket.
9. Take out timing cover timing belt.
10. Take off timing case cover.
11. Remove and discard gasket.
12. Remove washer.

## Assembly

13. Install a new washer with lug (locate engine). These washers 2.4 mm (locate front surface of timing case).
14. Assemble cover and lock gasket.

**NOTE:** Lightly grease gasket with suitable seal-lug paste.




15. Put on crankshaft pulley so as to center timing case cover.
16. Put in and tighten cover bolts and washers in correct timing cover.
17. Remove crankshaft pulley.
18. Tighten remaining timing case cover nuts and bolts.
19. Remove operations 1 to 8, except:
  - a) Tighten crankshaft pulley timing bolt to a torque of 10 kg-m.

## TIMING GEAR

## Intermediate gear

## Disassembly

1. Disconnect timing case cover.
2. Turn crankshaft and marks on injector pump, crankshaft and crankshaft gear are lined up with those of the corresponding intermediate gear.
3. Bend down lock plate.
4. Remove the three nuts.
5. Remove lock plate.
6. Remove lock washer.
7. Remove upper intermediate gear.
8. If necessary, disconnect intermediate gear hub.
9. Repeat operations 2 to 8 for lower intermediate gear.



**Assembly**

10. Put in intermediate gear hub, making sure that hub of steel balls are lined up with slots of cylinder block.
11. Assemble gear, making sure that timing pump, crankshaft and crankshaft gear timing marks are lined up with intermediate gear.
12. Reverse operations 2 to 6.
13. Check axial play of gear, which must be between 0.025 and 0.178 mm.



14. Check clearance between intermediate gear by means of a dial gauge or thickness gauge. The clearance must be between 0.205 and 0.303 mm. Check all points of engagement.

**NOTE:** If axial play obtained does not fall within the prescribed limits, replace timing gears involved.


15. Assemble timing case cover.

**Crankshaft gear****Disassembly**

1. Disassemble upper intermediate gear.
2. Remove the crank gear timing nuts and bolts.
3. Remove gear.

**Assembly**

4. Reverse operations 2 and 3, except:
  - a. Make sure gear and crankshaft flange faces are lined up.
5. Assemble upper intermediate gear.



**Injection pump gear****Disassembly**

1. Disassemble upper injection gear.
2. Remove the three fixing nuts and lock.
3. Remove gear.

**Assembly**


4. Reverse operations 2 and 3, except:
  - a) Make sure that gear shaft is removed in injection pump bearing set.
  - b) Tighten fixing bolts to a torque of 3 kg m.
5. Assemble upper intermediate gear.

**Crankshaft gear****Disassembly**

1. Disassemble lower intermediate gear.
2. Remove shaft.
3. Withdraw crankshaft gear.
4. Take out key (if necessary).
5. Remove spacer (if necessary).

**Assembly**

6. Reverse operations 2 to 5.
7. Assemble lower intermediate gear.

**CAMSHAFT****Disassembly**

1. Remove intake air shaft.
2. Remove upper intermediate gear.
3. Disconnect tachometer drive cable from end of camshaft housing.
4. Disassemble fuel jet pump.
5. Disassemble crankshaft gear.
6. Take spacer.
7. Withdraw camshaft through front of engine.
 

Take care that gears do not damage bearing.
8. Remove thrust washes (if necessary).

**Assembly**

9. Check that thrust washer is correctly placed on cylinder block/piston pin.
10. Reverse operations 3 to 7, except:
  - a) Make sure that thrust washes on gear and crankshaft flange are fixed up.
11. Assemble upper intermediate gear.
12. Assemble intake air shaft.




**TYING CASE****Disassembly**

1. Disassemble camshaft.
2. Disassemble injector pump gear.
3. Disassemble injector pump.
4. Disassemble overhauled.
5. Remove nuts and bolts securing timing case to cylinder block.
6. Take off timing case.
7. Remove piston.

**Assembly**

8. Reverse operations 2 to 7, except at final new piston lightly smeared with suitable coating joints.
9. Assemble injector pump gear.
10. Assemble camshaft.


**FLYWHEEL****Disassembly**

1. Disassemble clutch.
2. Remove the six bolts and lock plates.
3. Remove flywheel.

**Assembly**

4. Reverse operations 1 and 2, except at locate flywheel on crankshaft flange so that the unthreaded hole of flange lines up with the flywheel hole with no slack.
5. Tighten flywheel bolts to a torque of 90 kg m (65 ft lb) using them with new lock plates.

6. Assemble clutch.




**FLYWHEEL RING GEAR****Disassembly**

1. Disassemble flywheel.
2. Drill a hole 5 mm in diameter and 10 to a depth of 30 mm (allowing the flywheel to be disassembled) at midway point between lower diameter of ring gear and base of one of its teeth.
3. Place a cold chisel at base of tooth above drill hole.
4. Cover flywheel and cutting point with a steel mesh as combustion applies fragments that might fly off.
5. Hold flywheel and hammer cold chisel firmly to split ring gear.

**Replacement**


6. Heat ring gear to a temperature of approximately 200°C (390°F) in FURNACE.
7. Place ring gear on flywheel with tooth entry point towards front of flywheel, quickly fit ring gear into housing and let it cool slowly.
8. Assemble flywheel.

**FLYWHEEL HOUSING****Disassembly**

1. Disassemble flywheel.
2. Remove bolts and nuts.
3. Remove screws.
4. Disengage housing from legs.

**Assembly**

5. Reverse operations 2 to 4, except:
  - a) Make sure that flywheel housing and engine block surfaces are mutually clean.
  - b) Lightly coat both threads with an appropriate sealing paste.
6. Assemble flywheel.






## CRANKSHAFT REAR RETAINER

## Disassembly

1. Disconnect flywheel housing.
2. Remove bolts and washers.
3. Remove retainer housing together with gasket.
4. Remove and discard gasket.
5. Cover retainer from its housing.

## Reassembly

6. In reassembly, the fly retainer is assembled with its rear face aligned with the rear surface of its housing. Inspect wastebell flange and, if it is scored, the rear retainer must be inserted further into its housing. It should be inserted 3.2 mm and, if necessary, a further 3.2 mm, making 6.4 mm in all. If these operations should not be sufficient the wastebell flange contact surface has to be modified.
7. Lubricate retainer and its housing with clean engine oil. Place retainer in its housing to the required depth with tool PD 145-1.
8. Install new gasket lightly smeared with suitable sealing paste.
9. Lubricate retainer, wastebell flange and tool PD 145-2 with clean engine oil.
10. Using tool PD 145-2, install retainer assembly and its housing. Make sure it is correctly engaged on shaft top.
11. Remove tool PD 145-2.
12. Reverse operations 1 and 2.




**ENGINE CRANKCASE****Disassembly**

1. Disconnect belts between front side and engine.
2. Drain oil from crankcase and collect it in suitable container.
3. Remove nuts and washers securing front duct to belt pulley.
4. Remove bolts securing washers to flywheel housing.
5. Support crankcase and remove bolts, washers and self-locking nuts securing washers to engine.
6. Separate crankcase from engine.
7. Remove and discard gasket.

**Assembly**

8. Reverse operations 1 to 7, except:
  - a) Check that contact surfaces are clean.
  - b) Fit new gaskets, lightly coated with suitable sealing paste.
  - c) Place a new gasket in slot located on crankshaft end bearing cap.
  - d) Fit washers to correct level with specified engine oil.

**OIL PUMP****Disassembly**

1. Disconnect engine washers.
2. Remove intermediate gear shaft.
3. Withdraw intermediate gear.
4. Disconnect pump high pressure pipe.
5. Remove fixing bolts and washers.
6. Withdraw oil pump.

**Assembly**

7. Reverse operations 2 to 6.
8. Adjust oil pump clearance.



## REMOVING THE PUMP

## Disassembly

1. Disconnect all pipes.
2. Remove pressure pipe.
3. Remove the two bolts and washers securing screen filter plate.
4. Remove pipe and screen filter.
5. Remove dipole.
6. Remove pump driver gear.
7. Remove key.
8. Remove the two bolts and nuts securing pump plate.
9. Remove pump plate and safety valve.
10. Remove ring seal.
11. Check clearance at all points between maximum diameter of lateral valve and minimum diameter of external bore. If it exceeds 0.024 mm, a new pump must be installed.
12. Check clearance between top of valve and pump body. If it is greater than 0.202 mm, a new pump must be installed.
13. If necessary, remove collar pin.
14. Remove ring.
15. Remove dipole.
16. Remove safety valve.

## Assembly

17. Reverse operations 13 to 17 and 1 to 10, except at their primary gear with the 300-cm<sup>3</sup> model, until it is fixed up with dipole die.
18. Install a new valve.



**CONNECTING ROD END BEARINGS****Disassembly**

1. Disconnect oil pump.
2. Turn crankshaft housing to be disassembled to at B.D.C.
3. Remove nuts from big end bolts.
4. Remove big end cap together with half bearing.
5. Remove half bearing from cap.
6. Remove big end bolts.
7. Turn crankshaft until upper half bearing can be removed.
8. Rigged operations 2 to 7, to disassemble remain big bearings.

Inspect half bearings for wear or scoring. If any should be badly, replace complete set.

Check for wear on crankshaft crankpin with a micrometer. The diameter of crankpin should be checked both on a horizontal and vertical plane and at both ends.

When any condition exist over exceed 0.081 mm, if above this limit, the crankshaft must be ground or replaced.

**Assembly**

8. Reverse operations 1 to 8, IN/OCC.
  - a) Check that all components are maintenance clean and lubricated with clean engine oil according to specifications.
  - b) Make sure half bearing legs fit into connecting rod grooves and that they are correctly assembled to their original positions.
  - c) The remaining rod nuts and bolts are spaced and whenever they are replaced original parts from the engine manufacturer must be used.
  - d) Make sure that base of both heads is seated correctly on connecting rod shoulder.
  - e) Check that remaining rod and big end bolts are assembled with matching identification marks and on left side of engine.
  - f) Tighten big end nuts to a torque of 7 kg m.

## PISTONS AND CONNECTING RODS

## Disassembly

1. Disconnect cylinder head.
2. Disconnect big end bearings.
3. Withdraw pistons and connecting rods through top of cylinders.

## Assembly

Check condition of pistons, rings and liners and if they are in all respects, replace them.

4. Check all parts carefully and lubricate them with clean engine oil according to specifications.

**NOTE:** Place rings on pistons in such a way that each ring gap is at 180° to relation to previous one.

5. With tool 3825, insert each piston and connecting rod into top of its respective cylinder. Make sure that the wrist of 3825 is towards front of engine.

6. Assemble big end bearings, but without assembling oil pump.

7. Check height of each piston with tool P145B. A.T.S.C. die piece number 02707 is 0.2708 mm below top surface of block.



8. Assemble oil pump.
9. Assemble cylinder head.



## REMOVING PISTONS AND CONNECTING RODS

## Disassembly

1. Disassemble piston and connecting rods.
2. Remove rings from each piston.
3. Remove clippers from each piston.
4. Heat pistons in a clean bath to a temperature of 30° to 60° C.
5. Carefully extract piston pins.
6. Remove connecting rods from pistons; pay special attention to ring grooves.
7. Inspect pistons for scoring.
8. Check piston pin adjuster's.
9. If necessary, extract small end bearing.
10. Place rings in clean, grease proof oil tin of cylinder and check ring gap. This oil must be broken!



## Five piston rings:

1st ring 0.26 to 0.50 mm.

2nd, 3rd and 4th rings 0.26 to 0.50 mm.

## Turbocharger rings:

1st, 2nd and 3rd rings 0.26 to 0.50 mm.

4th ring 0.26 to 0.50 mm.

11. After installing new rings, check vertical clearance of grooves. This clearance must be between the piston rings:

1st and 4th rings 0.47 to 0.102 mm.

2nd ring 0.262 to 0.088 mm.

3rd ring 0.158 to 0.062 mm.

## Vertical piston rings:

1st and 2nd rings 1.058 to 0.887 mm.

3rd ring 0.885 to 0.887 mm.

4th ring 1.028 to 0.887 mm.

## Assembly

12. If necessary, install new small end bearings, using oil lubrication; hole with convenient oil small end.
13. With tool 355, check that each end is perpendicular and parallel. If there is any distortion, it must be replaced.
14. Rear pistons in a clean liquid, place connecting rods in each respective pistons and insert piston pins.

**NOTE:** The piston head cavity is offset toward towards one of its sides. Join up pistons in remaining side with cavity towards one resulting rod end top end bearing cap identification marks.

15. Install two new clippers on each piston pin.

18. Starting from the top, install rings in the following order:

- 1st. Chromium ring.
- 2nd. Intensely stepped compressor ring.
- 3rd. Internally stepped compressor ring.
- 4th. Adjustable scraper ring.

**NOTE:** The intensely stepped compressor ring must be planed with step renegade plane head. Place rings on each piston so that the gap of one ring is at 180° in relation to the previous one.

19. Assemble pistons and connecting rods.



### CYLINDER LINING

#### Disassembly

1. Disassemble pistons and rods.
2. Remove cylinder head bolts.
3. With put 70-80, suitable adapter and buffer hydraulic cylinder, extract liners from cylinders through top of block.

#### Replacement

4. Remove operations 1 to 3, reverse.
  - a) Cylinders head from should be handled and stored with care. The slightest defect or flaw could cause considerable damage when assembled in block.
  - b) Cast iron liners with flange should not be ground, but have to be replaced by new unflashed iron.
  - c) Before bearing a new liner, both it and the corresponding cylinder should be carefully cleaned, especially for grease at top of cylinder where lead flange is located.
  - d) All parts should be copiously lubricated before assembly with oil-antirust oil.
  - e) Check that flange of each liner does not deform by housing at top of cylinder.
  - f) When it is completely in place, the top of each liner must be between 0.050 and 0.150 mm above top face of block.
  - g) Check position of pistons until at all adjust, replace them.
  - h) Allow a settling in period before checking exact dimensions of liners.
  - i) Each liner must be checked in three positions: upper, middle and lower; the readings must be taken both vertically and parallel to center line of block.




**CRANKSHAFT THROST HALF WASHERS****Disassembly and replacement**

1. Disassemble crankshaft.
2. Push crankshaft backwards and check axial play between front half washer and crankshaft. The clearance should be between 0.15mm and 0.284mm.
3. If axial play does not lie within these limits, proceed as follows:
  - a. Disassemble crankshaft rear washer.
  - b. Take out the two timing belts.
  - c. Remove washers and bearing cap together with the two lower thrust half washers.
  - d. Push the two upper half washers with a wire steel key can be withdrawn.
  - e. Replace the two washers.
4. Before re-assembly, lubricate all components with clean engine oil.
5. Place the two rear upper thrust half washers in their housing with flat face towards half bearing.
6. Place the two rear lower thrust half washers in rear washers bearing cap and assemble it.
7. Put in timing belts and tighten them to a torque of 10 kg m.
8. Check axial play again.
9. If axial play is still not right, larger size thrust half washers may be bought. Repeat operations 4 to 8.

**NOTE:** Each upper and lower thrust half washers have to be of the same thickness.

10. Fit wearplate crankshaft rear washers.
11. Assemble crankshaft.





## CRANKSHAFT

## Disassembly

1. Drain engine oil.
2. Separate starter between front axle and engine and between engine and piston.
3. Support engine on suitable stand.
4. Disassemble timing case.
5. Disassemble fly and bearing.
6. Disassemble thrust ball washers.
7. Disassemble of pump.
8. Disassemble crankshaft gear.
9. Remove the eight bolts securing remaining bearing caps.
10. Remove the first bearing caps together with ball half bearings.
11. Withdraw crankshaft.
12. Remove upper half bearings from crankcase upper part.
13. Check all components carefully. Check with a micrometer for wear or ovalization on crankshaft journals and connecting. The diameter of journals and connecting should be checked both horizontally and vertically and at both ends. Wear and ovalization must not exceed 0.004 mm. Examine for cracks and deterioration crankshaft.

Diameter of journals and front and rear journals may be ground to the following measurements:

- a) Minus 0.24 mm
- b) Minus 0.08 mm
- c) Minus 0.702 mm

If crankshaft requires grinding below 0.702 mm, install a new crankshaft. The width of the crankpin might be increased on grinding, but in no circumstances must it exceed 58.88 mm.

It is important to keep journal and crankpin neck in accordance. After grinding, rough edges should be removed from lubrication holes. Tumbled crankshaft's surface treated with Tumbling process after grinding. If this treatment cannot be carried out, a new crankshaft must be assembled.

If the three assembly patches of the crankshaft are cracked from both ends, the crankshaft flange should be ground.

Remove only the minimum amount of metal from the flange to eliminate scoring. The flange should not be widened below a minimum diameter of 118.11 mm.



It is not necessary to apply tumbling process to flange. Examine carefully for cracks and damage on it.

## Assembly

14. Reverse operation 9 to 11, except:
  - a) Check that cylinder block and crankshaft installation lines are not blocked.
  - b) Check that bearing cap lining holes are not blocked. Only bolts supplied by engine manufacturer should be used.
  - c) Make sure all components are thoroughly clean and well lubricated with engine oil.
  - d) The bearing caps are numbered, starting from front of engine. Each bearing cap is also marked with the same serial number as it stamped on back bottom face and they must be reassembled.
  - e) Tighten bolts to a torque of 16 kg m.
15. Assemble crankshaft thrust ball washers.
16. Assemble oil pump.
17. Assemble fly and bearings.
18. Assemble timing case.
19. Reverse operation 2.
20. Fill engine with specified oil.

## SECTION 5:

# FUEL SYSTEM

### CONTENTS

	PAGE
Specifications Model 200	1
Specifications Model 400	3
Description	5
Air filter	5
Fuel tank	6
Fuel pump Model 200	8
Fuel Pump Model 400	8
Fuel filter	9
Fuel injection pump	9
Fuel injectors	7
Cold weather starting issues	7
Removing and installing the air cleaner oil pan	7
Removing and installing the air cleaner	8
Removing and installing the fuel tank	8
Removing and installing the fuel tank shut off valve	9
Removing the fuel shut off valve	9
Removing and installing the fuel pump	9
Disassembly and assembly of fuel pump Model 200	11
Disassembly and assembly of fuel pump Model 400	12
Removing and installing the fuel filter	12
Removing the fuel injection pump from the tractor	14
Installing fuel injection pump on the tractor	14
Injection pump setting	16
High lift sprayer adjustment	18
Low lift sprayer adjustment	18
Removing and installing injectors	19
Testing the injector needles	19
Bleeding the fuel system	20
Trouble shooting	20



Publication SP-529-USA-1  
1st Edition 1/78

**SPECIFICATIONS Model 300**

Fuel tank location	In upper part of engine, in front of cooling volume
Fuel tank capacity	60 l
Sediment trap	Subsidiary fuel pump
Fuel filter	Equipped with replaceable element
Injection	
Make	C.A.V.
Type	C.P.A.
Governor	Mechanical
Maintenance	11 or 14 200 revolutions/700 r.p.m.
Maximum full load engine speed	2,380 r.p.m.
High idle r.p.m. (no load)	2,380 r.p.m.
Injection at various throttle settings	Distributor
Code number of characteristic plate	6W15100-N/338
Synchronizer with engine (2000) inactive element	34"
Low idle r.p.m.	600 r.p.m.
Injection	
Injection pressure	180 atmospheres
Cold weather starting auxiliary device	Electric heater in the intake manifold

**SPECIFICATIONS Model 400**

Fuel tank location	In compartment located in front of steering column
Capacity of the fuel tank	88 ltr.
Sediment cup	Built in on fuel filter
Fuel filter	Equipped with replaceable element
Injection pump	
Make	E. A. S.
Type	E. P. A.
Governor	Mechanical
Mixture ratio	11.4 vol. to 200 cc/min at 1000 r.p.m.
Maximum full load engine speed	2,200 r.p.m.
High idle r.p.m. (no load)	2,375 r.p.m.
Number of injection timing couplings	One
Code number on identification plate	MP-11100-9-1200
Synchronizer with engine timing in action advanced	30° before T.D.C.
Low idle r.p.m.	600 ± 10
Injection	
Operating pressure	180 atmospheres
Cold weather starting auxiliary device	Electric heater in the intake manifold

**DESCRIPTION**

In the fuel system the fuel is sucked up by the mechanically controlled feed pump, which supplies it at low pressure, through the filter, to the injection pump. This component distributes the fuel at high pressure to the injectors. The moving parts of the injection pump are lubricated by the fuel which passes through it and do not require any additional lubrication. The fuel leak plug allows the excess fuel which was not injected to return to the filter.

The used injector starting heater is fed by means of the fuel leak pipe. The above operations must be observed when servicing any component of the fuel system. All plugs and sealing strips should be kept in hand so as to stop up the fuel connections as soon as any one of them is disconnected. Do not use solvents, steel or fire-retarding tape to clean any part of the system.

**AIR FILTER (Fig. 1)**

The air cleaner is fitted to the oil tank top and is located in the front part of the engine, behind the front grille and above the battery. It is equipped with a centrifugal type prefilter. The higher-than-average air flow rate performance provided by this unit is the result of preacceleration, which allows the greater part of the particles which are carried in suspension in the air to be deposited. The only maintenance which the prefilter requires is cleaning from time to time using the air.

The air passes through the prefilter and enters the cleaner by the central duct. On reaching the bottom it follows the oil contained in the lower part in order to pass to the cleaner elements. The centrifugal force resulting from the sudden change of direction of the air which it meets, the oil, produces a large number of particles here.

The air continues towards the upper part of the cleaner through the elements which complete the filtration of any possible remaining particles.

The oil and particles drawn by the air through the elements return to the cup which the particles sink to the bottom by sedimentation. In this way the filtered air reaches the upper part of the diesel and dieso pump via the valve of the engine intake manifold.

The air cleaner requires constant regular attention if its efficient operation is to be assured. Negligence with the regular care, can impact the performance of the engine.




Fig. 1 - Cross section of the air cleaner

The air cleaner may even be removed, cleaned and filled with new oil up to the oil level mark, every ten service hours or every day.

Attention must be given to the hose and clips which join the filter outlet to the engine intake manifold, since any defect in these components could cause the effect of the air filter.

### Fuel tank

The fuel tank has a capacity of 50 litres and is mounted in the upper part of the tractor, in front of the steering column. This ensures a constant flow of fuel to gravity feeder all weather. The tank is secured in rubber clamps secured by screws. The

fuel shut-off cock is located at the bottom of the tank and has a built-in wire mesh filter. The filler neck, located at the top of the tank, is provided with breather vent cap.

### Fuel pump Model 300

The fuel pump is of the mechanical diaphragm type, driven by the engine camshaft. This pump has a built-in manual primer and a direct-acting sediment tap through which accumulated water and sediment can be removed. The pump is mounted on the

right-hand side of the engine, between the fuel shut-off cock and the filter. A wire mesh screen, located above the sediment tap, protects the air-filter valves located in the upper pump body assembly.

### Fuel pump Model 400

The fuel pump is of the mechanical diaphragm type, driven by the engine camshaft. The pump is mounted on the right hand side of the engine between the fuel shut-off cock and the filter, and is equipped with

a manual primer. A wire mesh strainer, fitted to match the fuel pump cover, protects the sediment tap located in the pump body.

### Fuel filter

The fuel filter is mounted between the fuel pump and the injection pump. This filter prevents the dirt and non-combustible oil from the injection equipment from being sent to the fuel injectors that might be present in the fuel. Careless filling may wash the filter and render its operation. On Model 400, the lower part of

the filter is composed of a sediment trap with drain cock through which accumulated water and sediment can be removed. The filter element of the replaceable cartridge type, must be changed for a new one every 500 working hours. Do not try to clean a mesh in the sediment trap be discarded.

### Fuel injection pump

The fuel injection pump of the C.A.V. type, is a robust, high pressure unit with a built-in mechanical governor controlled by a gear from the engine timing case. If the control, when fuel is used and attention

is given to the fuel filter, the injection pump should give rise to very few problems. When servicing the injection pump, follow the recommendations given on pages 11 to 16.

### Fuel Injection

The fuel injection spray the engine combustion chamber with the required amount of fuel according to the speed of the engine. The operating position of the injector is 28° atmospheric. Do not attempt to service the system without adequate preparation

### Cold weather starting heater

To make cold weather starting easier, there is a heated heater fitted on the intake intake which facilitates the preheating and priming of the intake manifold and combustion chamber. The first clockwise movement made by the starter switch turns the heater on. A second movement in the same direction switches on the heater mounted in the intake manifold, so that the heater coil produces a spark which causes the fuel release valve. At the same time a small amount of fuel flows from the fuel line pipe through the heater where it is vaporized and then ignited by the heater coil. A third clockwise movement made by the starter switch activates the same motor and the ignited fuel is drawn into the engine. The operation of the heater may be checked by removing the plug A, fig. 2 from the heater manifold B, fig. 3.

If the heater is operating correctly, shortly after it has been turned on by the starter switch, the flame which is produced inside the manifold by the vaporization of the heated fuel may be observed through the plug hole.

If the heated heater is defective it cannot be repaired.

### TO REMOVE AND INSTALL THE AIR CLEANER OIL PAN (fig. 2)

- Remove the front grille from the heater.
- Open the three-way valve, disengaging the pet. Oil and filter cleaner (O),
- Assembly is reverse order, making sure that the oil pan is clean and filled with new oil up to the level indicated.

and the use of suitable equipment. It is advisable to service tank at least once every 500 working hours. This will require more frequent attention if the fuel is not kept sufficiently clean or if the engine cooling system is not properly attended to.



Fig. 2 - Cold weather starting heater.

- Before turning the clock, check the correct placement of the components as an oil to change the valve and which ensures the tightness of the cleaner.

**NOTE:** - It is very important to keep the oil clean to prevent engine performance from being adversely affected.



Fig. 2 - Disconnection of the air cleaner

#### REMOVAL AND INSTALLATION OF THE AIR CLEANER ON THE TRACTOR (Fig. 4)

- Disconnect the rubber tube (A) that goes from the air cleaner to the intake manifold.
- Remove the profile and the air cleaner intake elbow (B).

#### REMOVAL AND INSTALLATION OF THE FUEL TANK ON THE TRACTOR

- Remove the hood and instrument panel.
- Remove the steering wheel.
- Close the fuel shut-off cock and disconnect the pipe from the fuel pump to the shut-off cock of the cock.
- Disconnect the injector fuel tank pipe and the additional heater wiring pipe.

#### TO REMOVE THE FUEL SHUT-OFF COCK FROM THE TANK

- Disconnect and plug (a) the shut-off cock and the pipe which goes from the fuel shut-off cock to the fuel pump.



Fig. 3 - Removal of the air cleaner

- Take out the four cleaner clamp (C) and screw (D). Break the cleaner by following the procedure to remove (C).

- Take out the four screws that secure the fuel tank lock breaker.
- Remove the fuel tank.

To install the tank, carry out the above procedure in reverse order, making sure that the nut is always in place between the tank and the bracket.

- Drain the fuel tank.
- Uncover the fuel tank shut-off cock completely.



**TO REMOVE AND INSTALL THE FUEL PUMP**

(Fig. 3)

- Close the fuel shut-off cock.
- Disconnect the intake and outlet pipes, plugging their ends to prevent the entry of foreign matter.
- Remove the two nuts and washers which secure the pump to the intake filter inspection cover.
- Remove the pump, using required tools.

Install the fuel pump in the tractor by reversing the above procedure making sure that the pump flange face and its seat in the inspection cover are clean.



Fig. 3 - Removing the fuel pump

**Testing a newly installed fuel pump**

- Disconnect the outlet pipe from the pump to the filter, providing a free outlet from the pump.
- Crank the engine and check if there is a well defined jet of fuel from the outlet once every two revolutions of the engine.

Alternatively this operation can be carried out with

the manual primer, which would give the same result every time the primer is actuated. However, it might happen that the engine stops in a position that causes the cam which drives the fuel pump to be in an over-lifted position, thus making it impossible to operate the manual primer. In such a situation allow the solution to be crank the engine for one complete revolution.

**Testing the fuel pump before installation**

To test the fuel pump off the tractor, first operate the manual primer, moving the diaphragm to the left of its usual position, and seal or block the outlet hole with your finger. If the valve at the diaphragm are defective, the diaphragm will immediately resume the upper end of its travel when the manual primer is released. When placing your finger in the inlet hole and operating the manual primer, a

convuls' depression and resistance to its movement should be observed. When the manual primer is operated with the intake and outlet holes kept free, a characteristic sound should be heard. It should be kept in mind that when the manual primer is operated by hand, it may be applying a greater force to the diaphragm than it normally would when mounted on the engine.




Fig. 3 - Fuel pump Model 200

## Exploded view of the Model 90 fuel pump (Fig. 4)

- 1 - Drive and rocker
- 2 - Gasket
- 3 - Spring
- 4 - Diaphragm
- 5 - Diaphragm spring
- 6 - Gasket
- 7 - Rocker spring
- 8 - Nut
- 9 - Washer
- 10 - Seal
- 11 - Rocker pin retainer
- 12 - Rocker pin
- 13 - Cover pump body
- 14 - Expansion valve
- 15 - Expansion valve spring
- 16 - Nut
- 17 - Lockwash ring
- 18 - Lockwash ring
- 19 - Nut
- 20 - Gasket on cover (Fig. 5)
- 21 - Upper pump seal

## Exploded view of Model 90 fuel pump (Fig. 5)

- 1 - Cover
- 2 - Washer
- 3 - Top pin
- 4 - Gasket
- 5 - Spring
- 6 - Washer
- 7 - Upper pump body
- 8 - Valve gasket
- 9 - Valve
- 10 - Diaphragm
- 11 - Diaphragm spring
- 12 - Lower pump body
- 13 - Pin
- 14 - Valve pin
- 15 - Washer
- 16 - Spring
- 17 - Manual primer pin
- 18 - Spring ring
- 19 - Manual primer spring
- 20 - Manual primer

## DISASSEMBLY AND ASSEMBLY OF THE FUEL PUMP Model 90 (Fig. 4)

- Remove the fuel pump from the engine.
- Thoroughly clean the outside of the fuel pump.
- Remove the dip (17), the lockwash ring (18) and the cover gasket or seal (20).
- Mark the top cover and the lower body with a file so as to ensure correct assembly.
- Tighten the five screws and their washers (1) which secure the top cover to the body of the pump.
- Separate the cover and the body.
- Turn the diaphragm (4) and remove it (6). Its spring (5) and the valve (8). If the diaphragm is defective, it must be replaced with a new one. At the same time, if there is any sign of wear of the two springs (3 and 7) being damaged or weak or of the rocker (9) and the lower body being damaged, replace them as well.

**NOTE.** - Wear in the contact area of the pump can may be disregarded provided that it does not exceed 0.25 mm. Bear in mind that accumulated wear in the cam arm, pin, diaphragm and valve linkage can cause a considerable amount of the rocker travel, thereby reducing the movement of the diaphragm and reducing the efficiency of the pump.

Valve assemblies cannot be repaired. If a valve is defective it must be replaced by a new one. Before installing a new valve, first be sure to dip it in petroleum. If the diaphragm assembly does not work properly it should be fit a new one.

To assemble fuel pump, carry out the above procedure in reverse order.




Fig. 7 - Fuel pump Model 90

### DISASSEMBLY AND ASSEMBLY OF THE FUEL PUMP Model No. (Fig. 7)

- Remove the fuel pump from the tractor.
- Thoroughly clean the outside of the pump and mark the upper and lower pump body flanges to ensure reassembly in the same position.
- Take out the cover (1) and the washer (2) which secures the cover (3) on the upper body (7) and remove the cover and diaphragm (6). If the diaphragm is not in good condition, it should be replaced by a new one.
- Take out the six screws (8) and washers (9) which secure the upper to the lower body and separate them.
- Very carefully remove the valves (10) from their housing in the upper part of the pump. If the valves are defective replace them. Take out the gaskets (11). Assemble the new valves and gaskets in reverse order. To secure the valve in its housing, use an appropriate punch in four points of the upper body.
- Remove the lower body (12) and the diaphragm to see if it has become hard or cracked and replace it if necessary. At the same time, check the diaphragm post-rod.
- Remove the spring from the lower body of the

- pump (13) and examine it to see if it is twisted or noisy. If the spring has to be changed make sure it is replaced with one of the same characteristics.
- Remove the pin (14), the washer (see 21), the spring (15) and the linkage (16) from the lower body. Check to see if the parts are worn and replace them if necessary.
- Check to see if the upper and lower body flanges are warped. Lightly grind the cast faces if necessary.
- To assemble the pump follow the disassembly procedure in reverse order, making sure that the edge of the diaphragm (16) is flush with the flange of the pump bodies. If it projects, this is a sign that it has not been correctly assembled. Special care must be taken to maintain pressure in the pump and upon finally tightening the diaphragm set screws.
- After locating the pin (14), which must be flush with the pump body, use an appropriate punch in three points around the pin to do so.
- After testing the working of the pump, mount it on the tractor according to previously detailed procedures.

### REMOVAL AND INSTALLATION OF THE FUEL FILTER

- Disconnect and plug the fuel pipes at the filter end.

- Remove the set screw and take out the filter.
- Install the filter in reverse order.

### To change the fuel filter element (Fig. 8 and 9)

- Remove the lock (A) from the upper center of the filter head.
- Separate the filter body (B) from the head (C).

- Check to see if the gaskets have deteriorated.
- Assemble in reverse order, making sure the gaskets are correctly located.



The fuel filter of the Model 385 has a built-in sediment trap in the form of a telescopic glass 125. Its purpose is to drain off the impurities not retained in the fuel pump. To remove any impurity, sediment or accumulation of water, it is only necessary to unscrew the wing nut 120 and let the contents drain from the back by gravity.



Fig. 3 — Changing fuel filter (Model 385)

In the Model 385 tractor, the sediment trap is located at the fuel pump intake. To remove the trap, remove the nut of the cap (17, fig. 4) and once it has been removed separate the cap (18, fig. 4), the strainer or sieve (20, fig. 4) and the gasket (19, fig. 4), all of which can be easily cleaned. Assemble by following the procedure in reverse order.



Fig. 4 — Changing fuel filter (Model 385)

**TO REMOVE THE INJECTION PUMP FROM THE TRACTOR**

If it is necessary to remove the injection pump from the unit, proceed according to the following instructions:

- Remove the high pressure pipes between the pump and the injectors, plugging the holes to prevent the entry of foreign matter.
- Remove the low pressure fuel pipes from the intake and outlet terminals and plug the holes.
- Disconnect the shut-off and friction controls and their inter-connections.

**TO INSTALL THE INJECTION PUMP IN THE TRACTOR**

- Carefully clean the surfaces which have to be in contact with the injection pump and its coupling.
- Get the pump (fig. 11) in place, making sure that

- Remove the screws and washers which secure the injection pump on the mounting flange.
- Go to 53RD Model 385 manual, through the injection valve located in front of the firing pin, the three screws that secure the pump link pin on the firing pin.
- Mark the position of the control gear in such a way that it should always position in the level of a spring constant.
- Carefully take out the injection pump.

the link pin hole is correctly held up with the firing gear pin.




Fig. 16 - Fuel injection pump

- |                               |                                    |
|-------------------------------|------------------------------------|
| A - Drive shaft               | G - High pressure adjustment screw |
| B - Drive shaft splines       | H - Distributor                    |
| C - Distributor cover         | I - Low pressure adjustment screw  |
| D - Distributor control lever | J - Low pressure adjustment screw  |
| E - Timing lever              | K - Fuel body throttle screw       |
| F - Low pressure lever        | L - Distributor                    |
|                               | M - Distributor                    |

- The idle gear hole appears, by means of the timing gear pin, the idle pump can only be adjusted in a position when adjusting.
- When the hole and the pin are exactly fitted up, pressure can be put on the pump with the lock flange nut and the lock hole and respective nut can be assembled.
- Before finally tightening, it is necessary to align the pump-gearing marks, as is shown in Fig. 11.

- Once both marks match, align the nuts.
- Assemble the low pressure plate in their respective fuel intake and outlet connections.
- Assemble the high pressure pipes.
- Reconnect the shut-off and throttle control with their return springs.
- Eliminate air from fuel system.

#### INJECTION PUMP SETTING

If the timing order has been followed according to the marks on the timing gears and on the assembly flanges, which should be correctly aligned (Fig. 12), then the fuel injection pump setting will be correct.

It is also possible using the injector adjustment marks on the inside of the pump body. In order to be able to use these marks, the injection pump must be removed (C, Fig. 12).




Fig. 11 - Isolating the injection pump

It must be remembered that in order to gain access to these timing adjustment screws, the cap fitted on the cover must be broken. Therefore, once the necessary checks have been made, the pump must be sealed again with the flexible seal.

After first removing the inspection cover, proceed as follows:

- Turn the engine until the piston is at T.D.C. of the compression stroke.
- Loosen number 1 cylinder exhaust valve adjuster screw sufficiently to allow the rocker arm to be moved to one side and the push rod to be taken out. Turn the rocker arm on its shaft so that the valve spring is accessible for use of valve adjuster.
- Remove number 1 exhaust valve spring and allow the head of the valve to rest on the piston head.
- Draw a dial gauge on the end of the valve stem (see Fig. 12) and adjust to zero on the maximum lift point obtained by turning the engine, preferably the T.D.C.
- Turn the engine in the OPPOSITE direction to



Fig. 12 - Measuring adjusting screws on pump and tappet

that of normal rotation until the piston and valve have travelled a distance of 0.29 mm (0.011 in) and 0.16 mm (0.006 in) downwards in the cylinder.

- This is the equivalent of an angular movement of the T.D.C. to the B.D.C. of the flywheel of 24° (Model 350) and 20° (Model 400) and represents the static setting point. However, it is possible to turn the engine beyond this point, that is, 1.20 mm and then return to 0.29 mm (Model 350) or 0.46 mm and return to 0 mm (Model 400) in the normal direction of rotation. This will eliminate any error due to the normal timing gear clearance.
- When this point of static adjustment has been determined exactly, the mark (on Model 350) or (on Model 400) on the injection pump injector should be aligned with the straight end of the adjustment ring (Fig. 16).
- Then, the pump adjustment is correct if the 6 mm pin, as we attempt to move the ring inside the pump, as this will not alter the adjustment at all. If it were moved it would have to be necessary to remove the pump from the engine and place the ring correctly on a test bench.





Fig. 10 - Setting injection pump adjustment.

- To complete adjustment, in the case in which it is not yet correct, proceed as follows:
- Loosen the nuts which secure the injection pump on the mounting flange and turn the body of the pump in the appropriate direction. If after working on this last adjustment, the adjusting marks are not aligned, check once more on the injection pump flange and remove the oil seal.
- Once the injection pump adjustment has been completed, turn the engine in the opposite direction to that of normal operation until the pointer has moved 5.52 mm (Model 200) or 8.13 mm (Model 400), in order to check that the straight part of the plug and is now aligned with the mark on the topplate.
- Once the injection pump adjustment has been correctly carried out, always turn the engine in its normal direction of rotation until number 1 piston reaches T.D.C., in order to remove the oil gauge and reassemble the valve springs.
- TAKE CARE not to turn the engine backwards in the opposite direction, since this would cause the exhaust valve to fall inside the cylinder and




Fig. 11 - Letter and line stamped on pump flange, aligned with plug end.

valve is necessary to prevent the cylinder head to get it out.

- Fit gasket, loose rocker arm contacts and adjust valves again.

Fig. 12 - Setting exhaust drop.  
Arrow B - Faces of opposite main injection lines.

**HIGH IDLE ADJUSTMENT**

To adjust the high idle (without load), the idle control equipped on the injection pump characteristics plate should be taken as reference. The best fuel figure of this unit correspond to this speed. Cuts example: 50V 51755051300 (Model 300 and AP 517000 200 (Model 300) with three-cuts it model indicates that the engine should turn at a maximum of 2,500 r.p.m. and 2,300 r.p.m., respectively.

Adjustment of this speed has to be made by means of the high idle screw (E, fig. 10). Beating is strict that this screw is closed and that therefore, it will have to be needed again since this operation has been carried out.

The engine must not be allowed to operate at a speed above the specified one or serious damage will result.

**LOW IDLE ADJUSTMENT**

To adjust the low idle (r.p.m.), first run the engine off a medium normal operating temperature. Then set the adjusters screw (F, fig. 10), which are as stop for the throttle lever located about the governor cone, so that the engine turns at a minimum r.p.m. of 600 ± 50 r.p.m. (Model 300) or 600 ± 5 r.p.m.

**TO REMOVE AND INSTALL THE INJECTORS**

- Disconnect and remove the fuel injection pipe from the injector and plug them.
- Remove the fuel lock pipe.
- Remove the two nuts and the washers that secure each injector.

To carry out this adjustment, proceed as follows:

- Check for possible leaks in the fuel system and correct them if there are. Make sure that there is no air in the system.
- Run the engine until fuel and normal operating temperature is reached.
- Fit a tachometer with appropriate extension and adjust it in the center of the crankshaft pulley set screw.
- Revolute the engine until the maximum r.p.m. indicated on the injector pump characteristics plate is reached. If the speed does not reach the figure, turn the high idle adjustment screw (E, fig. 10) counterclockwise until the appropriate speed is obtained. Once adjusted, check it with the tachometer and seal the adjustment screw again.

Model 400, by turning the screw clockwise, engine speed is increased and by turning it counterclockwise, it decreases.

A new engine cannot be expected to life perfectly until the machined surfaces have had time to settle themselves to one another properly.

- Take out the injectors gently and evenly.

When installing them, reverse the procedure, noting you to always change the copper washers and to have the lock nuts correctly tightened.

**TO TEST THE INJECTOR NOZZLES**

An effective method of checking the operation of a suspected defective nozzle is as follows:

- Run the engine over at slightly above idling speed.
- Loosen the injector pipe connections at each injector, in turn.
- As soon stop to the engine r.p.m. indicates that the injectors are making noise. If a nozzle does

to the engine r.p.m. occurs when a particular injector connection is loosened, take out this injector for repair or replacement.

When a defective injector is found, it is advisable to take out all the others of the same type for removal during its replacement.

**NOTE.** - Do not attempt to service the injectors without appropriate means and adequate equipment.

**TO BLEED AIR FROM THE FUEL SYSTEM**

The presence of air in the fuel system will give rise to poor engine performance and prevent starting. For this reason the system must be bled whenever it is banded.

To bleed the system, carry out the following procedure:

- Check that at completion, work from those the have to be banded for bleeding purposes, are well tightened.
- Loosen the filter return pipe union nut and operate the fuel pump manual primer until fuel runs out through the nut without bubbles. Tighten the union nut.
- Loosen the two injection pump bleed valves and operate the manual primer until fuel runs out through both valves without bubbles. On operating the manual primer tighten the two pump valves from the lower side the upper one.

- Loosen the injection pump supply pipe union nut. Rotate the primer handle and tighten the union nut when fuel runs out through the nozzle with no bubbles.

- Loosen the fuel pipe union to the injector.
- Set throttle stop at full open position and check that engine shut-off control is fully tightened.
- Operate manual primer until fuel runs out through injector union without bubbles.
- Tighten fuel line nut and check that there are no fuel leakage lines through any pipe or union.

**NOTE.** - If the fuel supply pipe to the valve control starting lever has been disconnected for servicing or any other reason, it must be bled. To do this, loosen the primer plus union nut and operate the manual primer until fuel runs out through the threads without bubbles, and then tighten the union nut.

## TROUBLE SHOOTING

Problem	Possible Cause	Solution
A. Engine fails to start	1. Intake filter full	Use only recommended fuel.
	2. Fuel does not reach injection pump.	<p>Check fuel lines for blockages.</p> <p>Inspect the fuel pump and fuel line unions.</p> <p>Check to see if filter is clogged.</p> <p>Air bleed system.</p>
	3. Weak injection pump.	Install new injection pump.
	4. Injectors not working properly.	Service injectors.
	5. Injection timing incorrect.	Adjustment if necessary.
	6. Cold weather starting device does not work properly.	Inspect it's heater.
	7. Air filter dirty.	<p>Inspect connections.</p> <p>Check flow of fuel through filter.</p> <p>Clean it.</p> <p>Clean cup and fill with fuel wash with new oil.</p>
	8. Return pipe restricted.	Unblock it.

The majority of these faults can be the cause of loss of engine power.

## TROUBLE SHOOTING

Problem	Possible Cause	Solution
B. Excessive back pressure	<ol style="list-style-type: none"> <li>1. Restriction in air supply.</li> <li>2. Excessive fuel.</li> <li>3. Injectors not working properly.</li> <li>4. Faulty timing.</li> <li>5. Improper diesel fuel.</li> </ol>	<p>Unblock it.</p> <p>Adjust fuel maximum correctly.</p> <p>Service injectors.</p> <p>Adjust it correctly.</p> <p>Use only recommended fuel.</p>
C. Overheating	<ol style="list-style-type: none"> <li>1. Faulty timing.</li> <li>2. Injectors not working properly.</li> <li>3. Exhaust pipe restricted.</li> </ol>	<p>Adjust it correctly.</p> <p>Service injectors.</p> <p>Unblock it.</p>

## SECTION 6:

## COOLING SYSTEM

### CONTENTS

	PAGE
Specifications	1
Description	1
Removing and installing the radiator	4
Removing and installing the water pump	5
Disassembling the water pump Model 300	7
Assembling the water pump Model 300	8
Disassembling the water pump Model 400	9
Assembling the water pump Model 400	20
Radiator cap	11
Thermost radiator or thermostat	12
Removing and installing the thermostat	12
Fitting the thermostat	13
Anti freeze procedure	13
Trouble shooting	14
Trouble shooting chart	15



## SPECIFICATIONS

Type	Water circulation by thermostat aided by centrifugal pump and temperature control by thermostat.
Height of pump above water level:	
Model 300	290.3 mm
Model 400	297 mm
Valve(s)	With forward flow.
Fan	With free blades of 410 mm diameter.
Cooling water capacity:	
Model 300	10.5 litres
Model 400	12 litres
Thermostat	
Valve begins to open	70° - 76°C
Maximum opening of valve	88° - 97°C
Fan belt deflection	18 mm

## DESCRIPTION

As shown in Figure 1, both the components and the lay out of the cooling system are in the conventional type. The only alteration required by the system is to ensure that there is no obstruction that may hinder the passage of air through the radiator and that the fan belt has the correct tension.

The cooling system water circulates through the action of the pump and thermostat. The thermostat stops off the flow of water towards the radiator and sends it back again to the block until the time when the engine has reached normal operating temperature. The water is cooled by the air which circulates through the radiator. The fan creates a

draft or suction effect, which causes the surrounding air pass through the radiator, aided in this action by the fan cooling.

Both radiator and the cylinder block are provided with valves plugs for draining the system when necessary.

The radiator filler neck has incorporated a pressure valve which reduces cooling system expansion and allows slightly higher temperatures. The cap also incorporates a depression valve to prevent a vacuum from forming when system reaches peak level.




Fig. 3 - Components of the system



### REMOVING AND INSTALLING THE RADIATOR (Fig. 2)

To remove the radiator from the unit, carry out the following procedure:

- Remove the hood.
- Remove the cap (B) from the radiator (A).
- Remove the drain plugs from:
  - a) The radiator.
  - b) The cylinder block.

When draining the system, if anti-freeze solution has been used, it may be collected in a clean container for later use.

- Disconnect the radiator lower upper (C) and lower (D).
- Disconnect the clearance to intake manifold hose.
- Remove the fan winding (E) from the radiator (A) by taking out the screws (F).
- Take out the screws (G) which secure the radiator internally on the stand.
- Take out the lower bolts (H) which secure the radiator on the chassis rail.
- Remove the radiator.

To install the radiator, carry out the above procedure in reverse order.




Fig. 2 - Radiator assembly.

### REMOVING AND INSTALLING THE WATER PUMP

To remove the water pump from the engine, proceed in the following way:

- Remove the radiator along with the fan cooling;
- Loosen the strainer;
- Take off the fan belt.

- Disconnect the hose that connects the pump to the engine.

- Take out the water seal balls that secure the water pump on the timing gear cover. Remove the pump inlet-to-gasket.

To install the pump, reverse the above procedure, making sure that the nuts and balls are assembled with their washers.




Fig. 3 - Water pump (Model 20)

- |                      |              |
|----------------------|--------------|
| 1 - Gasket           | 6 - Bolt     |
| 2 - Water seal balls | 7 - Ball nut |
| 3 - Inlet-to-gasket  |              |
| 4 - Pulley           |              |
| 5 - Fan belt         |              |




Fig. 4 - Water pump Model 401

- |                        |                        |
|------------------------|------------------------|
| 1 - Pulley             | 4 - Impeller           |
| 2 - Water pump housing | 5 - Water pump housing |
| 3 - Pump bearing       |                        |

### DISASSEMBLING THE WATER PUMP (Model 300)

To disassemble the water pump, carry out the following procedure:

- Remove the fan after disengaging the pulley on screw locking pins.
- By means of special tool 318-330 and adaptor MF-200-418 and SK-0707, remove the pulley from the pump (Fig. 6).



Fig. 6 — Removing the pulley

- Using the above mentioned tool and adaptor, withdraw the bearing shell from the pump housing by exerting pressure on the end of the shaft for the pulley (Fig. 6).
- Turn out impeller and impeller with tool MF-200-32 (Fig. 7).

**NOTE.** — The two bearings and the shaft make up a single assembly and cannot be separated.

- Inspect the impeller and pump housing for possible damage or cracks.
- Check to see if shaft is worn or if there is any fit in the bearings.

If there are serious signs of wear, replace the complete pump.




Fig. 7 — Removing the impeller and housing



Fig. 8 — Joining the water pump together

**ASSEMBLING THE WATER PUMP Model 300**

Assemble the water pump in the following way:

- Using tool MF 203, press in the shaft bearing assembly with the long end of the shaft directed towards the impeller side of the pump until the bearing is flush with the pump housing (Fig. 8).




Fig. 8 — Inserting the shaft bearing assembly

- Remove the four water pump-to-housing gear screws and remove.

**NOTE.** — Use only copper washers and make sure that the longest screw is not in the top right part, making an escape from the fluid.

- Press the pulley onto the front end of the shaft (Fig. 9) and the back of the fan is 143.5 mm from the rear of the pump housing.
- Assemble the water discharge flange with the large side flange outside.
- Insert the square tooth drive side towards the pulley.
- Press the impeller onto the shaft until there is a clearance of 0.204-0.23 mm between impeller blades and pump surface (Fig. 10).



Fig. 9 — Assembling the pulley



Fig. 10 — Inserting impeller blades

**NOTE.** — The tool that forms the back of the impeller has to be flush with rear of pump housing. Make sure that the shaft has no clearance play whatsoever inside the pump housing.

### DISASSEMBLING THE WATER PUMP Model 400

To disassemble the water pump, proceed as follows:

- Remove the lock nut and washer that secured the pump pulley to the impeller shaft.
- Remove the fan after taking out the fan screws that secure it to the pulley (Fig. 10).



Fig. 10 - Removing the fan

- Take off pulley, using tool MF 200.

- With help of tool MF-200 and rollers MF-200-A, remove the shaft with the impeller and register from shaft (Fig. 11).



Fig. 11 - Disassembling the pump shaft and rollers



Fig. 12 - Disassembling the impeller and rollers



Fig. 13 - Disassembling the bearing cover and roller roller

- Remove rubber ring from shaft bearing.

#### ASSEMBLING THE WATER PUMP Model 88

Carry out assembly of pump in the following way:

- Mount the deflector rubber and lower bearing in the pump housing.

**NOTE.** - The lower bearing has to be mounted with its protruded side facing the deflector plate. It is important to make sure that the deflector plate is properly assembled and that there is no contact with the lower ball race.

- Assemble the bearing spacer and fit spacer between both bearings with grease.
- Using special tool MP-200 and adaptor MP-200-1/3, center the spacer and insert the outer bearing (with protruded side upwards) (Fig. 10).



Fig. 10 - Centering the spacer

- Put the rubber ring on.
- Install shaft in pump housing from inside with (Fig. 11).
- Put a new rubber on, making sure friction side is next to bearings.

- With tool MP-200 and adaptor, center bearings, spacer and lower rubber (Fig. 12).



Fig. 11 - Inserting the shaft



Fig. 12 - Centering the rubber

- Screw the long pump lock bolt in bottom right hole (see from the front of the pump).
- Install the pulley together with the (Fig. 17).
- Press on the impeller (Fig. 18) and check clearance (Fig. 19).

between the inner edge of the impeller blades and



Fig. 18 - Installing the impeller



Fig. 19 - Testing impeller clearance

the pump housing, there has to be a clearance or play of 0.30 to 0.21 mm.

**NOTE.** - The clearance can be tested by placing a ruler on the rear surface of the pump. If the clearance is correct, the ruler will also be in contact with rear surface of impeller.

- Tighten lock nut to a torque of 1.0 to 0.2 kg/m.

#### RADIATOR CAP (Fig. 20)

The radiator filler neck cap is equipped with pressure and discharge valves. When the cap is working correctly, it allows there to be pressure in the cooling system during periods of sustained temperature. This pressure raises the boiling point of the coolant, thereby reducing losses due to overflow. The effectiveness of the cap is reduced by its pressure of opening and by the boiling point of the coolant. To allow the lower shut-off, the radiator cap uses the pressure valve which is actuated by the force of the spring (R), raising the radiator cap (C) to clear on the lower seat of the filler neck (S). The pressure spring is set

at 200 g/cm<sup>2</sup> ± 20%. This pressure determines the opening of the valve.

The left-hand illustration of Fig. 20 shows the operation of the pressure valve.

If when heating out the system, the circuit is filled completely, it is possible that during the working in place, the volume of the water may increase (L), subsequently will the pressure when the coolant builds up under the valve and rubber gasket (C), the excess liquid and pressure will be expelled through the overflow hose (S).






Fig. 20 - Radiator filler neck cap

In the right-hand illustration of Fig. 20, the operation of the depression valve is shown.

When the engine is shut off, the whole cooling system starts to cool and the volume of the coolant subsequently decreases. To prevent a vacuum from forming as the coolant cools down, the cap contains a depression valve (F) which is normally held against its seat by the gentle pressure of its spring (G) ( $0.0129 \pm 0.001$ ). As the volume of the coolant decreases, there is a progressive change of position with formation of a vacuum which pulls the valve (F) downwards, overcoming the spring, with the result that air, aided by atmospheric pressure, penetrates into the system through the overflow tube (D) and the valve (F).

Although the cap mechanism does not require maintenance, periodically examine the top to see that it is clean and working properly. Also examine the cap gasket and rubber filler neck to check correct

#### Thermal Resistor or Thermistor (Fig. 21)

The thermistor is mounted on the top front part of the cylinder head (next to the thermostat). Its upper terminal (A) is wired up to the temperature gauge (installed in the instrument panel).

It has an insulator (C) and metal insulator (B). At the bottom end, the resistance (D) of which decreases as the surrounding coolant temperature rises.

cooling. If the rubber surface of the valve is damaged, install a new cap.

**NOTE.** — If a new cap is needed, always fit one of the specified top and pressure. Never alter the cap or replace it with an ordinary one.

**WARNING.** — Be very careful when taking off the radiator pressure cap. In overfilled engines, the sudden escape of a jet of steam may cause physical injury.

To remove the radiator cap when the temperature of the coolant is very high or boiling, place a cloth over the cap and give it a quarter turn to the left as far as the first pressure release notch. Hold the cap in this position while the pressure escapes. Then press the cap downwards and continue turning it until it can be taken off. When getting the pressure cap off, place it in position and turn it clockwise as far as possible.

With a coolant temperature of  $80^{\circ}\text{C}$ , it offers a resistance of  $120\ \Omega$ ; at  $90^{\circ}\text{C}$  a resistance of  $40\ \Omega$ ; at  $100^{\circ}\text{C}$  about  $20\ \Omega$ ; and at  $110^{\circ}\text{C}$  about  $10\ \Omega$ . Thus, as the temperature of the coolant rises, the electric current to the temperature indicator tends to increase.

If there is any doubt about the correct operation of the thermostat, replace it with a new one. If it still fails to give correct indications, check the general health of the temperature gauge.

When installing, check that the contact surfaces with the head are satisfactory.




Fig. 21 - Thermostat

#### REMOVING AND INSTALLING

To remove the thermostat, proceed as follows:

- Take off the radiator cap.
- Purge drain the cooling system.
- Disconnect the thermostat chamber over-filler hole.

- Take out the two bolts, nuts and washers which secure thermostat cover.

- Take off thermostat chamber cover and set it aside.

To install thermostat, reverse above procedure, making sure that chamber surface are clean and the gasket is in good condition.

#### TESTING THE THERMOSTAT

To test operation of thermostat, follow the procedure described below:

- Immerse thermostat in a container of water in which a thermometer bulb has also been placed.
- Heat the water gradually and observe behaviour of the thermostat as the water temperature rises.

- The thermostat should begin to open between 80° to 85° and be fully open between 85° and 95° C.

If the thermostat does not open or does not do so progressively in the temperature range as indicated, discard it and install a new one.

#### ANTI-FROST PRECAUTIONS

For obvious reasons it is necessary to adopt preventive measures to avert the freezing of cooling system water and avoid the damage that this could cause to the engine. The best preventive measure is the use of anti-freeze, which is the most common procedure nowadays. Anti-freeze solutions naturally possess a much greater protective capacity than water. In a

cooling system that is normally in good condition, some loss may occur through seeping and spraying when anti-freeze is used. Even if such loss is not apparent, after filling the system for the first time with anti-freeze solution, there is a possibility that it may enter later. It is for this reason that at the first connection, one of the cooling system should be in

perfect condition if serious damage is to be avoided. In a system which loses coolant and requires frequent additions, anti-freeze protection will be reduced to dangerous levels.

Before filling the cooling system with anti-freeze solution, the system must first be thoroughly flushed. To make this flushing easier, the use of JCB's Cooling Circuit Cleaner Pat. A-98 and JCB's Proprietary Pat. A-94 is recommended following the instructions contained on each container.

**NOTE:** — JCB's Cooling Circuit Cleaner Pat. A-98 should be used the first time that the system is

flushed out. On subsequent occasions, use only JCB's Proprietary Pat. A-94.

At the same time, check the cylinder head torques to avoid any possibility of the head gasket leaking to the cylinder or vice versa which it could cause serious damage.

In the JCB 300 and 450 models, where capacities are 10.2 and 12 litres respectively, use JCB's anti-freeze in the proportion described in the following table.

Model 300			
Protective Limit	Proportion	Anti-freeze	Water
- 1°C	15%	1.8	8.8
- 10°C	20%	2.1	8.9
- 15°C	30%	2.7	7.9
- 20°C	40%	3.2	8.2
- 30°C	50%	3.7	8.5

Model 450			
Protective Limit	Proportion	Anti-freeze	Water
- 1°C	15%	1.8	10.2
- 10°C	20%	2.1	9.9
- 15°C	30%	2.7	9.5
- 20°C	40%	3.2	9.2
- 30°C	50%	3.7	8.5

#### TROUBLE SHOOTING

All troubles leading to engine overheating must be carefully investigated, determining and remedying any cause other than the cooling system. A defect that may apparently be attributable to the system, may disappear, for example, through the correct adjustment of the injection system or by tightening the fan belt. In this section we deal, as already in (PART) 17,

causes that may give rise to engine overheating. The alternatives described below are defects of the cooling system, although they may obviously be aggravated by deficiencies in the engine, injector loading or other causes foreign to the system and are dealing with here.

Symptoms	Possible Causes	Solutions
Over heat	<p>Insufficient water in cooling system.</p> <p>Leak of water through radiator.</p> <p>Leak through hoses or connections.</p> <p>Low flywheel water pump rotation.</p> <p>Radiator cap spring weak or broken or faulty gasket seal.</p> <p>Fan blades badly tilted.</p> <p>Belt loose or worn.</p> <p>Blower adjusted over engine water or over-riding.</p> <p>Fan belt worn or incorrect thread or does not open sufficiently.</p> <p>Head cracked.</p> <p>Restrictions in radiator tubes or water lines.</p> <p>Faulty or corroded thermostat.</p> <p>Thermostat not seated correctly in block.</p>	<p>Add water.</p> <p>Correct.</p> <p>Correct.</p> <p>Correct.</p> <p>Replace cap.</p> <p>Correct.</p> <p>Tighten or replace fan.</p> <p>Replace fan assembly or work fan's drive.</p> <p>Replace thermostat.</p> <p>Replace.</p> <p>Check system for restrictions or if a restriction is found or found, correct it.</p> <p>Fix new one.</p> <p>Check correct seat gasket.</p>
Engine does not reach operating temperature.	<p>Faulty thermostat (remains open or does not close sufficiently).</p> <p>Adjustor or other condition (oil level, water, etc.).</p>	<p>Replace thermostat.</p> <p>Correct part of the system.</p>

## SECTION 7:

# CLUTCH

### CONTENTS

	PAGE
Specifications	1
Description	2
Disconnection from tractor	3
Removal of clutch from tractor	4
Disassembling the press	5
Testing and repairing the clutch	7
Assembly of clutch press	8
Installing clutch on tractor	11
Adjustment of clutch pedal free travel	12



Publication SP-908-EXP-1  
1st Edition 1/78

## SPECIFICATIONS

Main disc diameter	200 mm
Power take-off disc diameter	200 mm
Main disc friction surface	402 cm <sup>2</sup> (each face)
Power take-off disc friction surface	402 cm <sup>2</sup> (each face)
Control system	Foot-operated
Pressure plate	12 coiled steel springs (9 disc and 3 control)
Length under load	117 kg: 3.4 (Max) 29.8 mm 80 kg: 2.2 (Min) 25.8 mm
Function	Disc 7.5 kg/cm <sup>2</sup> Clutch 6.6 kg/cm <sup>2</sup>
Free length	Disc 94.0 mm Clutch 90.4 mm
Thickness of a new friction disc	
Power take-off disc	8.8 + 0.2 - 0.1 mm
Main disc	8.8 + 0.2 - 0.1 mm
Frisk free travel	20 mm




Fig. 1 - Main

- |                            |                  |
|----------------------------|------------------|
| A - Main piston plate      | I - Spring cover |
| B - Secondary piston plate | J - Spring plate |
| C - Main piston plate      | K - Spring cover |
| D - Secondary piston plate | L - Spring plate |
| E - Main piston plate      | M - Spring cover |
| F - Secondary piston plate | N - Spring plate |
| G - Main piston plate      | O - Spring cover |
| H - Secondary piston plate | P - Spring plate |

**DESCRIPTION (Fig. 1)**

The double clutch consists of two friction discs: the main one actuates the primary shaft, while the secondary one drives the power take-off shaft.

The double disc clutch device allows the main transmission to be disengaged without interrupting the operation of the hydraulic pump or power take-off shaft.

When the main transmission is disengaged, the lever depresses the main pressure plate against the main pressure plate (C) against the engine flywheel. The operation of the hydraulic pump is stopped.

The main friction disc acts through the main pressure plate (C) against the engine flywheel. The se-

condary friction disc acts through the secondary pressure plate (D) against a fixed flywheel.

The pressure plate is actuated by three main release bolts (E) which rest in the slots cut in the clutch cover.

When the foot pedal of the clutch pedal, the lever partly compresses the release springs (F) and moves the main pressure plate backwards until it comes up against the stop-pin (G), blocking the main friction disc. When the clutch pedal is fully depressed the stop-pins compress the release springs (F) and at the same time the three springs (H) act, whereby the secondary pressure plate and secondary friction disc are released, leaving the drive and power take-off totally disengaged.

**DISASSEMBLING FROM TRACTOR**

- Disconnect side-link levers.
- Disconnect main link on tractor side with constant pedal under unbraked and a chain fixed to support rear assembly.
- Apply hand brake.
- Remove foot.
- Disconnect steering drag link.
- Disconnect accelerator cable.
- Disconnect brake cable.
- Remove foot lock and heater fuel pipe.



Fig. 1 - Disassembling from tractor






Fig. 2 - Exploded view of the clutch assembly

- |                                  |                               |
|----------------------------------|-------------------------------|
| 1 - Cover Springs                | 11 - Sliding ring lock nut 22 |
| 2 - Sliding ring pressure plate  | 12 - Sliding ring lock nut 23 |
| 3 - Sliding ring pressure plate  | 13 - Sliding ring lock nut 24 |
| 4 - Sliding ring pressure plate  | 14 - Sliding ring lock nut 25 |
| 5 - Sliding ring pressure plate  | 15 - Sliding ring lock nut 26 |
| 6 - Sliding ring pressure plate  | 16 - Sliding ring lock nut 27 |
| 7 - Sliding ring pressure plate  | 17 - Sliding ring lock nut 28 |
| 8 - Sliding ring pressure plate  | 18 - Sliding ring lock nut 29 |
| 9 - Sliding ring pressure plate  | 19 - Sliding ring lock nut 30 |
| 10 - Sliding ring pressure plate | 20 - Sliding ring lock nut 31 |
|                                  | 21 - Sliding ring lock nut 32 |

- Disconnect oil pump feed pipe.
- Disconnect drive cable from the clutch to engine.
- Disconnect oil supply, piping to front part of clutch.
- Remove clutch front housing/angle lock cover.

#### REMOVAL OF CLUTCH FROM TRACTOR

Once the clutch has been disconnected from the engine, proceed as follows to bring it to rest on C.

- Mark the position of the clutch press with respect to the flywheel (Fig. 4). This will ensure that it returns to the original position.
- Take out the six long gas-cylinder set screws and the adjustment sleeve (thickness of 3 mm) screw.
- Withdraw clutch press.
- Take out the friction disc assembly.



Fig. 4 - Release marks

#### DISASSEMBLING THE PRESS (Fig. 5)

- Use a scribe line to mark the positions on the cover (A), main pressure plate (B), secondary pressure plate (C), fly wheel (D) and thrust plate (E).
- Remove pressure nuts (F).
- Give a slight pressure on the cover to take out the three screws (G) which lock the fly wheel and the nut rings.



Fig. 5 - Disassembling the slave piston



Fig. 6 - For assembly check

- Take out three nuts (H) which secure fork to cover, and six screws (B) which secure cover to ring gear.
- Remove ring gear, cover and coil springs.
- Remove three nuts (C) and three springs, secondary pressure plate, secondary friction disc, woodruff (L) and the main pressure plate.
- Take out the three splines (A, fig. 5) of lever (K, fig. 7).
- Remove the lever and cables (IT per level).
- Take out splines (E) from forks (D) (D per fork).



Fig. 7 - Reassembling the master pressure lever

## TESTING AND REPAIRING THE CLUTCH

## Engine flywheel

With the aid of a comparator, check that wear of crank face (A, Fig. 8) of flywheel, at its greatest diameter, does not exceed 0.2 mm. If it does exceed this value, grind it.

The face must have slight feed marks or scratches.

Maximum grinding value: 3 mm.

The distance (X, Fig. 8) should not exceed 5 mm; if it should be greater, grind the flywheel.

It would then be necessary to reduce the bolts (a and b, Fig. 8) to the same amount.

**NOTE:** When carrying out these measures, make sure the contact face between the flywheel and the crankshaft are clear of impurities.



Fig. 8 - Testing flywheel




Fig. 9 - Fitting flywheel




Fig. 10 - Testing secondary pressure plate

Make sure that wear of secondary pressure plate face does not exceed 0.2 mm. The friction face must have pressure face marks or scratches; if there are any, grind the face. Maximum grinding value: 0.2

mm. If the distance (B) is less than 20 mm, change secondary pressure plate. The distance (B) is measured with a slide gauge fixed to cover spindle in hole.



Fig. 10 - Testing main pressure plate

Check that wear of plate faces have not exceed 0.2 mm. As to the case with the secondary pressure plate, the friction faces should not show any heat marks or oxidation.

Maximum grinding value 0.2 mm per face.

If the value of  $U$  is less than 15.0 mm, replace the plate.

#### ASSEMBLY OF CLUTCH PRESS

Assembly of clutch press is to be carried out in the following order:

##### Assembly of forks to lever (Fig. 11)

Holding lever in a horizontal position, assemble a provisional spindle of 60 mm and 8 mm in length, in steel consisting of the steels. Insert the 2 needles in their bearings, insert spindles, with bearing grease.

Put the fork in the lever threaded steel using lockwrench.

Insert lever spindles, which will push out provisional spindle that had been assembled, and secure it with a lock pin.

The lever spindle has a bevel on one of its ends; this bevel indicates the direction of assembly.

Characteristics of needles:  $\varnothing$  1.00 mm, length 8.4 mm.



Fig. 11 - Assembling forks

**Assembling clutch release lever (Fig. 10)**

Carry out the same operations as for a fork spindle, with a positional update of D 7 row and B row in length number of needles in case IV pin lever.



Fig. 10 - Assembling lever

**Assembling counter-pressure pressure plate assembly**

- Place the nine springs (due to their location) on pressure plate (Fig. 14).
- Assemble cover so that make sure on it before it was disassembled' touch up and set springs in their corresponding locating in case.
- Check that springs are correctly assembled.
- Assemble thrust plate, holding ring (going with a bolt) and counter pressure on plate spring with a screwdriver (Fig. 15).
- Assemble the nut, exerting slight pressure on cover to facilitate assembly.



Fig. 14 - Assembling cover-pressure plate assembly



Fig. 15 - Assembling thrust plate

#### Assembly of P.T.O. friction disc and main pressure plate

With the engine flywheel on a bench, assemble the ring gear, friction disc and main pressure plate and cover shaft with friction disc. Cover them with oil TA No. 2 (Fig. 16).

Assemble the pressure plate-springs assembly on the main shaft. Place the three springs (except an auxiliary pressure plate (Fig. 17), securing them with the nuts. Tighten them up sufficiently to obtain the clearance of 0.4 ± 0.1 mm (see Fig. 18).

Install take and counter-nuts, fitting cover plate.

Fit the fork bar stops.



Fig. 16 - Assembling P.T.O. friction disc and main pressure plate assembly



Fig. 17 - Assembling springs



Fig. 18 - Adjusting three plate

#### Adjusting height of driver plate

With special tool, Item 12, adjust height between driver plate and ring gear plate by means of steel ball (Fig. 19) so as to obtain a clearance of 0.1 mm.

$$\frac{0.1 \pm 0.1}{2 \times 2}$$

**Adjusting main pressure plate**

To adjust a clutch assembly with new discs and plates, the separation distance (D) (Fig. 10) of 1.8 mm is obtained by leaving three shims (A, Fig. 20) for each screw.

When adjustment has to be made with used discs and plates, the separation distance of 1.8 mm (D) is obtained by removing shims as required.

Once the necessary number of shims has been determined, check the main pressure plate metal (Fig. 21), which must be at least 1.8 mm.



Fig. 10 - bearing adjustment



Fig. 20 - Adjusting the main pressure plate

**INSTALLING CLUTCH ON TRACTOR**

Having completed adjustment on a bench, separate clutch assembly and flywheel.

Mount flywheel on engine.

Assemble clutch assembly with aid of tool TA, Etili 46, carefully inserting friction disc between main bearing face screws flywheel.

Tighten the clutch-to-flywheel set screws, making use of the number of shims required according to the adjustment.



Fig. 21 - Adjusting the main pressure plate



**Adjustment of clutch pedal free travel (Fig. 20)**

In order to assure the correct operation of the clutch assembly, the pedal must have a free travel of 28 mm (1.1"). This free travel is adjusted by means of the control rod when the following conditions exist:

If they happen that, after making this adjustment, the pedal operation found will be inefficient or provide complete disengagement of the power take-off, in which case we must proceed with adjustment within Figs. 19 and 20.

To overcome this irregularity, proceed as follows:

- Take off the lower clutch housing inspection cover (Fig. 20).
- Turn engine with a weak handle so that top of the fly wheel screws (11), from ring gear (12) to flywheel, are in front of opening.
- Take out three screws and springs and adjustment wire (14) per screw; the wires are located between electromechanical stop plate (13) and the ring gear (12). In this way a minimum travel of 1.4" will be assured.
- Put these screws on and proceed with the other four in the same way.
- Check that operation of clutch is correct. If it is not, repeat the above operations removing a second wire.

**NOTE:** The same number of wires must be left on each screw.

If after removing of the wires, the clutch still cannot be released completely, disassemble the clutch and see and replace any parts as required.



Fig. 20 - Adjusting pedal free travel



Fig. 21 - Adjusting clutch

## SECTION B:

## GEARBOX

### CONTENTS

	PAGE
Specifications	1
Description	2
Disassembly from tractor	5
Removal of gearbox from tractor	6
Installing gearbox to tractor	7
Installing gear shaft and reducer lower end	7
Gearbox main bearing installation	7
Disassembling gearbox	8
Assembling gearbox	14
Positioning drive gear	18
Determining shaft thickness	19
Essential rules	19
Adjusting main shaft play	19
Installing main shaft	17
Installing 3rd and 4th gear rollers and	19
Installing gear shaft and reducer lower	19
Installing gear shaft and reducer lower	20
Gear shafting	20



Publication 50-1628-24F-1  
for Edition 128

**SYNCHRONIZED**

**Number of gears** 8 forward (synchronized) and 2 reverse (asynchronous).

**Reduction ratios**

1st	3.25 : 1	6th	2.50 : 1
2nd	3.15 : 1	5th	1.82 : 1
3rd	2.82 : 1	3rd	1.55 : 1
4th	2.24 : 1	4th	1.76 : 1
Reverse/1st	6.56 : 1	Reverse/High	2.13 : 1

**Adjustments**

**Power take-off shaft:** Front bearing side play adjusting shims, spaces 0.3-1-0.2 = 0.3.

**Main shaft**

**Rear:** Contact distance adjusting shims, spaces 0.1-0.2-0.25-0.5-1 mm.

**Front:** Side play adjusting shims, spaces: 0.1-0.2 mm.

**Reduction gears:** Main shaft side play adjusting shims, spaces 0.1-0.2-0.3-1 mm (mainshaft play 0.0).

**Oil**

**Capacity (ignition, rest 1st and 6th):** 20.0 litres.

**Power take-off**

**Maximum shaft speed:** 640 r.p.m. at 2,000 r.p.m. of engine.

## DESCRIPTION (Fig. 1)

The gearbox of the B-300 and B-400 tractor has four forward gears, fully synchronized, and one undriven reverse gear. It is supplied with a gear selector which permits a range of eight forward gears synchronized and one reverse gear (semipower shaft).

This box consists of:

- A casing attached to the clutch and rear axle casings.
- A fixed train shaft (F) with the constant mesh gears.




Fig. 1 - Schematic view of gearbox operation

- A slider or side shaft (18), which forms the drive gear (2nd/3rd).
- Two sliding gears (2) and (3) which lock 1st to 2nd and 3rd to 4th gears respectively.
- A reverse gear.
- A sliding reverse lever shown in the figure.

A primary transmission shaft (1), joined to the gear (10) which transmits motion to the fixed main shaft (7) by means of reduction gear (4/5/6/7).

A primary power take-off shaft (12) terminating in a gear which controls:

- Power take-off shaft (11) through gear (1) and sliding gear (3).
- Lower power take-off gear (8).

The reduction gear consists of a sliding gear (17) and an intermediate gear with (10) formed by two united gears.

#### Neutral position of gear selector

The sliding gear (2) is in mesh with gear (10). Motion passes directly to the fixed main shaft (7).

#### General drive position of gear selector

The gear (10) transmits motion to the intermediate gear (12) which transmits it to the sliding gear (11), which in turn transmits it to the fixed main shaft (7). If the gearbox must be disassembled for any reason, the outside should be cleaned. Never hit it with hard objects and preferably use plastic mallets or aluminium, brass or wooden chisels/hammers.

Grease/box has been discontinued, before proceeding to assemble it clean all parts and replace the oils that have been damaged.




Fig. 2 - Schematic view of high gear




Fig. 3 - Schematic view of low gear

**DISCONNECTION FROM TRACTOR**

Before proceeding to remove the gearbox, it must first be disconnected from the tractor. This should be done according to the following instructions:

- Disconnect the blades at the check-angle mounting (see check control and blade control).
- Steering wheel.
- Throttle control lever.
- Instrument panel.
- Fuel tank and its bracket.
- Hydraulic pipes.
- Fuel tank (see bracket with main hydraulic system filter).
- Brakes with steering linkage.
- Steering box.
- Hydraulic pump and its lock cover.
- Footrest.
- Brake and clutch pedal switches.
- Brake control lever.
- Clutch and gear shift and release levers.




Fig. 4 - Check-angle disconnect



Fig. 5 - Gearbox-mount disconnect

## REMOVING GEARBOX FROM TRACTOR

Draw the gearbox lid from disconnected base motor and the oil has been drained from the gearbox reservoir, proceed as follows:

- From inside the clutch housing, loosen the bolts that secure the gearbox to its casing (Fig. 6).
- Loosen the two bolts which secure the gearbox housing to the rear axle housing (Fig. 7).
- Attach lifting chain (TS-54), 3/4" on upper face of gearbox casing. Support gearbox with the aid of a hoist, and after breaking the exterior bolts which secure it to the rear axle housing, raise it (Fig. 8).




Fig. 6 - Removing clutch housing gearbox base bolts



Fig. 7 - Removing gearbox rear axle housing inside tractor



Fig. 8 - Removing gearbox rear axle housing outside tractor



**INSTALLING GEARBOX IN TRACTOR**

The gearbox is installed in the tractor by reversing the procedure described for its removal, paying particular attention to:

- Check that the two centering guides are correctly located in the rear axle housing.
- Assemble the gasket (marking it with sealing paste).

- Check tightness of two lock bolts located on table of gearbox.

- Assemble the two hexagonal lock bolts in the centering guide bearings.

**INSTALLING CASING OF GEAR SHIFT AND REDUCER LEVER**

The gear shift and reducer lever casing is installed in the following way:

- Fit all the shift forks in neutral, with their holes lined up to facilitate cover assembly.

- Assemble the gasket (marking it with sealing paste).

- Fit the central lever brackets (gear shift and reducer) on the side of shift forks and secure the work.

**GEARBOX CLUTCH HOUSING CONNECTION**

The gearbox is connected to the clutch housing in the following way:

- Check that the two centering guides are correctly set in the gearbox casing.

- Assemble the gasket (marking it with sealing paste).

- Connect them with lock-bolts and insert elastic bearing.

## DISASSEMBLING CHASSIS

To assemble gearbox when it has been removed, turn left and placed on a work-bench, proceed as follows:

## Disassembling the power take-off shaft

Remove P.T.O. sliding gear control lever (Fig. 10) according to this procedure:

- Take out shift fork lever coupling nut.
- Remove selector spring cover (A, Fig. 11).
- Remove shift fork (B) (Fig. 11) the collar with ball-end springs.
- Take out front bearing locking ring and washer.
- Blow P.T.O. drive gear lengthwise.
- Push P.T.O. shaft back (Fig. 12). Be careful when sliding gear balls and lever lock springs.



Fig. 10 - Disassembly of P.T.O. sliding gear control lever



Fig. 11 - P.T.O. sliding gear control lever



Fig. 12 - Shift fork with lever and indicator

- Remove drive gear.
- Remove P.T.O. sliding gear.

- If necessary, remove P.T.O. shaft rear bearing. Use a press to remove it after first taking out the lock ring.



Fig. 10 - Extraction of pressure side oil...



Fig. 11 - Power take-off shaft assembly

#### Disassembly intermediate gear and P.T.O. gear

Remove the intermediate reduce gear and lower P.T.O. gear (Fig. 14, 15, 16, 17).

- Take out the set screw (A, Fig. 14).

- Take out the three locking plate set screws (B, Fig. 15) and remove the plate.

The intermediate reduce gear and lower P.T.O. gear will then fall to the bottom of the casing.



Fig. 9 - Intermediate rollers and P.T.O. gear

Disassemble transmission and P.T.O. primary shafts, remove sliding gear and drive gear.

To disassemble primary shafts, sliding gear and drive gear, proceed as follows:

- Remove hub guide roller from primary shafts.
- Push shafts (Fig. 10) towards (Fig. 11).
- Remove drive gear from rollers, sliding gear, using nut shift lock and nut connector 2106.
- Remove sliding gear and its hub. Being careful with the balls and springs, releasing washers and thrust washers.
- From the bottom of the casing take out the parts which have fallen, and with the help of the set screw, remove hub guide from intermediate gear.




Fig. 10 - Intermediate gear set cover



Fig. 11 - Transmission and P.T.O. primary shafts




Fig. 17 - Disassembling primary shafts



Fig. 18 - Assembling transmission and P.T.O. primary shafts

#### Reassembling shift fork (Fig. 19)

Take out full-sized connection screws, removing reverse gear shift fork. Be careful with the two lock pins situated between the rods.




Fig. 19 - Reassembling shift fork

**Disassembling fixed axle**

Lock fixed axle lock nut (use spanner TL 84, 80, or lesser nut fig. 20).

Remove rear bearing washer plate (A, fig. 22).

Washers (fixed axle shaft) through the rear.



Fig. 20 - Removing fixed axle lock nut




Fig. 22 - Disassembling rear bearing washer plate



Fig. 23 - Fixed axle assembly



Fig. 23 - Reverse gear

**Disassembling reverse gear**

Remove lock stop (B, Fig. 27) and take out reverse gear shaft.

**Disassembling main shaft (Figs. 24 and 25)**

To do so, proceed as follows:




Fig. 24 - Disassembling main shaft

**Remove**

- 3rd and 2nd gear shift fork and its rod.
- Release nut (C, Fig. 16) of 3rd and 4th gear shaft (see carefully with ball and spring).

- 3rd and 4th gear shift fork and its rod (take care with the lock pin located in the shaft mounting bracket).
- Make shaft lock rod blocking if so it does not turn, and then withdraw the main shaft through the front.



Fig. 15 — Main shaft assembly

**ASSEMBLING GEARBOX**

The assembly of the gearbox should be carried out in the following order:

**Assembly of main shaft**

Before proceeding to install the main shaft in the gearbox, first adjust the position of the 4th gear. To do so, carry out the following procedure:



**Positioning drive gear (Fig. 26)**

The drive gear is in correct position when its inner face is at a distance of:

$A = 02,75$  to  $02,80$  mm from the outside face of the gearbox casing. This distance is obtained by inserting shims (C) between the strips formed by the wear bearing ball race and the outside face of the gearbox casing.




Fig. 26 - Drive gear dimensional figure

**Decreasing drive thickness**

To decrease the drive thickness necessary to mounting drive gear, carry out the following operations:

- Mount the bearing on the mesh shaft and secure the cable ball race to the gearbox casing, without shims.
- Place gearbox in a vertical position.
- Assemble the drive gear shaft without gear.
- Check the distance (A, Fig. 26) with respect to the bore TA, 94, 04, Fig. 27) by means of a caliper.

The difference will be equal to thickness of shims required. To make up (56) thickness, shims of 0.1 - 0.2 - 0.25 - 0.3 and 1 mm are available.



Fig. 27 - Checking drive gear housing

**SPECIAL CASE**

If the drive gear has a modifier marked to a slide on the hand face, this value must be subtracted from the slide thickness.

**Example:**

Slide thickness/distance 1.8 mm.

Modification marked on the gear 200.

Value of slide thickness  $1.80 - 200 = 1.60$  mm.

Remove shaft and make half race, assemble slide thickness 10, fig. 28 section.

Adjust height of main shaft axial plate 101, fig. 28.

Once the correct position of the drive gear has been determined, the main shaft axial plate should be adjusted. To do so insert the front bearing half race

**ADJUSTMENT OF HEVEL GEAR**

The drive gear and level gear are made as one piece and are NOT SEPARABLE.

Each part bears a reference mark for their control:

on the inside of the gearbox, without adjusting others.




Fig. 28 - Main shaft axial adjustment



Fig. 29 - Checking level gear axial adjustment

Insert the main shaft along with reverse gear, self-retaining bushes, synchroniser hub, reverse needle, accumulator and bearing, and tighten the lock nut to 18 kgm.

Mount the gearbox casing upright (Fig. 28).

Place a compressor on the back face of the 2nd gear.

Move the shaft longitudinally in both directions to test.

#### Assembling main shaft (Fig. 28)

After carrying out drive gear adjustments described above, assemble the main shaft in the following order:

##### Insert:

- Reverse gear.
- 1st and 2nd gear assembly.
- Reverse needle.

The maximum value recorded on the compressor corresponds to the thickness of shims (3, Fig. 28).

To tune up the engine, stress of 5.1 and 5.2 kgm are available.

Fit over the shaft and the ball race.

Insert the shims, insert the shaft and ball race and check the shaft must run without odd jitters.

- 2nd and 4th gear assembly.
- Synchroniser.
- Housing.
- Nut, tightening it to 18 kgm.

**NOTE:** The nut is to be locked with a ring of **LOCKWAX**, after removing grease from shaft threads and nut.



Fig. 28 - Assembling main shaft

Once the main shaft has been installed, assemble gearbox in the following order:

**Install**

- Reverse idling gear
- 2nd's teeth of 1st to 2nd set of 3rd to 4th and their rods become rod screws with nuts.
- Intermediate gear hub-plate after main shaft nut. Place in contact position on bearing of gearbox casing for later assembly; adjust intermediate gear shaft and lower power take-off gear.
- The fixed main shaft (the backing roller is set with levels measured).
- The nut retainer ring.
- Fixed main shaft nut. Tightening it to 40 kg using special spanner TA-20-40, then lock the nut with its seal.
- The hub splines.
- Clutch and transmission primary shafts, checking that distance between fixed (2nd lock set) and hub splines is of 0.8 mm (Fig. 31) (bearing shims should be chosen to be greater).

**NOTE:** This clearance should be measured with clutch and transmission primary shafts and fixed main shaft close to each other as possible.



Fig. 30 - Testing clearance of primary shafts




Fig. 31 - Assembling P.T.O. shaft

- Check primary shaft track guide rollers, fitting in guide channel with sliding joints.
- Intermediate release gear shaft and gear take-off gear (which has previously been off) at the bottom of the casing. Assemble the lock plate and the control/lock screw (lock it with DMSPT1).
- The joint take-off shaft (Fig. 30), on inserting the spring washer between the casing and the rear bearing. Set the washer with the pin and thus fit the ball race and bearing.
- Fit the take-off lever, locking the screw with wire.

#### Assembling 3rd to 4th shift fork rod.

To assemble 3rd to 4th shift fork rod, place the connection pin in rod TA.84, of Fig. 28, place the assembly in the path of the fork rod and pass in the connection pin with a rod.

#### DISASSEMBLING THE GEAR SHIFT AND REVERSE OPERATING LEVERS

##### Gear shift operating lever

To disassemble gear shift lever, proceed as follows:

- Remove the ball.



Fig. 28 - Assembling 3rd to 4th shift fork rod pin

- Remove operating lever synchronizing spring, disengage and take out washer.
- Remove control pin and take lever out (downward).

**Reduce operating lever**

Without having to remove lever housing:

- Remove designated lock plate and withdraw the lever assembly.

**ASSEMBLING GEAR SHIFT AND REDUCER OPERATING LEVERS**

To assemble the levers, follow the procedure described above in reverse order.

The assembly of the lever housing is described on page 7.




Fig. 38 - Disassembling gear shift and reducer assembly levers

**GEAR SHIFTING (Fig. 39)**

Levers are shifted by means of the control lever and reducer lever located above gear box. The slight forward and rear reverse gears which the box contains all, can be obtained by using both levers in combination. The positions of both levers are illustrated in Fig. 39. Key is Fig. 38.

Case - Low - Large - High  
 R.L.A. Case - Low reverse  
 R.A. Large - High reverse




Fig. 39 - Positions of gear shift and reducer levers

## SECTION 9:

# HYDRAULIC SYSTEM

### CONTENTS

	PAGE
Specifications	1
Description of hydraulic lift controls	3
Final adjustments	4
Operation of lift	4
Description of hydraulic circuit	4
Description of tractor lift linkage positions	5
Description of auxiliary services distributor	10
Marking of lift distributor	15
Hydraulic lift adjustments	21
Repairing hydraulic lift	26
Reaming hydraulic lift	26
Installing hydraulic lift	26
Reaming lift distributor	27
Installing lift distributor	28
Reaming raise and lower valves	28
Installing raise and lower valves	30
Reaming and installing main spool or valve	31
Reaming and installing flow regulator valve	31
Reaming and installing pilot valve	31
Reaming tractor Pull control mechanism	34
Installing tractor Pull control mechanism	32
Replacing retainers or bushings of tractor Pull Control connecting rod drive shaft	33
Replacing drive shaft retainers or bushings of lifting arm	34
Replacing lift cylinder piston retainer	35
Replacing gasket and retainer of control lever shafts	35
Installing lift control levers	35
Reaming and installing hydraulic pump	35
Disassembling and assembling hydraulic pump	35
Repairing hydraulic pump	37



## SPECIFICATIONS

## Hydraulic oil

## Type

Automatic depth control, controlled position and traction mechanism.

## Cylinder diameter

50 mm

## Piston stroke

150 mm

## Maximum force on piston

5,000 kg

## Maximum lifting force end of tractor

2,000 kg

## connecting rod

2,000 kg

## Depth adjustment by pull bracket

50 and 2,700 kg

## between

## Oil capacity 200, position and rear wheel

25.5 L

## and

Oil 2 of Drive shafts.

## Lubricate 200, position and rear wheel

## Hitch

## Type

Three point category TL

## Third point

Telescopic

## Straddles

Telescopic

## Sensitivity

In base mode

## Maximum upward movement of lifting

30 mm

## arms

## Maximum downward movement of lifting

End of arms on a plate with junction

## ing arms

point between rear plate and 20.

## Hydraulic pump

## Type

Gear, driven by gear on power take-off

shaft.

## Single pump unit

15 : 10

## Flow

90 L/min at 2,000 r.p.m.

## Pressure

100 kg/cm<sup>2</sup>

## Auxiliary service distributor

## Type

Double-acting

## Pressure limiting valve

100 to 120 kg/cm<sup>2</sup>363 9/14  
202/1 3/1



### DESCRIPTION OF HYDRAULIC LIFT CONTROLS (Figs. 1 and 2)

The master-control type hydraulic lift provides two selective systems: automatic Pull Control and Position Control. It is also equipped with valve adjustment in Pull Control and lower adjustment in Position Control. The lift controls are described below:

#### Position Control operating lever

The Position Control operating lever (A) is that one responding to the raise operation and it operates throughout the whole ascent. It controls the raising and lowering of the implement and the maintaining at a constant height.

#### Pull Control operating lever

The Pull Control operating lever (B) is that one responding to the lower operation and it automatically determines the operating depth with respect to pull. It moves along the lever sector with the following indications:

MAX: maximum depth, MIN: minimum depth,  $\Delta$ : center of automatic depth adjustment.

The combination of levers (A) and (B) allows operation with Tractor Stabilization.

#### Raising adjustment control

The control (C), located on the upper part of the lift distributor, controls speed of raise in Pull Control.

This control has the two following positions: Position (1): for raise speed, Position (2): slow raise speed.

#### Adjustment of lowering speed

The adjustment of lowering speed in Position Control is achieved in the following way:

The Position Control lever quadrant has a white (D) in the lower part at which the lever comes to a stop. In a stop, by pushing beyond the stop in a downward direction, slow speed.



Fig. 1 - Hydraulic lift controls



Fig. 2 - Hydraulic lift controls

**HYDRA ADJUSTMENTS**

To see if the implement the lifting speed of the implement, first at the beginning and slow at the end of travel, it is essential that the arms should be as short as possible.

**Length of third pivot arm**

— Arm in lift position

Adjust the length so that it is sufficient to obtain a water plough feeling and so as to prevent it exerting a pull force on itself.

**Hydra position (Fig. 2)**

When working, adjust the position of the third pivot (3) and the third pivot arm (4), indicated in the figure with dotted line in respect of a horizontal plane perpendicular to a reference line. In order to obtain the best results equivalent with ordinary plows.

These positions have been obtained by considering the height of the third pivot over implement and the extent of the force.

**Stabilizer rods (Fig. 3)**

The two stabilizer rods (2) include a sliding mechanism in order to allow the Hydra base to be moved backwards. To permit normal working of the lift, the stabilizer rods must not be blocked under any circumstances. There must be a minimum play of 6 mm on each side. Keep rods working in level or at 3mm.

When working, the arms should be situated as low as possible, always leaving a sufficient height to allow the operator control to correct position variations of frame.

— Arm in sliding position.

To be used only on strong ground or where the implement may suffer violent shocks.



Fig. 2 — Hydraulic lift Hydra

- A — Third pivot arm
- 1 — Hydraulic lift
- 2 — Plough
- 3 — Lift pivot
- 4 — Stabilizer rods

## OPERATION OF LIFT

The Tractor Control type hydraulic lift permits operation with:

## Automatic adjustment of depth (Fig. 4)

— Suspended implements: ploughs, cultivators...  
The automatic depth adjustment through means of permanent load, obtained by the high bar location connected with, transmits directly to the lift distributor the different forces received by the implements according to the nature of the soil, its profile and the position of tractor.

To determine the depth of operation:

- Move the Position Control lever (M) to the lower part of its quadrant.
- Place the Pull Control lever (B) in front of M10 in its quadrant.
- Move the tractor forwards, progressively lowering the Pull Control lever (B) until the desired working depth is obtained.

This depth is adjusted automatically with regard to soil. As long as the work lasts its cut tracks the best right.

## Manoeuvre

At the end of the run, move the Position Control lever (M) in the top part of its quadrant to raise the implement. The implement is lowered by placing this lever in the lower part of its quadrant.

## Traction Reduction (Fig. 5)

- Suspended implements: ploughs, cultivators...
- Semi-suspended implements: simple disc ploughs...
- Drawn implements: disc harrows, harrows...

Traction Modulation is obtained through the control



Fig. 4 - Automatic depth adjustment.

**Note:** When the Position Control lever (M) is moved from the low to the high position, the implement is first raised quickly and then reduced its speed before end of travel to prevent mechanical shaking and to increase driver comfort.

Suspended implements can also be used in Traction Modulation. All implements: ploughs, cultivators, etc., should be used without depth wheels.

ation of the two control levers and has the advantages of Automatic Depth Adjustment. In addition, it prevents suspended and semi-suspended implements from going below the desired depth in soils of a very varied nature and in particular when passing through stretches of very soft ground.

To determine working depth:

- Move the Position Control lever (A) forward to the lower part of quadrant.
- Put Pull Control lever (B) in front of (B1) in its position.
- Move the tractor forward, progressively lowering Pull Control lever (B) until desired working depth is obtained.
- Slowly raise Position Control lever (A) again until the same begins to rise. Once having done this, lower the same lever until the space between same level.

#### Remarks

At the end of the tractor run, adjust the Position Control lever (A) to the top part of its quadrant to raise the implement, moving it back as the former position lever implemented to start to working next run.

Do not touch Pull Control lever (B).

**Note:** To obtain Tractor Modulation and level work by when using harrows and rolling harrows, it is necessary to limit the implement head or boom to prevent its movement to a vertical position, making it lower having called out the command to the operator that gives the four-down lever.

#### Position Control (Fig. 8)

- Semi-axle and implements with level and low rates... The position Control enables the implement to be maintained at a fixed height in relation to the terrain.

To determine the position of implement:

- Move Pull Control lever forward (B) in low part of quadrant (B1) raised.
- Progressively lower Position Control lever (A) until the desired position of implement is obtained.



Fig. 7 - Tractor Modulation



Fig. 8 - Position Control

**Operation**

At the end of travel, place Position Control lever **IN** in the top part of quadrant to raise implement, putting it back again in the former position to lower implement.

**Rearing driver**

— Implements driver: rear ground, rotary tillage, etc. (Subsoiler/Cultivator).

The rearing obstacle can be free for use of implements that have to set on the soil.

**Transporting**

For any transfer of any implement, put the Pull Control lever in the bottom part of 6th quadrant. Use position Control lever.

**Suspended implements**

At the end of travel or when transporting in order to lift, move Pull Control lever in lower part of 6th quadrant and Position Control lever backside to

**Trailing and semi-suspended implements**

— Fixed on full bar (200, 300, 400).  
Put the Pull Control lever in the bottom part of 6th quadrant and Position Control lever in the

position that corresponds to the height at which the width of the working implement is to be transported.

**For use of implements**

- Move the two control levers forward in their respective quadrants to maximum point of travel.
- Use Position Control lever to raise and lower implement.

full extent of travel. In this position the lever will remain fixed no matter how long the movement is.

position that corresponds to the height at which the width of the working implement is to be transported.




Fig. 7 - Hydraulic Circuit

**DESCRIPTION OF HYDRAULIC CIRCUIT (Fig. 7)**

The oil stored by distributor and hydraulic tank is sucked by hydraulic pump (B) through primary line (A), providing it is necessary line (C) and auxiliary service distributor (D), from where it passes to the hydraulic (H) distributor (E).

The oil which flows through auxiliary service distributor (D) only reaches the (H) distributor (E) provided that the former is in neutral position, that is with control lever in vertical position, whereby whenever oil is used in external service it is cut off in (H)

system. The auxiliary service distributor which pressure setting value of 100 to 150kg/cm<sup>2</sup>. The (H) distributor (E), situated on the front right of hydraulic (H) housing, assumes the different functions of the system.

The main valve or speed (E) of the (H) distributor (E) is moved by different valve or levers according to the work to be done. This main valve or spool can be moved in three main positions. Forward, back or stop. Control Position, neutral, Backwards, forward.




Fig. 8- Pull Control

#### DESCRIPTION OF WORKER LEFT LEVERAGE POSITIONS

##### Pull Control (Fig. 8)

The Pull Control lever 14, connected to shaft 8), operates sliding link 10). This sliding link moves Pull lever 12) which is in contact with the main valve 1) spool. The Pull lever 12) is elastically returned by lever connecting rod of Pull Control 11) which, in turn, is return by the straight connecting rod 11), which is return to 3) the pull position by the spring 13). The spring 13) returns the lever control

ring rod of Pull Control 11) in accordance with pull on 14).

Different positions of the Pull lever 12) correspond to different positions of the lever 12). Therefore, to pull the main valve of spool 1) in neutral, there corresponds a given pull on the work lever in accordance with position of Pull lever 12).




Fig. 8 - Feather Control

#### DESCRIPTION OF INTERIOR LIFT LINKAGE POSITIONS

##### Feather Control (Fig. 8)

The main Feather Control lever (15), connected to shaft (10), controls the valve (13) which opens the spring tube (12), putting the main valve in stop in the zero position. While the lift arm (16), the pivot pin (14), attached to the rear, gets bedworn during the linkage (10) with it, which gives the main

valve or spring in the neutral position. So, different positions in the linkage for putting main valve or spring in neutral in accordance with pivot pin (14) correspond to different positions in the main lever, back-to-tilting and steering.






Fig. 10 - lowering control

#### DESCRIPTION OF INTERIOR LIFT LINKAGE POSITIONING

##### Lowering control (Fig. 10)

The lowering Control, fast or slow, is obtained by means of Position Control lever (A), operating in bottom part of its quadrant. In its lower part, this quadrant is provided with a pin against which the lever comes to stop, this lever being thereby obstructed. Slow lever is achieved by pushing beyond this stop in a downward direction.

Position Control lever lever shaft (B) controls cone (C) by means of linkage (D). Travel of cone (C) control is an act of adjusting screw (E), which determines the slow or fast lowering of lifting screw. To determine position of this screw, see the adjuster screw section.




Fig. 71 - Safety linkage

#### DESCRIPTION OF LIFT INTERIOR LINKAGE POSITIONS

##### Maximum lift safety (Fig. 71)

The safety linkage only operates when the lift cars reach their point of maximum lift. The movement of linkage (A) is governed by pivot pin (B) which is attached to the car.

If, for any irregularity in the lift, the main valve or spool wire pulled towards the main (A) then the wire device continues being until the pivot pin (B) is

by backward facing movement pulls the linkage (A), automatically disengaging of the cars which could be posing the main valve or spool, which then returns to its normal position.

Note. — The purpose of this safety linkage is merely to put the device in neutral in the event of a load adjustment, however movement of raised levels, making up for bridge of cars, etc.




Fig. 88 - Auxiliary Section Distributor

### DESCRIPTION OF AUXILIARY SERVICES DISTRIBUTOR (Fig. 12)

The auxiliary services distributor is of the double-acting type but nevertheless it can be used if a single-acting circuit, for example, is a return line in the distributor on the other side (this can be used). Example: see Fig. 12 plus all connections. If we fit a single-acting cylinder on IC and must fitted a return line on EX at occasion. With this operation we must the pressure limiting valve opening every time the lever is vertical as a result not achieve a faster lowering. This distributor has a pressure limiting valve which is set at 100 or 120 kg/cm<sup>2</sup>, being allowed to leak auxiliary services post 25. To check hydraulic pressure install a pressure gauge of 200 kg/cm<sup>2</sup> in both couples of lines IC or EX, for engine up to 2,000 L/min, and pressure distributor cannot leak.

IC enters the distributor by 13) and leaves by 18) and while the spool is in the neutral position it circulates freely from 14) to 16). When the spool valve is actuated in one direction or another by means of control lever, the circuit is cut at 15) with the oil going out to the external service selected.

Pressure readings will be carried out both side of connections Fig. 12 through IC) and EX). The return from IC) and EX) is made through 18). In 17) we have a plug which can be used as a hydraulic locking point without passing through the spool valve. Special stopper distributor is possible in which the oil will never be able to be cut off.

### LIFT DISTRIBUTOR

In the lift distributor the main spool or valve has three positions with regard to its body. These positions are obtained through the movement of the control rod which is in turn controlled by the control lever, lever that connecting rod or position cone.

Any movement of the above mechanism is transferred directly to the main spool or valve.

As we shall see in the later figures, the main spool or valve has the three following positions:

Valve in neutral position, neutral.

Valve to the left, raise.

Valve to the right, lower.




Fig. 16 - Main speed or valve to control

- |                     |                                  |
|---------------------|----------------------------------|
| A - Working valve   | E - Flow regulator valve         |
| B - Reservoir tank  | F - Main valve spring seat       |
| C - Main valve stem | G - Pressure relief valve piston |
| D - Main valve      | H - Working adjustment spring    |

## OPERATION OF LEFT DISTRIBUTOR

Main speed or valve to control:

## POSITION CONTROL, Fig. 16

The oil coming from the hydraulic pump has to take to the dist factor as is indicated by the upper arrow. The operation of the flow regulator valve and the main speed or valve has to be constant communication, so the oil will go on both at the same time. The flow regulator valve has a small side hole which communicates with another longitudinal one which communicates with the closed chamber (right-hand side) of valve. In its opposite end it has a spring housed in a chamber which connects by means of a gallery with the front part of the pilot valve.

The main speed or valve in its neutral position shows off the passage of oil to rear chamber of pilot valve. As this valve only receives oil to its front part, the

valve line to distributor is slowly opened, producing positive depression in the spring chamber of flow regulator valve to its left-hand side. This valve, on receiving more pressure on its right side, slowly closes to the left, overcoming the resistance of the spring and in turn opening another return line to reservoir. As long as the main valve or speed is not raised in any direction the oil will leave freely to the two above mentioned return lines.

Make in the distributor at the present on the working valve (A) has been replaced by another (see A and B, Fig. 16 and page 26) whose function is identical to that represented in this figure.




Fig. 18 - Main speed or valve in neutral

## OPERATION OF LPT DISTRIBUTOR

Main speed or valve in neutral  
FULL CONTROL (Fig. 18)

Except for the position of the main speed or valve piston which blocks the passage of oil in the body of this valve, all the other valves occupy the same position as in the previous figure.

The only difference is that the passage of oil from main speed or valve to J&C valve is restricted by main speed or valve piston. In this position the flow of oil which passes to the valve through flow regulator valve is greater and the return through J&C valve is less.

This position of main speed or valve, with internal piston displaced to left, corresponds solely to the neutral position of Pull Control. In this way we can obtain, by means of the raising adjustment control, a variable raising speed, increasing which cannot be obtained by Position Control alone. It does not displace main speed or valve internal piston.




Fig. 16 - Main spool valve on handle lift control

## OPERATION OF LIFT EXHAUSTOR

MAIN SPOOL VALVE ON INTAKE  
PAINT RAISE POSITION CONTROL (Fig. 16)

The main spool valve is moved to the left (raising), blocking the rest line of pilot valve and closing its return line. The depression which existed in the left chamber of flow regulator valve, when the spring is forced, disappears, balancing the chamber pressures on both sides of the valve. The rising foot pushes flow regulator valve to the right, closing second supply line to reservoir.

With both levers closed, the pressure then builds

and lifts the rising valve, compressing its spring. The oil passes directly to the rear cylinder, displacing the piston, and consequently an upward movement is produced. In this position the rising exhaustor second does not respond owing to the great passage of oil through the intake of main valve or foot as it is not blocked by the closed return of valve. Therefore rising in Position Control is always fast.




Fig. 8-1. Main spool or valve on brake slave cylinder

## OPERATION OF LPT DISTRIBUTION

Main spool or valve on brake slave cylinder

## FULL CONTROL (Fig. 10)

As in the previous case, the main spool or valve is moved to the left, opening the line in the rear part of the pilot valve and closing its return. This control pressure in the spring chamber of flow regulator valve. The pressure is the same as the previous one with the difference that, in this case, the main spool or valve internal groove is displaced to the left, pushing by the cone or lever of Full Control, thus blocking the passage of oil through the orifice of main spool or valve. In addition, in this case the

return adjustment control has been moved, closing an oil line to the cylinder. As a result, the pressure on the right-hand side of the flow regulator valve increases, moving it to the left, whereby part of the flow from the hydraulic pump is evacuated through the return line. In this case only a small part of the flow passes to the rear cylinder through the rising valve, as a result of which it gives an slow upward movement. Excessive flow from the hydraulic pump is shunted between the cylinder and the return.






Fig. 17 - Slow speed or raise the bucket fluid valve

#### OPERATION OF LIFT DISTRIBUTOR

##### Slow speed or raise-the-bucket (Fig. 18) PULL CONTROL (Fig. 17)

To obtain fast raise in Full Control it is necessary to modify the position of the raising adjustment control. In this figure it can be seen how this control puts the distributor valve in communication with the flow regulator valve left-hand chamber. This valve, constant flow increases as pressure in chamber on left side of the flow regulator valve which does a little more and only allows to pass to the return a small part of the flow which therefore goes to the cylinder, producing a faster raising. In this way two different speeds of raise are obtained, as has been explained. This is only achieved in Pull Control.

To obtain slow raise speed, see text of figure 16.

The raising adjustment control is used for heavy work or work at considerable depth. It enables a high performance to be obtained and reduces vibration and the risk of the load blocks being forced into the ground.

Note: With the raising adjustment control intermediate positions can be selected, progressively modifying the raising speed in Full Control. This control has no effect on the raising speed in Position Control.




Fig. 18-4. Main spool valve in raised position.

#### OPERATION OF LIFT DISTRIBUTOR

Main spool or valve in descent lower position—CONTROL OR FILL CONTROL Fig. 18

The main valve has been moved fully to the right and its boost port pushes the needle which enters into contact with the lowering valve, progressively lifting it from its seat. The oil contained in the wet cylinder is released by the lowering valve and returned to the reservoir.

The other valves play no part in this position and continue sending to the hoist all the flow delivered by the hydraulic pump, exactly as when in the neutral position.




Fig. 16 - Adjustment of lowering control speed

### HYDRAULIC LIFT ADJUSTMENT

Adjustment of speed of Lowering Control Response Control (Fig. 16). To carry out adjustment of lowering speed Response Control proceed as follows:

- a) Full approximately 400 kg. on the fish bars.
- b) Lowerwater 1M.
- c) 100% Position Control lever into 0% - 5%.
- d) Slowly move Position Control lever downwards until a slow lowering is obtained. Test the lowering with Full Control lever.
- e) If not lifting efficiently previous operation, adjust wire (A) (B) coming up against Full Control lever (D). Tighten/water out.
- f) With Full Control lever check slow lowering of 2 to 3 seconds. In the event of not obtaining B, repeat adjustment from point (b).
- g) Loosen Range of Position Control lever shaft and without moving this, push the lever downwards (making the quadrant sharper) until it is 2 mm before end of travel and tighten Range (making the limit).




Fig. 28 - Maximum raised position of arm

**HYDRAULIC LEVER ADJUSTMENTS****Maximum raised position of arm  
POSITION CONTROL (Fig. 28)**

To adjust maximum raised position of arm (POSITION CONTROL), carry out following operations:

- a) Loosen screw (A) and counter nut.
- b) Put Position Control lever in top part of its travel and fit the arm (a) and (b) to them (Fig. 28).
- c) Remove the cover of (B).
- d) With Position Control lever make a complete lowering, then a raising, the piston must fit on the measurement previously quoted.
- e) Slowly tighten up screw (C), already causing a raising of arm; continue tightening until piston has about 2 to 2 mm to reach and of its travel in the cylinder on up stroke.
- f) Lock counter nut. Fit (B) rear cover and check again.




Fig. 21 - Control valve assembly

**HYDRAULIC LIFT ADJUSTMENTS****Control of Pull or Depth (Fig. 21)**

To adjust Pull or Depth control, proceed as follows:

a) **Plane Position:** Control lever in bottom part of its travel is up against the stop plate. First screw of Locknut out and tighten screw (M).

- b) Begin to ride with Pull Control lever and gradually lowering screw (K), progressively raising or lowering lever until riding is made to height as screw (M) or (N) run before reaching ground stop.
- c) Tighten nut and check again.




Fig. 20 - Detection spring

**HYDRAULIC LEAK ADJUSTMENT****Detection spring (Fig. 20)**

Between the upper part of lever pull connecting rod and upper face of rear shaft (20), there has to be a clearance of 7 mm. This play is obtained by adjusting length of the detection rod (2).

To carry out adjustment of detection spring proceed in the following way:

- (i) Remove (1) and cover section (3).
- (ii) Loosen nut (4) (2).
- (iii) Place a 10 mm size shaft (5) over

(6) Turn screws (8) and (9) at the same time so that the distance between pull lever connecting rod and (10) is 7 mm.

- (iv) Tighten nut (2).
- (v) Adjust Pull Control lever.

If nuts (8) and (9) are loose, tighten (8) by hand to correct any play and then lock with nut (8). Torque value of 4 to 5 kg-m.

**REPAIRING HYDRAULIC LIFT**

All lift repair operations should be carried out in completely clean conditions. Since it has been assembled with high precision, any impurity introduced into the circuit may cause serious problems.

**DISASSEMBLING THE HYDRAULIC LIFT**

Carry out this operation in the following way:

- Unblock lift valve.
- Disconnect right side light connection.
- Remove seat.
- Disconnect the following five auxiliary service lines from the distributor (Fig. 22).



Fig. 22 - External auxiliary distributor

- a) Internal distributor.
- b) Chuck to lift cylinder.
- c) Control services.
- d) Control services.
- e) Filter.

- Remove lift seat cover (Fig. 23) to take out seats (C) and (d) (E).
- Take out (F) and cover plate with nuts and bolts which give control valve oil to valve (see Fig. 24).



Fig. 24 - Removing lift

- Fit fitting tool 14, Tap 26 to seat mounting hole (Fig. 25).
- Raise and withdraw (F) and cover section plate with aid of a bolt, (J) etc.
- Separate (H) and cover (I) as joined by three screws.



Fig. 25 - Fitting fitting tool

## TO INSTALL HYDRAULIC LIFT

To install hydraulic lift assembly as reactor carry out the following operations:

- Carefully clean the following contact surfaces:
  - a) Cover section plate
  - b) Floor into housing
  - c) Lift track cover
- Fit Pull-over (A) with seal TA, Tc or 2P (Fig. 20).



Fig. 20 - Mounting Pull-over

- Join cover section plate and lift with the three screws.
- Fit fitting seal TA, Tc or 2P on lift.
- With aid of bolt, 25, etc., affix cover section and lift to its mounting position on rear into HOUSING.
- Put Pull Control lever in front part of its speaker (convenient, in this way the travel of the seal (A) and the sliding link 10, 30, 27 is greater).
- Adjust seal (A) in vertical position using a spanner (Fig. 21).
- Strip lower lift and rear section, introducing seal into sliding link (Fig. 22).



Fig. 21 - Fitting cover section lift




Fig. 22 - Inserting rear sliding link

- When the front rear axle towing guide studs are introduced into lift cover section mounting holes, remove:
  - a) Spanner
  - b) The adjusting Pull lever.
- Break off housing lift cover section, perform in reverse order the dismantling operations carried out to assemble it.



**TO REMOVE LPT DISTRIBUTOR**

To remove the distributor, carry out the following operations:

- Through auxiliary service electrical line and remove the distributor.
- Fix the two 18 control lines in the lower part of their seat and 18th wire is bolted post 501.
- Take out the eight screws that fix front plate in fig. 20.



Fig. 18 - Removing 18th distributor

- Move 18th distributor together with front plate forward and lower linkage pin in the way.
- Through the valve that remains between the front plate and 18 take out the studs and pin fig. 19. 17th wire will be smaller if the control lines and 18 wires are cut out in position as indicated above.
- Remove the four Allen screws that secure front plate to distributor fig. 20 and separate both plates.



Fig. 20 - Removing front linkage front plate




Fig. 19 - Removing front plate from distributor

**TO INSTALL LIFT DISTRIBUTOR**

To install lift distributor carry out the following operations:

- Sc During installation housing or front plate (Fig. 32) a light layer of grease will help.
- Set the distributor in place.
- Carry out the assembly procedure in reverse order.



Fig. 32 - Installing lift distributor

**LIFT DISTRIBUTOR (Fig. 33)**

- A - Raising valve
- B - Lowering valve
- C - Main spool or valve
- D - Main valve piston rod
- E - Pilot regulator valve
- F - Pilot valve




Fig. 33 - Lift distributor system

### TO REMOVE RAISING AND LOWERING VALVES

To remove these valves, proceed as follows:

- Remove seat.
- Remove the distributor upper cover by cracking four set screws (Fig. 26).



Fig. 26 - Cracking distributor upper cover screws



Fig. 28 - Removing the distributor upper cover

Raising removed top cover (Fig. 26) proceed as follows (Fig. 26):

- Take out both valve springs (A and C).



Fig. 29 - Raising and lowering valves



Fig. 27 - Disassembling raising valve seat

- Extract valve (B and C) with sharp round plate (pencil) with parallel.
- Extract lowering valve seat (E) with help of tool TA, no. 28 (Fig. 25).
- Extract lowering valve needle (F) with sharp round plate, too slow.

- a) Put the two (B) control valves in lower part of spacers.
- b) Raise the (F)g arm.

### TO INSTALL (REMOVE) AND LOWERING VALVE

To install both valves carry out operations a removal in reverse order, taking care:

- To clean valves and seats carefully;
- To change O-ring seals;
- That the fat base of lowering valve needs to be protected on flat end of valve.

In the closed position, between needle and lowering valve, there is an opening diameter of 1 mm (Fig. 23). This diameter is factory-set when mounting both parts.

Lowering valve and seat are interchangeable; they have been tested together.

The lowering valve loading torque is 0.5 kg/cm<sup>2</sup> (with 20 drops of water). To use torque wrench, it is necessary to have read TS. 76.27 (Fig. 28) i.e. torque value of same set screw is 8.8 to 1.2 kg-cm.




Fig. 23 - Assembly and lowering valve

NOTE: To operate the pump, the pump and lowering valve should be tested in a closed position before the pressure is increased.



Fig. 28 - Tightening lowering valve loading

### TO REMOVE AND INSTALL MAIN SPOOL OR VALVE (Fig. 46)

- To remove main spool or valve, proceed as follows:
- Remove loading valve and its handle (operate according procedure).
  - Unscrew and take out plug (AL).
  - Take out spring (E), washer (C) and spring (D).
- To install main spool or valve, reverse the above pro-

cedure. The washer (C) which separates the spring (E) and (D) is installed with knotted part facing DOWN.

The plug torque value is 2 to 2½ kg·m.

Note: To protect the main spool or valve please push rod, the (B) also lower has to be disassembled.

Fig. 46 - Main spool or valve



Fig. 46 - Main spool or valve

### TO REMOVE AND INSTALL REGULATOR VALVE (Fig. 47)

To remove flow regulator valve, take out the following procedure:

- Unscrew and take out plug (AL).
- Remove housing (B).
- Remove regulator valve (C).
- Remove spring (D).

To install regulator valve, reverse the above procedure. The plug torque value is 2 to 2½ kg·m.

### TO REMOVE AND INSTALL PILOT VALVE (Fig. 48)

The pilot valve is removed in the following way:

- Unscrew and take out plug (AL).
- Take out valve (B).

To install valve, carry out the above operations in reverse order.



Fig. 47 - Flow regulator valve



Fig. 48 - Pilot valve

### TO REMOVE INTERIOR PULL CONTROL MECHANISM (Fig. 43)

To remove the mechanism, proceed in the following order:

- Remove 30 and cover section clips.
- Disconnect spring, rear axle and hydraulic system.
- Remove spring (A) relative to other (B) and Pull Control (C).



Fig. 43 - Disassembly of Interior Pull Control mechanism.

### TO INSTALL INTERIOR PULL CONTROL MECHANISM

To install lower Pull Control mechanism, carry out the following procedure:

- Introduce lower Pull connecting rod drive shaft through slot.

Take care with position of drive shaft and lower Pull connecting rod. (The drive shaft bevelled fitting has to coincide with connecting rod base (Fig. 44).

- Then carry out dismantling operations in reverse order.

- Withdraw shaft (D) towards the left.
- Release connecting rod at right-hand foot box.
- Remove the two screws from lock plate of left-hand connecting rod.
- Take out drive shaft of lower Pull connecting rod, from right to left (Fig. 44).




Fig. 44 - Removing interior Pull Control connecting rod drive shaft.



Fig. 45 - Position of drive shaft and lower Pull connecting rod.

Note: — Pay attention to position of Inner Pull lever spring (Fig. 46) and to position of lock bar covering the valve (Fig. 45).



Fig. 46 - Inside spring position



Fig. 47 - Connecting rod position

#### TO REPLACE RETAINERS OR BEARINGS OF INNER PULL CONNECTING ROD DRIVE SHAFT

To carry out these replacements, perform the following operations:

- Drain oil (engine, air valve and hydraulic system).
- Remove lock bar covering valve.
- Remove connecting rod lock pin.

- Push shaft a few millimeters in any direction or the other to replace retainers or bearings. (The bearing can be extracted with the aid of a pin).
- Once having made the replacement, assemble in reverse order.




Fig. 48 - Exploded view of position of inner Pull rod connecting rod drive shaft

### TO REPLACE FITTINGS ON RESERVE OF LIFTING AND DRIVE SHAFT

Carry out these operations in the following order:

- Remove fitting arm;
- Remove fit back cover (see Fig. 26);
- Take out inner shaft S, Fig. 46, located on left side of fixed rod;
- Withdraw drive shaft from left to right.

- Replace rollers;

- Replace bushings: use rollers and bearing TA, Tin, TF and TD, Te 20 (Fig. 40 and 41).

The bushings are greased and then fitted with grease inserts. To disassemble the assembly, carry out the above operations in reverse order.




Fig. 40 - Removing fit and fit the shaft rollers




Fig. 41 - Removing and installing fitting arm back top




Fig. 42 - Removing and installing fitting arm back top



#### TO REPLACE LEFT CYLINDER PISTON RETAINER (Fig. 82)

The replacement of the piston retainer is done in the following way:

- Disconnect auxiliary service distributor from main service distributor.
- Release front plate together with its distributor.
- Change piston retainer and front plate gasket.

To install assembly again, reverse the above procedure.

#### TO REPLACE SEAL AND RETAINER OF CONTROL LEVER SHAFTS (Fig. 83)

To replace O-ring seal and retainer of control levers, proceed as follows:

- Match the two control levers with respect to their shafts and remove them.
- Remove O-ring cover.
- Extract pin from Position Control lever shaft (Fig. 84).
- Take out shafts.
- Remove O-ring seal and retainer.



Fig. 82 - Replacing piston retainer




Fig. 83 - Replacing seal and retainer of control lever shafts

**TO INSTALL LIFT CONTROL LEVER**

Once the 2-lug seal and sealers have been replaced, proceed as follows:

- Fit shafts, using the torque wrench.
- Fit washers, clips or sealers pins, following reverse order of assembly.
- Install control lever.
- Check lift control lever and well adjusted for adjustment.



Fig. 14 - Hydraulic Control lever shaft pin lock

**TO REMOVE AND INSTALL HYDRAULIC PUMP**

To remove and install hydraulic pump, carry out the following operations:

- Disconnect the intake line.
- Disconnect the outlet line.
- Take out the two pump set screws.
- Pull out the pump backwards (Fig. 15).

To mount the pump, carry out the above operations in reverse, carefully ensuring the gasket with seal by steel.



Fig. 15 - Hydraulic pump

**DISASSEMBLE AND ASSEMBLE HYDRAULIC TO PUMP**

The hydraulic pump assembly procedure is as follows:

- Separate pump from mounting.
- Check pump with petroleum oil by 2 with com-

pressed air. Handle pump in a place free from dust and dirt.

- Take out pump shaft outer pin.
- Take out Allen screws that hold pump cover.

— Remove the cover and screw it in a position to be able to take out seals and remaining parts. In order to remove oil residue which has remained attached to the cover, push it through both part of cover, gently filling lower part of stator with a bronze rod, having first taken the precaution of removing fuel nozzle.

To assemble the pump, carry out the above operations in reverse order, always taking the precaution

to clean thoroughly with petroleum or gasoline. If it is necessary to fill pump, allow during disassembly or assembly, a plastic feather should be used.

**Note:** The precaution should be taken of fitting the bearings in the same position as they were before disassembly.

#### HYDRAULIC PUMP REPAIRS

As regards hydraulic pump repairs, two really serious troubles which may arise are the following:

##### i) Loss of oil through spinning shaft

There due to wear or rupture of double system and therefore the pump cover must be removed and inspected replaced as has been described above. As a general rule it can be said that work when when repair repairs comes it is due to wear or leakage, above these internal leaks increase and since they cannot be stopped, they tend to blow out the seals or burst it. Therefore, when any repair routine arises, it is advisable to check the adjacent part of bearings.

##### ii) Loss of oil between body and pump cover

This may occur when, for any reason, cover or screws have been loosened or the fastened joint is not in good condition. The screws should be tightened firmly and if this does not solve the problem, remove cover and replace worn gasket.

When a leak of pressure is observed in pump, check the following:

- Correctness of setting lines.
- Possibility of air intake.

If these points are correct, inspect spinning shaft stator or cover gasket. If they are in good condition, replace the pump.

**Note:** When pump is replaced in a unit that has been operating, clear all lines and components thereof.

## TROUBLESHOOTING TABLE

CAUSE	LOCATION	SOLUTION
<b>LOWERING OF IMPLEMENT WHEN TRACTOR IS STATIONARY</b>		
Leak in the hydraulic line	<ul style="list-style-type: none"> <li>- From body seal</li> <li>- From control valve</li> </ul>	<ul style="list-style-type: none"> <li>- Tighten seal nut</li> <li>- Replace gaskets</li> </ul>
Flow-restrictor valve	<ul style="list-style-type: none"> <li>- Adjust to 80 lb/in.² (5.5 bar) maximum to arms in high position and check there are no leaks in sub-line</li> </ul>	<ul style="list-style-type: none"> <li>- Change valve</li> </ul>
Loss in working valve	<ul style="list-style-type: none"> <li>- Tapered or scratched</li> <li>- Hydraulic line worn</li> <li>- Valve seized</li> <li>- Valve seat damaged (without repairing damaged)</li> </ul>	<ul style="list-style-type: none"> <li>- Close working valve and seal</li> <li>- Clean seat of valve</li> <li>- Replace damaged valve</li> <li>- Valve seat and front face of seat on valve plate if seat groove rollers worn</li> </ul>
Leak in cylinder	<ul style="list-style-type: none"> <li>- Tightness of cylinder</li> <li>- Valve seated</li> <li>- Tightness of these components can be tested by lowering heavy load (at least of 1,000 kg. or 2,000 lbs.) off arms, then to extend horizontally without peak lowering more than 0.2 mm (0.1 inches)</li> </ul>	<ul style="list-style-type: none"> <li>- Clean or replace valve</li> <li>- Repair cylinder</li> </ul>

## INSUFFICIENT RAISING OR LOWERING OF LEFT ARM

Position Control Switches adjusted		<ul style="list-style-type: none"> <li>- Don't use adjustment</li> </ul>
------------------------------------	--	--------------------------------------------------------------------------

## RAISE DOES NOT WORK OR WORKS IMPROPERLY

Position Control Valve Body or Seal	<ul style="list-style-type: none"> <li>- Sealer valve seal worn</li> </ul>	<ul style="list-style-type: none"> <li>- Tighten seal and verify seal reliability adjustment</li> </ul>
Insufficient oil capacity	<ul style="list-style-type: none"> <li>- Check level</li> </ul>	<ul style="list-style-type: none"> <li>- Fill up if needed</li> </ul>
Directional hydraulic		<ul style="list-style-type: none"> <li>- Check valve</li> </ul>
Control valve		<ul style="list-style-type: none"> <li>- Replace valve</li> </ul>
Leak in the cylinder		<ul style="list-style-type: none"> <li>- Replace valve</li> </ul>

CASE	LOCATION	SOLUTION
Primary filter	- Dirty - Tighten seal	- Clean or change - Correct
Secondary filter	- Exposed filter - Fault	- Replace seals - Replace pump
Secondary filter	- Dirty	- Clean or replace it

#### LOWER DOES NOT WORK ON HYDRA IN CORRECTLY

Full control regulator faulty adjusted		- Adjust
Overhaul valve stick		- Repair valve
Pump not start		- Replace
connecting valve broken or unhooked	- Reattach valve and hook	- Reattach correctly
Pressure valve broken operator stick	- It is not been closed low high pressure operation, check operator with equipment suspended in high position	- Correct or replace

#### INCORRECT OPERATION OF PULL CONTROL REGULATOR

Insufficient or excessive sensitivity in springs	- Get adjustment of lower pull according to	- Adjust
Over not work	- Replace springs or pull down spring broken	- Change faulty parts

**SECTION 10:****REAR AXLE****CONTENTS**

	<b>PAGE</b>
Specifications	1
Description	1
Removing rear axle assembly from tractor	2
Installing rear axle assembly in tractor	2
Disassembling and assembling rear axle	2
Disassembling power take-off	3
Disassembling hook for connecting rods	4
Disassembling differential locking control	4
Disassembling wheel axle shafts	8
Disassembling reducing shafts	8
Disassembling power take-off lower shaft and intermediate gear	9
Disassembling differential shafts	7
Disassembling differential	8
Disassembling differential group bearings	9
Assembling differential	9
Adjusting axial play of differential bearings	10
Adjusting gear clearance between crown wheel and drive gear	11
Adjusting clearance of wheel axle shaft level bearings	11
Assembling and adjusting differential locking control	12
External adjusting of differential locking control	12
Assembling Pull Control linear connecting rod	14
Assembling power take-off assembly	14
Assembling intermediate gear	14
Assembling power take-off upper shaft	15
Replacing a reducer wheel	15
Replacing differential crown wheel	15



## SPECIFICATIONS

Input gear	Countershaft 11 teeth Drive gear 7 teeth.
Output gear	10 x 40
Clearance between drive gear and crown wheel	0.10 mm
Thickness of adjusting shims for:	
- P.T.S. shaft bearing	0.1 and 0.15 mm
- Differential shaft bearing	0.2 mm.
- Axle shaft bearing	0.2 mm.
- Differential bearing	0.1 - 0.15 - 0.2 - 0.8 and 1 mm.
Gear-reducer crown wheel OR Capacity typebars, rear axle end 95	0
Capacity typebars, rear axle end 95	35.5 item
Viscosity	CG 2.

**NOTE:** The drive gear and crown wheel are mounted together in assembly. They are therefore inseparable.

## DESCRIPTION

The rear axle is of the semi-floating type with helical bevel type drive gear and crown wheel.

The differential has four spider gears and is mounted to the crown wheel. The four pinion gears mesh with two idler gears employed with helical splines at which the differential shaft fits.

The differential shafts have into contact with the gear reduce wheels which mesh with splines of the axle shafts. The counter-rear wheel is mounted on the pins formed by the axle shaft at its ends and which is equipped with conical roller bearings.

### TO REMOVE REAR AXLE ASSEMBLY FROM TRACTOR

Having cut shocks under rear axle housing and drained the oil from rear axle — gearbox assembly, the rear axle unit should be taken off the tractor by removing:

- Hitch system.
- Driver's seat.
- The two rear wheels.
- Right brake and direction indicator unit.
- Left brake and connector box.
- The two side plates.
- U/L of fenders.
- Ceiling of gearbox lower to give access to the rear gearbox - rear axle housing lock tools (Fig. 1).
- Disconnected control rods of brake boxes.

Use the gearbox on a trolley tool and lift out the gearbox - rear axle housing exterior mounting holes (Fig. 2). Remove gearbox - rear axle housing.




Fig. 1 — Taking out interior gearbox rear axle housing and covers.



Fig. 2 — Taking out outer gearbox rear axle housing and covers.



**INSTALLING REAR AXLE ASSEMBLY IN TRACTION**

To install the rear axle assembly in the tractor, carry out the operations previously described for removal, in reverse order, bearing in mind the following points:

- Fit the two longer mounting screws in the center-toy-pull bushings.

**Checklist - rear axle housing recording**

- Check that the two casting girth bolts are correctly located in the rear axle housing.
- Assemble gasket around with sealing paste.

**DISASSEMBLY AND ASSEMBLY OF GEAR AXLE**

To disassemble the rear axle the operations described (removing rear axle from tractor) should first be carried out. Once the rear axle is in a suitable position, proceed as follows:

- Remove pin.
- Remove rear axle supports.

**Disassembly/lay power take-off (Fig. 3)**

- Remove lock cover of power take-off shaft.
- Remove lock from universal joint and screw cover with screw Tc. Bcl. 10.

**Quality level testing**

- Check that the lock casting (pin) is in correct position.
- Assemble gasket around with sealing paste.
- The torque on the gear boxes is halved of 200 Nm.




Fig. 3 - Extracting P.T.O. upper shaft

Take out power take-off upper shaft through front part of housing. At the same time as you shift P.T.O. upper shaft forwards take out P.T.O. drive gear.

**Removing Inner Pin Control-mounting rod****Disassembling strut bar connecting rods**

To disassemble connecting rods, perform the following operations:

- Take out mounting screws of connecting rod plates.
- Remove right connecting rod.
- Take out connecting rod shaft (Fig. 4).




Fig. 4 - Removing shaft for connecting rod mounting

**Disassembling differential locking control**

The differential locking control is disassembled by the following:

- The shaft nut pack.
- The two set screws of pedal mounting bracket.
- The fork spring components.
- Springs.
- The fork.



Fig. 5 - Disassembling differential locking control

### Disassembling wheel axle shafts

To disassemble the axle shafts, proceed as follows:

- Drive axle shaft lock nuts and remove them with a 12 mm spanner (Fig. 8).
- Remove axle shaft nut cones in the hub and take out axle shafts (Fig. 9).
- Remove axle shaft cone bearing with aid of the press and bearing extractor T.A.225A (Fig. 6).

**NOTE:** On the left axle shaft it may happen that the nut which supports the first sleeve cannot be completely unscrewed, in which case nut and the axle shaft assembly must be removed.



Fig. 7 - Extraction of axle shafts



Fig. 8 - Turning nut with 12mm spanner



Fig. 6 - Extracting  
axle shaft  
cone bearing

**Disassembling gear reducer wheels**

To disassemble gear reducer wheels, carry out the following procedure:

- Remove brake bands.
- Remove nut side cover.
- Take out reducer wheel bearing lower rear part.
- Remove gear reducer wheel (to take out bearing mounted in crown wheel, use a Shimadzu extractor (Fig. 9).

**NOTE:** The beam is brought to bear on the roller edge. Therefore if the bearing is to be used again, it will be necessary to proceed with great care.



Fig. 9 - Extracting reducer wheel bearing




Fig. 10 - Disassembling power take-off lower shaft

**Disassembling P.T.O. lower shaft and intermediate gear (Fig. 10)**

The P.T.O. lower shaft and intermediate gear should be disassembled in the following order:

- Unlock and loosen castellated nut (1) with spanner (A, Fig. 11).
- Remove P.T.O. lower shaft (2) using a bronze rod as the appropriate extractor (Fig. 12). At the same time as the shaft slides out extract drive gear.



Fig. 11 - Disassembling P.F.O. housing

#### Disassembling differential shafts

The assembly of the differential shafts is to be carried out as follows:

— Remove differential axle together with axle mounting cage (Fig. 11). Then separate axle from cage (Fig. 12).



Fig. 12 - Disassembling differential axle



Fig. 13 - Disassembling differential axle and axle mounting cage

**Disassembling the differential**

Having taken out the differential gear cage from the axle housing, proceed in the following way:

- Mark differential gear cage before disassembling.
- Remove differential gear cage and cover wheel set screws (Fig. 13).
- With a punch, push out differential gear spindle cones toward the bottom of their housing (Fig. 14) (the latter is supported in order to see the

position in which it has to remain until they come to stop, in which position the cones are centered in the diameter of the rim axles).

- Take out the spindles (the long spindles will come out more easily through the side where the cone is housed).
- Remove pinion gears, friction washers and planetary gears.



Fig. 13 - Extracting pinion gear cones



Fig. 14 - Disassembling differential gear cone set screws



Fig. 15 - Differential gear cage disassembled

**Disassembling differential with bearings**

Once the differential assembly has been removed in order to extract bearings, use part 109-208 with solvers MP-30022.

**NOTE:** The bearings are coated with DANBUTT and have to be carefully degreased.

**Assembling differential**

To assemble the differential gear cage, proceed as follows:

- Dress splines.
- Assemble planetary gears.
- Assemble pinion gears and friction washers with their respective splines.
- Secure spider with lock pins.

**NOTE:** When securing spider, the pin should be inserted approximately 8 mm in their bearings measured from the head of the pin to the upper base of the housing lip. Do this when the pin is superposed to its position in which it has to remain.

- Fit the crown wheel with a torque value of 5.8 kg/m.



Fig. 12 - Extracting differential with bearings



Fig. 13 - Fitting lock pins

After installing the differential the following adjustments should be made:

#### Adjusting axial play of differential bearings

For this adjustment spaces are possible of 0.1 - 0.2 - 0.3 - 1 and 2 mm.

When carrying out differential bearing axial adjustment, two cases must be considered:

- a. Differential assembly installed without replacing any part: The assembly is installed fitting the spacers that were already there when it was disassembled.

Once the assembly has been installed it should be tested to see that the differential gear cage turns without play and that there is no more than a slight resistance to its rotation.

- b. Differential assembly installed with new parts:

- Assemble left-hand side differential side cage with a shim thickness of approximately 8 mm.
- Assemble left-hand side differential axle cage with a shim thickness of approximately 8 mm.
- Secure the two mounting cages and check the axial clearance of the differential gear cage.



Fig. 30 - Adjusting axial play of differential bearings

Adjust shim thickness in such a way that differential turns without play and that there is no more than a slight resistance (overload: 0.2 kg./lit).

Having adjusted the bearings, mount rear axle in position so as to be able to adjust clearance between crown wheel and pinion.

When mounting, take care in introducing the crown wheel shaft into its coupling sleeve.



Adjustment of tooth clearance between crown wheel and drive gear.

Desired gear tooth clearance: 0.2 mm.

To adjust tooth clearance between crown wheel and drive gear, carry out the following conditions:

- Fit the compressor on one side bearing with the perpendicular axis at the back of a crown wheel tooth (Fig. 26).
- Measure free play between crown wheel and drive gear.
- Calculate the difference between the maximum measurement and the real clearance (0.2 mm) to find out what thickness of shim has to be taken from the right hand side differential shaft, matching side is that of the left-hand side.

Example:

- Has measured 0.1 mm.
- Drive shaves that has to change side:  $0.1 - 0.2 = -0.1$  mm.

The shim that have to pass from the left side to the right will be of 1.0 mm. Check clearance again, which has to be 0.2 mm.



Fig. 26 - Adjusting tooth play between crown wheel and drive gear

Adjusting side shaft hand lever play

This adjustment is made off the tractor.

- Adjust it gradually without wiping shims (Fig. 27).
- Measure side play (from 0.00 to 0.05) with a compressor to determine thickness of shim to insert.
- Disassemble and reassemble again for a new check.

**Assembling axle shafts**

The wheel axle shafts are assembled in the following order:

- Assemble gear lock-up wires.
- Assemble bearing with the axial thickness determined previously.
- Install the nuts (torque of screws: 33 kg/m) and the paper gasket (torment) with sealing agent.
- Mount axle shaft (do not forget to cover the joint) the shaft between the bearing and the flange), assembling the nut lock plate, the bar and lock sleeve in that order.



Fig. 12 - Adjusting slip of axle shaft (road bearings)

**Assembling and adjusting differential locking control**

The differential locking control is assembled and adjusted in the following way:

- Set shaft in place.
- Fit locking fork and spring, pointing shaft towards.

- Secure fork on shaft with set screw, locking screw with wire.
- Assemble pedal brackets.
- Compress spring in order to fit pedal, installing the roller with cable.

The assembly will be correct when the sliding lock sleeve 3, fig. 22 is at a distance 20, fig. 22) equal to 4 mm from fixed lock sleeve 2, fig. 22).

Carry out this adjustment (fig. 22), whenever the rear axle is inter-leafed with, in the following way:

- Measure distance 20) compressed between the two sleeves. If this distance is not of 4 mm, loosen the screws 10) and correct the distance by means of 20) or 16) until correct distance is obtained.




Fig. 22 - Differential housing screw adjustment

#### Differential housing control selector adjustment (fig. 23)

When the working of differential housing is not correct, carry out control adjustment in the following way:

- Raise back, right wheel of train.
- Gently turn the wheel, at the same time pressing blocking pedal so that the two sleeves are working against each other from inside position.
- In this position, make a mark on the shaft 14) back with line of rear axle housing.
- Release blocking pedal and check equivalent position of shaft, measuring the distance 10) from axle between the mark and housing 14).
- If the distance is not of 4 mm, loosen screws 10) and correct it by means of axle 21) in fig. 23) and correct measurement is obtained.



Fig. 23 - Differential housing screw adjustment

#### Assembling Pull Control lower connecting rod (Fig. 24)

The Pull Control lower connecting rod is assembled by noting the assembly marks marked up.

The reference spline on the shaft is distinguished by the radius on the lower head, soldering with care to connecting rod reference point (the shaft is fitted from the left side).

Do not forget to fit E-clip seats to lower bearings.



Fig. 24 - Assembling Pull Control lower connecting rod

#### Installing power take-off assembly (Fig. 25)

The power take-off assembly is installed in the following order:

- Fit first bearings (1).
- Offer up P.T.O. shaft (2), assembling the separator (3), the gear (4) and bearing (5) to first shaft.
- Blank and lock coverplate (6).
- Fit lock plate and the perimeter, filled with grease.

#### Assembling into secondary gear (Fig. 26)

- Set shaft (7) in place.
- Assemble washer (removed for plate (8).
- Install gear (9) with its needle bearings (10).
- Assemble second washer (11), pushing the shaft so as to be able to locate the washer in position on the gear.




Fig. 25 - Installing P.T.O. assembly

**Assembling P.T.O. upper shaft (No. 10)**

Slide the roller bearing (72) in its place. Fit gear (73) in the rear bearing housing.

- Set the shaft in place and fit ball bearing (69) (74) and separator (75). Mate shaft and gear when match up.

- Fit ball bearing (76).
- Wash and lock nut.
- Fit lock washer (77).

**Replacing a gear roller wheel**

The gear roller wheel should be replaced according to the following procedure:

- Remove (81).
- Remove rear axle housing top cover.
- Remove rear wheel from axle on the carrier mounting side.

- Remove axle shaft.
- Remove brake box and shoe.
- Remove bearing and replace gear roller wheel.

Assembly is carried out in reverse order.

**Replacing differential crown wheel**

The differential crown wheel is replaced in the following way:

NOTE: The replacement of the crown wheel involves the replacement of the gearbox main shaft.

- Remove gearbox (see gearbox section).

- Remove rear axle from rear axle housing.
- Replace crown wheel and main shaft.

NOTE: When assembling these parts, it is necessary to carry out the corresponding adjustments (see pages 16 and 18 gearbox section and pages 10 and 11 rear axle section).

## SECTION 11:

## BRAKES

### CONTENTS

	PAGE
Specifications	1
Description	1
Adjustment of brakes	3
Disassembling and assembling brakes	4
Disassembling brake shoes	4
Disassembling drive plate assembly	5
Assembling drive plate assembly	5
Assembling brake shoes	6
Disassembling brake pedal	6
Assembling brake pedal	6
Disassembling brake pedal shaft	6
Assembling brake pedal shaft	7
Disassembling handbrake lever	7
Assembling handbrake lever	7



PUBLISHED BY FORD LAMP  
1st Edition, 1988

## SPECIFICATIONS

Type	DRUM, double-plate operated jointly or separately to assist in turning.
Outer surface of disc	11.2 mm.
Inner surface of disc	7.8 mm.
Friction surface of disc	155.8 cm <sup>2</sup> per face.
Section of rear disc	11.50 to 11.80 mm.
Maximum allowable wear of disc	2 mm (one per face).
Free travel of brake pedal	30 mm.
Handbrake	Blocks both wheels.

## DESCRIPTION

The fully protected disc brakes are self-adjusting and are equipped with two rotating friction discs. The two discs, secured to the differential shafts by means of a splined connection, are located one on each side of an assembly of drive plates whose brake faces are provided with four wedge-shaped pistons, in each of which a steel ball is housed. Two spiral springs hold the drive plates in contact with the steel balls and act as return springs.

On applying pressure to the brake pedal, it is transmitted to the drive plates by means of linkage.

This causes the drive plates to move in the opposite direction, as a result of which the balls climb up the inclinations of the shafts and force the plates to separate. On releasing, the plates come into contact with the friction discs, pressing them against the casing and the cover and consequently they brake the differential shafts.

When the pressure exerted on the pedal is removed, the springs force the plates to return to their original position and the balls house themselves again in the deepest part of the nozzles. As a result, the friction discs are able to turn freely.



Fig. 1— Brake system components



To guarantee uniform braking when engaging both brakes, the control linkage is provided with a non-compressible spring 17, (Fig. 11), which is lubricated by means of a seal secured with a spot weld.

The characteristics of this spring are:

- Diameter of wire: 5.5 mm.
- Spring force: 0.5-0.62 kgf/cm.

- Spring compressed when fixed: 87 mm.

The brakes are operated by two independent pedals (located at the right side of the tractor). The right pedal controls the right brake and the left pedal the left brake in order to avoid when it is necessary to make very tight turns.

## ADJUSTMENT OF BRAKES

Although it is recommended to adjust the brakes every 100 hours under normal conditions, this time may vary since it depends on many factors, such as type of work, state of driver, etc. The need for adjustment will become obvious when a reduction in brake efficiency and the need to work more pressure on the pedals are observed.

With use, the friction shoes gradually wear down. The wear which, on the other hand, may occur irregularly on either wheel, is noticeable through increased free travel of the pedals.

The free play of the brake pedals has to be adjusted 5-20 mm., measured between the pedal and the floor of the seat (A, Fig. 11) when the brake is set.

During operation, the operator will decrease spring to increase deceleration in the brake. On the other hand, if the operator were greater, there is a danger that when fully depressing the pedals, they reach their maximum level before applying the brake completely.

The adjustment of the brakes is carried out in the following way:

- Release of tension so that wheels are free.
- Disconnect pedal return springs.
- Loosen master control, (Fig. 11).



Fig. 2 - Adjusting wheel

- Tighten nut (B, Fig. 2) with wheel & shock: in this position increase the nut size or two turns, locking it again with conical nut.
- Adjust pedal free travel by means of adjustment fork (B, Fig. 2) of control linkage.
- Connect pedal return spring.



Fig. 3 - Adjusting pedal free travel

- Pressed steadily with the other brake and lower the cable.

The handbrake is adjusted automatically when adjusting front brakes.

## DISASSEMBLING AND ASSEMBLING SPARES

### DISASSEMBLING BRAKE BOSS

To disassemble one of the brake drums, proceed as follows:

- Remove stop plate and outer spring of brake and clutch pads.

- Remove brake:
- Take care of rotor and inner wheel.

- Disconnect brake control linkage at control arm.
- Remove brake box cover.
- Remove front steel guard.

Remove in this order:

- Drive friction disc.
- Drive plate assembly.



Fig. 1 - Disassembling brake box

- Brake friction disc.
- Brake box cover.

Disassembling drive plate assembly.

On the rear wheel, disassemble the rear axle, linkage and screws and the bolt (E) will be observed that the nuts are factory locked to secure them to the ground.



Fig. 2 - Disassembling drive plate assembly

Assembling drive plate assembly.

To assemble the drive plate unit, remove the following components:

- Thoroughly clean and inspect all components, replacing any faulty or worn parts.

NOTE: Harder steel balls and their housings should be lubricated.

- Install the four balls in their housings.

- Place the outer drive plate on top of the balls.
- Assemble the two spring springs.

- Assemble the upper and lower fork, securing the nuts on the oil axles.

#### Assembling brake lines

Before proceeding to assemble a brake line, check:

- That the friction faces of the lining and cover do not have excessive wear and are not scored or cracked.

- That the hoses do not have leaks (check that the hose are not deformed, worn or cracked and that there is no wear on the splices).

Being made these checks, to assemble brake line, carry out the disassembly procedure to remove both:

#### Disassembling brake pedals

The brake pedals should be disassembled in the following order:

- Unhook brake and clutch pedal return springs.

- Disconnect clutch control rod and control levers of brake pedals.

- Remove brake and clutch pedal shaft bracket.

- Withdraw pedal assembly.

#### Assembling brake pedals

To assemble brake pedals, carry out the disassembly procedure in reverse order.

#### Disassembling brake pedal shaft

Disconnect the parts according to the order of figure 8.

In case of clutch pedal bushing wear, replace the bushing with a new one so that the pedal turns on its shaft without play.



Fig. 6 - Disassembling brake pedal shaft

#### Assembling brake pedal shaft

Carry out assembly in reverse order to the disassembly procedure.

When mounting the parts on the pedal shaft, sufficient side play has to be left so that the pedals can turn freely.




Fig. 7 - Disassembling handbrake lever

#### Disassembling handbrake lever (Fig. 7)

To disassemble handbrake lever, perform the following operations, removing:

- The two return springs.
- The left frame (1).
- The left brake control linkage (2).
- The clutch control rod (3).
- The assembly made up of the clutch pedal (4) and the left brake control connecting rod (5).
- The handbrake lever (6).

#### Assembling the handbrake lever.

To reassemble the handbrake lever, carry out the following disassembly procedure in reverse order.

## SECTION 12:

# WHEELS, TIRES AND WHEEL COUNTERWEIGHTS

### CONTENTS

	PAGE
Specifications	1
Descriptions	2
Tireless	2
Inflation pressure	4
Table of pressures	7
Tractor ballast	8
Water ballast	9
Water ballast systems	10
Centering wheel	12
Counterweights	
Front wheel counterweights	12
Rear wheel counterweights	13
Front counterweights	13
Wheels	
To remove and install a front wheel	14
To remove and install a rear wheel	14
Rear wheel tread width	18
Tires	
To remove a rear wheel tire	16
To install a rear wheel tire	17
Troubleshooting table	19



Publication SP-100-E01-1  
For Edition 1.38

## SPECIFICATIONS

## Wheels

Front	Pressed steel rim and disc with holes for attaching counterweight, welded to rim.
Rear	Pressed steel rim with tubular spokes and disc with holes for attaching counterweights.
Dimensions Model 300	
Front	1.50 x 18
Rear	WT1 x 28 (optional), WT2 x 28 -- W0 x 28 -- 1410 x 28 -- WT3 x 28
Dimensions Model 400	
Front	W5,50 x 18 -- 6,50 x 18 and 7,00 x 18 WT3 x 28 (optional) WT1 x 28 -- WT2 x 28 W0 x 28 and 1410L x 28.

## TIRES

Dimensions Model 300	
Front	6.00 x 18 (optional 5.00 x 18)
Rear	12 x 28 (optional: 12 x 28 -- 11 x 28 -- 11 x 28 and 12 x 28)
Dimensions Model 400	
Front	6.50 x 18 (optional 5.50 x 18 and 6.00 x 18)
Rear	12 x 28 (optional: 12 x 28 -- 12 x 28 -- 14 x 28 and 14 x 28)

## Maximum allowable weight per tire Model 300

Front (5.00 x 18)	500 kg
Rear (12 x 28)	1,400 kg

## Maximum allowable weight per tire Model 400

Front (6.00 x 18)	575 kg
Rear (12 x 28)	1,875 kg

Front wheel track width: From 1.28 to 1.67 m in seven different positions, adjusted by front axle extension.

Rear track width Model 300: From 1.12 to 1.26 m in eight different positions of disc and rim.

Rear track width Model 400: From 1.25 to 1.50 m in eight different positions of disc and rim.

## Counterweights

Front	2 of 22.5 kg, approx.
Front wheels	2, one on each wheel of 28 kg, approx.
Rear wheels	4, one on each wheel of 45 kg, each approx., tires attached at Model 400 with 12 x 28 wheels.

**DESCRIPTION**

An important feature in the design of the 2000R is the proper maintenance of its tires. The tires used by the 2000R 200 and 400 systems have been designed to

obtain the best traction and the best wear in the conditions specified.

**TRACTION**

Four factors are used to test maximum traction capacity, mainly because the wear cannot be tested the excessive sideways or side. If a tractor is driven over a smooth flat surface, the tire tread or pattern will grip the ground best, most steel, as long as the reactive forces length forces applied to the tread is not greater than the coefficient of friction between the tire and ground. When the tire grips the ground without slipping the traction will be 100%.

In testing tire tread pattern design with other factors, the maximum traction percentage in the most favorable conditions normally, the 2000R is approximately 90%. In the case, a tractor capable of bearing a load of 5,000 kg will have approximately

$$\frac{5,000}{1} \times \frac{90}{100} = 4,500 \text{ kg}$$

In ploughing or other similar field tasks, the coefficient of friction is reduced to approximately 60-65%. For this reason (bearing in mind the weight of the tractor) to increase the weight over the 2000R 200 and the traction force of the 2000R.

To achieve the necessary coefficient of friction, it is essential that all the factors that affect the performance of the tractor be adjusted in accordance with the conditions of the soil.

Some of these factors include the following:

- The pressure of the tire has to be the minimum permitted for the load which it bears and the size and air rating of the tire used.
- The tire used for ploughing must not be more than 1/3 to 1/2 worn. The tread here has to be in the correct direction (shown at this time in areas on the manual) which indicates the correct rotation.
- The tractor and tire in accordance with the condition of the soil, for example:
  - a) Clay soil. Large diameter and narrow section tires. These tires have little contact area with the soil and consequently more weight per unit than the wide section ones so that the tread runs like the soil better and improves traction.
  - b) Very light sandy soil. The wide section tire concentrates less weight per unit than the narrow section one so as to prevent the wheel from sinking in the soil.
  - c) Heavy soil. In fields with stones the wide section, narrow profile tires have better and last longer as the tread is spread over a wider contact area.
  - d) Sandy soil. These soils require a completely different type of tire. Using a tire with normal tread is right, which has the soil. In these conditions, the most tread tire has to be used so as to achieve good flexing and to turn on the soil as far as possible.



## INFLATION PRESSURE

The load life and good performance of a tire depends on its maintenance. In general, and on correct inflation, is particular. The tire should never be used underinflated or overinflated.

In agreement with the load it is carrying, the condition and type of ground over which it is travelling and the speed of operation, the tractor tire requires a certain degree of flexibility. That is, the tire casing must be capable of changing shape so as to be able to absorb the forces it receives from the ground as it turns. However, this is true within specified limits, and if the tire should mistakenly be given an incorrect rigidity by modifying the recommended inflation pressure, it is liable to suffer from a series of troubles and problems that due to operation under normal conditions.

Overinflation reduces the ground contact area, making the tire narrower in this part and leading, with under load, to an excessive, excessive, when the tractor regularly travels on road it is advisable to increase the pressure slightly above the recommended for field working so that as the casing becomes more rigid, the tread ribs may be less mobile — as feeling less — whereas a typical form of irregular wear through the kind of work is prevented. It has also been observed that, when the tractor is working on a hard, smooth surface, it is usually advantageous to increase the inflation pressure, since a more effective traction is obtained with this, although without exceeding in any circumstances the maximum permitted for the size of the tire concerned.

Keeping to the recommendations that are made in regard to tire inflation is the most fundamental aspect of their care and maintenance, due to the great influence it has on their performance, although, paradoxically, it is the most generally neglected.

Underinflation produces excessive deflection and gives rise to structural stress in certain parts of the tire. It is true, however, that it is exceptional to

reduce the air pressure to obtain an increase in traction in certain conditions, such as working on loose, sandy soil, by up to 0.14 kg/cm<sup>2</sup> below the recommended. In any case, in these circumstances it is much better to increase the weight of the driving wheels, whereas the ground contact area of the tire will be increased while still maintaining the correct air pressure.

The tire pressure may also be reduced somewhat if work has to be done in very tough conditions on rocky ground where the leading tread quickly becomes flattened, but always bearing in mind that this is detrimental to the tire casing while additional weight is run.

The tire always warms up somewhat with work as the temperature of the air contained in the tube rises, which gives rise to a proportional increase in pressure. Consequently, when a slow speed operation, the pressure is greater than the recommended; this is corrected therefore such increase should not be reduced as, when the tire cools down, it will again acquire the correct pressure. Pressure must always be measured when cold. In a tire where there is in good condition, that is, which does not have any wear that a normal loss of pressure, the pressure should be checked at least once a week. If, just without using that, after being left for a long period, the pressure has experienced should be made up immediately, because the pressure causes the following effects:

- Overinflation, Overinflation is the cause of troubles in the tire system. Causing a slow might be supposed it does not increase the work capacity of the tire in any way. On the other hand, it weakens the casing fabric cords by reducing their shock absorbing power owing to the greater tension of the fabric, thereby making it most liable to burst.

Furthermore, it produces pressure wear in the road as well as lowering the level up of the tire against the ground and as a result, the loss of traction and increase in fuel consumption.

Blow-outs or impact bursts of a purely accidental nature are a typical failure of the casing, due to the rupture of the fabric when which compresses when they are subjected to a sudden force which exceeds their resistance limit of extension, resulting from a heavy impact or blow received by any part of the tire casing.

Blow-outs or impact bursts can present different forms. They may adopt the form of a single rupture of the fabric in a single chamber, diagonal to the casing and following the direction of the fabric fibres, or they may take the form of a double burst in the shape of an X or cross, following the two main directions of the wires of the different plies. If the impact is sufficiently extensive and the pressure very excessive, the burst may embrace the whole casing from bead to bead.

With extremely high pressure the tire casing is more vulnerable to impacts or blows against external objects. Nevertheless, at the normal pressure a very concentrated blow of high intensity, such as that caused by a sharp-pointed rock or a projecting piece of wood, may produce a very deep penetration through deformation in the casing and cause a blow-out like those described above, since the elasticity of the assembly is not able to absorb the energy released in such an impact.

An excessive inflation pressure is not only detrimental to the casing, through the possible blow-outs we have just referred to, but because it also affects the life of the tread rubber through irregular wear and by making it liable to cut and tear. When a motor vehicle with excessive pressure the ground contact area of the tread is very small, in such circumstances the track that the tread moves on the ground will be almost rectangular in shape corresponding to the central part of the tread pattern. Apart from the rapid wear due to a greater contact pressure with the ground and, consequently greater skidding, it

creates a considerable loss of speed and traction. In fact, the better the traction sought from the motor, the greater the contact area of the wheels required, so that the low take-up which are those which impact grip—may penetrate and hold fast to the ground.

The belief that an increase in pressure increases wearing capacity of the tire casing is false, as verified just now. However, for certain loads it is common to inflate the tires slightly above the normal, but only temporarily.

When working, for example, on heavy ground or with considerable stresses on both sides of the frame or when very hard surfaces are concerned, the tires may be inflated slightly more than the normal, but always exceeding the maximum specified.

- M Underinflation.** Underinflation of a tire has its own or more influence in the reduction of its working life as the opposite fault of overinflation.

Lack of pressure produces failure in the tire casing through the heavy fatigue of the fabric due to the abnormal flexure—excessive and continuous—in the rubber of the carcass.

In the case of an overinflated tire, its sidewall is kept in a flat shape by chance, and therefore, only occasionally, it cracks or exceptionally being impacted on the other hand, when working underinflated, the excessive deflection to which the sidewall when air subjected is continuous, with an energy being absorbed—and lost—which is converted and degraded in the form of heat. This explains these cases in such a way that it may give rise to ruptures, separations and tearing of the fabric layers, blowings, cracks, the formation of cracks in the sidewall.

Lack of pressure also causes uneven tread wear, but it remains the possibility of the casing sliding on the road, with the resultant air take follow through leading to skidding.

In plowing work, when the right wheel of the tractor is always kept in the furrow, the tractor runs at an angle and is, in addition, subjected to the twisting characteristic of this kind of work. When the tire sidewall is forced to bend considerably if the inflation pressure is not correct. In this way correct pressure helps to prevent cracks in the sidewalls due to tire stresses and also inhibits the formation of bulges from rubbing against the furrow.

This rubbing is worst on the sidewalls of the front tires when the center of application of the driving forces or tractive effort of the tractor shifts back or full load are not in line with the center of application of the steering forces (brakes, rollbars etc. etc.).

In the case a rubber fender is built up which tends to divert the tractor from advancing in a straight line. The driver counteracts this pull by turning the wheel in the opposite direction. The steering tires do not advance in plane completely parallel to the driving axis but rather they are slightly steered, thereby producing a lateral rubbing force which results in the previously mentioned scuffing action. The front tires have a slight steering and steering movement.

Therefore, the front right tire outer sidewall and the front left tire inner sidewall are rubbing and peeling against the ploughed furrow in the first case and against the hard ground in the second. This lateral force can cause an uneven and permanent deformation of the sidewalls, which if it is also accompanied by synthetic low pressure, can wear down the tires and producing blow-out or separation of ply in the shoulder area.

To prevent this trouble, when the tractor tire an additional 0.28 kg/cm<sup>2</sup>, apart from steering the correct maintenance to the other wheel is increased the load resistance and correct sidewalls through your adjustment. Since the wear

on the wheels is worse in this work, they should be changed over from 50% to 50%, being care to load them in the correct rotation direction.

Excessive flexure under load wears down the rubber. The forementioned phenomenon, as well as forces in general, since the tire case is necessarily flattened through lack of air pressure, can produce typical flexure cracks at the base of the tread bars, which in some cases can even affect the ply, perforating the innermost one as well. In fact, the bars are bowed, in its shape, in the heart of the air, producing very pronounced changes of shape in conditions as they are approached every time and which finally produce internal flexure fatigue and the formation of cracks on the outside of the tread bar joint angles. This fact, due to the fact the tread bars are too mobile because the riding which holds them is not sufficiently rigid, may be counteracted by inflating the tires to an additional 0.28 kg/cm<sup>2</sup>.

Low pressure is also harmful when the tractor is used in a field where the tire load, not only with regard to typical pressure wear, which are inevitable when dealing with excavation, but also for the risk of exceeding the loads allowed underload the tires, especially when traveling at high speed. The pressure over the tire is low pressure, when the tractor is working on the road, can be largely prevented by changing the direction of rotation of the tire, which is achieved by rotating the right and left wheels. Experience shows that by this the life of the tires can be prolonged by up to 20% in the case.

If, however, when the tractor returns to its normal work in the field, the wheels have to be found in the normal position with the arrow in the direction in which the tractor is given, if this is not done, the tire tends to separate to ply and wear fast.



## EXPLANATION OF THE TRACTION

The traction force of the tractor can be increased by ballasting. According to the conditions of the ground and implements that the tractor carries or tows, it gives tractive force, different in each case, is required, which makes a special study advisable.

The nature or type of additional load to be attached to the drive wheels has no importance in itself.

Whether it is in terms of cast-iron counterweights which are generally assumed to be wheel disc, or simply resulting to the well-known practice of water ballasting (liquid ballast), any system is acceptable. Weights have the advantage that they can be attached and removed quickly and easily. However, what is important, as always, is the principle of the procedure to itself. The routine of water ballasting the drive wheels, as sometimes happens, for the simple fact that water does not flow or freeze if water is to be in liquid, not to be avoided. The important thing is to know how to decide when it is right to apply it in a specific way or when it is superfluous or even detrimental to cause in this system of ballasting.

The basis of it all lies in whether the tractor wheels slip when making a strong effort or rolling a heavy load, why it does so, and what has to be done to prevent it. Above all, a clear idea must be had of the correct consequences that this problem has for the correct preservation of the tire tread bars which are exposed to particular and uneven wear through side and front to the other. The greater the stability, the quicker this will occur. Inevitably speaking, it is less so better for tough, heavy duty (heavyweight), cultivating, but ploughing etc., which is when the power of the tractor must be used to the full, while it is not necessary to fight a job and transport spare load.

Attempts must not be made to solve the problem there by means of increasing or reducing the pro-

cess so, apart from the fact that these solutions have little effect or, worse, they work on the other hand, lead to the destruction of the tire.

It is natural to find that in each particular case varying conditions are met, both in relation with and working conditions, whereby different degrees of pull power or the drive bars are required. Thus, to achieve optimum performance in each situation, it will be necessary to find the most suitable weight for ballasting. In practice, the value of the front-end pull was very considerable, as it depends on the soil surface, degree of compaction and the load pattern of the tires.

However, it is understood that the tire should not carry more weight than that specified for their maximum load capacity. If, with the additional weight in question, the tire would be overloaded, it will be necessary to replace the tires with others of greater load capacity. When fixing additional weight to the ground load side must always be kept in mind.

However, in particular circumstances certain over-loads can be permitted.

In principle, when the weight of the tractor rear wheels is increased, whether with water or by weights, it is advisable to increase the weight to the front as well in order to re-establish the correct balance of forces, which otherwise would affect the good operation and proper working conditions. Besides, with excessive indirect ballasting at the back of the tractor implements and there is a risk that, in certain heavy soils, the front of the tractor may sink in. The front counterweights can either be attached to the wheel discs or to the support protruding from the front axle.

**WATER BALLASTING**

Submerging of the tire with water, which is introduced into the air tube, is known to the name of water ballasting. It is the simplest and least detrimental way of increasing the weight of the wheels, apart from its low cost, ease and speed with which the operation is carried out, and the possibility of conveniently adjusting the required ballast weight. The system, as opposed to ballasting with weights has no influence on the axle, wheels and the rims, as the additional load bears down on the tread and the ground.

Although the ballast water can be fully easily removed, it generally remains there for some time. Therefore, in case of a light rain an additional weight is being carried, thus increasing the tractor fuel consumption. The water ballast tank is located at a very low level, producing a lowering of the center of gravity of the tractor and a reduction in the risk of its overturning on sloping ground.

To prevent the water used in ballasting from freezing in winter, an anti-freeze product must be used. The most common system is to use a mixture of water and calcium chloride. It is best to make the solution in an open container and add for it to cool before introducing it into the tire.

From the solution available take the water, pour into the water up to the calcium chloride. This anti-freeze should not be used in the engine radiator as it is corrosive to metals. Similarly, the anti-freeze used in the engine cooling system should not be used in the tires as it attacks the tubes.

It is best to discharge the water-chloride anti-freeze solution via a device of sanded tire per hundred of chloride, that is 1%, or so to eliminate any possibility of wetting.

**NOTE:** Do not attempt to add chloride directly to the tire fluid with water, as the resultant heat and expansion of the mixture can damage the tire.

Take care to wash with clean water those metal parts which have been splashed, as the anti-freeze solution is highly corrosive.

If, when draining a tire, the water which remains below the level of the inner tube valve, located in its lowest position, is not entirely removed, and will freeze when water only has been used, some the pieces of ice that may otherwise form, would damage the tube and the casing.

When introducing the liquid, do not use high pressure pumps such as those used for washing tires; it may be filled from a low pressure fountain, a specially prepared pump, a hand sprayer pump, or simply by gravity, forcing the liquid above the tire. The quantity of water or solution to be introduced into the tire is regulated by the position of the valve. When this is in its highest position approximately three quarters (75%) will be filled, but if the valve is located on a horizontal plane, only half will be filled.

Water ballasted tires carry the load under air pressure. An over-inflation of the inside of the tire enables to obtain better adhesion and to protect the carcass of the casing. Therefore the tire will never be totally filled with water as it has been proved that a size 30000 tire, with 50% water ballast, is 22% more resistant to impact and rupture than one completely filled with water at 1000 kPa.

When travelling fast on the road, if the wheels have water ballast, the water may splash the tractor to cause an slip on hard or loose. The following table shows the approximate capacities of tractor tires for agricultural use, filled to 75% of their volume, and the mixture of commercial calcium chloride recommended to protect them during a temperature of 30° C during use.

T <sub>1</sub>	T <sub>2</sub>	AIR PRESSURE (PSI)		
		Front	On a vehicle with a load of 1000 lb	Max. of vehicle
11.20	120	110	35	340
11.50	130	120	34	330
12.00	140	130	34	320
12.50	150	140	34	310
13.00	160	150	34	300
13.50	170	160	34	290
14.00	180	170	34	280

**NOTE:** The table and method of filling recommended below can be used for every kind of tire. Although front and rear tires are very slightly of different dimensions, according to the manufacturer, the degree of filling the vehicle will not affect the performance of the tire. The air pressure values are persons obtained by the addition of oxygen (oxygen) values but only according to the procedure shown but also with the degree of concentration of the vehicle. The following table shows, in a more graphic, a list of filling-air temperatures in relation to the recommended percentage of oxygen (oxygen) to be used by means of two different degrees of concentration, at 70/70% normal (normal) and at 11/20%.

#### WATER BALLASTING SYSTEMS

To facilitate the introduction of the water into the tire at rate, a number of methods can be used, with or without the aid of special adapters for water hoses. If only a hose is available, the following recommendations can be followed:

- Jack up the wheel from the ground. If the wheel is not installed on the vehicle, place it in a vertical position. In either case, the valve must be in its highest position.
- Take out the part of the valve that contains the core (Fig. 1) so that into the base of the valve remains, allowing all the air to escape.

Temperature in °C	Required water concentration (%)	
	Concentration 11/20 %	Concentration 70/70 %
5	0	9
10	20	12
15	30	15
20	40	18
25	42	20
30	50	42

- Connect the water hose or normal valve adapter into the body of the valve (C, Fig. 1).
- Turn on the water from the water supply or from a tank 1.5 or 2 meters above, introducing the operator from time to time to allow the air in the tire to escape.
- If on withdrawing the hose, the water runs out continuously through the valve, the water has reached the level of the valve and filling should be stopped.
- Connect the valve core and install the tire in the prescribed position.

Do not use a normal air pressure gauge to measure a water-filled tire or it goes wrong. There is a special gauge for this purpose.



Fig. 1 - Valve

To avoid the trouble of having to remove filling several times to air the air escape, when the tube is fixed directly to the body of the valve, some special devices are used which permit the air to escape at the same time as the water is being introduced. One of these is the well-known Schrader number 2552-A, which has an air bleeder built into its side. When the water runs out continuously through the bleeder — the valve being closed — the air case is full up to the level of the valve (75%).

The valve or small part 596, 20913, B, Fig. 2, which accompanies the adapter, can be used to fit a multiple per valve.

There are other adapters (Fig. 4) which, instead of a turner type side valve, have a small diameter, ylideic or rubber tube which is inserted through the body of the valve and which provides a continuous outlet for the air as it is being displaced by the water.

On the assumption that air up to 90% filling is desired, proceed as follows:

- Loosen the wheel with the valve in the bottom position (this is necessary because of what will be explained later on).
- Attach to the valve an adapter equipped with a tube or tap with 20-2000004 of 150 mm for tires of 7" to 10", of 200 mm for tires of 10" to 12", of 300 mm for tires of 12" to 15".


 Fig. 2 - Water filling by gravity  
 A - air B - water C - valve


Adapter (A) - in use

It should be attached to the air outlet tube as is illustrated in Figure 2.

- Pump the mixture with the aid of hand pump until it runs out through the adapter or removal tube, at which time a portion of the capacity of the tire will have been filled.
- Stop the air outlet with a finger and give the wheel a half turn so as to rotate the valve to the top position.
- Continue pumping the liquid until it runs out through the air removal tube.

At this moment approximately 50% of the capacity of the tire will have been filled.

With this reference, turn the wheel slightly to other position, allowing liquid to run out through the valve until an approximate 90% filling is achieved.





Fig. 4 - Filling with lead shot

**NOTE:** With respect to what has been previously discussed, the purpose of starting to fill the tire with the valve in the bottom position is to allow the adaptor extension tube to be inserted into the lower



Fig. 5 - Draining water

valve without vibration, which would not be easy with the valve in the top position as the lower tube would then be displaced on the rim.

#### DRAINED WATER

To remove the water, it is sufficient to locate the valve at the lowest point of the wheel and take care the valve core so that the water runs out through its own weight. If it is desired to remove all the water that remains below the level of the valve in its lower position, a water ballast adaptor is used, equipped with a bladder tube, which is inserted down into the tire valve hole. The pressure of the air delivered through the long tube of the adaptor will force the water to run out through the tube. If no water ballast adaptor is available, the following

procedure can be employed: fit a small rubber tube, like a garden hose, in the bottom end of the valve core and insert it into the tire valve tube through the body of the valve and then screw in the cork plug. The tire is then inflated and the cork removed, letting the residual water run out as it will be expelled by the pressure of air travelling inside the inner tube. To get rid of the garden hose, the cork-plug part is removed, which is screwed in again - with the cork - after taking away the tube. Finally the tire is inflated to the correct pressure.

**COUNTERWEIGHTS**

Equipping the tractor with cast iron counterweights provides advantage that they can be quickly removed when the tractor does not require extra wheel weight for some jobs. Through this advantage, more fuel is saved than in the case of solid cast iron. The tractor operates with liquid ballast under normal conditions.

**Front wheel counterweights**

These weights weigh approximately 20 kg. One counterweight is attached on the inside of each wheel (Fig. 8).

**Rear wheel counterweights**

Weighing approximately 40 kg., one or two weights can be fitted on the outside of each wheel, mounted into two slots. These weights are only valid for the Model 480 equipped with 12 x 30 wheels (Fig. 9).



Fig. 8 — Front wheel counterweight

**Front counterweights**

These weights, of approximately 30 kg., fit into the flange formed by the front support, being secured with nutted SA, SA, SA, 10-10 right wrench can be attached in the space in the above mentioned flange.



Fig. 9 — Rear wheel counterweight



Fig. 8 — Front counterweights

**W H E E L S****TO REMOVE AND INSTALL A FRONT WHEEL**  
**(Fig. 9)**

To remove a front wheel, proceed as follows:

- Apply 3000 psi for greater results, check the rear wheels.
- Loosen the axle hub nuts.
- Remove the ECU cap.
- Jack up the front of the tractor.
- Finish loosening the six hub bolts and take off the wheel. To install the front wheel, carry out the above operations in reverse order, tightening all the bolts to a torque setting of 6 to 8 ft-lb.



Fig. 9 - Front wheel

**TO REMOVE AND INSTALL A REAR WHEEL**  
**(Fig. 10)**

To remove a rear wheel, perform the following operations:

- Check the front wheels.
- Tighten the right hub nuts.
- Raise the rear of the tractor with an auxiliary jack.
- Secure the wheel with the aid of a block, which is fit and brake concerning the right side.
- Remove the wheel, taking care not to damage the threads of the bolts.

To install the rear wheel, carry out the above operations in reverse order, checking steel clearances. Apply grease to the bolts before screwing on the nuts. Tighten the nuts in alternate order to a torque setting of 22 to 28 ft-lb.

**NOTE:** Do not forget to re-adjust the brake after the wheel has been operating for a few hours.



Fig. 10 - Rear wheel

## REAR TREAD

The wheel tread can be changed in increments of 100 mm., owing to the fact that the wheel disc is offset in relation to the differential shaft pipe and can be reversed in conjunction with the wheel rim, which also has offset spacers. In this way, treads can be obtained as:

Model 300 with 12 x 20 wheels: treads of 1.11 to 1.89 m by means of eight different discs and rim positions (Fig. 11).

Model 400 with 12 x 20 wheels: treads of 1.20 to 1.89 m by means of eight different discs and rim positions (Fig. 12).

NOTE: The correct setting of the disc to rim spacer sets is 6.2 to 7.4 kg/cm<sup>2</sup>.




Fig. 11 - Rear wheel treads Model 300




Fig. 12 - Rear wheel treads Model 400

## TIRES

### TO REMOVE A REAR WHEEL TIRE

To remove a rear wheel tire, proceed as follows:

- Place the wheel in position with the convex side towards the ground (fig. 13).
- Deflate the tire by taking out the inside of the valve (fig. 13).
- Loosen the heel from the rim flange and force it so that it slides and becomes lodged in the rim channel on the opposite side from the valve (fig. 14).
- Insert two tire irons at a distance of some 30 to 40 cm from each other; press one of these down towards the the inside of the rim and with the other, begin the operation of removing the heel (fig. 15).



Fig. 13 — Taking out valve internals



Fig. 14 — Loosening heel from rim flange



Fig. 15 — Removing first heel

- Raise the heel of the casing on the valve side and take out the inner tube, pulling it carefully to avoid tearing (fig. 16).
- Having taken out the tube, lift up the case together with the rim; insert a tire iron as far as the

inner rim flange, forcing so as to make the heel pass over the flange. Continue the operation with second tire iron until the case is completely clear (fig. 17).




Fig. 16 - Taking out inner tube




Fig. 17 - Removing second heel

#### TO INSTALL A REAR WHEEL TIRE

To install a rear wheel tire, proceed as follows:

- Set the cover, slightly inclined, over the rim, setting the tread rotation in the right direction and with the valve correctly placed. Hold the tire cover with the foot and right hand, at the same time pushing with the left hand so that the first heel enters the rim channel. Continue the operation with a tire iron until the heel is totally installed.
- Slightly inflate the inner tube and place it on the tire case. Lift the heel and insert the inner tube, pulling the valve out through the hole in the rim (fig. 19).



Fig. 18 - Installing first heel

- With the aid of two tire irons begin to install the second heel on the side opposite the valve (fig. 20).



Fig. 19 - Inserting inner tube



Fig. 20 - Installing second heel

- Once part of the second heel has been fitted, continue the operation with one tire iron while exerting pressure on the tire case with the feet until the heel is completely installed (fig. 21).

**NOTE:** After the tires have been mounted on the rims, inflate them to a pressure of 2.5 kg/cm<sup>2</sup> so as to seat the casing heels perfectly on the rims. Then deflate the tires completely to allow the inner tube to adopt its normal position and re-inflate to the recommended working pressure.



Fig. 21 - Complete installation of second heel

**TROUBLE SHOOTING TABLE**

Trouble	Possible Cause	Solution
Wheelslip or spinning.	Too low gear selected.	Use highest gear possible in which tractor can work without being forced.
Wheelslip due to load of the tires on ground.	Overinflation.	Adjust pressure to recommended minimum.
	Underinflation.	Increase pressure to correct value according to load or wheels.
	Insufficient weight on front of tractor.	Attach front and front wheel counterweights.
Lateral oscillation of tractor when working on hard soil or road.	Buckling of tire through insufficient pressure.	Increase pressure. This effect can cause damage to tire sidewalls.
Uneven tread wear when the tractor is used a lot on the road.	a) Insufficient pressure. b) Overload.	Increase pressure. This is observed by wear on tread bar edges.




Trouble	Possible Cause	Solution
<p>Uneven wear of pattern</p>	<p>Overinflation.</p> <p>Wheels off-center.</p>	<p>Adjust pressure to recommended value. Observed by wear limited to the center of the pattern bars.</p> <p>a) Jack up wheels, loosen and retighten wheel nuts.</p> <p>b) Check correct position of tire rim.</p>
<p>Sliding of tire on rim.</p>	<p>Underinflation.</p>	<p>a) Increase pressure.</p> <p>b) Check rim and seat position; replace if necessary.</p>
<p>Slit tire sidewall.</p>	<p>Underinflated tire collided with sharp object.</p>	<p>Small slits may be repaired. Very large slits require tire replacement.</p>

## SECTION 13:

# ELECTRICAL EQUIPMENT AND INSTRUMENTS

### CONTENTS

	Page
Description	1
<b>REMOVAL AND INSTALLATION OF THE SYSTEM COMPONENTS</b>	<b>3</b>
Headlights	5
Bulbs	7
Fuses	10
<b>DESCRIPTION AND CHECK OF THE DIFFERENT ELECTRICAL SYSTEM INSTRUMENTS</b>	<b>11</b>
<b>BATTERY CHARGE SYSTEM</b>	
Battery	
Specifications	17
Battery care, cleaning and maintenance rules	18
<b>ALTERNATOR</b>	
Specifications	22
Description	25
Disassembly of the alternator and check of its components	30
Assembly of the alternator	37
<b>REGULATOR</b>	
Specifications	39
Description	40
Trouble shooting	41
Trouble shooting tables	42-44
<b>START SYSTEM</b>	
Starter	
Specifications	45
Description	47
Bench tests	47
Test value trouble shooting chart	48
Trouble shooting causes of abnormal current absorption	49
Trouble shooting causes of incorrect starter operation	49
Disassembling the starter and checking its components	50
Assembly of the starter	55
Lubrication table	58



## DESCRIPTION

The EBRO 350 and 460 tractors have a 12 V. battery with grounded negative and control by voltage compensation regulator. Fig. 1 shows the arrangement of all the components and wiring of the system.

The regulator, horn, battery and headlights are installed in the front part of the tractor in front of the




Fig. 1 — Arrangement of the electrical equipment

radiator. Access can be gained to all these units by removing the tractor's front grille.

The alternator is installed on the right hand side of the engine and is driven by a V-belt that is connected to the crankshaft pulley. The alternator assembly is adjustable to maintain correct belt tension.

The starter is secured in place on the right hand side of the engine by means of three nuts that screws onto the three pins installed on the block.

The electrical facility is protected by eight 8A fuses that are located in a box on the lower left hand side of the fuel tank.

The electrical system has been designed and installed in such a way as to withstand long periods of use with minimal maintenance, but it is still best to keep it clean and check that the battery terminals are correctly tightened.

This section deals with the way in which to remove and install all of the components of the system, and how to check their operation when any trouble is observed. Directions are also provided for disassembling and assembling the starter and alternator according to the relevant manufacturers' instructions.

**Note:** Make sure to disconnect the battery terminals before handling the electrical system.




Fig. 2 - Electric system diagram

## REMOVAL AND INSTALLATION OF THE SYSTEM COMPONENTS

### Instrument Panel

The following instruments are found on the panel:

- a) Temperature gauge.
- b) Fuel level gauge.
- c) Tractometer.
- d) Low oil pressure warning light.
- e) Battery charge control light.
- f) Electric circuit and starter switch (ignition switch).
- g) Light switch (with horn button).
- h) Direction (turn signal) switch.

The instrument panel is secured to the dashboard by six screws. In order to gain access to any of the forementioned instruments, the instrument panel must be removed. To do so, follow the procedure described below:

- Remove the steering wheel with the help of an extractor.
- Remove the throttle lever.
- Loosen the six set screws which secure the panel to the dashboard.




Fig. 3 — Removal of the instrument panel

- Pull the instrument panel upwards and out, disconnect the electrical system sockets and tractometer control wire (fig. 3).

When installing the instrument panel, reverse the foregoing procedure.

### Battery, horn and regulator (fig. 4)

In order to remove the battery, horn or regulator, proceed as follows:

- Remove the front grille of the tractor, thereby gaining access to the forementioned components. Then follow this procedure.

#### a) Battery:

- Disconnect the battery terminals.
- Disconnect the plugs of the head lights.
- Disassemble the lock support of the lights.

- Loosen the nuts of the lock pins and remove the battery.

#### b) Horn:

- Disconnect the battery ground cable.
- Disconnect the horn unit cables.
- Loosen the lock nut and remove the ground cable and horn.

#### c) Regulator:

- Disconnect the ground cable of the battery.

- Disconnect the plug of the regulator unit.
- Loosen the two set screws and remove the regulator (be careful when loosening the right hand screw since it also secures the horn).




Fig. 4 - Removal of battery horn and regulator

When re-installing these components, just reverse the foregoing removal procedures.




Fig. 5 - Removal of alternator

#### Alternator (fig. 5)

In order to remove the alternator, carry out the following procedure:

- Disconnect the battery ground cable.
- Disconnect the plug and cable of the alternator unit.
- Loosen the adjustment arm screw.
- Rock the alternator toward the block and remove the belt.

- Loosen the screw that secures the alternator to the attachment support and remove the screw and the alternator.

When re-installing the alternator, reverse the foregoing procedure.

Note: The deflection of the drive belt is approximately 10 mm.

#### Starter (fig. 6)

In order to remove the starter, proceed as follows:

- Disconnect the battery ground cable.
- Disconnect the positive cable between the starter and the battery.

- Disconnect the starter unit wiring.
- Remove the lock nuts and take out the starter.

When re-installing the starter, just reverse the foregoing procedure.






Fig. 6 - Removal of starter




Fig. 7 - Headlights

### Headlights (fig. 7)

The headlights are assembled on the lock support (A) by means of the screws (B, C and D), which also serve to adjust the lights.

These lights are composed of a bulb holder (E), a bulb (F), dustguard (G), reflector and lens. The lights are of the half-sealed type, that is, the lens and the reflector form a unit called the optical assembly (H). The terminals of the electrical wiring are located in a plug (I), which only allows one connection position for the bulb holder. When removing a front light, carry out the following procedure:

- Remove the front grille.
- Separate the bulb holder from the plug in the space found between the lock support and the radiator.
- Push the dustguard rearwards.
- Release the two elastic clamps connected to the reflector which secure the bulb holder, and remove the bulb holder together with the bulb.
- Loosen the three set screws, procuring not to lose the compression springs that are mounted on them. Next remove the optical assembly.

Just as can be seen from the description of the foregoing procedure, it is not necessary to disassemble the head light assembly in order to replace a bulb.

When re-installing the head light, simply reverse the foregoing removal procedure.

Once the head light has been re-installed, it should be adjusted as follows: (fig. 8).

- a) Place the tractor at a right angle and a distance of 80 cm. from a wall or screen.
- b) Draw a vertical line (1) on the wall or screen, which should concur with the axis of symmetry of the tractor.
- c) Draw a horizontal line (2) through the vertical line (1) at the height of the center of the lights (4).
- d) Mark two points (3) on the horizontal line which shall be equidistant from the vertical line (1). The distance between the two shall be equal to the distance between the centers of the lights.
- e) Check one light while covering the other so that the point (3) that is marked on the wall is in the center of the beam of light.

- f) Adjust the position of the light as required, using the forementioned adjustment screws to do so.
- g) Check and adjust the other light in the same way.

The vertical focus adjustment, that is, the raising or lowering of the beam of light, is carried out by means of the screws C and C (fig. 7). For horizontal adjustment, that is, in order to regulate the direction of the beam of light towards one side or the other, tighten or loosen screws B and D as required (fig. 7).




Fig. 8 — Head light focusing

#### Parking and Direction (Turn Signal) Light Assembly (fig. 9)

This light assembly is mounted on the fenders and equipped with two lights, namely: the direction (turn signal) light and the parking light. They are easily accessible by removing the screws that secure the lens. In order to remove a front assembly, proceed as follows:

- Loosen the two lock nuts which are located on the inside of the fender.
- Take out the assembly far enough to be able to disconnect the two terminals that are connected to the lights.

When re-installing this front turn-parking light assembly, just reverse the foregoing removal procedure.




Fig. 9 — Removal of a front turn-parking light assembly



Rear light assembly comprising parking, brake, direction (turn signal) and license lights (fig. 10).

This light assembly is mounted on the rear part of the fenders and has a double divider component that separates it into two compartments. One compartment is for the direction (turn signal) light while the other one contains the brake and parking lights. The left rear light assembly, which can be seen in the picture, also has a transparent white plate through which the parking light shines in order to illuminate the license plate.

When removing the rear light assembly, proceed as follows:

- Loosen the two lock nuts that are located on the inside of the fender.
- Remove the light assembly far enough to be able to disconnect the three terminals that are connected to the lights.

When re-installing the rear light assemblies, simply reverse the foregoing removal procedure.

#### BULBS

The following table shows the characteristics (part number, quantity, location and power consumption) of the bulbs that are used in the electrical system.

Part Nr.	Quantity	Description	Watts
205-E-13007-A	2	Front light bulb. EUROPEAN type. Twin-filament:	45/40
1.830.243-M1	4	Parking light bulb. Vacuum, «Plafoniers» base.	7
1.830.244-M1	4	Direction (Turn Signal) bulb. Gas. «Plafoniers» base.	18
1.830.244-M1	2	Brake light bulb. Gas, «Plafoniers» base.	18
969.616-M1	2	Dashboard illumination bulb.	2
SP-13466	1	Working light bulb. Single filament, Bosch base, pear shaped.	35




Fig. 10 — Removal of a rear light assembly

**Main electrical facility**

In order to disassemble the main electrical facility, proceed as follows:

- Remove the front grille.

**Disconnect:**


- The battery.
- The front light unit plugs.
- The two horn wires and the ground cable.
- The regulator unit plug.

Once the front connections have been disconnected, the front cowling must be partially removed (and subsequently, the hood as well) before proceeding to disassemble the rear electrical system.

- The alternator unit plug and the ground cable (right-hand side).

- The two starter cables (right-hand side) and the ground cable.
- The cold weather heat cable (right-hand side).
- The thermistor wire (left-hand side).
- The mono-contact wire (left side).
- The fuse terminals (left side).
- The rear light unit plug.
- Remove the instrument panel in order to disconnect the two plugs of the panel's instrument assembly.
- Remove the facility.

**Note:** Remove the elastic clamps as the wires and plugs are disconnected. When assembling the main facility, just reverse the foregoing disassembly procedure.



### Rear light facility

In order to disassemble the rear light facility, proceed as follows:

Disconnect the following:

- The plug connecting the main facility to the rear lights facility (behind the fuse box).
- The rear light facility wires connected to the fuse box (left side).
- The wiring between the facility and the stop switch (beneath the left-hand step plate).

- The wiring in the connection box (left side).
- The wiring of the rear lights, disassembling the light assemblies.
- Disassemble the elastic clamps and remove the wires together with their casings.

In order to reassemble the rear light facility, just reverse the foregoing procedure.




Fig. 12 - Rear light facility

## Fuses

The fuse box is located on the lower left-hand side of the fuel tank. In order to gain access to the fuses, remove the cover of the box by taking out the set screw which secures it.

The fuses may be easily replaced by simply removing them from their supports. Check that both the sup-

port and the new fuse to be installed have clean contacts and that the fuse is of the same capacity.

In the event that, after replacement, a new fuse should burn out immediately, do not replace it with any object that allows a greater current capacity to pass than the one specified for the fuse, since this would result in an overload and endanger the facility.




Fig. 13 - Fuse box

### Identification of fuses (fig. 13)

- A - Direction (turn signal) lights
- B - Horn
- C - Brake lights
- D - Parking lights
- E - Low beams
- F - Reserved
- G - High beams
- H - Reserved

### Electrical circuit and starter switch (ignition switch)

This switch, which is actuated by the ignition key, is located on the lower right-hand side of the instrument panel. Its operation is as follows: (fi. 14).

- When the key is in position (A), the electrical circuit is disconnected.
- When the key is turned to the right to point (B), the circuit is connected.
- When the key is turned further to the right, to point (C), the cold weather starting heater device is connected.
- When the key is moved still further to the right, to point (D), the starter is actuated.

In position (C) or (D), the ignition key will be returned to point (A) unless held in place by hand, thanks to a spring mechanism. The key must be held in the «connected heater» position for cold weather starting for a period of 15-20 seconds in order for this device to operate correctly. Once this time is up, the key should be turned to point (D) against the spring resistance in order to actuate the starter.

The starter stops operating as soon as the key is released. The key then returns to the initial «connected circuit» position by spring action.

Under normal weather conditions, the starter should be actuated without stopping the key at point (C), that is there should be a continuous movement of the key from point (B) to point (D).

When the operation of the switch is rough or defective, check it according to the following procedure:

- Remove the switch from the instrument panel.
- Connect the positive terminal of a battery to the BAT terminal of the switch.
- Place three high-Wattage lamps in series, connecting them to each other with the ground terminal.




Fig. 14 — Ignition key positions




Fig. 15 — Ignition switch check

- Connect the negative terminal of the battery to the ground of the lamps.
- Connect each of the lamps to the terminals of the switch: START, PREHEAT and ACT respectively.

According to the three positions of the key in the switch, the circuit of each lamp should be connected. If the switch does not operate correctly, replace it with a new one without handling the one that is removed (in the event a claim is to be filed). If on the other hand, the switch operates correctly, search for the cause of the trouble in some other point.



### Light Switch

This switch is located in the lower right-hand side of the instrument panel and has the following four positions: (fig. 16).

- Pointer in a vertical position (B): lights off.
- Pointer to the right in position (D): parking lights and low beams.
- Pointer to the right in position (E): parking lights and high beams.
- Pointer to the left in position (A): parking lights.

The horn button (C) is located in the center of the light switch. The horn is actuated when this button is depressed.

When the switch does not operate correctly, check it according to the following procedure:

- Remove the switch from the instrument panel.
- Connect the positive terminal of a battery to the positive terminal of the switch.




Fig. 16 — Light switch positions

- Place three high-wattage lamps in series, connecting them to each other with the ground terminal.
- Connect the negative terminal of the battery to the ground of the lamps.
- Connect each of the lamps to terminals 56A, 56B and 58 of the switch, respectively.

### Direction (Turn Signal) light switch

This switch is located in the lower left-hand part of the instrument panel, and has the following three positions:

- Pointer to the right: right direction indicator (turn signal) lights.
- Pointer to the left: left direction indicator (turn signal) lights.
- Pointer in the center: direction (turn signal) lights off.

The three positions of the switch pointer connect each of the three lamp circuits, respectively.

In order to check the operation of the horn button, proceed as follows:

- Disconnect all the wiring of the switch.

- Connect the positive terminal of the battery to terminal 30 of the switch.
- Place a wire between one of the lamps and terminal 85 of the switch.

The circuit should be connected when the horn button is depressed.

In order to check the correct operation of this switch, proceed as follows:

- Connect the positive terminal of the battery to the positive terminal of the switch.
- Place two wires between the lamps in series and terminals 58 and 58 of the switch.

The respective circuit should be connected when the switch pointer is set in each position.

### Tractometer

This is a combined instrument which comprises a tachometer (rpm-counter), a speedometer and an operation-hour counter (fig. 17).

The four calibrated scales (A) on the lower part of the dial indicate tractor speed in km/hr on long runs.

The upper scale (B) indicates the rpm of the engine in hundred revolutions per minute.

The windows (C) in the middle of the dial show the total operation time in units equivalent to operation-hours at 90,000 rpm, which represents an average rating of 1,500 rpm.

If the engine is operated at over 1,500 rpm, the instrument tabulates a higher number of hours than the real time, and a lesser number in the case of operation below that rating. This value indicates the real work of the engine and is very useful in determining when to carry out maintenance operations.

When the operation of the tractometer is defective, check the following fluctuations, return or seizing of the needle and the rpm and operation-hour counter with a comparative test bench clock. To do so, proceed as follows:

- Set up a connection with the corresponding wire of the model on a test bench.

When carrying out these bench tests, remember that the tractometer has a gear ratio of 2:1, for which it will indicate twice as many revolutions as the bench engine.

- Check the fluctuations or seizing of the needle.
- Allow the needle to rise slowly up to 800 rpm, stabilize it for a few seconds, and then allow it to rise progressively to 2,000 and 2,400 rpm, respectively.
- Stabilize the needle at 1,500 rpm in order to check the operation-hour counter. Every 6 minutes the red roll gauge of the hour counter should mark a fraction until one hour is reached.

In the event in which there is no test bench available, the foregoing checks may be carried out in the following way:




Fig. 17 - Tractometer



Fig. 18 - Checking tractometer rpm

- Connect the tractometer on the outside with a new wire in the housing located in the upper rear

part of the cylinder block, and then carry out the engine speed tests.

If the fluctuations of the needle are quick and the same as those of the wire, the trouble is located in the wire itself or its casing.

### Fuel level gauge

This gauge (fig. 19) is located in the upper right-hand part of the instrument panel and indicates the fuel tank level. The slope of the green scale (A) which runs from upper right to lower left, marks the progressive drop in the fuel level from full to empty.

This instrument is made up of two components: the gauge on the instrument panel and the float in the fuel tank. The gauge is connected to the electric circuit and only operates when the circuit is connected.

If the gauge stops recording the fuel level or does so incorrectly, examine all of the relevant wiring connections to make sure that they are tight and clean.

- Connect a wire from the positive terminal of the battery to the red terminal of the gauge.
- Connect the negative terminal of the battery to one of the two ground terminals of the gauge.
- Make a bridge between the other ground terminal of the gauge and the ground terminal of the float.




Fig. 19 — Fuel level gauge

- Make another bridge between the blue terminal of the gauge and the «Faston» terminal of the float.

### Temperature gauge

This instrument (Fig. 20) indicates the cooling water temperature at the engine outlet.

When the engine reaches operating temperature after running for a few minutes, the needle should move into the green area (B) of the scale. The red area (C) indicates engine overheating.

If the fluctuations of the needle are intermittent or uneven, the trouble is located in the instrument.

Actuate the float arm all along its travel, observing the gauge to see if it is recording this change correctly. If not, carry out the following test:

- Disconnect the wire that goes to the «Faston» terminal of the float and make contact with the float ground with the tip of this wire.






Fig. 20 — Temperature gauge

The needle of the gauge should indicate the maximum when this contact is made. If not, the trouble is in the float. Do not attempt to repair these components, for they can only be replaced.

The white area (A) means that the engine is cold.

This instrument is made up of two components: the gauge on the instrument panel and the thermistor, which is located in the upper front part of the cylinder head.

The gauge is composed of two interconnected coils, one with fixed resistance and the other with variable resistance.

The current that comes from the battery through the ignition switch is divided between the two coils (the fixed one and the one with the variable resistance addition of the thermistor), to which it is connected. The needle of the gauge is connected to a revolving armature that responds to a fixed magnetic field and a variable one. In this case the gauge is calculated so that the needle indicates five different points between Cold, Normal and Danger, according to be real temperature of the coolant liquid in the front part of the cylinder head. If the gauge does not operate correctly, examine the connections and wiring. If it continues to operate incorrectly after carrying out this inspection, perform a practical test on the gauge and thermistor. To do so, proceed as follows:

- Remove the gauge and the thermistor.



Fig. 21 — Checking the temperature gauge

- Heat a receptacle with liquid glycerin or some other liquid with a boiling point that is higher than that of the water (fig. 21).
- Place a thermometer with capacity for indicating over 100° C in the receptacle.
- Connect the positive terminal of the battery to the positive (red) terminal of the gauge.
- Connect the thermistor terminal to the blue terminal of the indicator.
- Place the thermistor in the receptacle.
- Connect two ground wires, one to the receptacle and the other to the gauge.

When placed in the receptacle that is being heated, the gauge should begin to move out of the white area between 65° and 70° C and enter the red area at the temperature of 100° C. A tolerance of 1/4 needle should be taken into account.

Check of the ohmic value with a tester:

From 65° to 70° C equal to 470 and at 100° C equal to 145 in approximate terms. These tests are to be carried out at 13 to 13.5 V.

### Stop switch

The rear light assemblies of the tractor are equipped with a brake light which acts in conjunction with the brake pedals. In order to assure their actuation, a spring-equipped stop switch has been installed.

One side of this switch is secured beneath the left

step plate, while the other side, where the spring is found, is attached to the left brake control rod.

When the brake pedals are depressed, the left brake control rod stretches the spring, which connects the switch circuit, turning on the brake lights.

### Low oil pressure warning light

This red light is located in the middle left part of the instrument panel and under normal operating conditions it lights up when the ignition key is turned on to start the engine. Once the engine has started, the light should go out and stay out while the engine is in operation.

Engine lubrication is correct as long as this light does not go on.

If the ignition key is turned without starting the engine, and yet the warning light does not come on, the bulb is burnt out, loose or has a disconnected wire. Change or tighten the bulb and inspect the wire.

If the warning light comes on while the engine is in

operation, quickly turn off the engine. Check the oil level in the engine, and if it is correct, remove the pressure switch that is installed in the left-hand side of the cylinder block. Start up the engine and if the switch does not flow, it may be due to one of the following causes.

- Break-down of the shaft or trouble in the oil pump.
- Loose or obstructed suction pipe.
- Obstruction in the suction strainer, oil filter or lubrication ducts.

If there is an abundant flow of oil, the pressure switch is damaged and requires replacement.

### Battery charge control light

This is a red light that is located in the right central part of the instrument panel and turns on when the electrical circuit is connected. The light goes out once the alternator begins to charge, that is shortly after the engine exceeds idling speed.

If the two lights do not go on at the same time when the tractor is braked, check the operation of the switch in the following way:

- Inspect the relevant fuse and determine whether there is a correct supply of current.

- Make a bridge between the two terminals of the switch.


If the switch is operating normally, the lights should go on. If not, replace the switch. Check the condition of the spring before carrying out the replacement.

If the light does not go out, this means that the battery is not receiving any charge, in which case the causes of the trouble should be sought in the alternator or regulator.

BATTERY CHARGE SYSTEM

BATTERY

Specifications



CAPACITE  
 IN 10 HR. = 112 Ah.  
 IN 20 HR. = 125 Ah.




Fig. Fig. 22 - Battery characteristics diagram

### Battery care, cleaning and maintenance rules

The following instructions are some practical and easy-to-follow advices for always giving the battery adequate care.

Considering the important functions which the bat-

#### Always keep the battery clean

Dirt, regardless of its origin, together with moisture go to form conductive sludges that discharge the battery and corrode the metal parts in contact with them.

When installing a battery in the tractor, dry it com-

#### Battery placement

Check that the battery is well secured on its support to prevent it from moving while the tractor is in operation. This is necessary in order to avoid any possible breakage of the receptacle and to prevent

#### Connect with the right polarity

When installing the battery, be careful to make a good connection or coupling between the positive (+) and negative (-) poles and the positive and negative poles of the facility. First connect the current pole (insulated wire) with the terminal, and then the ground wire (bare wire). Whenever it is necessary to remove the battery, proceed in reverse order in relation to the terminal removal process. This precaution prevents a mistake from causing a short-circuit.

A battery that is connected with the opposite polarity deteriorates quickly and irreversibly.

The life of the battery is greatly influenced by its correct installation and the care that is given to it. By following the advice and instructions presented on these pages, you will obtain a high yield from the battery in terms of both service and long life. This will be the benefit obtained from the small cares given to the battery and negligence in this maintenance will only be to the detriment of the unit.

tery has in the different components of the electrical system (start, horn, lighting, etc.), it is of prime importance to always keep it in the best possible service conditions and assure that it will have a long life.

pletely first; this is especially important with regard to the positive and negative terminals. Clean these wire terminals periodically, scraping them with a file to remove the solid crust formed by corrosion.

any false contacts from coming about and impeding the normal flow of electrical current due to loose installation.

Clean the top of the battery, removing the dust that has accumulated there and then drying the covers well if they should be soaked with fluid.

The plugs of the battery elements should always have clean breather holes to assure gas outlet. An obstruction due to dirtiness may even be so harmful as to cause an explosion that would break open the cover and the receptacle of one or more elements.

When tools are to be used over the battery, protect its top with a sheet of rubber or foam rubber which should only be removed after the job is finished.

When two batteries are installed and connected in series or in parallel, both of them must be exactly the same in terms of voltage and capacity. The wires used to join the poles of the two batteries must also be of exactly the same cross-section.

The clamps or terminals of the wires must be adjusted on the corresponding terminals of the battery



and well tightened to avoid false contacts. All these components should have clean contact surfaces, for which it is advisable to have the terminals and inside cone of the terminals scraped with sandpaper or a file. The clamps should be well covered with a layer of petroleum jelly in order to prevent their corrosion

#### Periodically fill with distilled water

The battery loses water, but no acid, by evaporation, decomposition and while charging. For this reason the water that is used up must be restored, more or less frequently according to the work of the battery and the temperature of the season (summer or winter). The fluid level of the battery must be checked at least once a month although, as a general rule, refills should be carried out whenever necessary in order to prevent the plates from being left exposed, which would quickly make the battery useless.

The abnormal drop in fluid level in one or more of the battery elements which makes it necessary to refill it unusually often, above all after using the tractor at full output, calls for a careful inspection. If there are no recent signs of corrosion or moisture on the support, the receptacle is probably not broken, for which the cause of this abnormal evaporation should be sought in the charge circuit.

The high charge rate of a maladjusted regulator is the most frequent cause of this problem. In such a case, quickly carry out the required adjustment of the regulator to prevent the battery from becoming useless in a short time.

It is indispensable that the fluid level in each element cover the upper edge of the separators by about 10 mm. When filling, only use distilled or deionized water. Rain water is not suitable and should not be used to fill the battery. Periodic filling with electrolyte (sulfuric acid solution) leads to excessive sulfation of the plates and their early destruction. A common mistake is to think that low acid density is corrected and improved by refilling with acid. Low acid density in a battery in service is a symptom of discharge, for which the best remedy is to charge the battery correctly in order to raise this density.

The ground wire should be well tightened on the end that makes contact with the tractor chassis. Loose

which would subsequently lead to a reduction in battery yield due to the hindering of electric current supply. The wires must be of sufficiently large cross-section and be suitably flexible and long in order to avoid a tension or stress that might break the terminals of the battery.

contacts impede the passage of current. This defect may be detected in light fluctuations and starting trouble.

Only in the case in which the battery is tipped over or something else happens to cause a loss of electrolyte, should a densimeter be used to measure the concentration of the fluid remaining in each well of the battery. Then prepare a solution of acid and distilled water, slowly adding the acid to the water (NEVER ADD WATER TO ACID), of the same density and use it to fill the wells, replacing the lost fluid. Under no other circumstances should the electrolyte concentration in the wells be changed, since if more acid were to be added, not only would the plates be damaged, but the readings of the densimeter would become incorrect and this means of determining the charge condition of the battery would no longer be valid.

Distilled water refills can be made at any time in the summer. This is not the case, however, in winter, since in that season of the year the battery should preferably be refilled while the tractor is in service. If winter filling is carried out while the tractor is closed up in very cold buildings or outside with only partial shelter, there is a dangerous possibility of the water freezing and bursting the battery receptacle before it has the time to mix completely with the acid.

Never use solid or liquid products (more or less «miracle-working» additives) which are purposed to have virtues and plate-regeneration or battery capacity increase properties. The only sure thing is that distilled water is not harmful and the most practical procedure is to refill the battery correctly and on time to prevent abnormal sulfating.

The fluid level can be measured with a piece of glass tubing. Insert the tube until it touches the separators, then cover the outside end with your finger and take the tube out to check.

### Check the density

Check the acid density of the battery at least once a month. It should be within a range of  $1.28 \pm 0.01$  at an ambient temperature of approximately  $25^{\circ}\text{C}$ . A density that exceeds the maximum specified value, in the case in which the electrolyte level in the wells is correct, may be due to the previous addition of acid on some occasion instead of distilled water. In order to correct the density, charge up the battery and then empty the fluid from the wells. After that, fill the wells with electrolyte having the correct density.

High density may also be due to systematic overloading caused by poor adjustment of the regulator. The electrolyte level is usually low in such cases.

Density values that are repeatedly below 1.28 may be due to the addition of water in the wake of a loss of acid in the wells. It may also be due to a systematic charge deficiency caused by using the tractor only at low rpm or because of regulator misadjustments.

The results of density checks will be inaccurate if the check is carried out immediately after filling the battery with distilled water. The water must first be allowed to mix with the acid, for which the battery should be subjected to a charge period lasting approximately two hours.

The density of each of the elements of a battery are not often identical, even when it is in perfect condition. Small differences are not important as long as they do not exceed 0.01. For example, densities of 1.275, 1.280 and 1.285 are considered to be normal were they to be found at the same time in three different cells of the battery, since the differences lie within the tolerable limits.

### Charge the battery correctly

The alternator should charge only as much as necessary to compensate discharge. Overloads are as harmful to the battery as excessive discharges.

The ideal alternator charge rate is the one that normally allows the electrolyte density to remain within the limits of  $1.28 \pm 0.01$  at an ambient temperature of approximately  $25^{\circ}\text{C}$ . Given the great importance of balancing the battery charge and discharge according to the service of each tractor, give maximum



Fig. 22 b — Checking the electrolyte density

The acid density lowers in proportion to battery discharge. With densities of 1.12 to 1.15 s.p., the battery is considered to be completely discharged. This situation whose causes are explained in the following section, must be avoided. Check to see if the alternator and the regulator are operating correctly in case they do not maintain an adequate charge rate.

If the battery is completely discharged during the cold season, there is a danger of the electrolyte freezing and bursting the receptacle.

attention to correcting, when necessary, the charge rate of the alternator and to adjusting the regulator.

In any case, if the charge rate of the alternator, because of some irregular service, does not compensate the power consumed by the starter, headlights, horn, etc., it will be necessary to charge the battery outside of the tractor, as long as the electrolyte density is less than 1.18 s.p. and before it drops to the limit of 1.12 s.p. which is the point of total discharge.

Overloading should be checked when the electrolyte density is habitually over  $1.28 \pm 0.01$  and there is excessive fluid evaporation, making it necessary to keep up the level with unusually frequent refills of distilled water.

The foregoing care is especially important if the trac-

tor is operated only a few days each month, carrying out short jobs with frequent stops.

If the battery is not given supplementary charges outside of or disconnected from the tractor, it will become totally discharged and ruined in a short time.

### Winter care

At colder times and places in winter, tractors increase their current consumption. On one hand, the engine requires more power for starting because of the higher resistance entailed by the increased density of the engine and gearbox oil. This increased

current consumption is also brought about by the headlights, which need to be on for longer periods of time because of the reduction in the number of hours of light per day.

### Store the battery when not in use

If the tractor is not to be used for two or three months, the battery must be stored away. If it is simply left unattended, it will deteriorate until it is ruined. This is because the battery loses capacity by self-discharge which constitutes a progressive loss that is more pronounced the greater the duration of the period of idleness. This self-discharge leads to the abnormal sulfating of the plates, bringing about their destruction.

Just as has been previously mentioned, this problem can be solved by carrying out an inspection on the electrical equipment. The opposite case, that is when an increase in the charge rate is called for, denotes low electrolyte density, which is always below  $1.28 \pm 0.01$ .

Do not habitually resort to the so-called «quick-charging» apparatus or procedures since they are always harmful for the battery. The more often this charge system is used, the quicker the battery will be ruined.

On the other hand, since the capacity of the battery is reduced at low temperatures, it is much more difficult for the alternator to produce enough current to keep it charged, since the tractor jobs are usually shorter than during other seasons of the year. For these reasons, the battery must be more carefully checked in the winter and charged outside the tractor as often as necessary to keep it in perfect condition.

The remedy for these drawbacks lies in periodically charging the battery. It should be charged at least once a month with the normal rating, and always previously filled with distilled water, if necessary. The duration of these charges will vary, depending on the charge condition of the battery and will generally fluctuate between 4 and 12 hours. The charge should not be concluded until the electrolyte density reaches  $1.28 \pm 0.01$ .

**ALTERNATOR****Specifications**

Type of alternator	G1 (R) BOSCH
Rated voltage	14 V.
Maximum current	28 A.
Polarity	Negative ground.
Rectification	By 6 diodes.
Power tests	
Maximum charge current	10 A. from 1,500 rpm 18 A. from 2,200 rpm 28 A. from 7,000 rpm
Resistance values (short circuit tests between loops)	
Stator	0.4 + 10% (between phase outlets).
Rotor	4.0 + 10%.
Test voltages (short circuit to ground)	
Stator	40 V (approx.).
Rotor	40 V. (approx.).
Friction rings	
Setting	3.7 ± 0.1 mm.
Outside machining length	20 mm.
Maximum eccentricity	0.03 mm.
Minimum diameter	26.8 mm.
Brushes	
Maximum length	10 mm.
Minimum length	5 mm.
Torque values	
Cylindrical head screws	35 — 55 kg. cm.
Pulley lock nut	3.5 — 4.5 kg. m.
Bearing lubricant	
Molykote grease	Type Ft 70 v. 1.







Fig. 23 - Exploded view of alternator

- |                                           |                                 |
|-------------------------------------------|---------------------------------|
| 1 - Stator                                | 18 - Lock clamp                 |
| 2 - 19 mm. long screw                     | 19 - 4 mm. dia. pressure washer |
| 3 - Pulley side bearing                   | 20 - Hexagonal nut              |
| 4 - 3.3 mm. dia. fan washer               | 21 - Lockwasher                 |
| 5 - 5 mm. dia. lockwasher                 | 22 - Pulley side bearing        |
| 6 - Screw (ground terminal)               | 23 - Bearing cover              |
| 7 - Washer                                | 24 - Bearing cover lockwasher   |
| 8 - Fan                                   | 25 - Bearing cover screw        |
| 9 - Positive terminal components assembly | 26 - Woodruff key, fan-pulley   |
| 10 - Complete diode assembly plate        | 27 - Rotor                      |
| 11 - Commutator side cover                | 28 - Commutator                 |
| 12 - Brush holder assembly                | 29 - Elastic ring               |
| 13 - Brushes                              | 30 - Commutator side bearing    |
| 14 - Compression spring                   | 31 - Lockwasher                 |
| 15 - Nut washer                           | 32 - Fan pulley lock nut        |
| 16 - 4 mm. dia lockwasher                 | 33 - Spacer                     |
| 17 - M x 18 screw                         |                                 |

### General

The alternator comprises the following components:

- Two supports housing the rotor shaft by means of bearings. The stator is located between these two supports. One of these supports locates the brush holders which ensure the electrical connection to the induction coil or to the stator. It also houses the hexa-diodes and the alternator terminals.

The other end support lets the rotor shaft through to fit the drive pulley.

- The stator is made up of a series of steel plates cut into circular crown shape. Slots in the crown inner diameter house the stator coils.
- The spring inducer or rotor is made up of a single coil fitted between the two commutators. The coil is fed through the slip rings and the coil ends are soldered to them. All components are mounted on one shaft thus built into a rugged unit to overcome the centrifugal force.

### Operation

The rotor coil is fed through the brushes and slip rings so producing a magnetic field within the rotor. Due to the lay out of commutators the rotor break-in device presents a series of North and South poles.

When the alternator is in operation the rotor faces these magnetic poles against the stator teeth thus creating induced alternate current.

The current generated is of the three-phase type due to the lay out and connections of the inducers.

The alternator is self-fed, that is to say that the inducer coil uses part of the current generated.

The tractor contact key switches off the battery-inducer coil circuit through the regulator which means that the alternator will start to generate current just as the engine has started.

### Operation of the rectifier assembly

The rectifier assembly is basically made up of silicon diodes. These components offer a high resistance to the passage of current in one direction while no resistance is opposed when the current flows in the opposite direction.

Its operation can be compared to a valve which opens when the flow goes in one direction but blocks the passage in the opposite direction.

The diodes are classified as listed below as per the diode end tip contacting the metal casing in which it is contained and which holds it onto the rectifier support.

- a) cathode base
- b) anode base

These names also apply to the direction in which the current is let through.

### Rectifier assembly for three-phase alternators

Three-phase alternators are fitted with six diodes to rectify the three phases in «full wave» that is to say that each diode rectifies half a wave, the pair covering the full wave, the negative and the positive halves. This provides a constant flow of current pulses.

Fig. 24 shows the diode connections. Straight line arrows show the path covered by one phase during

the positive half-wave and the dotted line arrows show the path covered during the negative half-wave.

Fig. 25 shows the rectified wave. The continuous line curves show the positive half-waves and the dotted line curves show the negative half waves. The thicker line shows the rectified current waves.




Fig. 24 — Diode connection




Fig. 25 — Three-phase alternator voltage

### Alternator drive system

The drive system used in the alternator is as follows:

By V-belt. To assure the correct drive of the alternator, the use of belts with the following characteris-

tics is indispensable: Neoprene rubber belt with polyester fiber. The maximum deflection of the belt is 10 mm.

### Precautions

In tractors that are equipped with an alternator, a series of precautions must be kept in mind which, if not heeded, may lead to irreparable damage in the alternator or regulator.

- Check the polarity of the battery before connecting it to the tractor. If the terminals of the battery are reversed, the rectified diodes may be damaged.
- In the event in which an auxiliary battery is used to start the tractor, take the precaution of correctly connecting the cables of the auxiliary battery to the terminals of the tractor battery in this: positive terminal to positive terminal and negative terminal to negative terminal.

- When a charger is used, check the correct connection of its terminals to those of the battery. In such cases disconnect the battery from the rest of the tractor circuit.
- Prevent short-circuits from coming about between the diode holder plates or between the positive «Ex» and ground terminals in the alternator.
- The alternator should not be operated without load or with the circuit disconnected. Also avoid disconnecting the battery or regulator while the alternator is turning.

### Periodic maintenance

The alternator does not practically require any periodic maintenance. However, it is advisable to follow certain maintenance rules in order to assure the maximum life of the apparatus.

- The regulator should always be connected to the alternator. Whenever possible, directly connect the positive terminals, and connect the ground of both apparatus in the same way.
- Never supply the alternator directly with battery voltage. If it should prove necessary to do so, first connect a 3 — 4 W bulb with suitable voltage (12 V) in series between the battery terminal and the alternator excitation terminal.
- When removing the alternator, first disconnect the battery.

- Provide means of insulation and never use testers with built-in generator.
- In ground bridging tests, place a resistor in series that limits the current to approximately 0.05 A.
- When spot or arc welding jobs are carried out on the tractor, first disconnect the alternator.
- The charge indicator light found in the tractor should never be short-circuited, even if another control component should be installed.

The maintenance rules and schedule for the alternator are set forth in the relevant chapter of this manual. The maintenance periods mentioned there are merely for illustrative purposes and will actually depend on the service of each tractor.

### Checking operation of alternator mounted on tractor

In order to check the operation of the alternator while it is mounted on the tractor, proceed as follows:

- Check the charge condition of the battery.
- Place voltmeter with an adequate scale between the positive and negative terminals of the alternator. In the case in which there is ground return, place the voltmeter between the insulated terminal and the ground being careful with the polarity.
- Connect an ammeter with an adequate scale in the connection joining the alternator with the battery, and bear in mind the polarity of the metering apparatus.
- Actuate the ignition key without starting the tractor engine. The ammeter needle should indicate discharge. Should it remain stationary on the zero point of the scale, the apparatus is not operating correctly.
- Disconnect all of the tractor's accessories.

### Checking operation of alternator on the test bench

Before carrying out the alternator tests on the test bench, the following precautions should be observed:

- The conductors connecting the alternator and the regulator, or the test bench, must have well-made connections. Do not set up temporary type connections, since the release of a conductor from one of them during the test would lead to voltage peaks in the alternator which could damage the diodes.
- Do not operate the alternator with the battery disconnected. Do not take off the terminal connections of the battery until the alternator has stopped.
- In order to check the diodes, use direct current of 24 V. maximum voltage. Higher voltages than this will damage the diodes.

- Start the engine and let it idle. In the case in which the ammeter should indicate discharge with the engine idling, accelerate a little until the ammeter indicates a charge.
- Slowly raise the engine speed and check that the needle of the voltmeter remains fairly still, indicating the regulator is operating correctly. If it is found that the voltmeter reading increases with the speed of the alternator, immediately stop, since this is a sign that the regulator is operating incorrectly.
- Do not accelerate the engine until the correct operation of the regulator has been checked.
- Stop the engine and discharge the battery a little, turning on the tractor lights for approximately five minutes. Accelerate the engine and check that the alternator is charging the battery. The current supply value should be the one set forth in the relevant specifications.

- The check of the insulation and grounding of the windings with higher voltages may be carried out if the diodes are first disconnected before testing.
- When the alternator is in operation, do not release the battery cable since this might lead to deterioration of the diodes as a result of the voltage peaks that would be produced.

In order to carry out the test bench tests on the alternator, proceed as follows:

- Secure the alternator on the test bench.
- Set up the connections between the alternator and the regulator.

In facilities with «Bendix» plugs, an adequate plug connection must be used.

- Connect the positive cable of the bench battery with terminal B + of the alternator.
- Connect the ammeter for supply to cable «DF» between the alternator and the regulator, being careful that the connection cannot come loose during the testing process.

For pre-excitation, connect a 2.0 W control bulb (charge indicator) between terminal B + (the test bench battery terminal) and terminal D + /61 of the alternator.

#### Power test

- Connect the battery.
- Connect the charge resistor.
- Adjust the rotation speed to the specified value and simultaneously increase the charge until it reaches the value set forth in the specifications, as a minimum.

If the values indicated in the specifications are not attained in the power test, or if the control bulb flashes or lights up, there may possibly be trouble with the alternator, assuming that the connections and the regulator are in perfect conditions.

The alternator trouble can later be determined with the help of a BOSCH alternator tester model AW 192. When doing so, release the drive-side bearing set screws in order to gain access to the commutator points and proceed as indicated in the chapter entitled «Disassembly and Assembly of the Alternator and Check of its Components».




Fig. 28 - Alternator-regulator diagram



### DISASSEMBLY OF THE ALTERNATOR AND CHECK OF ITS COMPONENTS

In order to disassemble the alternator and check its components, proceed as follows:

- Block the pulley with a suitable tool and loosen the lock nut with a star wrench (fig. 27).




Fig. 27 — Disassembly of the pulley

- Mark the position of the stator drive side support and the friction ring side support (fig. 29). These marks should match up when reassembling the apparatus.




Fig. 29 — Marking the parts

Disassemble the brush holder plate, loosening the set screws very carefully (fig. 28).




Fig. 28 — Removal of the brush holder plate

- Loosen the set screws in the drive side support. Carefully remove the stator and the friction ring side support (fig. 30), and the rotor together with the drive side support.




Fig. 30 — Disassembly of the alternator

### Checking the diodes

In order to check the diodes with the help of the BOSCH alternator tester model AW 192, proceed as follows:

- Place the metering selector in the position indica-




Fig. 31 — Checking the mounted diodes

ted in fig. 31. If the diodes are in good condition, the needle will move indistinctly to the left or right within the green area.




Fig. 32 — Separate check of the diodes once the stator winding connections have been unsoldered

### Positive diodes

- Apply the test point to the cooling element of the positive diodes or to the B + plug tab and to the commutator points.

### Negative diodes

- Apply the test points to the cooling element of the negative diodes or else to the friction ring support side and to the commutator points.
- Apply the test points to the contact bar and to the commutator points.

In order to separately check the diodes when they have been disassembled, the stator winding must be unsoldered.

- Release the stator winding connections with a soldering iron as indicated by the arrow in fig. 32.

- Take the precaution of bending the phase outlets as little as possible.

- Then remove the stator from the friction ring support and check the diodes separately after having cleaned them with a suitable liquid.

If any diode is found to be defective when carrying out these tests, the whole diode plate must be replaced.

### Power diodes

- Place the metering selector of the tester in the position that is indicated in Fig. 33 and apply the testing points to the cooling element and to the commutator points.

The needle will indicate the passage direction, moving to the left within the green area. The blocking direction should show a maximum value of 0.8 mA.






Fig. 33 — Checking the passage direction of the power diodes

- When checking the blocking direction of the power diodes, place the metering selector in the position indicated in fig. 34. Apply the testing points to the cooling element and to the commutator points.

The needle should move indistinctly to the left or the right within the green area of the tester.




Fig. 34 — Checking the blocking direction of the power diodes

#### Excitation diodes

- Move the metering selector to the position indica-

ted in fig. 35 and apply the testing points to the contact bar and to the commutator points.

The needle of the tester will indicate the passage direction, moving to the left within the green area.




Fig. 35 — Checking the passage direction in the excitation diodes

- When checking the blocking direction, turn the tester selector to the left until it is located according to fig. 6. Apply the testing points to the contact bars and to the commutator points.

The indicator needle of the tester will move to the left or right, indistinctly, within the green area and its maximum value will be 0.8 mA.




Fig. 36 — Checking the blocking direction of the excitation diodes

- Remove the rotor drive side support using a press with a suitable seat base as indicated in fig. 37.

While carrying out this operation, take the precaution of securing the rotor so that it does not fall and get damaged.




Fig. 37 — Disassembly of the drive side support

- Next remove the ball bearing with a suitable tool as indicated in fig. 38.




Fig. 38 — Removing the ball bearing

- Then remove the friction ring side ball bearing, which is inserted by pressure. To do so, use a press with a suitable base and a tool as indicated in fig. 38.

Any ball bearing that is disassembled must be replaced with a new one.

#### Checking the rotor

Two electrical checks should be carried out on the rotor:

- Ground short-circuit.
- Short-circuit between loops.

- In order to carry out the first mentioned check, install the rotor on an insulated spot on the test bench; take the testing points and place of them on any metal part of the rotor. The other testing point should be placed on the surface of the friction rings (one each time) (fig. 39), while the control bulb connected in series with the testing points is observed.




Fig. 39 — Checking ground short circuit of the rotor

The control bulb should not light up during this check.

A voltage of approximately 40 V. should be applied during this test.

- Use an ohmmeter to carry out the second test. Measure the resistance of the excitation winding in the rotor of interleaved poles, applying the testing points to both friction rings as indicated in fig. 40.




Fig. 40 — Checking short-circuit between rotor loops

The resistance value that should appear in the ohmmeter is  $4.0 + 10\%$ .

#### Checking the stator

The same as with the rotor, two tests should be carried out on the stator: the ground short-circuit one and the short-circuit between loops test.

- In order to control the ground short-circuit, use the testing points with a bulb connected in series, put one of the points on any metal part of the stator, and apply the other point successively to the winding outlet terminals (fig. 41).

The test lamp should not light up during this test. Apply a voltage of approximately 40 V. to the windings.

- For the second test, use an ohmmeter and measure the resistance of the stator windings between the outlets of the three phases (fig. 42).

The resistance value that should appear in the ohmmeter is  $0.4 \text{ ohms} + 10\%$  between phases.




Fig. 41 — Checking stator ground short-circuit




Fig 42 — Checking stator short-circuit between loops

#### Repair or replacement of the friction rings of the alternator

- Secure the rotor on a support with a surface composed of two inclined planes to prevent it from turning. Unweld the two winding ends from the friction ring with a soldering iron, also using needle-nosed pliers to help out with (fig. 43).






Fig. 43 — Applying the soldering iron to the friction ring

- Remove the friction ring from the rotor shaft with the help of a twin-prong extractor, just as can be seen in fig. 44.

Be very careful about removing the friction ring in such a way that there is no damage done to the contact point where the extractor prongs exert a pressure.




Fig. 44 — Removal of the friction ring with an extractor

- Install a new friction ring on the rotor shaft, matching up the closed grooves with the ends of the winds as can be seen in fig. 45.




Fig. 45 — Inserting the friction ring on the rotor shaft

- Insert the long end of the winding a little on the friction ring.

Install a grooved shaft on the friction ring so that the groove matches up with the point in which the connection wire is located when pressing on the friction rings.




Fig. 46 — Setting point of the friction rings

- Next press on the friction rings until they stop on the shaft projection.

As shown in fig. 46, check the setting point «Δ», whose length is 3.7 — 0.1 mm.

- Secure the ends of the winding in the two slots of the friction ring and solder them (fig. 47). The insulating cover over both ends of the windings should not be damaged or worn in any way, since such deterioration might lead to ground short-circuits.




Fig. 47 — Soldering the ends of the windings to the friction rings

- Once the ends of the winds have been soldered, the friction rings must be turned on the outside for a length of 20 mm (fig. 48). In order to do this, use a hard metal blade or a diamond blade.




Fig. 48 — Outside turning of the friction rings

- Next install the rotor on two «V» supports (fig. 49) in order to check the concentricity of the friction rings and the rotor.

- The maximum admissible eccentricity for the friction rings is 0.3 mm, and for the rotor, it is 0,5 mm.

The minimum admissible diameter of the friction rings is 26.8 mm.




Fig. 49 — Checking the eccentricity of the friction rings

#### Assembly of the ball bearings

- Press the ball bearing onto the friction ring side rotor with the help of a press.




Fig. 50 — Press-on assembly of the drive side support ball bearing

- Assemble the ball bearing of the drive side support (fig. 50), after first lubricating it with grease. Press to insert with the closed side facing down and then screwing on the lock plate.

**Note:** In some cases the lock plate is secured with through bolts, in which cases such bolts should be secured with shellac.

#### Replacement of brushes

- Check the length of the brushes; when the projecting length is 5 mm. or less, the brushes should be changed.

When installing new brushes, the projecting length (fig. 51) should be 10 mm. Be careful when soldering so that the solder does not penetrate into the braided copper cable of the brush, and carefully set the flexible tube that covers the braided cable at the soldering point.

- Check that the brushes slide easily on the brush holder.




Fig. 51 — Replacement of the brushes

#### ASSEMBLY OF THE ALTERNATOR

When assembling the alternator, proceed in the following way:

- With the help of a press, press on the drive side support and pressure ring on the rotor shaft (fig. 52).




Fig. 52 — Assembly of the support and pressure ring on the rotor shaft

Use a bushing to carry out this operation in order to allow the rotor shaft to come through. The bushing or tube should only be set on the inside ring of the ball bearing or else on the pressure ring. Never exert any pressure on the drive side support.

- Next install the rotor friction rings side ball bearing.
- Screw on the friction ring side support, the diode plate and assemble the stator.
- Solder the stator windings to the commutator points of the diode plate (fig. 53). Be very careful not to overheat the diodes and not to let any drops of solder fall inside the diode plate when soldering. Do not bend the plug connections.
- Lubricate the seat of the friction ring side support and assemble the metal washer. Carefully insert the rotor together with the drive side support and screw on the different alternator components so that the marks that were made before disassembling match up (fig. 54).






Fig. 53 – Soldering of the stator windings to the commutator points of the diode plate




Fig. 55 – Testing the connection of the negative diodes with the housing




Fig. 54 – Even tightening of the screws and matching up of the marks when assembling

The cylindrical head screws should be evenly tightened at a torque value of 38 to 55 kg. cm.

- Once again use the alternator tester with the metering selector control in the position indicated in fig. 55. Put the testing points in the position shown in the same figure to test whether the cooling element of the negative diodes has a good connection with the housing.

If this connection is correct, the movement of the needle of the indicator will be very small.

Install the brush holder plate being careful that the contact spring of the diode plate has a good contact with the brush holder.

**REGULATOR****Specifications**

Regulator	Type AD 1 — 13 V.
Regulation voltage	13.9 — 14.8 V.
Regulation amplitude	0 — 0.45 V.
Alternator rpm	4,000 rpm.
Charge current for testing regulation amplitude	—20% (24 A.)
Charge current for testing the regulation voltage	3 ... 8 A.
Position of the terminals for testing	Downwards.

**Important Note**

Regulators cannot be repaired since they lack replacement and parts lists, for which the whole unit must be replaced when necessary.



### Description

This regulator is of the double contact type with negative ground. It is independent of the alternator.

### Checking the regulation voltage

The regulation voltage can be checked and adjusted with charge only. The regulator contacts must be pointed downwards. Both the alternator and the regulator must be at a temperature of approximately 20° C.

The alternator must be connected to the battery through a retainer resistance and the charge resistor must also be connected.

### Connections on the test bench

- Connect the terminals D +, DF and D- of the alternator with those of the same designation on the regulator; connect the negative conductor of the test bench to terminal D- of the alternator. In the case in which there is no alternative, connect the threaded terminal of the plate.
- Connect the positive conductor of the test bench to terminal B + of the alternator through a retainer resistor.
- Connect a voltmeter to terminals B + and D- of the alternator. Be very careful of assuring that this polarity is correct and do not connect the negative conductor of the voltmeter to the threaded terminal of the regulation plate.
- Connect the conductor that goes from the charge control bulb to terminal D + of the alternator or of the regulator.

During the testing time it is not wise to recharge the battery since the values might not be valid if such action were to be taken.

Be very careful about not endangering the alternator or regulator semi-conductors by not connecting or disconnecting the terminals of the regulator until the alternator has stopped. Also make sure that the regulator is always tested together with the alternator if the battery is connected in parallel. The battery should always be disconnected after having stopped the alternator.

### Testing process

- Connect the charge resistor and operate the alternator at 4,000 rpm. Adjust the charge current of the alternator (1 max-20%), varying the charge resistance. Reduce the number of revolutions and then increase it again in order to prevent errors due to hysteresis. If necessary, readjust the charge current.
- Read the regulation voltage in a one minute interval. Reduce the charge now from 3 ... 8 A, and the difference between the voltage that is indicated and the regulation voltage that was previously metered with charge current constitutes the regulation amplitude.




Fig. 56 - Voltage regulator

**Trouble shooting**

After carrying out the tests on the tractor, on the basis of the charge condition of the battery and the charge current observed, check tables 1 and 2 for the possible troubles found in the regulator-alternator.

On the basis of the values obtained in the test bench test, check table nr. 3 for the possible trouble found in the alternator.

**Trouble control**

The numbers of the following sections correspond to the ones in the trouble shooting tables.

**Control nr. 1**

Check the regulator and repair or change if necessary.

**Control nr. 2**

Remove the alternator from the tractor and check it on

**Control nr. 3**

Check that there is not excessive voltage drop in the wiring, checking to see if there are any noticeable differences between the different connections and the ground.

Check to find if there is continuity in the different circuits and that there are no broken or loose wires and then check the three following readings:

- a) In the alternator terminals or between the positive terminal and ground.
- b) In the regulator terminals or between the positive terminal and ground.
- c) In the battery terminals.

In order to carry out this metering procedure, start the engine and run it at a moderate speed, and then turn on the headlights so that there will be current throughout the circuit.

**Control nr. 4**

Check the tension of the drive belt. If this tension is low, tighten it correctly. In the case in which the belt is very worn or deteriorated, change it.

**Control nr. 5**

Check with the tractor diagram to see if the connections have been changed in the terminals of the different apparatus.

Before carrying out the inspection, the different parts must first be thoroughly cleaned, eliminating all grease, sludge, etc, which may be adhering to them.

TABLE NR. 1

Tractor-mounted Apparatus Test




TABLE NR. 2

Tractor-mounted apparatus test





TABLE NR. 3

Test bench tests



**START SYSTEM****STARTER****Specifications**

Type	JF-12 (BOSCH).
Voltage	12 V.
Power	2.5 Hp.
Minimum commutator diameter	39.5 mm.
Brush pressure	1,500 to 1,300 gr.
Minimum brush length	15.5 mm.
Longitudinal armature play	0.1 to 0.3 mm.
Maximum armature plate package ovalization	0.05 mm.
Armature brake torque	4.5 to 7.5 kg. cm.
Separation torque	1.2 to 3.2 kg. cm.
Torque moment	3.7 to 4.5 kg. cm.
Minimum contactor drive voltage	7.5 V.
Distance between gear and ring gear	2.5 to 3.0 mm.
Play between tooth sides	0.35 to 0.5 mm.

**Unloaded test**

Voltage	11.5 V.
Current	65 to 95 A.
rpm	6,500 to 8,500 (for 1 min).

**Short-circuit test**

Current	530 to 880 A.
Voltage	3.5 to 4.5 V.




Fig. 57 — Exploded view of starter

- |                              |                                  |
|------------------------------|----------------------------------|
| 1 — Field coils              | 22 — Bearing bushing             |
| 2 — Screw                    | 23 — Brush set                   |
| 3 — Bushing side cover       | 24 — Brush lock spring           |
| 4 — Bearing bushing          | 25 — Brush holder plate          |
| 5 — Clutch lever             | 26 — Screw                       |
| 6 — Screw                    | 27 — 5 mm dia. lockwasher        |
| 7 — 8 mm. dia. lockwasher    | 28 — Flat washer                 |
| 8 — Nut                      | 29 — Contactor                   |
| 9 — Screw                    | 30 — Screw                       |
| 10 — Washer                  | 31 — Screw                       |
| 11 — Nut                     | 32 — Connection terminal         |
| 12 — Middle cover            | 33 — Nut                         |
| 13 — Bearing bushing         | 34 — 10 mm. dia. lockwasher      |
| 14 — Insulations washer      | 35 — Armature washer set         |
| 15 — Brake plate             | 36 — Gear bushing                |
| 16 — Helical spring          | 37 — Rubber connection protector |
| 17 — Guide washer            | 38 — Rubber seal                 |
| 18 — Gear                    | 39 — Sealing plate               |
| 19 — Bearing bushing         |                                  |
| 20 — Armature                |                                  |
| 21 — Commutator side housing |                                  |

NOTE: Numbers 19-35-37-38 and 39 are only supplied as replacement parts in the form of a complete assembly.

## DESCRIPTION

An internal combustion engine cannot start by itself, as opposed to other engines, which start by simply connecting the supply circuit in order to begin operation. This type of engine, however, calls for an outside component supplied with a source of auxiliary power. This function is carried out by an electric motor that is supplied from the tractor battery.

When starting a Diesel engine, the resistances must be overcome which arise from cylinder compression, piston ring and bearing friction, flywheel inertia, etc. These resistances vary according to the quality of the lubricants used and the ambient temperature at which starting is carried out, and are larger in cold weather due to the fact that the frictions and lubricant viscosity are higher at that time.

Furthermore, an internal combustion engine will not start unless a minimum rpm is attained.

### Test bench test

The electrical test value depend on the condition of the test (starter heating, battery discharge). These values are only valid for the test bench and may not be used for starters that are mounted on the tractor. The battery that is mounted on the test bench subjects a small starter to larger stress, while on the other hand, in the case of larger starters, the capacity of the test bench battery is not enough to obtain maximum power from the unit.

The test bench conductors, which are unavoidably longer, also exert an influence on the power of the starter. The duration of the test should thus be as short as possible and the battery should be in good condition and charge to a minimum of three fourths total capacity.

Testing should be performed at an ambient temperature of 20° C.

In the case in which the starter is damaged, the mean values will differ a good deal from the specified ones.

The minimum rpm at which the Diesel engine should turn depends on factors such as the engine temperature when starting, the type of combustion chambers and the preheating assist components.

The function of the starting system is to crank the thermal engine at sufficient speed so that it can start up. The system is composed of an electric motor with a solenoid mounted on the housing, a moveable start pinion (bendix), a battery and a remote control switch.

The amount of resistance in the circuit should be kept to a minimum in order to provide maximum current to the circuit and motor while it is in operation, for which it should be checked that the connections are not loose, contacts are not sulfated and wires not partially broken or with excessively small cross-section, which would cause overheating in these points and reduce the rpm of the engine.




Fig. 58 — Starter connection diagram

- 1 — Winding in series
- 4 — Retainer winding
- 10 — Gear relay
- 14 — Thrust and reactive winding

In the case of doubt, check the field windings and armature winding to detect any possible ruptures or short circuits between loops or ground.



The inside connection of the starter is shown in fig. 58.

#### Unloaded operation test

In order to carry out the unloaded operation tests, proceed as follows:

- Secure the starter on the test bench so that the pinion being set forward, cannot mesh with the gear.

- Connect the starter (fig. 59).

The electrical connection for the test bench test can be seen in fig. 59.

- Measure the absorbed current, voltage and rpm of the starter.

The following table sets forth the possible causes of trouble in the case in which the mean values should differ from the test (specification) values.




Fig. 59 — Connection of starter on test bench

#### TEST VALUE TROUBLESHOOTING CHART

Trouble	Cause
rpm and absorbed current too low.	Battery discharged—large voltage drops in the relay contacts, connection terminals or passage through commutator — armature winding is unsoldered — armature rupture — brushes seized or worn.
rpm too low, absorbed current too high (strong heating).	Short-circuit between field or armature winding loops — mechanical friction due to seizing of bearing retainers or armature brake, or high pressure in brushes.
Strong sparking in brushes.	Ovalized commutator — insulation between the segments in projecting commutator is unsoldered.
Voltage too low.	Battery discharged — resistance due to contact in supply conductors; set up a ground connection between the test bench and the starter if necessary.

**Short-circuit test**

When carrying out the short-circuit tests, proceed as follows:

- Connect the starter and brake it until it stops; read the absorbed current and the voltage. Perform the test for only a short time (from 1 to 2 seconds as a maximum).

In order to carry out this operation, the ring gear of the test bench and the pinion of the starter must have the same toothing (same modulus). If not, change the ring gear.

Carefully check the play between the tooth sides and the distance between the pinion and the ring gear.

When checking the mesh conditions, make the pinion mesh several different times. It should easily mesh with the ring gear, without blocking or making sharp noises.

The current and voltage values indicated in the specifications are valid if the battery that is used is charged to a minimum of 75% total capacity.

The following table sets forth the possible causes of abnormal current absorption.

Trouble	Cause
Current absorption.	Short-circuit between loops or to ground.
Current absorption too low.	Rupture of a coil branch, seized brush, unwelded armature winding, broken commutator connection, discharged battery.

**Load test**

It is enough to carry out this test as an operation check.

- Start the motor and brake it without stopping it.

- Secure the starter and connect it the same way as for the short-circuit test.

The following table sets forth the possible causes of incorrect starter operation.

**TROUBLESHOOTING CAUSES OF INCORRECT  
INCORRECT STARTER OPERATION**

Defect	
Strong sparking of brushes.	Ovalized commutator, short-circuit between loops in the field winding or armature, rupture in the armature.




Fig. 60 - Cross section view of the mixed system starter with thrust gear and bendix

A - Connection terminal	J - Armature
B - Housing	k - Armature shaft
C - Brush spring	L - Helical spring
D - Housing	M - Freewheel mechanism
E - Commutator	N - Pinion
F - Brush	O - Drag
G - Brush	P - Guide ring
H - Field winding	Q - Gear lever
I - Pole ground	R - Contactor

### DISASSEMBLING THE STARTER AND CHECKING ITS COMPONENTS

In order to disassemble the starter and check its components, proceed as follows:

- Secure the starter on a suitable support so that it cannot be moved.
- Remove the brush lock cover (fig. 61), raising the brush lock springs with a hook and remove the brushes from their housings.
- Release the connection between the field winding and the brush holder.




Fig. 61 - Removal of brushes




Fig. 62 — Disassembly of contactor

- Release the contactor connection and remove the gear lever bolt.
- Unscrew the drive lever contactor and remove it, pulling on the pinion (fig. 62).




Fig. 63 — Disassembly of the rear housing

- Remove the lock nuts and take off the rear housing (fig. 63) (being careful with the metal washers which act to correct the axial play of the armature, and the insulation washer).
- Remove the armature housing with the drive bearing.




Fig. 64 — Removing the stud bolts

Unscrew the stud bolts attaching the front support to the rear housing.

They can be unscrewed by loosening the two nuts that are tightened together (Fig. 64).



Fig. 65 — Removal of the control lever

- Set the drive support to one side and draw the drive lever to one side of the gear (fig. 65).
- Keep the armature inclined downwards and slide the control lever upwards until the lever drag pistons can be removed from the guide sleeve.



Fig. 66 — Removing the armature from the front support




Fig. 68 — Removing the bendix

- Pull the steering control lever to the intermediate bearing while moving the armature even lower at the same time.
- Pull out the control lever and the armature shaft of the drive bearing together (fig. 66).
- Secure the armature on a support, remove the through bolt of the castellated nut and unscrew the nut (fig. 67). If the motor spins to right, the thread will be to the left, and vice versa.
- Next remove the gear (fig. 68), the intermediate bearing and the armature brake of the armature shaft.




Fig. 67 — Removing the castellated nut

#### Visual check and cleaning of components

Clean the grease off the different components with some type of solvent liquid, and then dry them with compressed air at a pressure of not over 5 kg/cm<sup>2</sup>.

The armature, the windings of the armature coils and the gear should not come into contact with the cleaning fluid.

Check all of the components thoroughly to determine whether they are considerably worn or contain any mechanical fault.

Once the surface have been cleaned of grease and dried, they should be applied a thin layer of oil to prevent rust.

#### Checking the armature

Two electrical tests should be carried out on the armature to check the condition of the winding:

- a) Ground short-circuit.
- b) Short-circuit between loops.






Fig. 69 — Checking the armature ground short circuit

In the first test, use testing points connected in series with a bulb. A single phase current of 40 V. shall be applied to these points. One of the testing points should be applied to any metal part of the armature, while the other should be applied to the commutator (fig. 69). Under these conditions, the bulb should stay off.

In order to carry out the second test for a possible short-circuit between loops, install the armature in a magnetic tester. Place a metal lamina on it and slowly turn the armature. Each time that the metal lamina meets one of the winding insertion slots, it should be stabilized, which indicates that the armature is operating correctly.

If it should, on the other hand, begin to vibrate, this is a sign of a short-circuit between loops.

Also check that the armature does not rub the pole grounds or the field windings. The maximum admissible ovalization for the lamina package is 0.05 mm.

Also check the friction surface of the commutator in the area where the brushes rest (fig. 70). This area should have an even blue-grey colour and not be dirty or stained with oil.




Fig. 70 — Checking the ovalization of the commutator

Check that the commutator connections are well soldered and that the commutator shows no signs of burning due to sparks. Likewise, check for a possible lack of roundness, a maximum eccentricity of 0.03 mm. being admissible.

The minimum diameter of the commutator is 39.5 mm.




Fig. 71 — Machine reduction of the insulation between commutator segments




Fig. 72 — Checking ground short-circuits of the field coils




Fig. 73 — Checking the insulated brush holder

If necessary, turn the commutator. Once this operation has been performed, check that the diameter does not lie below the minimum acceptable value.

Once the commutator has been turned, reduce the insulation between segments to a length of approximately 0.5 to 0.8 mm. with a commutator saw. Eliminate the edge of the segments and then check again to determine whether there is ground short-circuit or short-circuit between the loops in the armature.

Check the field windings in the pole housing. They should not be burnt, unwelded or projecting from the pole grounds.

Check all the field windings to detect any possible ruptures. To do so, first disconnect all the coils that are connected in parallel. For this test use testing points to which a voltage of 6 V. direct current is applied. The bulb connected in series with the testing points should go on to indicate the continuity of the winding.

Also check all the windings to see if there are ground short-circuits. To do so, release all the ground connections, and apply a voltage of 40 V./ single phase alternating current to the testing points (fig. 72). The bulb connected in series should stay off.

Check that the brushes slide easily on their guides and that the lock springs are not retracted or damaged (fig. 73). Also check the pressure that these springs exert with a dynamometer. The correct pressure is 1,150 to 1,300 gr.

Check the length of the brushes. It should not be less than the value indicated as the minimum according to specifications. If the length is shorter than specified, a strong sparking will be produced in the commutator and endanger the operation of the starter.

Check the condition of the self-lubricating bearing (fig. 74). If it shows considerable wear, replace it.

Whenever the starter is disassembled, it is wise to replace the toric rings of the front support (fig. 75).

Check the condition of the self-lubricating bearing of this support and replace it if they show considerable wear.

Replace the gear (fig. 76) when the freewheel mechanism is worn or the teeth are worn or otherwise damaged.




Fig. 74 — Self-lubricating bearing



Fig. 76 — Bendix pinion




Fig. 75 — Position of the toric rings in the front support

#### Assembly of the starter

Once the pinion assembly has been assembled on the armature shaft, without neglecting to install the intermediate washer and the helical spring, slide the drive support over the armature gear and set the control lever in place (fig. 77).



Fig. 77 — Assembly of the front support

#### Contactors

Change the joint and the rubber gasket if they are worn or damaged. Completely replace the contactor if it has been affected by water. Check that there is good contact and firm seating of the connection terminals.

The drag studs of the control lever should fit into the guide ring of the two parts of the gear.

Screw on the lock rods of the front support assembly and correctly insert the slightly lubricated rubber gasket in its housing in the support.



The positions of the lock slots of the rotor and intermediate bearings should match up.

Insert the insulation tubes on the lock slots of the assembly and install the housing (Fig. 28). Check the rotor gears and lock projection.



Fig. 28 - Assembly of the housing

The axial play of the stator is adjusted by means of non-ferrous washers that are placed on the stator shaft (Fig. 29).



Fig. 29 - Assembly of the washers to give play adjustment of the stator

The excess longitudinal play of the stator is 0.2 to 0.3 mm.

Draw the rotor lever downwards and hook up the stator joint pins as 8. Insert on the stator with the three seal lead wires.

Draw on the lock and the wiring-connecting of the stator (Fig. 30).



Fig. 30 - Assembly of the stator

Insert the coupler (Fig. 31) in such a position so that their connection wires so that they are not rubbing or touching dry metal part.



Fig. 31 - Assembly of the coupler

Next assemble the coupling plate inside the housing and then screw on the housing head.

- Variation of the speed is the consequence of the start.

#### Arresting braking torque

The arresting braking torque is composed of the friction of brushes, bearings and of the arresting brake, which is assembled as an additional part.

- An excessively large braking torque causes wear and additional heating of the armature brake. If the torque value is too low, the time which the rotor spends on its elements until stopping is too long. Likewise, when it is surpassed by the normal value, starting is dragged out or an engine is too high.

#### Advance torque

Advance torque means the torque that is necessary to turn the pinion in the direction of rotation of the

rotor, while the rotor is excited and the commutator stationary.

- If the advance torque is too low, under certain circumstances the coupling does not transmit power. On the other hand, if the advance torque is too high, since the start is surpassed by the rotor angle, it is dragged to an unacceptably high speed which may wear it.

#### Play between tooth sides


This play means the clearance between the sides of the pinion teeth and those of the ring wheel while the pinion is meshed.

- When the play is too small there will be a large noise and high wear on the teeth. If the play is too large, the lost on the teeth will be excessive and may cause thermal losses.



Fig. 10 — Checking the braking torque.

LUBRICATION TABLE		
Lubricant	Lubrication point	Lubrication instructions
	Bearing Bushings	Before assembling new bushings submerge them in oil for at least a half an hour.
	Armature shaft	Slightly lubricate the bearing points on the drive and commutator side, the slide surface and the clutch flanges, as well as the large thread of the gear.
	Armature brake	Lubricate all brake discs and their separations well. Slightly lubricate the spring.
	Commutator and drive side washers	Slightly lubricate.
	Contactors	Lubricate the inside surface of the joint fork and bolt lightly



0072-2608

ELEVADOR HIDRAULICO / STD.  
HYDRAULIC LIFT / STD.  
RELEVAGE HYDRAULIQUE / STD.

DISTRIBUIDOR  
DISTRIBUTOR  
DISTRIBUTEUR

1

6

0072-2608

1	-207024-0	1	CJTO. DISTRIBUIDOR ENS. DISTRIBUTEUR	DISTRIBUTOR ASSY	
2	1 SS-18-0028C	1	TAPON BOUCHON	PLUG	
3	1 -1441698-X1	2	JUNTA ALOJ. JOINT TORIQUE	O'RING	
4	1 SS-11-0018B	1	MUELLE RESSORT	SPRING	
5	1 -377181-0	1	SEPARADOR ENTRETOISE	SLEEVE	
6	1 -379094-0	1	VALYULA CLAPET	VALVE	
7	1 SS-16-0082A	2	JUNTA JOINT TORIQUE	O'RING	
8	1 -339009-X1	4	TORNILLO VIS	SCREW	
9	1 -339374-X1	4	ARANDELA RONDELLE	WASHER	● -353446-X1
10	1 -377034-0	1	TAPA SUPERIOR COUVERCLE	COVER	
11	1 SS-11-0012B	1	MUELLE RESSORT	SPRING	
12	1 -377039-0	1	VALYULA CLAPET	VALVE	
13	1 -377042-0	1	VALYULA PILOTO CLAPET	VALVE	
14	1 SS-16-0085A	1	JUNTA TAPON JOINT	GASKET	
15	1 SS-18-0027C	1	TAPON BOUCHON	PLUG	
16	1 -377134-0	1	VALYULA CLAPET	VALVE	
17	1 SS-11-0007B	1	MUELLE RESSORT	SPRING	
18	1 -339024-X1	1	ARANDELA RONDELLE	WASHER	
19	1 SS-11-0022B	1	MUELLE RESSORT	SPRING	
20	1 -377040-0	1	TIRADOR TIROIR	VALVE HOUSING	
21	1 SS-16-0087A	2	JUNTA TAPON JOINT	GASKET	
22	1 SS-18-0013B	1	TAPON BOUCHON	PLUG	
23	1 -377041-0	1	COMPENSADOR COMPENSATEUR	COMPENSATOR	
24	1 SS-08-0033B	1	SEPARADOR ENTRETOISE	BUSH	
25	1 SS-16-0065A	2	JUNTA JOINT	GASKET	
26	1 SS-18-0029C	1	TAPON BOUCHON	PLUG	

ELEVADOR HIDRAULICO/STD.  
HYDRAULIC LIFT/STD.  
RELEVAGE HYDRAULIQUE/STD.

DISTRIBUIDOR  
DISTRIBUTOR  
DISTRIBUTEUR

2

6

0072-2608

27	1	SS-11-0013B	1 MUELLE RESSORT	SPRING	
28	1	SS-18-0030C	1 TAPON M10 BOUCHON	PLUG	
29	1	SS-16-0083A	1 JUNTA TAPON JOINT	GASKET	
30	1	-377035-1	1 VALYULA CLAPET	VALVE	
31	1	SS-16-0086A	1 JUNTA TAPON JOINT	GASKET	
32	1	SS-04-0085C	1 ANILLO JOINT TORIQUE	O'RING	
33	1	SS-18-0010G	1 TAPON M10 BOUCHON	PLUG	
34	1	-377116-0	1 AGUJA AIGUILLE	PIN	± 22,2 ± 22,148
34	1	-377118-0	1 AGUJA AIGUILLE	PIN	± 22,1 ± 22,048
34	1	-377120-0	1 AGUJA AIGUILLE	PIN	± 22,0 ± 21,948
34	1	-377122-0	1 AGUJA AIGUILLE	PIN	± 21,9 ± 21,848
34	1	-377124-0	1 AGUJA AIGUILLE	PIN	± 21,8 ± 21,748