



STRALIS □ AT/AD

REPAIR MANUAL

MECHANICAL

ELECTRIC

ELECTRONIC

IVECO





STRALIS AT/AD

REPAIR MANUAL

IVECO



This publication describes the characteristics, the data, the correct methodology of the repairs that can be made on each individual component of the vehicle.

By complying with the instructions supplied and using the specific tools it is possible to perform any repair intervention correctly, within the specified time frames, while protecting the technicians against incidents.

Before starting any repair work, make sure that all accident prevention devices are ready at hand.

Check and wear the protective personal equipment provided for by the safety standards: goggles, helmet, gloves, shoes.

Check the efficiency of all processing, lifting and transport tools before using them.

The data contained in this publication might fail to reflect the latest changes which the Manufacturer may introduce at any time, for technical or sales purposes, or to meet the requirements of local legislation.

Copy, even partial, of text and drawings is forbidden.

Publication Edited by:
IVECO S.p.A.
T.C.O. - B.U. Customer Service
Lungo Stura Lazio, 15/19
10156 Torino (Italy)

Printed **603.93.141** - 1st Ed. 2003

Produced by:



B.U. TECHNICAL PUBLISHING
C.so Svizzera, 185
10149 Torino (Italy)

SPECIAL REMARKS

The workshop manuals for mechanical parts have been divided into Sections, each of which has a number and its relevant contents are indicated in the General Specifications. Each section features a main Unit (e.g. engine, gears etc.).


The subjects usually dealt with in each section are:

Technical data table, Driving torques, Equipment, Diagnostic, Removal and Fitting in place, Repair operations.

Where possible, the same sequence of procedures has been followed for easy reference.

Diagrams and symbols have been widely used to give a clearer and more immediate illustration of the subject being dealt with, (see next page) instead of giving descriptions of some operations or procedures.

Example



Ø 1 = housing for connecting rod small end bush

Ø 2 = housing for connecting rod bearings



Tighten to torque
Tighten to torque +
angular value

Furthermore, within each section, every heading or sub-heading concerning the operations to be carried out is preceded by a six digit number. This number is the Product Code that is to be found in the repair operation described in the REPAIR TIMES CHARTS and in the FAULT CODES.

For quick reference the indication of how to read this code is described below (see the Repair time charts also).

Product Code:



PRODUCT



UNIT



SUB-ASSEMBLY
COMPONENT

Example:

Product 50 = Frame;

Product 52 = Axles;

Product 53 = Gears etc.

Unit Code:



PRODUCT



UNIT



SUB-ASSEMBLY
COMPONENT

Figures three and four identify the ASSEMBLY within the PRODUCT

Example:

Product 50 = Frame;

Unit 01 = Chassis;

Unit 02 = Bumpers etc .

Sub-assembly Code:



PRODUCT



UNIT



SUB-ASSEMBLY
COMPONENT



















Example:
















Product 50 = Frame;

Unit 01 = Chassis;

Sub-assembly 40 = Chassis cross members etc.

Graphs and symbols

	Removal Disconnection
	Refitting Connection
	Removal Disassembly
	Fitting in place Assembly
	Tighten to torque
	Tighten to torque + angle value
	Press or caulk
	Regulation Adjustment
	Warning Note
	Visual inspection Fitting position check
	Measurement Value to find Check
	Equipment
	Surface for machining Machine finish
	Interference Strained assembly
	Thickness Clearance
	Lubrication Damp Grease
	Sealant Adhesive
	Air bleeding

	Intake
	Exhaust
	Operation
ϱ	Compression ratio
	Tolerance Weight difference
	Rolling torque
	Replacement Original spare parts
	Rotation
	Angle Angular value
	Preload
	Number of revolutions
	Temperature
	Pressure
$>$	Oversized Higher than.... Maximum, peak
$<$	Undersized Less than.... Minimum
	Selection Classes Oversizing
	Temperature < 0° Cold Winter
	Temperature > 0° Hot Summer

STRALIS AT/AD

Print 603.93.141 – 1st edition
Base – January 2003

UPDATE DATA

Section	Description	Page	Revision date

INDEX OF SECTIONS

	Section
General information	I
Engine	2
Clutch	3
Gearbox	4
Hydraulic retarder	5
Propeller shafts	6
Rear axles	7
Front axle	8
Front and rear suspensions	9
Wheels and tyres	10
Steering system	11
Pneumatic system - brakes	12
Bodywork and chassis frame	13
Maintenance	14


SECTION I

General

	Page
VEHICLE IDENTIFICATION DATA	3
<input type="checkbox"/> Vehicle identification plate	4
<input type="checkbox"/> Production identification plate	4
COMPOSITION OF MODELS	5
P.I.C. NUMBER CODING	9
REPLENISHING FLUIDS	13



VEHICLE IDENTIFICATION DATA

The type and number of engine, type and number of chassis and manufacturer's plate comprise the vehicle identification data.




Manufacturer's plate

To identify the vehicle in accordance with the E.E.C. directive (under the front radiator cowling).



Chassis frame

Punching (front on right side member of chassis frame).



Engine

Plate on the left rear side of the crankcase

Vehicle Identification Plate

Plate legend

- a) Type-approval number marking (if applicable).
- b) Vehicle identification code number (V.I.N.).
- c) Total tractor weight.
- d) Total weight of tractor + trailer (if applicable).
- e) Permissible weight limit on 1st axle.
- f) Permissible weight limit on 2nd axle (if applicable).
- g) Permissible weight limit on 3rd axle.
- h) Permissible weight limit on 4th axle (if applicable).
- i) Specific identification of type.
- l) Wheelbase in mm.
- m) Engine type.
- n) Engine power.
- o) No. of axles.
- p) Place of manufacture.

IVECO MAGIRUS AG	
Kg	
Kg	
Kg	
Kg	
Kg	
Kg	
Type	N° of axles
	o)
Wheelbase	Corrected absorption value
Engine type	Engine power KW
	n)
Made in	
IVECO	









Production identification plate

This plate shows the P.I.C. (production identification code number), which is needed when referring to the **spare parts catalogue** (electronic and/or microfiche catalogue). The P.I.C. is also given on the vehicle warranty card.
Note: When consulting the catalogues, use only the first 8 digits of the product identification code number.

Unit No
Part No
Serial No
P.I.C. No
Made in Germany-Iveco Magirus AG
IVECO
9843 8247

Permissible grade of smoke









COMPOSITION OF MODELS

		CHASSIS CABS - 6x2 P MODELS																												
ASSEMBLIES		AD 260 S 40Y/P	AT 260 S 40Y/P	AD 260 S 40Y/PS	AT 260 S 40Y/PS	AD 260 S 40Y/FP-D	AT 260 S 40Y/FP-D	AD 260 S 40Y/FS-D	AT 260 S 40Y/FS-D	AD 260 S 40Y/FS-CM	AT 260 S 40Y/FS-CM	AD 260 S 43Y/P	AT 260 S 43Y/P	AD 260 S 43Y/PS	AT 260 S 43Y/PS	AD 260 S 43Y/FP-D	AT 260 S 43Y/FP-D	AD 260 S 43Y/FS-D	AT 260 S 43Y/FS-D	AD 260 S 43Y/FS-CM	AT 260 S 43Y/FS-CM	AD 260 S 40Y/PT	AT 260 S 40Y/PT	AD 260 S 40Y/TN	AT 260 S 40Y/TN	AD 260 S 43Y/PT	AT 260 S 43Y/PT	AD 260 S 43Y/TN	AT 260 S 43Y/TN	
	F2BE0681F (270 CV)																													
	F2AE0681E (300 CV)																													
	F2BE0681B (310 CV)																													
	F2BE0681A (350 CV)																													
	F3AE0681B (400 CV)			○	○	○	○	○	○	○	○	○											○	○	○	○				
F3AE0681D (430 CV)												○	○	○	○	○	○	○	○	○	○					○	○	○	○	○
	Single disc 16"																													
	Single disc 17"	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	ZF 9S 109 D.D.																													
	ZF 16S 151 O.D.																													
	ZF 16S 181 O.D.																													
	ZF 16S 181 D.D.	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	ZF 16S 221 D.D.																													
	EuroTronic Automated 12 AS 2301 D.D.																													
	EuroTronic Automated 12 AS 2301 O.D.	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
Allison MD 3060 P - MD 3066 P																														
	FRONT AXLE:																													
	5876/4 (F 8021)	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗							⊗	⊗	⊗	⊗	⊗	⊗	⊗		
	5876/5 (F 8021)	●	●	●	●	●	●	●	●	●	●	●	●	●	●							●	●	●	●	●	●	●	●	
	5886/5 (F 9021)															○	○	○	○	○	○									
	ADDED AXLE:																													
	Steering central	5876/4 (F 8021)																												
Rigid rear	55080/D1 (N 8071) *	○	○									○	○		○	○														
Rigid rear	56082/D1 (N 9171) *																					○	○	○	○	○	○	○		
Steering rear	57080/D1 (N 8072) *			○	○	○	○	○	○	○	○			○	○			○	○	○	○									
	MERITOR MS 13-175/T - MS 13-175/D	○	○	○	○	○	○	○	○	○	○	○	○	○	○							○	○	○	○	○	○	○		
	MERITOR RT 160/1																													
	451391 HR																													
	ZF 8098	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○		
	FRONT MECHANICA0L																													
	Front	□	□	□	□							□	□	□	□							□	□	□	□	□	□	□		
	Rear																								□	□		□		
	PNEUMATIC																													
	Front					□	□	□	□	◇	◇					□	□	□	□	◇	◇									
	Rear	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○		
	Added axle	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○		

- T = 4x2 tractor
- TX = 6x2 C tractor (central added axle cannot be lifted)
- TY = 6x2 P tractor (rear added axle can be lifted)
- TN = 6x2 vehicles with mechanical rear suspensions and raisable rigid rear added axle
- TZ = 6x4 tractor (bogie rear axle)
- P = 4x2 – 6x2P – 6x2C vehicles with air suspension on rear axle and 6x2P vehicles with rigid rear axle that can be lifted with single wheels
- PT = 6x2P vehicles with air suspension on rear axle and rigid rear added axle that can be lifted with twin wheels
- PS = 6x2P vehicles with air suspension on rear axle and on steering rear added axle that can be lifted with single wheels
- FP = 4x2 – 6x4 – 6x2P – 6x2C vehicles with front and rear air suspensions
- FS = 6x2P vehicles with front and rear air suspensions, steering rear added axle can be lifted with single wheels
- 4x2 = Vehicles with two axles with rear driving axle
- 6x2P = Vehicles with three axles with rear driving axle and rear added third axle that can be lifted
- 6x2C = Vehicles with three axles with rear driving axle and central added third axle that cannot be lifted
- 6x4 = Vehicles with three axles with two rear driving axles (in tandem)
- CM = Movable Boxes
- LT = Tractor with lowered chassis frame
- CT = Chassis cab with lowered chassis frame
- RR = Rough Roads
- D = Distribution
- HR = Hub Reduction
- AT = Active Time
- AD = Active Day

⊗ = With brake calliper assembly at 57° without parking brake
 ● = With brake calliper assembly at 0° with parking brake
 ◇ = With longitudinal and transversal bars
 □ = With parabolic leaf springs
 * = TI with drum brakes

COMPOSITION OF MODELS

TRACTORS - MODELS		4x2																6x2 C				6x4							
		AD 440 S 31T/P	AT 440 S 31T/P	AD 440 S 35T/P	AT 440 S 35T/P	AD 440 S 35T/P-HR	AT 440 S 35T/P-HR	AD 440 S 40T/P	AT 440 S 40T/P	AD 440 S 40T/P-RR	AT 440 S 40T/P-RR	AD 440 S 40T/P-HR	AT 440 S 40T/P-HR	AT 440 S 40T/FP-CT	AT 440 S 40T/FP-LT	AD 440 S 43T/P	AT 440 S 43T/P	AD 440 S 43T/P-RR	AT 440 S 43T/P-RR	AD 440 S 43T/P-HR	AT 440 S 43T/P-HR	AT 440 S 43T/FP-CT	AT 440 S 43T/FP-LT	AD 440 S 40TX/P	AT 440 S 40TX/P	AD 440 S 43TX/P	AT 440 S 43TXP	AT 440 S 43TZ/P	
	F2BE0681F (270 CV)																												
	F2AE0681E (300 CV)																												
	F2BE0681B (310 CV)	○	○																										
	F2BE0681A (350 CV)			○	○	○	○																						
	F3AE0681B (400 CV)							○	○	○	○	○	○	○	○														
	F3AE0681D (430 CV)															○	○	○	○	○	○	○	○	○	○	○	○	○	○
	Single disc 16"																												
	Single disc 17"	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	ZF 9S 109 D.D.																												
	ZF 16S 151 O.D.	○	○	○	○	○	○																						
	ZF 16S 181 O.D.																												
	ZF 16S 181 D.D.							○	○	○	○	○	○	○	○														
	ZF 16S 221 D.D.																											○	
	EuroTronic Automated 12 AS 2301 D.D.																												
	EuroTronic Automated 12 AS 2301 O.D.	○	○	○	○	○	○	○							○	○	○	○	○	○	○	○	○	○	○	○	○	○	
Allison MD 3060 P - MD 3066 P																													
	FRONT AXLE:																												
	5876/4 (F 8021)	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗		
	5876/5 (F 8021)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
	5886/5 (F 9021)																												
	ADDED AXLE:																												
	Steering central																								○	○	○	○	
	Rigid rear																												
Rigid rear																													
Steering rear																													
	MERITOR MS 13-175/T - MS 13-175/D	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○		
	MERITOR RT 160/I																											○	
	451391 HR																												
	ZF 8098	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	FRONT MECHANICAL																												
	Front	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□	□	
	Rear																											□	
	PNEUMATIC																												
	Front																												
	Rear	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	Added axle																												

- ⊗ = With brake calliper assembly at 57° without parking brake
- = With brake calliper assembly at 0° with parking brake
- ◇ = With longitudinal and transversal bars
- = With parabolic leaf springs
- * = T1 with drum brakes

- T = 4x2 tractor
- TX = 6x2 C tractor (central added axle cannot be lifted)
- TY = 6x2 P tractor (rear added axle can be lifted)
- TN = 6x2 vehicles with mechanical rear suspensions and raisable rigid rear added axle
- TZ = 6x4 tractor (bogie rear axle)
- P = 4x2 - 6x2P - 6x2C vehicles with air suspension on rear axle and 6x2P vehicles with rigid rear axle that can be lifted with single wheels
- PT = 6x2P vehicles with air suspension on rear axle and rigid rear added axle that can be lifted with twin wheels
- PS = 6x2P vehicles with air suspension on rear axle and on steering rear added axle that can be lifted with single wheels
- FP = 4x2 - 6x4 - 6x2P - 6x2C vehicles with front and rear air suspensions
- FS = 6x2P vehicles with front and rear air suspensions, steering rear added axle can be lifted with single wheels
- 4x2 = Vehicles with two axles with rear driving axle
- 6x2P = Vehicles with three axles with rear driving axle and rear added third axle that can be lifted
- 6x2C = Vehicles with three axles with rear driving axle and central added third axle that cannot be lifted
- 6x4 = Vehicles with three axles with two rear driving axles (in tandem)
- CM = Movable Boxes
- HM = Heavy Mission
- LT = Tractor with lowered chassis frame
- CT = Chassis cab with lowered chassis frame
- RR = Rough Roads
- D = Distribution
- AT = Active Time
- AD = Active Day

P.I.C. NUMBER CODING

CAB LIVEABILITY

A

A

A

B

B

C

C

D

M



= Stralis AD (Active Day)

N



= Stralis AT (Active Time)

TOTAL WEIGHT ON GROUND - AXLES CONFIGURATION

A

A

A

B

B

C

C

D

C



= 4x2; 18-20 ton.

D



= 4x2T; 19-20 ton.

E



= 6x2C; 26 ton.

F



= 6x2P; 26 ton.

G



= 6x2P; 26 ton.

H



= 4x2T; 19-20 ton.

J



= 6x2C; 26 ton.

K



= 6x4; 26 ton.

L



= 4x2P; 19-20 ton.

M



= 6x2P; 26 ton.

N



= 6x2P; 26 ton.

ENGINE

A

A

A

B

B

C

C

D

H



E 270

L



E 400

K



E 430

P



E 310

Q




E 300

R




E 352

SUSPENSION TYPE - REAR AXLE TYPE - TYPE OF ADDITIONAL AXLE



- * = Suspensions with 5886/D front axle
- TWIN = Twin rear wheels
- CENT = Middle axle (6x2C vehicles)
- SING = Added axle with rear single wheels
- STER = Added axle with rear steering single wheels
- HR = Double reduction rear axle
- SR = Simple reduction rear axle

VERSION COMBINATION - USE




- Cartran = Car transport
- LOW TR = Lowered tractor
- STD = Standard use
- GRAV = Heavy duty use

WHEELBASE




VERSION	WHEELBASE	VERSION	WHEELBASE	VERSION	WHEELBASE	VERSION	WHEELBASE	
T 6 x 2 C	3800	T 4 x 2	3650	6 x 2 P	3120	T 6 x 4	2800	➔ 1
						T 6 x 4	3200	➔ 2
				6 x 2 P C 4 x 2	3805	T 4 x 2 C 6 x 2 C	3800	➔ 3
						C 4 x 2 C 6 x 2 C 6 x 2 P	4200	➔ 4
						C 4 x 2 C 6 x 2 6 x 2 P	4500	➔ 5
						C 4 x 2 6 x 2 P	4800	➔ 6
						C 4 x 2 6 x 2 P	5100	➔ 7
						C 4 x 2 6 x 2 P	5700	➔ 8
				C 4 x 2	6300	6 x 2 P	6050	➔ 9
						C 4 x 2	5500	➔ L
						C 4 x 2	6300	➔ M









GEARBOX - BRAKES COMBINATION












CAB - DRIVE - BRAKES COMBINATION



REPLENISHING FLUIDS

LUBRICANTS RECOMMENDED BY IVECO	PARTS TO BE FILLED UP	Quantity		
		Litres	Kg	
 Urania FE 5W30⁽¹⁾ Urania LD5 Urania Turbo LD	 Engine F2B	Total capacity for first filling		
		28	25,2	
		Capacity:		
		- engine sump min level	12,5	11,2
		- engine sump max level	23	21
		- quantity in circulation that does not flow back to the engine sump	5	4,5
	- quantity contained in the cartridge filter (which has to be added to the cartridge filter re-fill)	2,5	2,3	
 Urania FE 5W30⁽¹⁾ Urania LD5 Urania Turbo LD	 Engine F3A	Total capacity 1 st filling		
		30	29,8	
		Capacity:		
		- engine sump at minimum level	17	15,3
		- engine sump at maximum level	25	22,5
		- quantity in circulation that does not return to sump	7	6,3
	- quantity contained in cartridge filter (to add when changing the cartridge filter)	2,5	2,3	
 Tutela Truck FE-Gear¹ Tutela ZC 90	 Gearbox	ZF 9 S 109 *		
		8	7,2	
		ZF 16 S 151 *		
		11	10	
		ZF 16 S 151 + Intarder *		
		18,5	16,65	
		ZF 16 S 181 *		
		13	12	
		ZF 16 S 181 + Intarder*		
		21,5	19,35	
ZF 16 S 221 *				
13	12			
ZF 16 S 221 + Intarder*				
21,5	19,35			
EuroTronic automated 12 AS 2301*				
12	11			
EuroTronic automated 12 AS 2301* + intarder				
23	21			
 Tutela GI/A	Allison MD 3060 P - MD 3066 P	18	16	
 Tutela Truck FE-Gear¹ Tutela ZC 90	Power take off (Multipower)	2,5		
<p>(1) IVECO recommends using these oils for reasons of fuel economy. IVECO provides new vehicles already with these types of lubricants. Also suited for cold climates (minimum temperature down to -30°C) These quantities are not decisive. An exact check must be made by verifying the levels</p>				

REPLENISHING FLUIDS

LUBRICANTS RECOMMENDED BY IVECO		PARTS FOR REPLENISHING		Quantity	
				Litres	kg
	Tutela Truck FE-Axle⁽²⁾ Tutela W140/M-DA Tutela W90/M-DA ³	Front hubs (single)			
		FRONT AXLE	5876/4-/5 (F8021)	0.35	0.32
		FRONT AXLE	5886/5	0.35	0.32
		ADDED AXLE::			
		Steering central	5876/4 (F 8021)	0.35	0.32
		Rigid rear	55080/DI (N 8071)	0.35	0.32
		Rigid rear	56082/DI (N 9171)	0.35	0.32
Steering rear	57080/DI (N 8072)	0.35	0.32		
	Tutela Truck FE-Axle⁽²⁾ Tutela W140/M-DA Tutela W90/M-DA ³	Bridge Meritor MS 13-175/T - MS 13-175/D:			
		<input type="checkbox"/> (mechanical suspension)		18.5	16.5
		<input type="checkbox"/> (pneumatic suspension)		17	15.5
		Bridge 45 391 HR		16	14.5
		Rear axle Meritor in tandem RT 160E/I			
- middle		18.5	16.6		
- rear		16.5	14.8		
	Tutela GI/A		Power steering	2.7*	2.4
				13.5**	12
			* Excluding vehicles with steering rear axle		
			** For vehicles with steering rear axle only		
	Tutela TRUCK DOT SPECIAL		Clutch circuit (excluding vehicles with Euro Tronic gearbox)	0.5	0.45
	Water+Paraflu ¹¹	Cooling system			
		Engine F2B	Total capacity*	~34	~23.4
		Engine F2B with Intarder	Total capacity*	~50	~27
		Engine F3A	Total capacity*	~38	~39.6
		Engine F3A with Intarder	Total capacity*	~58	~57.6
			* = Protective anti-freeze (concentration 50% freezing point -35°C)		
	Tutela LHM		Cab tilting system	0.6	0.54

(2) Only on axles with disc brakes, IVECO recommends using these oils for reasons of fuel economy. IVECO provides new vehicles already with these types of lubricants. Also suited for cold climates (minimum temperature down to -30°C)

(3) Specific for cold climates

These quantities are not decisive. An exact check must be made by verifying the levels

International lubricant designation	FL products	
Engine oil Meets the specifications: ACEA E4 with a totally synthetic base ACEA E5 with a mineral base ACEA E3 with a mineral base	SAE 50W 30 SAE 15W 40 SAE 15W 40	URANIA FE 5W30 Urania LD5 Urania Turbo LD
Oil for differential gear and wheel hubs Meets the specifications: API GL5, MT-I with a totally synthetic base API GL5 with a mineral base API GL5 with a mineral base	SAE 75W 90 SAE 85W 140 SAE 80W 90	Tutela Truck FE-Axle Tutela W140/M-DA Tutela W90/M-DA
Oil for mechanical gearboxes Containing non-EP anti-wear additives Meets the specifications: API GL4 with a totally synthetic base API GL3 with a mineral base	SAE 75W 85 SAE 80W 90	Tutela Truck FE-Gear Tutela ZC90
Oil for power steering and hydrostatic transmissions A.T.F. DEXRON II D		Tutela GI/A
Grease for general greasing based on lithium soaps, N.L.G.I. consistency no. 2		Tutela MR 2
Specific grease for bearings and wheel hubs based on lithium soaps, N.L.G.I. consistency no. 3		Tutela MR 3
Clutch drive fluid Conforming to N.H.T.S.A. standards 116, ISO 4925, Std. SAEJ 1703, IVECO STANDARD 18-1820		Tutela TRUCK DOT SPECIAL
Mineral oil for hydraulic circuits In compliance with IVECO STANDARD 18-1823		Tutela LHM
Windscreen washer fluid , mixture of spirit, water and surfactants CUNA NC 956-11		Tutela PROFESSIONAL SC 35
Grease for central lubrication systems based on lithium soaps, with synthetic base, N.L.G.I. no. 2. Working temperatures: from -30°C to +140°C		Tutela COMAR 2
Concentrated protective fluid for radiators based on ethylene glycol containing corrosion inhibitors, conforming to the standard: IVECO-STANDARD 18-1830		Parafu ¹¹

SECTION 2

Engine

	Page
<input type="checkbox"/> F2B Engine	3
<input type="checkbox"/> F3A Engine	113
<input type="checkbox"/> Hidrocar pressure take-off on timing system (P.T.O. - Optional)	223

F2B Engine


	Page
VIEWS OF THE ENGINE	8
GENERAL CHARACTERISTICS	13
ASSEMBLY CLEARANCE DATA	16
TIGHTENING TORQUES	22
TOOLS	28
DISMANTLING THE ENGINE ON THE BENCH	40
REPAIR OPERATIONS	47
CYLINDER BLOCK	47
<input type="checkbox"/> Checks and measurements	47
CYLINDER LINERS	48
<input type="checkbox"/> Fitting and checking protrusion	49
<input type="checkbox"/> Removal	49
<input type="checkbox"/> Replacing cylinder liners	49
CRANKSHAFT	50
<input type="checkbox"/> Measuring main journals and crank pins	51
PRELIMINARY MEASUREMENT OF MAIN AND BIG END BEARING SHELL SELECTION DATA . .	52
<input type="checkbox"/> Replacing the timing control gear and the oil pump	59
<input type="checkbox"/> Checking main journal installation clearance . . .	59
<input type="checkbox"/> Checking crankshaft end float	60
PISTON-CONNECTING ROD ASSEMBLY	61
<input type="checkbox"/> Removal	61
<input type="checkbox"/> Measuring the diameter of the pistons	62
<input type="checkbox"/> Conditions for correct gudgeon pin-piston coupling	62
<input type="checkbox"/> Piston rings	63
CONNECTING ROD	64
<input type="checkbox"/> Checking connecting rod alignment	65

	Page
<input type="checkbox"/> Mounting the connecting rod-piston assembly .	65
<input type="checkbox"/> Mounting the piston rings	65
<input type="checkbox"/> Fitting the connecting rod-piston assembly into the piston liners	66
<input type="checkbox"/> Piston protrusion check	66
<input type="checkbox"/> Checking assembly clearance of big end pins . .	67
CYLINDER HEAD	67
<input type="checkbox"/> Valve removal	67
<input type="checkbox"/> Checking the planarity of the head on the cylinder block	67
VALVE	67
<input type="checkbox"/> Removing deposits and checking the valves . . .	67
VALVE GUIDES	68
<input type="checkbox"/> Replacing of valve guides	69
<input type="checkbox"/> Replacing - Reaming the valve seats	69
REPLACING INJECTOR HOLDER CASES	69
<input type="checkbox"/> Removal	69
<input type="checkbox"/> Checking protrusion of injectors	71
TIMING GEAR	72
<input type="checkbox"/> Checking cam lift and pin alignment	72
<input type="checkbox"/> Camshaft	73
<input type="checkbox"/> Bushes	73
<input type="checkbox"/> Replacing camshaft bushes using beater 99360487	74
<input type="checkbox"/> Removal	74
<input type="checkbox"/> Assembly	74
VALVE SPRINGS	75
<input type="checkbox"/> Fitting the valves and oil seal ring	75
ROCKER SHAFT	76
<input type="checkbox"/> Rocker	76
<input type="checkbox"/> Shaft	76
ASSEMBLING THE ENGINE ON THE BENCH	77
DIAGRAM SHOWING THE UNDERBLOCK FIXING SCREWS TIGHTENING ORDER	79

	Page
<input type="checkbox"/> Fitting the connecting rod-piston assembly into the cylinder liners	80
ENGINE FLYWHEEL	83
<input type="checkbox"/> Fitting engine flywheel	83
<input type="checkbox"/> Fitting camshaft	84
<input type="checkbox"/> Fitting pump-injectors	85
<input type="checkbox"/> Fitting rocker-arm shaft assembly	85
<input type="checkbox"/> Camshaft timing	86
<input type="checkbox"/> Phonic wheel timing	88
<input type="checkbox"/> Intake and exhaust rocker play adjustment and pre-loading of rockers controlling pump injectors.	89
ENGINE COMPLETION	90
LUBRICATION	93
<input type="checkbox"/> Oil pump	95
<input type="checkbox"/> Overpressure valve	95
<input type="checkbox"/> Oil pressure control valve	96
<input type="checkbox"/> Heat exchanger	96
<input type="checkbox"/> By-pass valve	97
<input type="checkbox"/> Thermostatic valve	97
<input type="checkbox"/> Engine oil filters	97
COOLING	99
<input type="checkbox"/> Description	99
<input type="checkbox"/> Operation	99
<input type="checkbox"/> Water pump	101
<input type="checkbox"/> Thermostat	101
<input type="checkbox"/> Electromagnetic coupling	101
TURBOCHARGER	102
TURBOCHARGING	102
TURBO COMPRESSOR HOLSET HX 40V	104
<input type="checkbox"/> Actuator	107
<input type="checkbox"/> Solenoid valve for VGT control	107

	Page
FUEL FEED	108
<input type="checkbox"/> Replacing injectors-pump	109
<input type="checkbox"/> Injector-pump	109
<input type="checkbox"/> Fuel pump	109
<input type="checkbox"/> Injector Phases	110

Figure 1



78840

F2B ENGINE

VIEWS OF THE ENGINE

ENGINE





Figure 2



52244

F2BE068 I F: POWER-TORQUE CURVES

Max OUTPUT 200 kW

273HP


at 2400 rpm

Max TORQUE 1115 Nm

114 kgm

at 1000 to 1770 rpm

Figure 3



52243

F2BE068 IE: POWER-TORQUE CURVES

Max OUTPUT 221 kW

30HP


at 2400 rpm

Max TORQUE 1110 Nm

113 kgm

at 1000 rpm

Figure 4



47531

F2BE0681B: POWER-TORQUE CURVES

Max OUTPUT 228 kW

310HP


at 2400 rpm

Max TORQUE 1100 Nm

114 kgm

at 1000 to 1950 rpm

Figure 5



47532

F2BE068 1A: POWER-TORQUE CURVES

Max OUTPUT 259 kW

352HP












at 2400 rpm









Max TORQUE 1280 Nm





131 kgm

at 1080 to 1930 rpm















GENERAL CHARACTERISTICS














	Type	F2BE0681A	F2BE0681B	F2BE0681E	F2BE0681F	
	Cycle	Diesel 4 strokes				
	Feeding	Turbocharged with aftercooler				
	Injection	Direct				
	N. of cylinders	6 on-line				
	Diameter	mm		115		
	Stroke	mm		125		
	Total displacement	cm ³		7790		
	Compression ratio	16 ± 0.8				
	Max. power	KW (HP)	259 (352)	228 (310)	221 (301)	200 (273)
		rpm	2400	2400	2400	2400
	Max. torque	Nm (Kgm)	1280 (131)	1115 (114)	1110 (113)	1115 (114)
		rpm	1080 to 1930	1000 to 1950	1000	1000 to 1770
	Engine idling speed, no load	rpm		525 ± 25		
	Maximum engine speed, no load	rpm		2760 ± 20		











	<p>Type</p>	<p>F2B</p>
	<p>VALVE TIMING</p> <p>opens before T.D.C. A</p> <p>closes after B.D.C. B</p> <p>opens before B.D.C. D</p> <p>closes after T.D.C. C</p>	<p>17°</p> <p>31°</p> <p>48°</p> <p>9°</p>
 <p>For timing check</p> <p>Running</p>	<p>X</p> <p>X</p> <p>{ mm</p> <p>{ mm</p> <p>{ mm</p> <p>{ mm</p>	<p>-</p> <p>-</p> <p>0.35 to 0.45</p> <p>0.35 to 0.45</p>
	<p>FEED</p>	<p>Through fuel pump - Filters</p>
	<p>Injection type Bosch</p>	<p>With electronically regulated injectors PDE 30 pump injectors controlled by overhead camshaft</p>
	<p>Nozzle type</p>	<p>-</p>
	<p>Injection order</p>	<p>1 - 4 - 2 - 6 - 3 - 5</p>
	<p>Injection pressure bar</p> <p>Injector calibration bar</p>	<p>1500</p>

	Type	F2B
	SUPERCHARGING Turbocharger type:	Holset, with variable geometry HY 40 V
	LUBRICATION Oil pressure, engine hot (100 °C ± 5 °C): at idling speed bar at maximum speed bar	Forced by gear pump, pressure control valve, oil filter 1.5 5
COOLING	Water pump control Thermostat: starts to open: fully open:	By centrifugal pump, regulating thermostat, viscostatic fan, radiator and heat exchanger By belt N. 1 ~ 85 °C -
 Fiat lubricants Urania Turbo LD (according to E3-96 standard) Urania Turbo (according to E2-96 standard)	OIL FILLING Total capacity at 1st filling liters kg Capacity: - engine sump min level liters kg - engine sump max level liters kg - quantity in circulation that does not flow back to the engine sump liters kg - quantity contained in the cartridge filter (which has to be added to the cartridge filter refill) liters kg	28 25.5 12.5 11.2 23 21 5 2.5 2.3

ASSEMBLY CLEARANCE DATA


























	Type	F2B
CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS		mm
	Cylinder sleeve bore upper $\varnothing 1$ lower	130.200 to 130.225 128.510 to 128.535
	Cylinder liners: outer diameter: upper $\varnothing 2$ lower length L	130.161 to 130.186 128.475 to 128.500
	Cylinder sleeve - crankcase bore upper lower	0.014 to 0.064 0.010 to 0.060
	 Outside diameter $\varnothing 2$	
	Cylinder sleeve inside diameter Protrusion	A* $\varnothing 3$ B* X 0.035 to 0.065
* Available dia. class		
	Pistons: measuring dimension X outside diameter $\varnothing 1$ A• outside diameter $\varnothing 1$ B•• outside diameter $\varnothing 2$	18 114.888 to 114.900 114.898 to 114.910 46.010 to 46.018 114.898 to 114.910
• Class A pistons supplied as spares. •• Class B pistons are fitted in production only and are not supplied as spares.		
	Piston - cylinder sleeve	0.100 to 0.124
	 Piston diameter $\varnothing 1$	-
	Pistons protrusion X	0.32 to 0.99
	Gudgeon pin $\varnothing 3$	45.994 to 46.000
	Gudgeon pin - pin housing	0.010 to 0.024













		F2B	
		mm	
	Piston ring grooves	X1*	2.71 to 2.74
		X 2	2.55 to 2.57
		X3	4.02 to 4.04
		*measured on Ø of 112 mm	
	Piston rings: trapezoidal seal	S1*	2.575 to 2.595 2.470 to 2.490
	lune seal	S2	
	milled scraper ring with slits and internal spring	S3	3.975 to 3.990
		*measured on Ø of 112 mm	
	Piston rings - grooves	1	0.115 to 0.165
		2	0.060 to 0.100
		3	0.030 to 0.065
	 > Piston rings		-
	Piston ring end gap in cylinder liners:	X1	0.35 to 0.50
		X2	0.70 to 0.96
		X3	0.30 to 0.60
	Small end bush housing	Ø 1	49.975 to 50.000
	Big end bearing housing	Ø 2	Rated value 77.000 to 77.030
	Selection classes Ø 2	{ 1 2 3	
	Small end bush diameter outside	Ø 4	
	inside	Ø 3	46.015 to 46.030
	Big end bearing shell	S	Red 2.000 to 2.010 Green 2.011 to 2.020 Yellow 2.021 to 2.030
	Small end bush - housing		0.055 to 0.105
	Piston pin - bush		0.015 to 0.036
	 > Big end bearing shells		0.127 - 0.254 - 0.508
	Connecting rod weight	A	g. 2890 to 2920
	Class	B	g. 2921 to 2950
		C	g. 2951 to 2980












Type		F2B										
		mm										
	Measuring dimension X		125									
	Max. connecting rod axis misalignment tolerance =		0.08									
	Main journals	∅ 1	Rated value 82.910 to 82.940									
	Selection class	<table border="0"> <tr><td>{</td><td>1</td></tr> <tr><td> </td><td>2</td></tr> <tr><td>}</td><td>3</td></tr> </table>	{	1		2	}	3	82.910 to 82.919 82.920 to 82.929 82.930 to 82.940			
	{	1										
		2										
}	3											
Crankpins	∅ 2	Rated value 72.915 to 72.945										
Selection class	<table border="0"> <tr><td>{</td><td>1</td></tr> <tr><td> </td><td>2</td></tr> <tr><td>}</td><td>3</td></tr> </table>	{	1		2	}	3	72.915 to 72.924 72.925 to 72.934 72.935 to 72.945				
{	1											
	2											
}	3											
	Main bearing shells	S1										
	Red		3.000 to 3.010									
	Green		3.011 to 3.020									
	Yellow ●		3.021 to 3.030									
	Big end bearing shells	S2										
	Red		2.000 to 2.010									
	Green		2.011 to 2.020									
	Yellow ●		2.021 to 2.030									
	Main bearing housings	∅ 3	Rated value 89.000 to 89.030									
	Selection class	<table border="0"> <tr><td>{</td><td>1</td></tr> <tr><td> </td><td>2</td></tr> <tr><td>}</td><td>3</td></tr> </table>	{	1		2	}	3	89.000 to 89.009 89.010 to 89.019 89.020 to 89.030			
{	1											
	2											
}	3											
	Bearing shells - main journals		0.040 to 0.080									
	Bearing shells - big ends		0.035 to 0.075									
	Main bearing shells		0.127 - 0.254 - 0.508									
	Big end bearing shells		0.127 - 0.254 - 0.508									
	Main journal, thrust bearing	X1	39.96 to 40.00									
	Main bearing housing, thrust bearing	X2	32.94 to 32.99									
	Thrust washer halves	X3	3.38 to 3.43									
	Driving shaft shoulder		0.11 to 0.30									
	Alignment	<table border="0"> <tr><td>{</td><td>≡</td><td>1</td></tr> <tr><td> </td><td>○</td><td>2</td></tr> <tr><td>}</td><td>/</td><td>1 - 2</td></tr> </table>	{	≡	1		○	2	}	/	1 - 2	≤ 0.05
	{	≡	1									
		○	2									
}	/	1 - 2										
Ovality			0.010									
Taper			0.010									

● Fitted in production only and not supplied as spares

11

 Type	F2B
CYLINDER HEADS - VALVE TRAIN	mm
 Valve guide housings in cylinder head  Ø 1	12.980 to 12.997
 Valve guide  Ø 2  Ø 3	8.023 to 8.038 13.012 to 13.025
 Valve guides - housings in the cylinder heads	0.015 to 0.045
  > Valve guide	-
 Valves:  Ø 4 α  Ø 4 α	7.985 to 8.000 60° 30' ± 7' 30" 7.985 to 8.000 45° + 15'
 Valve stem and its guide	0.023 to 0.053
 Housing in head for valve seat  Ø 1  Ø 1	41.985 to 42.020 40.985 to 41.020
 Outside diameter of valve seat; angle of valve seat in cylinder head:  Ø 2 α  Ø 2 α	42.060 to 42.075 60° - 30' 41.060 to 41.075 45° - 30'
 Recessing of valve  X  X	0.5 to 0.8 1.6 to 1.9
 Between valve seat and head  	0.040 to 0.090

	Type	F2B
		mm
	Valve outside spring height: free height H under a load of: N 454 ± 22 H1 N 840 ± 42 H2	62.6 48.5 36.5
	Injector protrusion X	0.7
	Camshaft bush housing fitted in the cylinder head: I ⇒ 7 Ø	80.000 to 80.030
	Camshaft journal diameter: I ⇒ 7 Ø	75.924 to 75.940
	Camshaft bushing outer diameter: Ø	80.090 to 80.115
	Camshaft bushing inner diameter: Ø	75.990 to 76.045
	Bushings and housings in engine block	0.060 to 0.115
	Bushings and journals	0.050 to 0.121
	Cam lift: 	8.07 7.63 8.80 to 8.82
	Rocker shaft Ø I	37.984 to 38.000

	Type	F2B	
		mm	
	Bushing housing in rocker arms 	41.000 to 41.016	
		53.000 to 53.019	
		42.000 to 42.016	
	Bushing outer diameter for rocker arms: 	41.097 to 41.135	
		53.105 to 53.156	
		42.066 to 42.091	
	Bushing inner diameter for rocker arms: 	38.025 to 38.041	
		50.025 to 50.041	
		38.015 to 38.071	
	Between bushings and housings 	0.081 to 0.135	
		0.086 to 0.156	
		0.050 to 0.091	
	Between rocker arms and shaft 	0.025 to 0.057	
		0.225 to 0.057	
		0.015 to 0.087	
TURBOCHARGER Type End float Radial play		HOLSET, variable geometry - -	

TIGHTENING TORQUES

PART	TORQUE			
		Nm	kgm	
Under-basement fastening screws to cylinder block (see Figure 6) ◆				
Outer screws	First stage : pre-tightening	M10x1.25	25	2.5
Inner screws	Second stage : pre-tightening	M16x2	140	14
Inner screws	Third stage : angle closing	M16x2		60°
Inner screws	Fourth stage : angle closing	M16x2		60°
Outer screws	Fifth stage : angle closing	M10x1.5		90°
Pipe union for piston cooling nozzle		M12X1.5	35 ± 2	3.5 ± 0.2
Intercooler fastening screws to cylinder block ◆ (see Figure 10)				
	pre-tightening		11.5 ± 3.5	1.15 ± 0.35
	tightening		19 ± 3	1.9 ± 0.3
Plug			125 ± 15	12.5 ± 1.5
Spacer and oil sump fastening screws (see Figure 11)			41.5 ± 3.5	4.1 ± 0.3
Gearcase fastening screws to cylinder block			41.5 ± 3.5	4.1 ± 0.3
			63 ± 7	6.3 ± 0.7
			9 ± 3	1.9 ± 0.3
Cylinder head fastening screw: (see Figure 7) ◆				
First stage	pre-tightening		50	5
Second stage	pre-tightening		100	10
Third stage	angle closing			90°
Fourth stage	angle closing			75°
Rocker arm shaft fastening screw ◆				
First stage	pre-tightening		40	4
Second stage	pre-tightening			60°
Locknut for rocker arm adjusting screw ◆			39 ± 5	3.9 ± 5
Screws for injector fastening brackets ◆			36.5	3.65
Shoulder plate fastening screws to head ◆			23.5	2.35
Engine support bracket fastening screws to cylinder head			74 ± 8	7.4 ± 0.8
Gear fastening screws to camshaft: ◆				
First stage	pre-tightening		50	5
Second stage	pre-tightening			50°
Phonic wheel fastening screws to distribution gear			8.5 ± 1.5	0.8 ± 0.1
Exhaust pipe fastening screws • (see Figure 8)				
	pre-tightening		32.5 ± 7.5	3.2 ± 0.7
	tightening		47 ± 2.5	4.7 ± 0.2
Engine brake actuator cylinder fastening screws			24.5 ± 2.5	2.4 ± 0.2
Connecting rod cap fastening screws: ◆				
First stage	pre-tightening		50	5
Second stage	pre-tightening			40°
Engine flywheel fastening screws: ◆		M16x1.5x58		
First stage	pre-tightening		100	10
Second stage	pre-tightening			60°
Engine flywheel fastening screws: ◆		M16x1.5x110		
First stage	pre-tightening		100	10
Second stage	pre-tightening			120°
Flywheel pulley fastening screws to crankshaft : ◆				
First stage	pre-tightening		70	7
Second stage	pre-tightening			50°

◆ Lubricate with oil MOLYKOTE before assembly

• Lubricate with graphitized oil before assembly

TIGHTENING TORQUES

PART	TORQUE	
	Nm	kgm
Damper flywheel fastening screws: ♦	115 ± 15	11.5 ± 1.5
Idler gear pin fastening screws: ♦		
First stage pre-tightening	30	3
Second stage pre-tightening	90°	
Idle gear link rod fastening screw	24.5 ± 2.5	2.4 ± 0.2
Oil pump fastening screw	24.5 ± 2.5	2.4 ± 0.2
Oil pump suction rose fastening screw	24.5 ± 2.5	2.4 ± 0.2
Front cover fastening screw to cylinder block ♦	19 ± 3	1.9 ± 0.3
Control unit fastening screw to cylinder block ♦	19 ± 3	1.9 ± 0.3
Supply pump fastening screw to gearcase ♦	19 ± 3	1.9 ± 0.3
Fuel filter support fastening screw to cylinder head ♦	37 ± 3	3.7 ± 0.3
Turbo-compressor fastening screws and nuts • (see Figure 9)		
pre-tightening	32.5 ± 7.5	3.2 ± 0.7
tightening	46 ± 2	4.6 ± 0.2
Water pump fastening screw to cylinder block	24.5 ± 2.5	2.4 ± 0.2
Pulley fastening screw to hub	55 ± 5	5.5 ± 0.5
Rocker arm cover fastening screws (see Figure 12)	9	0.9
Thermostat box fastening screws to cylinder head	24.5 ± 2.5	2.4 ± 0.2
Automatic tightener fastening screws to cylinder block	45 ± 5	4.5 ± 0.5
Fixed tightener fastening screws to cylinder block	105 ± 5	10.5 ± 0.5
Fan support fastening screws to cylinder block	24.5 ± 2.5	2.4 ± 0.2
Starter fastening screws	44 ± 4	4 ± 0.4
Air heater on cylinder head	30 ± 3	3 ± 0.3
Air compressor fastening screw to cylinder head	74 ± 8	7.4 ± 0.8
Air compressor control gear fastening nut	170	17 ± 1
Hydraulic power steering pump gear fastening nut	46.5 ± 4.5	4.6 ± 0.4
Air conditioner compressor fastening screw to support	24.5 ± 2.5	2.4 ± 0.2
Air conditioner compressor support fastening screw to cylinder block	44 ± 4	4.4 ± 0.4
Alternator support fastening screw to cylinder block	44 ± 4	4.4 ± 0.4
Alternator bracket fastening screw to cylinder block	24.5 ± 2.5	2.4 ± 0.2
Water pipe unions	35	3.5
Water temperature sensor	32.5 ± 2.5	3.2 ± 0.2
♦ Lubricate with oil MOLYKOTE before assembly		
• Lubricate with graphitized oil before assembly		

TIGHTENING TORQUES

PART	TORQUE	
	Nm	kgm
Engine brake solenoid valve fastening screws	32.5 ± 2.5	3.2 ± 0.2
Flywheel rev sensor fastening screw	8 ± 4	0.8 ± 0.2
Camshaft rev sensor fastening screw	8 ± 2	0.8 ± 0.2
P.D.E solenoid connector fastening screw	1.62 ± 0.3	0.1 ± 0.3
Overboost pressure sensor fastening screw	8 ± 2	0.8 ± 0.2
Absolute pressure sensor fastening screw	22.5 ± 2.5	2.2 ± 0.2
P.W.M. control valve fastening screw/nut	8 ± 2	0.8 ± 0.2
Fuel/coolant temperature sensor	35	3.5
Coolant temperature indicator	23.5 ± 2.5	2.3 ± 0.2
Filter clogging sensor	10	1
Oil temperature switch	25 ± 1	2.5 ± 0.1
Oil pressure sensor	25 ± 1	2.5 ± 0.1
Oil clogging sensor	55 ± 5	5.5 ± 0.5
Electric wire fastening screw	8 ± 2	0.8 ± 0.2
Heater fastening screw	12.5 ± 2.5	1.2 ± 0.2

UNDERBLOCK FIXING SCREWS TIGHTENING SEQUENCE

Figure 6






Figure 7



44900

DIAGRAM OF CYLINDER HEAD FIXING SCREWS TIGHTENING SEQUENCE


Figure 8



45359

DIAGRAM OF EXHAUST MANIFOLD FIXING SCREWS TIGHTENING SEQUENCE

Figure 9




45360

DIAGRAM OF TURBOCHARGER FIXING SCREWS AND NUTS TIGHTENING SEQUENCE

SEQUENCE: Preliminary tightening 4 - 3 - 1 - 2
 Tightening 1 - 4 - 2 - 3


Figure 10



455361

DIAGRAM OF HEAT EXCHANGER FIXING SCREWS TIGHTENING SEQUENCE


Figure 11



45362

DIAGRAM OF ENGINE OIL SUMP FIXING SCREWS TIGHTENING SEQUENCE

Figure 12









45363

DIAGRAM OF ROCKER ARM CAP FIXING SCREWS TIGHTENING SEQUENCE

TOOLS

TOOL NO.	DESCRIPTION
99305019	Full-optional tool-kit to rectify valve seat
99305047	Equipment for spring load check
99322230	Rotary telescopic stand
99340051	Extractor for crankshaft front gasket
99340052	Extractor for crankshaft rear gasket
99340205	Percussion extractor

TOOLS

TOOL NO.	DESCRIPTION
99342148	Injector extractor 
99342149	Extractor for injector-holder 
99346245	Tool to install the crankshaft front gasket 
99346246	Tool to install the crankshaft rear gasket 
99348004	Universal extractor for 5 to 70 mm internal components 
99350072	Box wrench for transmission gear support fixing screws 







TOOLS

TOOL NO.	DESCRIPTION
99350074	Box wrench for block junction bolts to the underblock
99360144	Skid retaining tools (12+6) for rocker arm adjusting screws during rocker arm shaft removal/ refitting
99360177	Injector housing plug
99360184	Pincers for removing and refitting circlips and pistons (105-160 mm)
99360264	Tool to take down-fit engine valves
99360288	Tool to remove valve guide

TOOLS

TOOL NO.	DESCRIPTION
99360292	Tool to install gasket on valve guide
99360294	Tool to drive valve guide
99360314	Tool to remove cartridge filters
99360321	Tool to rotate engine flywheel
99360334	Tool for checking cylinder barrel projection.
99360335	Cylinder barrel compression cap (to be used with 99360334)







TOOLS

TOOL NO.	DESCRIPTION	
99360351		Tool to stop engine flywheel
99360487		Tool to take down and fit back camshaft bushes
99360500		Tool to lift crankshaft
99360551		Bracket to take down and fit engine flywheel
99360558		Tool to lift and transport rocker shaft
99360585		Balance for lifting and handling engine







TOOLS

TOOL NO.	DESCRIPTION
99360605	Belt to insert piston in cylinder liner (60 - 125 mm)
99360612	Engine flywheel timing pin
99360613	Tool for timing of phonic wheel on timing gear
99360703	Tool to stop cylinder liners
99360706	Tool to extract cylinder liners
99360724	Tool to extract the cylinder liners (to be used with 99360723)

TOOLS

TOOL NO.	DESCRIPTION
99361035	 Brackets fixing the engine to rotary stand 99322230
99365054	 Tool for injector holder heading
99370415	 Tool to detect cylinder liner projections (use with 99395603)
99378100	 Tool for printing engine identification plates (to be used with special punches)
99378101	 Punches (A) for printing engine identification plates (to be used with 99378100)
99378102	 Punches (B) for printing engine identification plates (to be used with 99378100)

TOOLS

TOOL NO.	DESCRIPTION
99378105	 Punches (E) for printing engine identification plates (to be used with 99378100)
99378106	 Punches (F) for printing engine identification plates (to be used with 99378100)
99389834	 Dynamometric screwdriver to calibrate screws for injector solenoid valve
99390310	 Valve guide sleeker
99390772	 Tool to remove residues from injector holder
99390804	 Tool to thread injector holders to be extracted

TOOLS

TOOL NO.	DESCRIPTION
99394014	Guide bush (to be used with 99394041 or 99394043)
99394041	Cutter to rectify injector holder housing (to be used with 99394015)
99394043	Reamer to rectify injector holder lower side (to be used with 99394015)
99395215	Gauge for centre distance check between camshaft and idle gear
99395216	Measuring pair for angular tightening with 1/2" and 3/4" square couplings
99395363	Complete square to check connecting rod squaring

TOOLS





TOOL NO.	DESCRIPTION
99395603	Dial gauge (0 - 5 mm)
	
99395687	Reaming gauge (50-178 mm)
	
99396033	Centering ring of crankshaft front cap
	


Figure 13



78839

ENGINE - LONGITUDINAL SECTION

Figure 14




ENGINE - CROSS SECTION

78841

54010 DISMANTLING THE ENGINE ON THE BENCH

Figure 15




47562

Before dismantling the engine on the rotary stand 99322230, remove the following components:

- starter (2)
- turbocharger soundproofing shield (1)


Figure 16



47563

Remove the soundproofing shield (1) and plug (2)


Figure 17



47601

Fix the engine to the rotary stand 99322230, by means of brackets 99361035 (1), remove the fan.

Figure 18




73579

Using an appropriate tool (2), operate in the direction of the arrow, and remove the belt (1) driving the water pump, alternator and fan.

Take out the screws and remove the electromagnetic coupling (3).

Figure 19




60489

Remove the following components:

- thermostat unit (6) fitted with turbine actuator pressure sensor (7);
- alternator (2);
- pulley support (1);
- water pump (8) and piping;
- automatic belt tightener support (3);
- fixed belt tightener (9);
- damping flywheel (4) and pulley underneath it;
- automatic belt tightener (5);
- disconnect all the electric connections and the sensors.


Figure 20



60490

Fit the extractor 99340053 (2) and remove the engine crankshaft seal gasket (1), remove the cover (3).

Figure 21




60491

Remove the following components:

- water outlet line (2);
- oil delivery line (4);
- actuator air line (3);
- water delivery line (6);
- oil return line (7);
- turbocharger (5);
- exhaust manifold (1).


Figure 22



47564

Load the belt tensioner spring by tool (4), acting in the direction shown by the arrow, on the head of the screw fixing the roller. The screw cannot be untightened as the thread is counterclockwise. Remove the belt (3). By tool (2), act in the direction shown by the arrow and remove the fan, alternator and water pump control belt (1).

Figure 23




47565

Remove the following components:

- alternator (1);
- belt tightener support (2);
- air conditioner compressor (3);
- flywheel (4);
- water pump and piping (5);
- fan pulley spacer (6);
- thermostat unit (7).


Figure 24



45254

Install extractor 99340051 (2) and remove the seal gaskets (1). Unscrew the screws and remove the cover. Disconnect all electric connections and sensors.


Figure 25



47566

Remove the following components: oil supply lines (1); water cooling supply lines (3); water discharge lines (2); oil return lines (4); turbocharger (5); exhaust manifold (6).


Figure 26



47567

Unscrew the oil filter (1) by tool 99360314 (2). Unscrew the screws and remove the entire heat exchanger (3).


Figure 27



47587

Remove the following components: intake manifold (6); support for fuel filter (1); fuel lines (2); fuel pump (3); compressor (4); control unit (5).

Figure 28




70708

To remove the P.T.O. (if applicable):

- Disconnect the oil pipe (1).
- Unscrew the 4 screws (2) and (3).


Figure 29



84377

Remove the rocker arm cover (1), take off the screws (2) and remove: the cover (3), the filter (5) and the gaskets (4 and 6). Take off the screws (8) and remove the blow-by case (7).


Figure 30



45661

Unscrew the screws (2), by using the proper wrench and remove the gear (1) with the phonic wheel.


Figure 31



45265

Unscrew the screws (1); tighten a screw in a reaction hole and remove the shoulder plate (3), remove the sheet gasket.


Figure 32



47568

By means of a properly splined wrench, untighten screws (2) and remove the transmission gear (1)


Figure 33



47568

Stop the engine flywheel (3) rotation by means of tool 99360351 (1), untighten the fixing screws (2) and remove the engine flywheel.


Figure 34



45257

Apply extractor 99340052 (2) and pull out the seal gasket (1).


Figure 35



47569

Untighten the screws (1) and take down the gear box (2).


Figure 36



In sequence, take out the:

- if the P.T.O. control gear (1) is present;
- idle gear (2);
- oil pump gear (3).


Figure 37



45259

- Remove the check springs (2) of the exhaust brake lever;
- Untighten the fixing screws (1) of rocker arm shaft.


Figure 38



73533


- Using tool 99360144 (3), constrain the blocks (4) to the rockers (2).
- Apply tool 99360553 (1) to the rocker holder shaft (5) and remove the shaft (5) from the cylinder head.

Figure 39




- Remove the piping (1) for exhaust brake pins;
- Untighten screws and remove electric connections (2) from solenoid valves;
- Untighten fixing screws (3) of injector brackets (4).

Figure 40




- Remove injectors (2)
- If this operations is difficult, use extractor 99342148 (1). Install plugs 99360177 instead of injectors.

Figure 41




- Remove the camshaft and the fixing screws on cylinder heads
- By means of wire ropes, lift the cylinder head (1) and remove seals (2).

Figure 42




Untighten screws (2) and remove the engine oil sump (1) with spacer (3) and seal .

Figure 43




Untighten screws and remove suction rose (1).

Figure 44



Rotate the block (1) to the vertical position.


Figure 45



47575

Untighten screws (2) fixing the connecting rod cap (3) and remove it. Remove the connecting rod-piston assembly from the upper side. Repeat these operations for the other pistons.


Figure 46



47576

By means of proper and splined wrenches, untighten the screws (1) and (2) and remove the under-block (3).


Figure 47



47570

Remove the crankshaft (2) with tool 99360500 (1).

Figure 48



47571

Remove the crankshaft half-bearings (1), untighten the screws and remove oil spray nozzles (2). Take down cylinder liners as specified in the relative paragraph on page 49.




After disassembling the engine, thoroughly clean disassembled parts and check their integrity. Instructions for main checks and measures are given in the following pages, in order to determine whether the parts can be re-used.

REPAIR OPERATIONS

540410 CYLINDER BLOCK
540420 Checks and measurements

Figure 49 (Demonstration)



34994

Internal diameter of the cylinder liners is checked for ovalization, taper and wear, using a bore dial (1) centesimal gauge 99395687 (2) previously reset to ring gauge (3), diameter 115 mm.



 If a 115 ring gauge is not available use a micrometer caliper.

Figure 50




47439

- 1 = 1st measuring
- 2 = 2nd measuring
- 3 = 3rd measuring

Carry out measurements on each cylinder liner at three different levels and on two (A-B) surfaces, to one another perpendicular, as shown in Figure 50.


Figure 51



47440

- A = Selection class \varnothing 115 to 115.012 mm
- B = Selection class \varnothing 115.010 to 115.022 mm

In case of maximum wear max 0.150 mm or maximum ovalization max 0.100 mm compared to the values indicated in the figure, the liners must be replaced as they cannot be ground, lapped or trued.

 Cylinder liners are equipped with spare parts with "A" selection class.





Figure 52



47441


- A = \varnothing 130.200 to 130.225 mm
- B = \varnothing 128.510 to 128.535 mm
- C = \varnothing 130.161 to 130.186
- D = \varnothing 128.475 to 128.500 mm

The figure shows the outer diameters of the cylinder liners and the relative seat inner diameters.

The cylinder liners can be extracted and installed several times in different seats, if necessary.


CYLINDER LINERS

Figure 53



BLOCK WITH CYLINDER LINERS


Figure 54



Selection class {
 A mm 115.000 to 115.012
 B mm 115.010 to 115.022

CYLINDER LINERS MAIN DATA

Figure 55




DETAIL "X"
 "A" = Selection class marking area

540420 Replacing cylinder liners

Removal

Figure 56




47577

Place details 99360706 (1 and 2) and plate 99360724 (4) as shown in the figure, by making sure that the plate (4) is properly placed on the cylinder liners. Tighten the screw nut (1) and remove the cylinder liner (3) from the block.

Fitting and checking protrusion

Figure 57



16798


Always replace water sealing rings (3, 4 and 5). Install the adjustment ring (1) on the cylinder liner (2); lubricate lower part of liner and install it in the cylinder unit using the proper tool.



The adjustment ring (1) is supplied as spare parts in the following thicknesses: 0.08 mm - 0.10 mm - 0.12 mm.



Figure 58




77812

Check cylinder barrel protrusion with tool 99360334 (1-2-3-4) and tighten screw (1) to 170 Nm. With dial gauge 99395603 (5) placed on base 99370415 (6). Measure the cylinder barrel protrusion compared to the cylinder head supporting plane, it must be 0,035 to 0,065 mm (Figure 59); otherwise replace the adjusting ring (1, Figure 57) fitted with spare parts having different thickness.

Figure 59

0,035 ÷ 0,065




49017

CYLINDER LINER PROTRUSION

Figure 60

(Demonstration)




35012

When the installation is completed, block the cylinder liners (1) to the block (2) with studs 99360703 (3).

5408 CRANKSHAFT

Figure 61




49018

MAIN DATA FOR THE CRANK SHAFT PINS AND THE HALF BEARINGS

Check the condition of the journals and the big end pins; there must no be signs of scoring, ovalization or excessive wear.
The data given refer to the normal diameter of the pins.


Figure 62



47537

X. Detail of main journals connections

Figure 63




47538

Y. Detail of crank pins connections

540812 Measuring main journals and crank pins


Before grinding the crank pins using a micrometer (1), measure the main journals and the crank pins (2) and decide, on the basis of the undersizing of the bearings, the final diameter to which the pins are to be ground.

Figure 64



! It is advisable to enter the values found in a table (Figure 66).

Figure 65




During grinding, pay attention to journal and crank pins values specified in figures 62 and 63.

! All journals and crank pins must also be ground to the same undersizing class, in order to avoid any alteration to shaft balance.

Figure 66

Fill in this table with the measurements of the main journals and the crank pins.

MAIN JOURNALS



CRANK PINS

36061

PRELIMINARY MEASUREMENT OF MAIN AND BIG END BEARING SHELL SELECTION DATA

For each of the journals of the crankshaft, it is necessary to carry out the following operations:

MAIN JOURNALS:

- Determine the class of diameter of the seat in the crankcase.
- Determine the class of diameter of the main journal.
- Select the class of the bearing shells to mount.

CRANKPINS:




- Determine the class of diameter of the seat in the connecting rod.
- Determine the class of diameter of the crankpin.
- Select the class of the bearing shells to mount.

DEFINING THE CLASS OF DIAMETER OF THE SEATS FOR BEARING SHELLS ON THE CRANKCASE

On the front of the crankcase, two sets of numbers are marked in the position shown (Figure 67 at top).

- The first set of digits (four) is the coupling number of the crankcase with its base.
- The following seven digits, taken singly, are the class of diameter of each of the seats referred to (Figure 67 at bottom).
- Each of these digits may be **1**, **2** or **3**.

Figure 67



Selecting the main and big end bearing shells



To obtain the required assembly clearances, the main and big end bearing shells need to be selected as described hereunder.



This operation makes it possible to identify the most suitable bearing shells for each of the journals (the bearing shells, if necessary, can have different classes from one journal to another).

Depending on the thickness, the bearing shells are selected in classes of tolerance marked by a coloured sign (red-green – red/black – green/black).


The following tables give the specifications of the main and big end bearing shells available as spares in the standard sizes (STD) and in the permissible oversizes (+0.127, +0.254, +0.508).

Figure 68

	STD	+0.127	+0.254	+0.508
red	2.000 to 2.010		2.127 to 2.137	2.254 to 2.264
red/black		2.063 to 2.073		
green	2.011 to 2.020		2.138 to 2.147	2.265 to 2.274
green/black		2.074 to 2.083		
yellow*	2.021 to 2.030			
yellow/black*		2.084 to 2.093		



	STD	+0.127	+0.254	+0.508
red	3.000 to 3.010		3.127 to 3.137	2.254 to 3.264
red/black		3.063 to 3.073		
green	3.011 to 3.020			
green/black		3.074 to 3.083		
yellow*	3.021 to 3.030			
yellow/black*		3.084 to 3.093		



* Fitted in production only and not supplied as spares

DEFINING THE CLASS OF DIAMETER OF THE MAIN JOURNALS AND CRANKPINS (Journals with nominal diameter)





Main journals and crankpins: determining the class of diameter of the journals.

Three sets of numbers are marked on the crankshaft in the position shown by the arrow (Figure 69 at top):

- The first number, of five digits, is the part number of the shaft.
- Under this number, on the left, a set of six digits refers to the crankpins and is preceded by a single digit showing the status of the journals (1 = STD, 2 = -0.127), the other six digits, taken singly, give the class of diameter of each of the crankpins they refer to (Figure 69 at top).
- The set of seven digits, on the right, refers to the main journals and is preceded by a single digit: the single digit shows the status of the journals (1 = STD, 2 = -0.127), the other seven digits, taken singly, give the class of diameter of each of the main journals they refer to (Figure 69 at bottom).

Figure 69

CLASS	CRANKPIN NOMINAL DIAMETER
1	72.915 to 72.924
2	72.925 to 72.934
3	72.935 to 72.945




CLASS	MAIN JOURNALS NOMINAL DIAMETER
1	82.910 to 82.919
2	82.920 to 82.929
3	82.930 to 82.940

Selection of main half-bearings (nominal diameter pins)

After detecting, for each journal, the necessary data on block and crankshaft, select the type of half-bearings to be used, in compliance with the following table:

Figure 70


STD.



1

2

3



1

green

green

green


green

green

green

2

red



green

green

red

green

green

3

red

red

red

red

red

red

Selection of main half-bearings (rectified pins)


If the journals have been rectified, the procedure described cannot be applied. In this case, make sure that the new diameter of the journals is as specified on the table and install the only half-bearing type required for this undersizing.

Figure 71

red/black =
mm 3.063 to 3.073

green/black =
mm 3.063 to 3.073


-0.127



	1	2	3
82.784 82.793	green/black	green/black	green/black
	green/black	green/black	green/black
82.794 82.803	red/black	green/black	green/black
	red/black	green/black	green/black
82.804 82.814	red/black	red/black	red/black
	red/black	red/black	red/black

-0.254


red =
mm 3.127 to 3.137



	1	2	3
82,666 82,686	red	red	red
	red	red	red

-0.508

red =
mm 3.254 to 3.264



	1	2	3
82.412 82.432	red	red	red
	red	red	red

SELECTING THE BIG END BEARING SHELLS (JOURNALS WITH NOMINAL DIAMETER)

There are three markings on the body of the connecting rod in the position shown in the view from "A":

- 1 Letter indicating the class of weight:
 - A = 2890 to 2920 g.
 - B = 2921 to 2950 g.
 - C = 2951 to 2980 g.
- 2 Number indicating the selection of the diameter of the big end bearing seat:
 - 1 = 77.000 to 77.010 mm
 - 2 = 77.011 to 77.020 mm
 - 3 = 77.021 to 77.030 mm
- 3 Numbers identifying the cap-connecting rod coupling.

The number, indicating the class of diameter of the bearing shell seat may be **1, 2** or **3**.

Determine the type of big end bearing to fit on each journal by following the indications in the table (Figure 73).

Figure 72






Figure 73

STD.



Class	1	2	3
1	green	green	green
	green	green	green
2	red	green	green
	red	green	green
3	red	red	red
	red	red	red

Selection of connecting rod half-bearings (rectified pins)



If pins have been rectified, the procedure described must be applied. In this case, (for each undersizing) determine the tolerance field the new big end pins belong to, and install the half-bearings identified according to the relative table.

Figure 74

red/black =
mm 2.074 to 2.083

green/black =
mm 2.063 to 2.073



-0.127



	1	2	3
72.789 72.798	green/black	green/black	green/black
	green/black	green/black	green/black
72.799 72.808	red/black	green/black	green/black
	red/black	green/black	green/black
72.809 72.818	red/black	red/black	green/black
	red/black	red/black	green/black

-0.254



red
mm 2.127 to 2.137
green =
mm 2.138 to 2.147



	1	2	3
72.671 72.680	red	green	green
	red	green	green
72.681 72.691	red	red	green
	red	red	green

-0.508

red =
mm 2.254 to 2.264
green =
mm 2.265 to 2.274




	1	2	3
72.417 72.426	red	green	green
	red	green	green
72.427 72.437	red	red	green
	red	red	green

540815 Replacing the timing control gear and the oil pump

Check that the teeth of the gears are not damaged or worn, otherwise remove them using the appropriate extractor.

Figure 75




After fitting the gear (1) on the crankshaft (2), heat it for ~ 15 minutes in an oven at temperature not higher than 180°C.

Let them cool down after the installation.

If changing the pin (3), after fitting it on, check it protrudes from the crankshaft as shown in the figure.

540811 Checking main journal installation clearance


Figure 76



Install the oil spray nozzles (2) and have the dowel coincide with the block hole (3).


Install the half-bearings (1) on the main bearings.

Figure 77



Using the hoist and hook 99360500 (1) mount the driving shaft (2).


Figure 78



Install the half-bearings (1) on the main bearings in the underblock (2).

Check the installation clearance between the main journals and the relative bearings as follows:


Figure 79



49022

Place a piece of calibrated wire on the journal of the crankshaft (2), parallel to the longitudinal axis; install the underblock (1), by hoist and appropriate hooks.


Figure 80



47578

☐ Lubricate inside screws (1) con UTDM oil, and tighten them by dynamometric wrench to 140 Nm torque, thus with 60° angle closing, following the diagram in Figure 81.


Figure 81



44898

Diagram showing the tightening order of the screws fixing the lower under-block to the block

Figure 82




47579

☐ Remove the under-block

The clearance between the main bearings and the journals is obtained by comparing the calibrated wire length (2) at the maximum deflection point, with the calibrated scale on the coating (1) containing the calibrated wire (1). Numbers shown on the scale specify the clearance in coupling millimeters. If the clearance obtained is different from the clearance required, replace the half-bearings and repeat this check.

Checking crankshaft end float

Figure 83




47588

End float is checked by placing a magnetic dial gauge (1) on the crankshaft (2), as shown in the figure. If the value obtained is higher than specified, replace the rear thrust half-bearings and repeat this check.

5408 PISTON-CONNECTING ROD ASSEMBLY

Figure 84



47580

PISTON CONNECTING ROD ASSEMBLY

- 1. Connecting rod body - 2. Half bearings - 3. Connecting rod cap - 4. Cap fastening screws - 5. Split ring - 6. Scraper ring with spiral spring - 7. Bevel cut sealing ring - 8. Trapezoidal sealing ring - 9. Piston pin - 10. Piston


Make sure the piston does not show any trace of seizing, scoring, cracking; replace as necessary.

Pistons are equipped with three elastic rings: a sealing ring, a trapezoidal ring and a scraper ring.

Pistons are grouped into classes A and B for diameter.

Removal


Figure 85



49023

Removal of the piston split rings (2) using the pliers 99360184 (1).


Figure 86



49024

Remove the piston pin split rings (2) using the round-tipped pliers (1).

Figure 87




49025

Remove the piston pin (1).
If removal is difficult use the appropriate beater.

Measuring the diameter of the pistons


Figure 88



47584

Using a micrometer (2), measure the diameter of the piston (1) to determine the assembly clearance; the diameter should be measured at the specified value.

Figure 89



32618

Measuring the gudgeon pin diameter (1) with a micrometer (2).

Conditions for correct gudgeon pin-piston coupling


Figure 90



49026

Lubricate the pin (1) and the relevant housing on the piston hubs with engine oil; piston must be inserted with a slight finger pressure and it should not come out by gravity.

Figure 91




MAIN DATA ON PISTONS, AND PISTONS RINGS

77816

* Values are determined on Ø of 112 mm.

540842 Piston rings


Figure 92



16552

Check the thickness of the piston ring (2) using a micrometer (1).


Figure 93



16552

Check the clearance between the sealing rings (2) and the relative piston housings (1) using a thickness gauge (3).


Figure 94



3513

The sealing ring (2) of the 1° cavity is trapezoidal. Clearance "X" between the sealing ring and its housing is measured by placing the piston (1) with its ring in the cylinder barrel (3), so that the sealing ring is half-projected out of the cylinder barrel.

Figure 95



36134

Check the opening between the ends of the sealing rings (1), using a thickness gauge (2), entered in the cylinder barrel (3). If the distance between ends is lower or higher than the value required, replace split rings.

540830 CONNECTING ROD

Figure 96


Data concerning the class section of connecting rod housing and weight are stamped on the big end.



When installing connecting rods, make sure they all belong to the same weight class.


DIAGRAM CONNECTING ROD MARKS

- 1 Letter indicating the weight class:
 A = 2890 to 2920 g.
 B = 2921 to 2950 g.
 C = 2951 to 2980 g.
- 2 Number indicating the selection of diameter for the big end bearing housing:
 1 = 77.000 to 77.010 mm
 2 = 77.011 to 77.020 mm
 3 = 77.021 to 77.030 mm
- 3 Numbers identifying cap-connecting rod coupling



47557

Figure 97




44927

MAIN DATA - BUSH, CONNECTING ROD, PIN AND HALF-BEARINGS
 * Values to be obtained after installing the bush

Checking connecting rod alignment

Figure 98




Checking axis alignment

Check the alignment of the axes of the connecting rods (1) with device 99395363 (5), proceeding as follows:

- Fit the connecting rod (1) on the spindle of the tool 99395363 (5) and lock it with the screw (4).
- Set the spindle (3) on the V-prisms, resting the connecting rod (1) on the stop bar (2).

Checking torsion

Figure 99




Check the torsion of the connecting rod (5) by comparing two points (A and B) of the pin (3) on the horizontal plane of the axis of the connecting rod.

Position the mount (1) of the dial gauge (2) so that this pre-loads by approx. 0.5 mm on the pin (3) at point A and zero the dial gauge (2). Shift the spindle (4) with the connecting rod (5) and compare any deviation on the opposite side B of the pin (3): the difference between A and B must be no greater than 0.08 mm.

Checking bending

Figure 100



Check the bending of the connecting rod (5) by comparing two points C and D of the pin (3) on the vertical plane of the axis of the connecting rod.

Position the vertical mount (1) of the dial gauge (2) so that this rests on the pin (3) at point C.

Swing the connecting rod backwards and forwards seeking the highest position of the pin and in this condition zero the dial gauge (2).

Shift the spindle (4) with the connecting rod (5) and repeat the check on the highest point on the opposite side D of the pin (3). The difference between point C and point D must be no greater than 0.08 mm.

Mounting the connecting rod - piston assembly


Carry out the steps for removal described on page 61 in reverse order.



The connecting rod screws can be reused as long as the diameter of the thread is not less than 13.4 mm.

Mounting the piston rings

Figure 101




To fit the piston rings (1) on the piston (2) use the pliers 99360184 (3).

The rings need to be mounted with the word "TOP" (4) facing upwards. Direct the ring openings so they are staggered 120° apart.

Fitting the connecting rod-piston assembly into the piston liners

Figure 102




Install half-bearings (1), selected as specified on page 66, on both the connecting rod and the cap.

 As spares, class A pistons are provided and can be fitted also to cylinder barrels belonging to class B.

Fit the connecting rod-piston assemblies (1) into the piston liners (2) using band 99360605 (1, Figure 104). Check the following:


- the openings of the split rings are offset by 120°;

Figure 103



- 1 Connecting rod-piston assembly
- 2 Marking area on the piston crown of ideogram specifying the assembly position and the selection class
- 3 Connecting rod marking area (see fig. 96).

Figure 104



- all pistons belong to the same class, A or B;
- ideogram stamped on the piston crown is placed toward the engine flywheel, or the cavity, on the piston cover, corresponds to the position of the oil spray nozzles.

Piston protrusion check


Once assembly is complete, check piston protrusion from cylinder barrels: it must be 0.32-0.69 mm.

540831 Checking assembly clearance of big end pins

To check the clearance proceed as follows:

Connect the connecting rods to the relative main journals, place a length of calibrated wire on the latter.

Figure 105



47594

Install the connecting rod caps (1) with half-bearings; tighten the connecting rod cap fixing screws (2) to 50 Nm (5 kgm) torque. By tool 99395216 (3), tighten the screws further at 40° angle.


Remove the caps and check the clearance by comparing the width of the calibrated wire with the scale calibration on the envelope containing the wire.

540610 CYLINDER HEAD

Before taking down the cylinder head, check the seal using the appropriate tool; in case of leakage replace the cylinder head.

Valve removal

Figure 106




47583

Install and fix tool 99360264 (2) with bracket (4); tighten by lever (1) until cotters are removed (3); remove the tool (2) and the upper plate (5), the spring (6) and the lower plate (7). Repeat the operation on all the valves. Turn the cylinder head upside down and remove the valves (8).

Checking the planarity of the head on the cylinder block

Figure 107

(Demonstration)



36159

The planarity (1) is checked using a ruler (2) and a thickness gauge (3). If deformations exist, surface the head using proper surface grinder; the maximum amount of material to be removed is 0.2 mm.




After leveling, make sure that valve sinking and injector protrusion are as described in the relative paragraph.

540622 VALVE

Removing deposits and checking the valves


Figure 108



48625

Remove carbon deposits using the metal brush supplied. Check that the valves show no signs of seizure or cracking. Check the diameter of the valve stem using a micrometer (see fig. 109) and replace if necessary.

Figure 109



47584


MAIN DATA - VALVES AND VALVE GUIDES

* Values to be obtained after installing the valve guides

Check, by means of a micrometer, that valve stem diameters are as specified; if necessary, grind the valves seat with a grinder, removing the minimum quantity of material.

540667 VALVE GUIDES

Figure 110



INSTALLATION DIAGRAM FOR VALVE GUIDES AND VALVES

47509

* Values to be obtained after installing the guide valves


Replacing of valve guides

Remove valve guides by means of tool 99360288. Install by means of tool 99360288 equipped with part 99360294, which determines the exact installation position of valve guides into the cylinder heads; if they are not available, install the valve guides in the cylinder head so that they project out by mm 16.3 to 16.7 (fig. 110). After installing the valve guides, smooth their holes with sleeker 99390310.

Replacing - Reaming the valve seats

To replace the valve seats, remove them using the appropriate tool.

Figure 111



Ream the valve seats (2) on cylinder head using tool 99305019 (1).

! Valve seats must be reamed whenever valves or valve guides are replaced or ground.


After reaming the valve seats, use tool 99370415, to make sure that the valve position, with respect to the cylinder head surface, is the following:

- 0.5 to -0.8 mm (recessing) of exhaust valves;
- 1.6 to 1.9 mm (recessing) of discharge valves.

540613 REPLACING INJECTOR HOLDER CASES

Removal

Figure 112




To replace the injector case (2), act as follows:

- thread the case (2) with tool 99390804 (1).

Carry out operations described in figs. 112-115-116-117 by fixing tools to the cylinder head by means of bracket A.


Figure 113



45631

- fasten extractor 99342149 (2) to case (3), by tightening the nut (1), and pull out the case from cylinder head.


Figure 114



45633

- Remove any residue (1), with tool 99390772 (2), from the cylinder head groove.


Figure 115



45635

- Lubricate sealing rings (3) and fit them to the case (4); fix tool 99360554 (2) to the cylinder head by means of bracket A, install the new case, tighten the screw (1), upsetting the case lower part.


Figure 116



45632

- Adjust the casing hole (3) with borer 99394043 (1) and guide bushing 99394014 (2).

Figure I 17




45636

- Through miller 99394041 (1) and bushing 99394014 (2), ream the injector seat in the case (3), check the injector protrusion from the cylinder head plane which must be 0.7 mm.

Checking protrusion of injectors


Figure I 18



47585

- Using dial gauge (1), check the protrusion of the injector (2) which must be 0.7 mm.

Figure I 19




44909

INSTALLATION DIAGRAM FOR INJECTOR CASE

5412 TIMING GEAR**541211 Checking cam lift and pin alignment**


Figure 120



47506

Place the camshaft (4) on the tailstock (1) and check cam lift (3) using a centesimal gauge (2); values are shown in table on page 20.


Figure 121



47507

When the camshaft (4) is on the tailstock (1), check alignment of supporting pin (3) using a centesimal gauge (2); it must not exceed 0.030 mm. If misalignment exceeds this value, replace the shaft.

Figure 122




47505

In order to check installation clearance, measure bush inner diameter and camshaft pin (1) diameter; the real clearance is obtained by their difference.

If clearance exceeds 0.150 mm, replace bushes and, if necessary, the camshaft.

541210 Camshaft

Figure I23



47504


MAIN DATA - CAMSHAFT AND TOLERANCES

The surfaces of shaft supporting pin and cams must be extremely smooth; if you see any sign of seizing or scoring, replace the shaft and the relative bushes.

TOLERANCES	TOLERANCE CHARACTERISTIC	SYMBOL
ORIENTATION	Perpendicularity	⊥
POSITION	Concentricity or coaxial alignment	◎
OSCILLATION	Circular oscillation	↗
IMPORTANCE CLASS ASSIGNED TO PRODUCT CHARACTERISTICS		SYMBOL
CRITICAL		◎
IMPORTANT		⊕
SECONDARY		⊖

541213 Bushes

Figure I24



47508

MAIN DATA - CAMSHAFT BUSHES AND RELATIVE BLOCK SEATS


* Bush inner diameter after installation

The bush surfaces must not show any sign of seizing or scoring; if they do replace them.

Measure the bush inner diameters with a baremeter and replace them, if the value measured exceeds the tolerance value. To take down and fit back the bushes, use the proper tool 99360487.

541213 Replacing camshaft bushes using beater 99360487

Figure 125





A. Drift with seat for bushings to insert/extract. - B. Grub screw for positioning bushings. - C. Reference mark to insert seventh bushing correctly. - D. Reference mark to insert bushings 1, 2, 3, 4, 5, 6 correctly (red marks). - E. Guide bushing. - F. Guide line. - G. Guide bushing to secure to the seventh bushing mount. - H. Plate fixing yellow bushing to cylinder head. - I. Grip. - L. Extension coupling.

71721

Removal

Figure 126




71725

The sequence for removing the bushings is 7, 6, 5, 4, 3, 2, 1. The bushings are extracted from the front of the single seats. Removal does not require the drift extension for bushings 5, 6 and 7 and it is not necessary to use the guide bushing. For bushings 1, 2, 3 and 4 it is necessary to use the extension and the guide bushings. Position the drift accurately during the phase of removal.

- 1 Position the bushing to insert on the drift (A) making the grub screw on it coincide with the seat (B) (Figure 125) on the bushing.
- 2 Position the guide bushing (E) and secure the guide bushing (G) (Figure 125) on the seat of the 7th bushing with the plate (H).
- 3 While driving in the bushing, make the reference mark (F) match the mark (M). In this way, when it is driven home, the lubrication hole on the bushing will coincide with the oil pipe in its seat.
The bushing is driven home when the 1st red reference mark (D) is flush with the guide bushing (G).

Figure 128





71723

To insert the bushing (6), proceed as follows:

- Unscrew the grip (I) and the extension (N).
- Position the extension (N) and the guide bushing (E) as shown in the figure.
- Repeat steps 1, 2, 3.

Assembly

Figure 127



77795

Assemble the drift together with the extension.
To insert bushings 1, 2, 3, 4 and 5, proceed as follows:

Figure 129




To insert bushing (7), proceed as follows:

- Unscrew the grip (I) and the extension (N).
- Refit the guide (G) from the inside as shown in the figure.
- Position the bushing on the drift (A) and bring it close up to the seat, making the bushing hole match the lubrication hole in the head. Drive it home. The 7th bushing is driven in when the reference mark (C) is flush with the bushing seat.


540665 VALVE SPRINGS

Figure 130




Before assembly, the flexibility of the valve springs has to be checked with the tool 99305047. Compare the load and elastic deformation data with those of the new springs given in the following figure.

Figure 131




Fitting the valves and oil seal ring

Figure 132



Lubricate the valve stem and place the valves in the relevant valve guides; install the lower plates (3) using tool 99360292, fit the oil seal ring (1) on valve guides (2), then install the valves as shown:


Figure 133



- fit springs (6) and the upper plate (5);
- apply tool 99360264 (2) and block it with bracket (4); tighten the lever (1) until cotters are installed (3), remove tool (2).

5412 ROCKER SHAFT

Figure 134



44925

The camshaft cams directly control rockers: 6 for injectors and 12 for valves.

Rockers slide directly on the cam profiles via rollers.

The other end acts on a bar directly supported by the two valves stems.


A pad is placed between the rocker adjusting screw and the bar.

Two lubrication holes are obtained inside the rockers.

The rocker shaft practically covers the whole cylinder head; remove it to have access to all the underlying components.

Shaft

Figure 135



37,984
38,000


79171

MAIN DATA OF THE ROCKER ARM SHAFT

Check that the surface of the shaft shows no scoring or signs of seizure; if it does, replace it.

Rocker

Figure 136




44914

PUMP INJECTOR ROCKER

The bush surfaces must not show any trace of scoring or excessive wear; otherwise, replace bushes or the whole rocker.


Figure 137



44912

EXHAUST VALVES ROCKER

Figure 138




44913

DISCHARGE VALVE ROCKER

ASSEMBLING THE ENGINE ON THE BENCH

Fix the engine block to the stand 99322230 by means of brackets 99361035.
Install the cylinder liners as described in page 49.

Figure 139




47586

Fit the oil spray nozzles (2), so that the dowel coincides with the block hole (3).

Place the half bearings (1) on the main bearings.


Figure 140



47570

Lubricate the half bearings, then install the crankshaft (2) by means of hoist and hook 99360500 (1).


Figure 141



49021

Place the half-bearings (1) on the main bearings in the underblock (2).


Figure 142



47595

By means of suitable equipment (1) apply silicone LOCTITE 5699 to the block, as shown in the figure.

Figure 143




47596

Sealant application diagram



Fit the underblock within 10' of the application of the sealant.


Figure I44



49022

Fit the underblock by means of a suitable hoist and hooks (1).


Figure I45



47581

Fit the underblock and, using a dynamometric wrench (2), close the splined outer (1) screws to 25 Nm torque, according to the diagram shown on page 79.

Figure I46




47579

Close the inner screws (1) to 140 Nm torque by means of a dynamometric wrench (3), then with two further angular phases $60^\circ + 60^\circ$, using tool 99395216 (4). Tighten again the outer screws (1, Figure I45) with 90° angular closing, using tool 99395215 (3, Figure I45).

DIAGRAM SHOWING THE UNDERBLOCK FIXING SCREWS TIGHTENING ORDER

Figure I47


FRONT SIDE



First phase: outer screws preliminary tightening (25 Nm)

44897


FRONT SIDE



Second phase: inner screws preliminary tightening (140 Nm)

44898


FRONT SIDE



Third phase: inner screws angle closing (60°)

44898


FRONT SIDE



Fourth phase: inner screws angle closing (60°)

44898


FRONT SIDE



Fifth phase: outer screws angle closing (90°)

44899

Figure 148



Rotate the cylinder assembly placing it vertically. Lubricate the half-bearings (1) and fit them in the connecting rod and the cap.




Not finding it necessary to replace the connecting rod bearings, you need to fit them back in exactly the same sequence and position as in removal. If the big end bearings need to be replaced, choose them according to the description given from page 52 to page 58.



Do not make any adjustment on the bearing shells.


Fitting the connecting rod-piston assembly into the cylinder liners

Figure 149



- 1 Connecting rod-piston assembly
- 2 Marking area of ideogram on the piston crown
- 3 Connecting rod marking area

Figure 150




Fit the connecting rod-piston assemblies (2) into the piston liners, using the band 99360605 (1, Figure 150). Check the following:

- the openings of the split rings are offset by 120°;
- all pistons belong to the same class, A or B;
- ideogram (2, Figure 149), stamped on the piston crown, is placed toward the engine flywheel, or the cavity, on the piston skirt, corresponds to the position of the oil spray nozzles



The pistons are supplied as spares in class A and can also be fitted in class B cylinder liners.


Figure 151



47594

Connect the connecting rods to the relative journals, fit the connection rod caps (1) with half bearings; tighten the fixing screws (2) of the connecting rod caps to 50 Nm torque (5 kgm). Using tool 99395216 (3), further tighten screws with 40° angle.


Figure 152



45255

By means of centering ring 99396033 (2), check the exact cover position (1), otherwise act as necessary and tighten the screws.


Figure 153



45256

Fit the sealing gasket (1), install the fitting tool 99346245 (2) and drive the sealing gasket (1) by screwing nut (3).


Figure 154



45266

Make sure that pistons 1-6 are exactly at the TDC. Place the sealing gasket (2) on the block. Fit the cylinder head (1) and tighten screws as shown in figs. 155, 156 and 157.


Figure 155



44900

Diagram showing the cylinder head fixing screws tightening order


Figure 156



45267

□ Preliminary tightening by means of a dynamometric wrench (1):
 1st phase: 50 Nm (5 kgm);
 2nd phase: 100 Nm (10 kgm)


Figure 157



45268

- Angle closing by means of tool 99395216 (1):
- 3rd phase: 90° angle
- 4th phase: 75° angle


Figure 158



47597

- Fit the oil pump (4), intermediate gears (2) with rod (1) and tighten screws (3) in two phases:
- preliminary tightening 30 Nm
- angle closing 90°

Figure 159



47592


Apply sealant LOCTITE 5699 to the gear box using the proper equipment (1).

The sealer string (1) diameter is to be $1,5 \pm_{0,2}^{0,5}$

Install the gear box within 10' of the application of the sealant.

Tighten the screws shown in the figure by means of a dynamometric wrench, in compliance with the following order and tightening torque:

Figure 160




47598

Engines without power take-off

- ☆ no. 13 screws M12 x 1.75 x 80 tightening torque 63 Nm
- * no. 3 screws M10 x 1.5 x 35 tightening torque 42 Nm
- no. 1 screw M10 x 1.5 x 100 tightening torque 42 Nm
- △ no. 1 screw M10 x 1.5 x 180 tightening torque 42 Nm
- ▭ no. 2 screws M18 x 1.25 x 125 tightening torque 24 Nm

Figure 161




84390

Engines with power take-off

- ☆ no. 10 screws M12 x 1.75 x 80 tightening torque 63 Nm
- ⊙ no. 3 screws M10 x 1.5 x 35 tightening torque 42 Nm
- no. 1 screw M10 x 1.5 x 170 tightening torque 42 Nm
- △ no. 1 screw M10 x 1.5 x 180 tightening torque 42 Nm
- ▭ no. 2 screws M12 x 1.75 x 125 tightening torque 63 Nm
- no. 8 screw M10 x 1,5 x 120
- ◇ no. 2 screw M10 x 1,5 x 120 (apply to the thread LOCTITE 275)

Figure 162



45258

Fit the sealing gasket (1), install the fitting tool 99346246 (2) and drive the sealing gasket by screwing the nut (3).

540850 ENGINE FLYWHEEL




If the teeth of the ring gear mounted on the engine flywheel, for starting the engine, are very damaged, replace the ring gear. It must be fitted after heating the ring gear to a temperature of approx. 200°C.

Fitting engine flywheel



The crankshaft has a locating peg that has to couple with the relevant seat on the engine flywheel.

Figure 163




60668

DETAIL OF PUNCH MARKS ON ENGINE FLYWHEEL FOR PISTON POSITIONS

A. Hole on flywheel with one reference mark, corresponding to the TDC of pistons 3-4. - B. Hole on flywheel with one reference mark, corresponding to the TDC of pistons 1-6. - C. Hole on flywheel with one reference mark, corresponding to the TDC of pistons 2-5. - D. Hole on flywheel with two reference marks, position corresponding to 54°.

Figure 164




49037

Position the flywheel (1) on the crankshaft, lubricate the thread of the screws (2) with engine oil and screw them down. Lock rotation with tool 99360351 (3). Lock the screws (2) in three phases.

First phase: pre-tightening with torque wrench (4) to a torque of 100 Nm (10 kgm).

Figure 165




49036

Second phase: closing to angle of 60° with tool 99395216 (1).

Fitting camshaft

Figure 166



72436

Position the crankshaft with the pistons 1 and 6 at the top dead centre (T.D.C.).


This situation occurs when:

1. The hole with reference mark (5) of the engine flywheel (4) can be seen through the inspection window.
2. The tool 99360612 (1), through the seat (2) of the engine speed sensor, enters the hole (3) in the engine flywheel (4).

If this condition does not occur, turn the engine flywheel (4) appropriately.

Remove the tool 99360612 (1).

Figure 167




73843

Fit the camshaft (4), positioning it observing the reference marks (→) as shown in the figure.

Lubricate the seal (3) and fit it on the shoulder plate (2).

Mount the shoulder plate (2) with the sheet metal gasket (1) and tighten the screws (5) to the required torque.


Figure 168



45376

- Apply gauge 99395215 (1), check and record the position of the rod (3) for the transmission gear, tighten the screw (2) to the prescribed torque.

Figure 169




45269

- Remove the transmission gear (1) and tighten screws (2) by means of proper splined wrench, to the prescribed torque.



Replace the idle gear bushing (1) when wear is detected. After installing the bushing, adjust it to 58.010 ± 0.10 mm.

Figure 170




Position the gear (2) on the camshaft so that the 4 slots are centred with the holes for fixing the camshaft, without fully locking the screws (5).

Using the dial gauge with a magnetic base (1), check that the clearance between the gears (2 and 3) is 0.073 – 0.195 mm; if this is not so, adjust the clearance as follows:

- Loosen the screws (4) fixing the idle gear (3).
- Loosen the screw (2, Figure 168) fixing the link rod. Shift the link rod (3, Figure 168) to obtain the required clearance.
- Lock the screw (2, Figure 168) fixing the link rod and screws (4, Figure 170) fixing the idle gear to the required torque.


Fitting pump-injectors

Figure 171



Fit the seals (1) (2) (3) on the injectors.

Figure 172



Mount:


- The injectors (2) and, using a torque wrench, lock the bracket fixing screws to a torque of 26 Nm.
- The exhaust brake cylinders (1) and (4) and, using a torque wrench, fix them to a torque of 19 Nm.
- The crosspieces (3) on the valve stem, all with the largest hole on the same side.

Fitting rocker-arm shaft assembly

Figure 173




Before refitting the rocker-arm shaft assembly, make sure that all the adjustment screws have been fully unscrewed.



Using tool 99360144 (3), fasten the blocks (4) to the rocker arms (2).

Apply the tool 99360553 (1) to the rocker arm shaft (5) and mount the shaft on the cylinder head.

Figure 174




45261

Lock the screws (2) fixing the rocker-arm shaft as follows:

- 1st phase: tightening to a torque of 40 Nm (10 kgm) with the torque wrench (1).
- 2nd phase: closing with an angle of 60° using the tool 99395216 (3).


Figure 175



60574

- Mount the engine brake lever retaining springs (3).
- Connect the pipe (2) to the engine brake cylinders (4) and to the cylinder with the engine brake solenoid valve (1).

Figure 176




71777

Mount the electric wiring (2), securing it on the electro-injectors with a torque screwdriver (1) to a torque of 1.36 - 1.92 Nm.

Camshaft timing

Figure 177



71776


Apply the tool 99360321 (6) to the gearbox (3).



The arrow shows the direction of rotation of the engine when running.

Using the above-mentioned tool, turn the engine flywheel (1) in the direction of rotation of the engine so as to take the piston of cylinder no.1 to approximately the T.D.C. in the phase of combustion. This condition occurs when the hole with one reference mark (4), after the hole with two reference marks (5) on the engine flywheel (1), can be seen through the inspection window (2).

Figure 178




71774

The exact position of piston no.1 at the T.D.C. is obtained when in the above-described conditions the tool 99360612 (1) goes through the seat (2) of the engine speed sensor into the hole (3) in the engine flywheel (4).

If this is not the case, turn and adjust the engine flywheel (4) appropriately.

Remove the tool 99360612 (1).

Figure 179



60573


Set the dial gauge with the magnetic base (1) with the rod on the roller (2) of the rocker arm that governs the injector of cylinder no.1 and pre-load it by 6 mm.

With tool 99360321 (6, Figure 177), turn the crankshaft clockwise until the pointer of the dial gauge reaches the minimum value beyond which it can no longer fall.

Reset the dial gauge.

Turn the engine flywheel anticlockwise until the dial gauge gives a reading for the lift of the cam of the camshaft of 4.90 ± 0.05 mm.

Figure 180




77259

The camshaft is in step if at the cam lift values of 4.90 ± 0.05 mm there are the following conditions:

- 1) The hole marked with a notch (5) can be seen through the inspection window
- 2) The tool 99360612 (1) through the seat (2) of the engine speed sensor goes into the hole (3) in the engine flywheel (4).

Figure 181




60575

If you do not obtain the conditions illustrated in Figure 180 and described in points 1 and 2, proceed as follows:

- 1) Loosen the screws (2) securing the gear (1) to the camshaft and utilize the slots (1, Figure 182) on the gear (2, Figure 182).
- 2) Turn the engine flywheel appropriately so as to bring about the conditions described in points 1 and 2 Figure 180, it being understood that the cam lift must not change at all.
- 3) Lock the screws (2) and repeat the check as described above.
- 4) Tighten the screws (2) to the required torque.


Figure 182



When it is not possible to adjust advance through the slots (1) and the camshaft turns because integral with the gear (2); thus the cam lift reference value varies and it is necessary to proceed in the following way:

- 1) Fasten the screws (2, Figure 181) and rotate the engine flywheel clockwise by $\sim 1/2$ turn;
- 2) Turn the engine flywheel anticlockwise until the dial gauge gives a reading of the lift of the cam of the camshaft of 4.90 ± 0.05 mm
- 3) Take out the screws (2, Figure 181) and remove the gear (2) from the camshaft.

Figure 183



Turn the flywheel (4) again to bring about the following conditions:



- Notch (5) visible through the lower inspection window;
- The tool 99360612 (1) inserted in the hole (3) in the engine flywheel (4) through the seat (2) of the engine speed sensor.

Mount the gear (2, Figure 182) with the 4 slots (1, Figure 182) centred with the fixing holes of the camshaft, locking the relevant screws to the required tightening torque. Check the timing of the shaft by first turning the flywheel clockwise to discharge the cam completely and then turn the flywheel anticlockwise until the dial gauge gives a reading of: 4.90 ± 0.05 mm

Check the timing conditions described in Figure 180.

Phonic wheel timing

Figure 184




Turn the output shaft bringing cylinder piston I at compression stage to TDC; turn the flywheel by about $1/4$ turn in opposite direction than normal direction of rotation. Turn the flywheel again according to normal direction of rotation until the hole marked with the double notch (4) can be seen through the inspection hole set under the flywheel housing. Fit tool 99360612 (5) into the flywheel sensor seat (6).

Fit tool 99360613 (2), through the timing sensor seat, on the tooth obtained on the phonic wheel.

Should tool (2) fitting be difficult, slacken screws (3) and direct the phonic wheel (1) properly to position the tool (2) on the tooth. Tighten the screws (3).

Intake and exhaust rocker play adjustment and pre-loading of rockers controlling pump injectors.

Figure 185



44936A

ADJUSTMENT OF INTAKE, EXHAUST AND INJECTION ROCKERS

Adjustment of clearances between rockers and valve studs and preloading of pump injector rockers should be carried out with extreme care.

Take the cylinder where clearance must be adjusted to the bursting phase; its valves are closed while balancing the symmetric cylinder valves.

Symmetric cylinders are 1-6, 2-5 and 3-4.

In order to properly operate, follow these instructions and data specified on the table.

Adjustment of clearance between the rockers and rods controlling intake and exhaust valves:

- Using a polygonal wrench, loosen nut (1) locking the adjustment screw;
- Insert the thickness gauge blade (3);
- Tighten or untighten the adjustment screw with the appropriate wrench;
- Make sure that the gauge blade (3) can slide with a slight friction;
- Lock the nut (1), by blocking the adjustment screw.

Pre-loading of rockers controlling pump injectors:

- Using a polygonal wrench, loosen the nut locking the rocker adjustment screw (5) controlling the pump injector (6);

- Using an appropriate wrench (4), loosen the adjustment screw until the pumping element is at the end-of-stroke;
- Tighten the adjustment screw, with a dynamometric wrench, to 5 Nm tightening torque (0.5 kgm);
- Untighten the adjustment screw by 1/2 to 3/4 rotation;
- Tighten the locking nut.


FIRING ORDER **1-4-2-6-3-5**

Clockwise start-up and rotation	Adjusting cylinder valve no.	Adjusting clearance of cylinder valve no.	Adjusting pre-loading of cylinder injector no.
1 and 6 at P.M.S.	6	1	5
120°	3	4	1
120°	5	2	4
120°	1	6	2
120°	4	3	6
120°	2	5	3




In order to properly carry out the above-mentioned adjustments, follow the sequence specified in the table, checking the exact position in each rotation phase by means of pin 99360612, to be inserted in the 11th hole in each of the three sectors with 18 holes each.

Figure 186




Fit the distribution cover (1).
Fit the blow-by case (7) and its gasket and then tighten the screws (8) to the prescribed torque.
Install the filter (5) and the gaskets (4 and 6).

 The filter (5) operation is unidirectional, therefore it must be assembled with the two sight supports as illustrated in the figure.


Fit the cover (3) and tighten the fastening screws (2) to the prescribed torque.

 Apply silicone LOCTITE 5699 on the blow-by case (7) surface of engines fitted with P.T.O. according to the procedure described in the following figure.

Figure 187



Apply silicone LOCTITE 5699 on the blow-by case and form a string (2) of $\varnothing 1.5 \pm_{0.2}^{0.5}$ as shown in the figure.

 Fit the blow-by case (1) within 10' from sealer application.

ENGINE COMPLETION

Complete the engine by installing or connecting the following components:

- thermostatic unit;
- belt tensioner, water pump, alternator;
- control belt;
- belt tensioner, conditioner compressor;
- control belt.

Figure 188





DIAGRAM FOR THE INSTALLATION OF FAN BELTS - WATER PUMP - ALTERNATOR AND CONDITIONER COMPRESSOR

1. Alternator - 2. Fan - 3. Water pump - 4. Crankshaft - 5. Conditioner compressor

Figure 189




To install belts (1-3), use the appropriate tools (2-4.) to work on the tensioners, as shown by arrows.



Automatic tensioners do not require further adjustments after the installation.

- damping flywheel;
- fan;
- compressor;
- fuel pump;
- fuel filter and piping;
- pre-heating resistance;
- intake manifold;
- soundproof shields;
- heat exchanger;
- oil filter, lubricating the gasket;
- rockers caps;
- exhaust manifold;
- turbocharger and its oil and water piping;
- power take-off (P.T.O.) (if any) and related pipes;
- oil level stick and oil vapor vent;
- rotate the engine and install the oil rose pipe.

Figure 190




47573

- place the gasket (4) on the oil sump (1), position the spacer (3) and fit the sump to the engine block by tightening screws (2) to the prescribed torque;
- electric connections and sensors;
- remove the engine from the stand and fit the starter;
- fill the engine with the oil quantity required.

5430 LUBRICATION


Engine lubrication is obtained with a gear pump driven by the crankshaft via gears.
A heat exchanger governs the temperature of the lubricating oil.
The oil filter, signalling sensors and safety valves are installed in the intercooler.

Figure 191



543010 Oil pump

Figure 192





60560

The oil pump (1) cannot be overhauled. On finding any damage, replace the oil pump assembly.

See under the relevant heading for replacing the gear (2) of the crankshaft.

Figure 193




77817

OIL PUMP CROSS-SECTION

I. Overpressure valve – Start of opening pressure 10.1 ± 0.7 bars

Overpressure valve

Figure 194




77820

MAIN DATA TO CHECK THE OVERPRESSURE VALVE SPRING


Oil pressure control valve

Figure 195



The oil pressure control valve is located on the left-hand side of the crankcase.
Start of opening pressure 5 bars.


Figure 196



MAIN DATA TO CHECK THE OIL PRESSURE CONTROL VALVE SPRING

543110 Heat exchanger

Figure 197




HEAT EXCHANGER

The following elements are fitted on the intercooler: 1. Transmitter for low pressure warning lamp - 2. By-pass valve - 3. Oil temperature sensor - 4. Oil pressure sensor for single gauge - 5. Heat valve. Number of intercooler elements: 7

By-pass valve


Figure 198



The valve quickly opens at a pressure of: 3 bars.

Thermostatic valve

Figure 199



Start of opening:


- travel 0.1 mm at a temperature of $82 \pm 2^\circ\text{C}$.

End of opening:

- travel 8 mm at a temperature of 97°C .

Engine oil filters

Figure 200



This is a new generation of filters that permit much more thorough filtration as they are able to hold back a greater amount of particles of smaller dimensions than those held back by conventional filters with a paper filtering element.

These high-filtration devices, to date used only in industrial processes, make it possible to:

- reduce the wear of engine components over time;
- maintain the performance/specifications of the oil and thereby lengthen the time intervals between changes.

External spiral winding

The filtering elements are closely wound by a spiral so that each fold is firmly anchored to the spiral with respect to the others. This produces a uniform use of the element even in the worst conditions such as cold starting with fluids with a high viscosity and peaks of flow. In addition, it ensures uniform distribution of the flow over the entire length of the filtering element, with consequent optimization of the loss of load and of its working life.

Mount upstream

To optimize flow distribution and the rigidity of the filtering element, this has an exclusive mount composed of a strong mesh made of nylon and an extremely strong synthetic material.

Filtering element

Composed of inert inorganic fibres bound with an exclusive resin to a structure with graded holes, the element is manufactured exclusively to precise procedures and strict quality control.

Mount downstream

A mount for the filtering element and a strong nylon mesh make it even stronger, which is especially helpful during cold starts and long periods of use. The performance of the filter remains constant and reliable throughout its working life and from one element to another, irrespective of the changes in working conditions.

Structural parts

The o-rings equipping the filtering element ensure a perfect seal between it and the container, eliminating by-pass risks and keeping filter performance constant. Strong corrosion-proof bottoms and a sturdy internal metal core complete the structure of the filtering element.

When mounting the filters, keep to the following rules:

- Oil and fit new seals.
- Screw down the filters to bring the seals into contact with the supporting bases.
- Tighten the filter to a torque of $35\pm 40\text{ Nm}$.

5432 COOLING

Description

The engine cooling system works with forced circulation inside closed circuit and can be connected to an additional heater (if any) and to the intarder intercooler. It consists mainly of the following components:

- ❑ an expansion reservoir whose plug (I) incorporates two valves – discharge and charge – controlling the system pressure.
- ❑ a coolant level sensor placed at the bottom of the expansion reservoir with two coupling points:
 - coupling point for sensor S1 6 litres
 - coupling point for sensor S2 3.7 litres
- ❑ an engine cooling unit to dissipate the heat taken by the coolant from the engine through the intercooler.
- ❑ a heat exchanger to cool down lubrication oil;
- ❑ a water pump with centrifugal system incorporated in the cylinder block;
- ❑ an electric fan consisting of a 2-speed electro-magnetic joint equipped with a neutral wheel shaft hub fitted with a metal plate moving along the axis and where the fan is installed. It is controlled electronically by the vehicle Multiplex system.
- ❑ a 3-way thermostat controlling the coolant circulation.

Operation

The water pump is actuated by the crankshaft through a poli-V belt and sends coolant to the cylinder block, especially to the cylinder head (bigger quantity). When the coolant temperature reaches and overcomes the operating temperature, the thermostat is opened and from here the coolant flows into the radiator and is cooled down by the fan. The pressure inside the system depending on the temperature variation is controlled by the discharge and charge valves incorporated in the expansion reservoir filling plug (I).

The discharge valve has a double function:

- ❑ keep the system under light pressure in order to raise the coolant boiling point;
- ❑ discharge the pressure surplus in the atmosphere as a result of the coolant high temperature.


The charge valve makes it possible to transfer the coolant from the expansion reservoir to the radiator when a depression is generated inside the system as a result of the coolant volume reduction depending on the fall in the coolant temperature.

Discharge valve opening:

- 1st breather 0.9 ^{+0.2}/_{-0.1} bar
- 2nd breather 1.2 ^{+0.2}/_{-0.1} bar

Charge valve opening -0.03 ⁺⁰/_{-0.02} bar


Figure 201



- Water leaving the thermostat
- Water circulating in the engine
- Water entering the pump

543210 Water pump

Figure 202



44915

WATER PUMP SECTION

The water pump consists of: rotor, seal bearing and control pulley.



Make sure that the pump casing has no cracking or water leakage; otherwise, replace the entire pump.

543250 Thermostat

THERMOSTAT OPERATION VIEW

Figure 203




45357

TO BY-PASS FROM THE HEAD

Water circulating in the engine

Figure 204



45358


Water issuing from thermostat

Check the thermostat works properly; replace it if in doubt.

Temperature of start of travel $84^{\circ}\text{C} \pm 2^{\circ}\text{C}$.
Minimum travel 15 mm at $94^{\circ}\text{C} \pm 2^{\circ}\text{C}$.

543210 Electromagnetic coupling

Figure 205



78842

ELECTROMAGNETIC COUPLING SECTION

The electro-magnetic joint action depends on:

- the coolant temperature;
- the climate control system fluid pressure (if any);
- the slowing down action of the intarder on (if any).

Coolant temperature for:

- engagement 93°C
- disengagement 88°C

With climate control system

Climate control system fluid pressure:

- 2nd speed engagement 22 bar

With intarder

With braking power below 41% of maximum power:

Coolant temperature for:

- 2nd speed engagement 93°C
- disengagement 88°C

With braking power over 41% of maximum power:

Coolant temperature for:

- 2nd speed engagement 85°C
- disengagement 80°C

Using a feeler gauge, check the gap between the anchor assembly (2) and the pulley (1), it must be no greater than 2.5 mm.


As to the description of the electro-magnetic joint operation and servicing, see the "Manual for electric/electronic system repairing" St. 603.93.191.

5424 TURBOCHARGING

The turbocharging system consists of:

- air filter;
- variable geometry turbocharger;
- "intercooler" radiator.

Figure 206



44916

TURBOCHARGING DIAGRAM

TURBOCHARGER

Operating principle

The variable geometry turbocharger (VGT) consists of a centrifugal compressor and a turbine, equipped with a mobile device which adjusts the speed by changing the area of the passing section of exhaust gases to the turbine.

Thanks to this solution, gas velocity and turbine speed can be high even when the engine is idling.

If the gas is made to go through a narrow passage, in fact, it flows faster, so that the turbine rotates more quickly.

The movement of the device, choking the exhaust gas flowing section, is carried out by a mechanism, activated by a pneumatic actuator.


This actuator is directly controlled by the electronic control unit by a proportional solenoid valve.

The device is in maximum closing condition at idle speed.

At high engine operating speed, the electronic control system is activated and increases the passing section, in order to allow the in-coming gases to flow without increasing their speed.

A toroidal chamber is obtained during the casting process in the central body for the passage of the coolant.

Figure 207




CONTROL AIR SYSTEM DIAGRAM

- | | |
|----------------------------|-------------------------------|
| 1) Service tank | 4) VGT control solenoid valve |
| 2) Shut-off solenoid valve | 5) Actuator pressure sensor |
| 3) Air filter | 6) Turbine actuator |


TURBO COMPRESSOR HOLSET HX 40V

Figure 208




71759

1. Air delivery to the intake manifold - 2. Compressor - 3. Air inlet - 4. Actuator -
5. Exhaust gas speed governor - 6. Exhaust gas inlet - 7. Exhaust gas outlet - 8. Turbine



CROSS-SECTION OF MINIMUM FLOW

71733




CROSS-SECTION OF MAXIMUM FLOW

71734

CROSS-SECTION OF TURBOCHARGER


1. Air delivery to the intake manifold - 2. Compressor - 3. Air inlet - 4. Actuator - 5. Exhaust gas flow-rate adjustment ring -
6. Exhaust gas inlet - 7. Exhaust gas outlet - 8. Turbine - 9. Exhaust gas flow-rate control fork

Figure 209



60753


Figure 210



60754


- 1. Slide guide - 2. Compressor - 3. Slide rods - 4. Compressor fan - 5. Lubrication bushings -
- 6. Exhaust gas flow-rate adjustment ring - 7. Exhaust gas fan - 8. Gas exhaust body -
- 9. Locking rings - 10. Oil delivery - 11. Oil outlet - 12. Actuator drive shaft

Figure 211



71762

Figure 212




- I. Slide guide - 3. Slide rod - 11. Oil outlet - 12. Actuator drive shaft -
13. Actuator - 14. Exhaust gas flow-rate control fork


71763

Actuator

Figure 213



- a Gradient characterized by the effect of the external spring (4).
- b Gradient characterized by the effect of the external (4) and internal (6) springs.



- 1. Air inlet - 2. Gasket - 3. Piston - 4. External spring - 5. Internal spring control disc - 6. Internal spring - 7. O-ring - 8. Spring holder - 9. Limit stop - 10. Dust seal - 11. Control rod

Working principle

The actuator piston, connected to the drive rod, is controlled with the compressed air introduced through the air inlet (1) on the top of the actuator.

Modulating the air pressure varies the movement of the piston and turbine control rod. As the piston moves, it progressively compresses the external spring (4) until the base of the piston reaches the disc (5) controlling the internal spring (6).

On further increasing the pressure, the piston, via the disc (5), interferes with the bottom limit stop (10).

Using two springs makes it possible to vary the ratio between the piston stroke and the pressure. Approximately 85% of the stroke of the rod is opposed by the external spring and 15% by the internal one.

Solenoid valve for VGT control

This N.C. proportional solenoid valve is located on the left-hand side of the crankcase under the turbine.

The electronic control unit, via a PWM signal, controls the solenoid valve, governing the supply pressure of the turbine actuator, which, on changing its position, modifies the cross-section of the flow of exhaust gases onto the blades of the impeller and therefore its speed.

The VGT solenoid valve is connected to the electronic control unit between pins A18/A31.

The resistance of the coil is approx. 20-30 Ohms.


71834

72421

FUEL FEED

Fuel feed is obtained by means of a pump, fuel filter and pre-filter, 6 pump-injectors controlled by the camshaft by means of rockers and by the electronic control unit.

Figure 214




52877

1. Valve for return circuit, starts opening 0.2 bar - 2. Valve for return circuit, starts opening 3.5 bar

Fuel pump


Figure 215



73547

- A. Fuel inlet – B. Fuel delivery – C. By-pass nut –
- D. Fuel return from the pump-injectors –
- E. Pressure relief valve – Opening pressure: 5-8 bars

Figure 216




73548

CROSS-SECTION OF THE FUEL PUMP
I. Oil and fuel leakage indicator

Injector-pump

Figure 217



44908

- 1. Fuel/oil seal – 2. Fuel/diesel seal – 3. Fuel/exhaust gas seal
- The injector-pump is composed of: pumping element, nozzle, solenoid valve.

Pumping element

The pumping element is operated by a rocker arm governed directly by the cam of the camshaft. The pumping element is able to ensure a high delivery pressure. The return stroke is made by means of a return spring.

Nozzle

Garages are authorized to perform fault diagnosis solely on the entire injection system and may not work inside the injector-pump, which must only be replaced.

A specific fault-diagnosis program, included in the control unit, is able to check the operation of each injector (it deactivates one at a time and checks the delivery of the other five). Fault diagnosis makes it possible to distinguish errors of an electrical origin from ones of a mechanical/hydraulic origin. It indicates broken pump-injectors.

It is therefore necessary to interpret all the control unit error messages correctly.

Any defects in the injectors are to be resolved by replacing them.

Solenoid valve

The solenoid, which is energized at each active phase of the cycle, via a signal from the control unit, controls a slide valve that shuts off the pumping element delivery pipe.

When the solenoid is not energized, the valve is open, the fuel is pumped but it flows back into the return pipe with the normal transfer pressure of approximately 5 bars.

When the solenoid is energized, the valve shuts and the fuel, not being able to flow back into the return pipe, is pumped into the nozzle at high pressure, causing the needle to lift.

The amount of fuel injected depends on the length of time the slide valve is closed and therefore on the time for which the solenoid is energized.

The solenoid valve is joined to the injector body and cannot be removed.

On the top there are two screws securing the electrical wiring from the control unit.

To ensure signal transmission, tighten the screws with a torque wrench to a torque of 1.36 – 1.92 Nm (0.136 – 0.192 kgm).


775010 Replacing injectors-pump

Injectors have to be replaced with great care (for their removal see the description on pages 44 and 45, for fitting them see the description on pages 85 and 86).



If this job is done with the engine on the vehicle, before removing the injectors-pump drain off the fuel contained in the pipes in the cylinder head by unscrewing the delivery and return fittings on the cylinder head.

Figure 218




For each injector replaced, hook up to the MODUS station and, when asked by the program, enter the code punched on the injector (→) to reprogram the control unit.



When checking the clearance of the rocker arms, it is important to check the injector-pump pre-load.

Injector Phases

Figure 219



60669

1. Fuel valve - 2. Pumping element - 3. Fuel outlet -
4. Filling and backflow passage

Filling phase


During the filling phase the pumping element (2) runs up to the top position.

After passing the highest point of the cam, the rocker arm roller comes near the base ring of the cam.

The fuel valve (1) is open and fuel can flow into the injector via the bottom passage (4) of the cylinder head.

Filling continues until the pumping element reaches its top limit.

Figure 220



- 1. Fuel valve - 2. Pumping element - 3. Fuel outlet -
- 4. Filling and backflow passage


Injection phase

The injection phase begins when, at a certain point in the down phase of the pumping element, the solenoid valve gets energized and the fuel valve (1) shuts.

The moment delivery begins, appropriately calculated by the electronic control unit, depends on the working conditions of the engine.

The cam continues with the rocker arm to push the pumping element (2) and the injection phase continues as long as the fuel valve (1) stays shut.

Figure 221



- 1. Fuel valve - 2. Pumping element - 3. Fuel outlet -
- 4. Filling and backflow passage

Pressure Reduction phase

Injection ceases when the fuel valve (1) opens, at a certain point in the down stroke of the pumping element, after the solenoid valve gets de-energized.

The fuel flows back through the open valve (1), the injector holes and the passage (4) into the cylinder head.

The time for which the solenoid valve stays energized, appropriately calculated by the electronic control unit, is the duration of injection (delivery) and it depends on the working conditions of the engine.

F3A Engine


	Page
VIEWS OF THE ENGINE	115
TECHNICAL DESIGNATION	119
CHARACTERISTIC CURVES	120
GENERAL CHARACTERISTICS	122
ASSEMBLY CLEARANCE DATA	125
TIGHTENING TORQUE	131
TOOLS	137
DISMANTLING THE ENGINE ON THE BENCH	149
REPAIR OPERATIONS	156
CYLINDER BLOCK	156
<input type="checkbox"/> Checks and measurements	156
CYLINDER LINERS	157
<input type="checkbox"/> Replacing cylinder liners	158
CRANKSHAFT	159
<input type="checkbox"/> Measuring the main journals and crankpins . . .	160
<input type="checkbox"/> Preliminary measurement of main and big end bearing shell selection data	161
<input type="checkbox"/> Selecting the main and big end bearing shells . .	162
<input type="checkbox"/> Replacing the timing gear and oil pump	168
<input type="checkbox"/> Checking main journal assembly clearance	168
<input type="checkbox"/> Checking crankshaft end float	169
PISTON CONNECTING ROD ASSEMBLY	170
<input type="checkbox"/> Piston rings	172
CONNECTING RODS	173
<input type="checkbox"/> Bushings	174
<input type="checkbox"/> Checking connecting rods	174
<input type="checkbox"/> Mounting the connecting rod – piston assembly	175

	Page
<input type="checkbox"/> Mounting the piston rings	175
<input type="checkbox"/> Fitting the big end bearing shells	175
<input type="checkbox"/> Fitting connecting rod - piston assemblies in the cylinder liners	176
<input type="checkbox"/> Checking piston protrusion	176
<input type="checkbox"/> Checking crankpin assembly clearance	177
CYLINDER HEAD	177
<input type="checkbox"/> Removing valves	177
<input type="checkbox"/> Checking the planarity of the head on the cylinder block	177
<input type="checkbox"/> Valves	177
<input type="checkbox"/> Removing deposits and checking the valves ...	177
<input type="checkbox"/> Valve seats	178
<input type="checkbox"/> Checking clearance between valve-stem and associated valve guide	179
<input type="checkbox"/> Valve guides	179
<input type="checkbox"/> Replacing injector cases	179
<input type="checkbox"/> Checking injector protrusion	181
TIMING SYSTEM	182
<input type="checkbox"/> Bushings	183
<input type="checkbox"/> Camshaft	183
<input type="checkbox"/> Valve springs	185
<input type="checkbox"/> Fitting valves and oil seal	186
ROCKER SHAFT	186
<input type="checkbox"/> Rocker arms	187
<input type="checkbox"/> Shaft	187
ENGINE ASSEMBLY ON BENCH	188
<input type="checkbox"/> Fitting connecting rod - piston assemblies in cylinder liners	191
ENGINE FLYWHEEL	194

	Page
<input type="checkbox"/> Fitting engine flywheel	194
<input type="checkbox"/> Fitting camshaft	195
<input type="checkbox"/> Fitting pump-injectors	196
<input type="checkbox"/> Fitting rocker-arm shaft assembly	196
<input type="checkbox"/> Camshaft timing	197
<input type="checkbox"/> Phonic wheel timing	199
<input type="checkbox"/> Intake and exhaust rocker play adjustment and pre-loading of rockers controlling pump injectors	200
<input type="checkbox"/> Completing Engine Assembly	201
LUBRICATION	203
<input type="checkbox"/> Oil pump	205
<input type="checkbox"/> Overpressure valve	205
<input type="checkbox"/> Oil pressure control valve	206
<input type="checkbox"/> Heat exchanger	206
<input type="checkbox"/> By-pass valve	207
<input type="checkbox"/> Thermostatic valve	207
<input type="checkbox"/> Engine oil filters	207
COOLING	209
<input type="checkbox"/> Description	209
<input type="checkbox"/> Operation	209
<input type="checkbox"/> Water pump	211
<input type="checkbox"/> Thermostat	211
<input type="checkbox"/> Electromagnetic coupling	211
TURBOCHARGING	212
<input type="checkbox"/> Turbocharger HOLSET HY55V	212
<input type="checkbox"/> Actuator	216
<input type="checkbox"/> Solenoid valve for VGT control	216
FEEDING	218
<input type="checkbox"/> Fuel pump	219
<input type="checkbox"/> Injector-pump	219
<input type="checkbox"/> Replacing injectors-pump	219
<input type="checkbox"/> Injector Phases	220

VIEWS OF THE ENGINE


Figure 1



73835

F3A ENGINE


Figure 2



73526

RIGHT-HAND SIDE VIEW OF THE ENGINE


Figure 3



73527

REAR VIEW OF THE ENGINE


Figure 4



73528

RIGHT-HAND SIDE VIEW OF THE ENGINE


Figure 5



73529

LEFT-HAND SIDE VIEW OF THE ENGINE

Figure 6




73834

VIEW OF THE ENGINE FROM ABOVE


TECHNICAL DESIGNATION

ENGINE



CHARACTERISTIC CURVES

Figure 7



73531

CHARACTERISTIC CURVES OF ENGINE F3AE 0681B

Max OUTPUT 294 kW

400 HP

at 2100 rpm


Max TORQUE 1900 Nm

194 kgm

at 1050 ÷ 1480 rpm

17

Figure 8



73532

CHARACTERISTIC CURVES OF ENGINE F3A068 I D

Max OUTPUT 316 kW

430 HP












at 2100 rpm








Max TORQUE 1900 Nm





194 kgm

at 1050 ÷ 1590 rpm













GENERAL CHARACTERISTICS

	Type		F3AE0681B	F3AE0681D
	Cycle		4-stroke Diesel engine	
	Fuel feed		Turbocharged with aftercooler	
	Injection		Direct	
	No. of cylinders		6 in line	
	Bore	mm	125	
	Stroke	mm	140	
	Total displacement	cm ³	10300	
	Compression ratio		17 ± 0.8	
	Max output	KW (HP)	294 (400)	316 (430)
		rpm	2100	2100
	Max. torque	Nm (kgm)	1900 (194)	1900 (194)
		rpm	1050 ÷ 1480	1050 ÷ 1590
	Engine idling speed, no load	rpm	550 ±25	
	Maximum engine speed, no load	rpm	2550 ±20	

	<p>Type</p> <p style="text-align: right;">F3A</p>
 <p>VALVE TIMING</p> <p>opens before T.D.C. A</p> <p>closes after B.D.C. B</p> <p>opens before B.D.C. D</p> <p>closes after T.D.C. C</p>	<p>16°</p> <p>32°</p> <p>50°</p> <p>9°</p>
<p>For timing check</p>  <p>Running</p> <p>X { mm</p> <p>X { mm</p> <p>X { mm</p> <p>X { mm</p>	<p>-</p> <p>-</p> <p>0.35 to 0.45</p> <p>0.45 to 0.55</p>
 <p>FEED</p> <p>Injection type: Bosch</p>	<p>Through fuel pump - filters</p> <p>With electronically regulated injectors PDE 3 l pump injectors controlled by overhead camshaft</p>
 <p>Nozzle type</p>	<p>-</p>
 <p>Injection order</p>	<p>1 - 4 - 2 - 6 - 3 - 5</p>
 <p>Injection pressure bar</p> <p>Injector calibration bar</p>	<p>1500</p> <p>290</p>

	Type	F3A	
	SUPERCHARGING		
	Turbocharger type	Variable geometry Holset HY 55 V	
	LUBRICATION	Forced by gear pump, pressure control valve, oil filter	
	Oil pressure with hot engine (100°C ±5°C):		
	at idling speed	bar	1.5
	at maximum rpm	bar	5
	COOLING	By centrifugal pump, regulating thermostat, viscostatic fan, radiator and heat exchanger	
	Water pump control	By belt	
	Thermostat	N. 1	
	initial opening	~84°C ±2°C	
	maximum opening	94°C ±2°C	
	OIL FILLING		
	Total capacity at 1 st filling	litres	30
		kg	29.8
	Fiat Lubrificanti		
	Urania Turbo LD		
	(according to E3-96 standard)		
	Urania Turbo		
	(according to E2-96 standard)		
	- engine sump min level	litres	17
		kg	15.3
	- engine sump max level	litres	25
		kg	22.5
	- quantity in circulation that does not flow back to the engine sump	litres	7
		kg	6.3
	- quantity contained in the cartridge filter (which has to be added to the cartridge filter refill)	litres	2.5
		kg	2.3

ASSEMBLY CLEARANCE DATA

	Type	F3A	
CYLINDER BLOCK AND CRANKMECHANISM COMPONENTS		mm	
	Bores for cylinder liners: upper $\varnothing 1$ lower	142.000 to 142.025 140.000 to 140.025	
	Cylinder liners: external diameter: upper $\varnothing 2$ lower length L	141.961 to 141.986 139.890 to 139.915 -	
	Cylinder liners - crankcase bores upper lower	0.014 to 0.064 0.085 to 0.135	
	External diameter $\varnothing 2$	-	
	Cylinder sleeve inside diameter $\varnothing 3A^*$ inside diameter $\varnothing 3B^*$ Protrusion X	125.000 to 125.013 125.011 to 125.024 0.045 to 0.075	
* Selection class			
	Pistons: measuring dimension X external diameter $\varnothing 1A^{\bullet}$ external diameter $\varnothing 1B^{\circ}$ pin bore $\varnothing 2$	NUERAL 18 124.884 to 124.896 124.895 to 124.907	MAHLE - MONDIAL 18 124.881 to 124.893 124.892 to 124.904
	Piston - cylinder sleeve A* B*	0.104 to 0.129 0.093 to 0.118	0.107 to 0.132 0.096 to 0.131
* Selection class			
	Piston diameter $\varnothing 1$	-	
	Pistons protrusion X	0.23 to 0.53	
	Gudgeon pin $\varnothing 3$	49.994 to 50.000	
	Gudgeon pin - pin housing	0.010 to 0.024	
<p>\bullet Class A pistons supplied as spares. \circ Class B pistons are fitted in production only and are not supplied as spares.</p>			