

|                                  |    |
|----------------------------------|----|
| TECHNICAL DATA                   | 0  |
| DIAGNOSTICS                      | 1  |
| COMPONENTS                       | 2  |
| WIRING REPAIR                    | 3  |
| BATTERIES                        | 4  |
|                                  | 5  |
| CONNECTION OF ACCESSORIES        | 6  |
| READING DIAGRAMS                 | 7  |
| LOCATION OF COMPONENTS           | 8  |
| LOCATION OF CONNECTORS           | 9  |
| ELECTRICAL SYSTEM                | 10 |
| CHANGES IN THE ELECTRICAL SYSTEM | 11 |



CONTENTS

|                              | Page     | Date   |
|------------------------------|----------|--------|
| 1. COMPONENTS .....          | 1-1 .... | 200440 |
| 1.1 General .....            | 1-1 .... | 200440 |
| 1.2 Tightening torques ..... | 1-3 .... | 200440 |





**1. COMPONENTS****1.1 GENERAL****BULBS**

|                          |           |
|--------------------------|-----------|
| Dipped beam light        | 70 W      |
| Main beam light          | 70 W      |
| Parking light            | 5 W       |
| Rear light               | 10 W      |
| Rear fog light           | 21 W      |
| Reversing light          | 21 W      |
| Stop light               | 21 W      |
| Direction indicator lamp | 21 W      |
| Front fog light          | 70 W      |
| Front spot lights        | 70 W      |
| Interior lighting        | 10 - 21 W |
| Bunk lamp                | 21 W      |
| Stepwell lighting        | 5 W       |
| Marker light             | 5 W       |

| Max. current and wire diameter (mm <sup>2</sup> ) |           |         |         |          |
|---|-----------|---------|---------|----------|
| Wire diameter                                     | Up to 2 m | 2 - 4 m | 4 - 8 m | From 8 m |
| 0.5   | 3         | 1.5     | 0.5     |          |
| 1   | 9         | 5       | 4       |          |
| 1.5   | 22.5      | 13.5    | 7.5     | 6        |
| 2.0   | 30        | 17      | 10      | 8        |
| 2.5   | 37.5      | 22.5    | 12.5    | 10       |
| 3.0   | 47        | 27      | 16      | 13       |
| 4   | 60        | 36      | 20      | 16       |
| 4.5   | 69        | 43      | 24      | 19       |
| 6   | 90        | 54      | 30      | 24       |
| 7.5   | 114       | 73      | 40      | 33       |
| 10  | 150       | 90      | 50      | 40       |
| 16  | 240       | 144     | 80      | 64       |
| 25  | 375       | 225     | 125     | 100      |
| 35  | 525       | 315     | 175     | 140      |
| 50  | 750       | 450     | 250     | 200      |
| 70  | 1050      | 630     | 350     | 280      |
| 95  | 1425      | 855     | 475     | 380      |
| 120   | 1800      | 1080    | 600     | 480      |

0

### Alternator

#### NCB1

Max. current 80 A  
 Rated voltage 28 V

#### NCB2

Max. current 100 A  
 Rated voltage 28 V

### Battery



Voltage 12 V  
 Max. capacity 128 Ah

#### Optional:

Voltage 12 V  
 Max. capacity 170 Ah

### Mini relay (20 A)



Resistance value of coil approx. 250 Ω  
 Measured between points 1 and 2



E501287

### Relay (50 A)

Resistance value of coil approx. 175 Ω  
 Measured between points 1 and 2



E501288

### CDS hand-held transmitters

Battery type (2x) CR1620, 3 V

## 1.2 TIGHTENING TORQUES

### Alternator

Drive pulley

80 Nm  $\pm$  5 Nm

B+ connection

15 Nm

### Earth connection

Chassis

35  $\pm$  10 Nm





**CONTENTS**

|                               | <b>Page</b> | <b>Date</b> |
|-------------------------------|-------------|-------------|
| <b>1. BATTERIES</b> .....     | 1-1         | 200440      |
| 1.1 Fault-finding table ..... | 1-1         | 200440      |
| 1.2 Service life .....        | 1-4         | 200440      |
| <b>2. ALTERNATOR</b> .....    | 2-1         | 200440      |
| 2.1 Fault-finding table ..... | 2-1         | 200440      |
| <b>3. FAULT FINDING</b> ..... | 3-1         | 200440      |
| 3.1 Short circuits .....      | 3-2         | 200440      |
| 3.2 Open circuit .....        | 3-3         | 200440      |
| 3.3 Earthing problems .....   | 3-4         | 200440      |



## 1. BATTERIES

### 1.1 FAULT-FINDING TABLE

| SYMPTOM: NEW BATTERY HEATS UP CONSIDERABLY DURING FILLING                                   |   |
|---|---|
| Possible cause  | Remedy  |
| Inadequate formation because of storage in unsuitable or damp conditions over a long period | Allow to cool<br>Charge fully<br>Check the relative density |

| SYMPTOM: BATTERY OVERFLOWS, BATTERY ACID SPILLS FROM PLUG HOLES |   |
|---|---|
| Possible cause  | Remedy  |
| Battery overfilled  | Siphon off some of the fluid                            |
| Overcharging  | Check charging voltage<br>Check/repair charging circuit |

| SYMPTOM: ACID LEVEL TOO LOW  |   |
|--|---|
| Possible cause   | Remedy  |
| Leaking battery  | Replace the battery                                     |
| Excessive gas development due to charging current being set too high | Check charging voltage<br>Check/repair charging circuit |

| SYMPTOM: RELATIVE DENSITY TOO LOW (< 1.240)<br>STARTING TROUBLE |   |
|---|---|
| Possible cause  | Remedy  |
| Power consumer left on by mistake                               | Charge the battery                                      |
| Insufficient charging   | Check alternator drive<br>Check/repair charging circuit |

| SYMPTOM: RELATIVE DENSITY TOO HIGH (> 1.290)           |   |
|--|---|
| Possible cause   | Remedy  |
| Topped up with battery acid instead of distilled water | Siphon off some of the fluid and top up with distilled water<br>If necessary, repeat this after mixing (charging) |

**1**

| <b>SYMPTOM: STARTING TROUBLE<br/>POOR STARTING TEST RESULT<br/>POWER FAILS UNDER LOAD</b> |                     |
|---|---------------------|
| <b>Possible cause</b>   | <b>Remedy</b>       |
| Discharged battery  | Charge the battery  |
| Worn battery (plates corroded and worn away)  | Replace the battery |
| Defective battery ("dead cell")   | Replace the battery |
| Battery sulphated (plates have hardened)  | Replace the battery |

| <b>SYMPTOM: BURNT-IN BATTERY TERMINALS</b>       |  |
|--|--|
| <b>Possible cause</b>                            | <b>Remedy</b>  |
| Cable clamps not securely fitted or poor contact | Have the battery terminals repaired, fit the cable clamps properly and replace the cable clamps if necessary |

| <b>SYMPTOM: 1 OR 2 CELLS BUBBLE EXCESSIVELY UNDER HIGH LOAD<br/>(STARTING OR STARTING TEST)</b> |                     |
|---|---------------------|
| <b>Possible cause</b>   | <b>Remedy</b>       |
| Defective cells   | Replace the battery |
| Leaking cell partition  | Replace the battery |

| <b>SYMPTOM: BATTERY DISCHARGES VERY FAST (DOES NOT RETAIN POWER)</b>                                |   |
|---|---|
| <b>Possible cause</b>   | <b>Remedy</b>   |
| Insufficient charging   | Check the charging. Is the charging time (driving time) sufficient? |
| Short circuit in charging circuit   | Check the charging circuit  |
| Major self discharging, for example due to contamination  | Clean the battery   |
| Battery sulphated (on examining the plates, they are found to be hard and, in some cases, whitened) | Replace the battery   |

| <b>SYMPTOM: SHORT BATTERY LIFE</b>  |  |
|---|--|
| <b>Possible cause</b>   | <b>Remedy</b>                                      |
| Wrong type of battery chosen (for example if the vehicle has a tail lift) | Replace with battery of a higher capacity (170 Ah) |
| Often too deeply discharged   | Intermediate charging with rectifier               |
| Not recharged after deep discharge (white deposits)                       | Always charge the battery after deep discharge     |
| Alternator capacity too low   | Use alternator with higher capacity (100 A)        |

| <b>SYMPTOM: THE BATTERY HEATS UP DURING USE AND CONSUMES A LOT OF FLUID</b> |  |
|---|--|
| <b>Possible cause</b>   | <b>Remedy</b>                                  |
| Overloading, or charging voltage too high                                   | Check the charging circuit (voltage regulator) |

| <b>SYMPTOM: BATTERY HAS EXPLODED</b>         |   |
|--|---|
| <b>Possible cause</b>                        | <b>Remedy</b>   |
| Fire or sparks during or just after charging | Ensure good ventilation and exercise due caution as regards fire and sparks |
| Short circuit between the battery terminals  | Exercise caution when storing conductive material (for example, tools)      |
| Internal defect (loose connection)           | Replace the battery   |

| <b>SYMPTOM: DEFECTIVE ALTERNATOR AND/OR DIODES (RADIO AND OTHER POLARITY SENSITIVE EQUIPMENT NOT WORKING)</b> |   |
|---|---|
| <b>Possible cause</b>   | <b>Remedy</b>   |
| Reversed battery polarity, or incorrect charging  | Discharge the battery and charge in the correct direction<br>Replace the battery and/or alternator if necessary |

| <b>SYMPTOM: BATTERY HAS NO VOLTAGE</b> |  |
|--|--|
| <b>Possible cause</b>                  | <b>Remedy</b>  |
| Internal open circuit                  | Replace the battery                                  |
| Battery very deeply discharged         | Charge the battery and test it; replace if necessary |

## 1.2 SERVICE LIFE

The service life of a battery is significantly shortened if it used “cyclically”.

This means that the batteries are used a lot without their being charged.

For example when using a tail lift, cab heater, microwave oven or cooler box.

This is why batteries in commercial vehicles and vehicles used for international transport often fail prematurely (within 1.5 years).

The battery must be charged whenever the voltage measured across one battery falls below 12.5 V. If the battery is not charged, the “sulphating” process will begin.

This is a chemical reaction in the battery that produces lead sulphate. Lead sulphate adheres to the battery plates and can cause short-circuiting between the plates, reducing the capacity of the battery.

However, most lead sulphate breaks down when the battery is recharged.

If a battery is used (discharged) while it is not being charged by the alternator, short-circuiting between the battery plates will occur sooner.

This reduces the capacity and consequently the service life of the battery.

## 2. ALTERNATOR

### 2.1 FAULT-FINDING TABLE

| SYMPTOM: ALTERNATOR NOT PRODUCING POWER WHEN IDLING  |                      |
|--|----------------------|
| Possible cause                                       | Remedy               |
| Open circuit in connection 15 on alternator          | Repair connection 15 |
| Connection 15 on alternator short-circuited to earth | Repair connection 15 |
| Internal defect                                      | Replace regulator    |

| SYMPTOM: ALTERNATOR WARNING (YELLOW)                                      |  |
|---|--|
| Possible cause  | Remedy   |
| Open circuit in "S" connection  | Measure the regulated alternator voltage with as many consumers as possible switched on and with the engine turning above idling speed |
| Open circuit in "L" connection  | Check/repair wiring  |
| Open circuit in connection 15   | Increase the engine speed to approx. 1500 rpm. If voltage is now present, check connection 15 on the alternator                        |
| Voltage difference between "B+" and "S" connections is greater than 2.5 V | Check all contacts between alternator and B+ (contact resistors)<br>Internal battery resistance too high                               |
| Voltage too low < 16 V  | Check alternator drive.<br>Check wiring on contact resistors   |

| SYMPTOM: ALTERNATOR VOLTAGE HIGH (RED) |                              |
|--|------------------------------|
| Possible cause                         | Remedy                       |
| Voltage too high > 31 V                | Measure voltage              |
| Internal defect                        | Replace regulator/alternator |

**1**



### 3. FAULT FINDING

The following test equipment and tools can be used to trace faults.

1. The best instrument for this is a digital multimeter. This instrument can be used to measure voltages, currents and resistances without reading errors and it can be used to trace virtually any faults.
2. The "Multimeter" function of DAVIE XD can be used to carry out all the measurements that can be made with an ordinary, separate multimeter.
3. Many, but not all, faults are easily traced by means of warning lamps. Failures caused by poor earthing cannot normally be detected by a warning lamp or buzzer.

The most frequently occurring faults are:

- a. short circuit
- b. open circuits
- c. earthing problems (poor earthing due to corrosion).

### 3.1 SHORT CIRCUITS

A short circuit is caused by a positive wire shorting somewhere to earth. This can generate a very high current. In most cases this will cause a fuse to blow.

To remedy this failure, use a test lamp of approximately 70 W. First check the diagram to see which consumers are connected to the fuse in question and then switch them all off.


Remove the fuse and connect the test lamp in its place. Now switch each of the consumers on and off one by one. If the lamp comes on very brightly when a consumer is switched on, the fault is almost certainly in the wiring of that consumer. Now check the diagram to see via which connectors the consumer is connected. Now disconnect the first wiring connection (as seen from the fuse).

If the lamp is still bright, the fault is between the fuse and this wiring connection.

If, however, the lamp goes out, the fault is somewhere further on in the wiring.

Now reconnect the connectors and disconnect the next wiring connection. If the lamp is still bright, the failure is between these two wiring connections.

However, if the lamp goes out again, the fault-finding procedure must be continued. The faulty wiring section can be found in this way.



W 5 03 013

### 3.2 OPEN CIRCUIT

Suppose a consumer is not functioning. The fault may be in the consumer itself, or there may be an open circuit in the wiring.

First switch on the consumer. Then check the consumer for voltage using a test lamp. If no voltage is found, first check whether the fuse is still intact.

If there is voltage at the fuse, check the wiring from the fuse to the consumer. This means every wiring connection must be checked.


Stop at the first wiring connection that has no voltage. The open circuit will be between this connection and the previous one.

However, if there was a voltage at the consumer, there may still be an open circuit in the negative (earth) wiring. Check this using a test lamp.


Ensure that the relevant circuit is switched on. Connect one end of the test lamp to earth and the other end to the earth connection of the component to be checked.

If the test lamp comes on, the earth connection of the component is interrupted. If the test lamp does **not** light up, the earth connection will in many cases be in good condition.

If both the positive and negative connections are in good order, the consumer in question must be replaced.



W 5 03 015



W 5 03 016

### 3.3 EARTHING PROBLEMS

Earthing problems are mainly caused by corrosion between the contact surfaces of electrical connections.


Earthing problems can only be detected using a multimeter (preferably digital). A digital tester is preferable because usually only a few volts will be measured and an analogue meter is generally not precise enough for this purpose. To find out whether a specific earthing point has a good earth connection, use a voltmeter to measure the voltage between the negative battery pole and this earthing point.

Switch on as many consumers as possible. If there is a correct earth connection, **no** voltage should be found.

In practice, however, a loss of approx. 0.5 volts will often be measured.

If the reading is higher, the earth connection must be checked carefully.

In this way, the earth connections of all consumers can be checked and measured.



W 5 03 014

## CONTENTS

|   | Page | Date   |
|---|------|--------|
| <b>1. GENERAL</b> .....                     | 1-1  | 200440 |
| 1.1 Multimeter .....                        | 1-1  | 200440 |
| 1.2 Scopemeter .....                        | 1-2  | 200440 |
| 1.3 Signal measurements .....               | 1-2  | 200440 |
| <b>2. DESCRIPTION OF COMPONENTS</b> .....   | 2-1  | 200440 |
| 2.1 Inductive sensor .....                  | 2-1  | 200440 |
| 2.2 Vehicle speed sensor .....              | 2-2  | 200440 |
| 2.3 Temperature sensors .....               | 2-3  | 200440 |
| 2.4 Pressure sensors .....                  | 2-4  | 200440 |
| 2.5 Alternator .....                        | 2-4  | 200440 |
| 2.6 Windscreen heating relay .....          | 2-6  | 200440 |
| <b>3. DIAGNOSTICS</b> .....                 | 3-1  | 200440 |
| 3.1 Diagnostics in electrical systems ..... | 3-1  | 200440 |



## 1. GENERAL

### 1.1 MULTIMETER

The Fluke 87 multimeter allows you to select various measuring options:

#### Units of measurement

The multimeter should be set to the range for the unit of measurement required.

For example, the voltage, current or resistance range.

The units of measurement are indicated by symbols on the meter. The following symbols are used.

1. DC voltage
2. AC voltage
3. DC current
4. AC current
5. resistance
6. duty cycle
7. frequency

- 1 DCV -  $\overline{\overline{V}}$
- 2 ACV -  $\tilde{V}$
- 3 DCA -  $A\overline{\overline{=}}$
- 4 ACA -  $A\tilde{\sim}$
- 5 Ohm -  $\Omega$
- 6 %
- 7 Hz

W 5 01 004

1.2 SCOPEMETER

Diagnostics in modern electronic systems is steadily becoming more complex. Using a multimeter on its own is not always sufficient to diagnose a fault.

The scopemeter allows complex signals to be measured.


Practical examples of complex signals are:

- PWM signals
- deformation of signals
- CAN-bus signals

1.3 SIGNAL MEASUREMENTS


Sine-wave signal (AC voltage)

This signal regularly changes polarity with respect to the "0" line



Frequency


The frequency is shown in Hertz (Hz). The number of complete sines per second is the frequency of the signal (3 Hz in the diagram).



t = 1 second

Voltage

If the number of sines per second increases, not just the frequency increases but also the voltage. This depends on the type of sensor.



W 5 01 002



**Measuring a sine-wave signal**

The sine-wave signal can be measured in the following ways using a multimeter:


- with the multimeter in the frequency (Hz) position.  
In this way, the number of complete sines per second is measured.
- multimeter in the AC voltage position.  
In this way, the average value of the supplied voltage is measured.

**Sine-wave signals in the vehicle**


- Wheel speed sensor output signal
- Engine speed sensor output signal.

**Square-wave signal**

Square-wave signals are signals with only two voltage levels, both of which have the same duration in principle (t1 is equal to t2).



If the duration is different for the two levels (t1 is not equal to t2), the signal is also called "pulse train".




**Duty cycle**

The duty cycle is the ratio between the two voltage levels, expressed as a percentage.


$$\frac{A}{B} \times 100\%$$

The voltage level ratio of a pulse train may change (for example, when the vehicle speed increases).



**Voltage**

If the duty cycle increases, the average voltage will also increase.



W 5 01 001

**Measuring a square-wave signal**

The square-wave signal can be measured in the following ways using a multimeter:

- with the multimeter in the duty cycle (%) position.

In this way, the voltage level ratio is measured.

- multimeter in the DC voltage position. In this way, the average value of the supplied voltage is measured.

**Square-wave signals in the vehicle**

- Output signal of the vehicle speed sensor
- Vehicle speed signal from tachograph to electronic units

## 2. DESCRIPTION OF COMPONENTS


### 2.1 INDUCTIVE SENSOR

The vehicle has a number of inductive sensors, such as:

- wheel speed sensor
- engine speed sensor
- camshaft sensor

#### Registering engine speed

The engine speed is registered via the crankshaft position sensor. The crankshaft position sensor output signal is a sine-wave signal with a frequency corresponding to the number of holes in the pulse disc and the crankshaft rotation frequency. In the engine management electronic unit, the signal is converted into a message, which is sent via the CAN network. The VIC sends this message to the DIP, which then activates the rev counter.



i400442

#### Engine speed sensor operating principle


The inductive sensor consists of a permanent magnet (1), a core (2) and a coil (3). When the inductive sensor is situated between two teeth, the lines of force of the magnetic field will run directly from the north pole to the south pole via the housing.

The moment a tooth approaches the inductive sensor, the lines of force of the magnetic field will run from the north pole to the south pole via the housing, the teeth of the toothed wheel and the core.

As more lines of force are now running through the core, a more powerful magnetic field is obtained.

As a result of this change in the magnetic field, an AC voltage is generated in the coil.

The value of the AC voltage generated depends on the speed of rotation of the toothed wheel and the air gap between sensor (core) and tooth.



W 5 01 005

2.2 VEHICLE SPEED SENSOR

The vehicle speed sensor has two connections for output signals. The real-time speed signal, triggered by a Hall IC, is sent via the first connection,

Via the other connection, a data signal (bi-directional signal) is sent, which involves an exchange of data between the MTCO and the speed sensor. The MTCO requests data from the sensor.

The sensor sends the coded data to the MTCO in sequence, and the MTCO checks the accuracy of this data.

The coded signal consists of the following data:

- serial number of the sensor
- Master key (the same as that of the MTCO)
- coded speed signal

In the MTCO, the coded speed signal is compared with the real-time speed signal. The MTCO sends commands and data to the sensor at 10-second intervals.

**Duty cycle speed signal**


The speed signal sent via the vehicle speed sensor to the MTCO is processed by the MTCO and sent as a message via the CAN network. The speed signal is also converted into a duty cycle signal. This duty cycle signal is used by the electronic units that do not receive the speed signal message via the CAN network.

The diagram alongside shows the linear characteristic of the duty cycle (%) in relation to the vehicle speed (V).


This graph applies to all vehicle models.

**Inspection**

The duty cycle signal (square-wave voltage) can be checked with a multimeter that is set to the DC voltage or duty cycle range or with a scopemeter.



E501055



E501057

## 2.3 TEMPERATURE SENSORS

The vehicle has a number of temperature sensors, such as:

- coolant temperature sensor
- inlet air temperature sensor
- fuel temperature sensor
- ambient air temperature sensor

These sensors are temperature-sensitive resistors.

The resistance of these sensors changes considerably with rises or drops in temperature.

There are two types of temperature sensor:


- NTC resistor (Negative Temperature Coefficient)
- PTC resistor (Positive Temperature Coefficient).

### NTC resistor

In an NTC resistor, the resistance value reduces as the temperature rises.

Application:

- measuring coolant temperature.



### PTC resistor

In a PTC resistor, the resistance value increases as the temperature rises.


In the PTC resistor, in contrast to the NTC resistor, there will be a great change in resistance within a small temperature range.

Application:

- measuring air temperature when cab heater is on.

### Inspection

The temperature sensors can be checked using a multimeter that is set to the resistance range.



2.4 PRESSURE SENSORS

The vehicle has a number of pressure sensors, such as:


- pressure sensor to register the bellows pressure in ECAS.
- pressure sensor on the air supply unit for pressure gauges in the DIP-4.

There is a diaphragm made of semiconducting material (silicon) in the pressure sensor. When pressure is applied to the diaphragm, it will be deflected. Deflection of the diaphragm leads to a change in the resistance of the semiconducting material.

The diaphragm is part of what is known as a bridge circuit. Deflection of the diaphragm unbalances the bridge circuit, which changes the output signal. The output voltage is in direct proportion to the pressure applied (deflection of the diaphragm).

Inspection

The output voltage can be checked using a multimeter set to the DC voltage range.




W 5 01 012

2.5 ALTERNATOR

The compact alternator is a lightweight alternator with two internal cooling fans. The electronic controller also controls pre-excitation of the alternator. The function of the exciter diodes has also been taken over by the controller. The alternator generates high currents in the lower speed range.

- S sens connection of the regulator
- 15 power supply after contact
- L connection to VIC

The alternator has two B+ connections that are connected to each other internally. B+1 is connected to the batteries and the B+2 connection is connected to the "S" connection on the regulator. B- (earth) is connected to the alternator housing.



E501373

**Connection 15**

When the contact has been turned on, power is supplied to the alternator via connection 15, pin 3 (1010). The regulator uses this power to activate pre-excitation (self-energising). If there is an open circuit in this connection, the alternator will not produce any power until it reaches a speed of about 5000 rpm. This corresponds to an engine speed of approx. 1500 rpm. The alternator will energise itself when it reaches this speed.

**Sens connection**

The sens connection, pin 4, can be used to compensate for voltage losses in B+.

There are voltage differences between the alternator and the battery.

Voltage regulation can be improved if these voltage variations can be controlled.

This function is, however, not used. The sens connection is connected directly to B+2 and therefore no voltage differences are measured.

**L connection**

The L connection, pin 2, is connected to the VIC electronic unit.

This connection is used to activate a fault message in the main display via the VIC, if necessary.

L voltage high: no fault


L voltage low: fault

The following faults can be detected via the "L"-connection:

- voltage too low (< 16 V)
- open circuit in connection 15 (1010)
- open circuit in "S" connection - open circuit in "L" connection

These faults are indicated by the yellow "Alternator fault" warning.


Too high a voltage (red warning) can be recognised by too high a voltage (> 31 V) on the VIC electronic unit.



E501129


2.6 WINDSCREEN HEATING RELAY

The windscreen heating relay (2) is a time relay with a duration of 12 minutes. The relay is activated by the mirror heating switch (1). This activates the timer (4) in the relay. The timer in its turn activates the internal relay (5), thus supplying the windscreen heating system (3) with power.



E501512

- A. After 12 minutes the timer automatically switches off the internal relay, although the switch continues to be operated.
- B. If the switch is turned off before the 12 minutes have passed, the relay is still switched on for 12 minutes.
- C. If the switch is turned on and off twice in succession within the twelve minutes, the timer will turn off the relay.



E501513



### 3. DIAGNOSTICS

#### 3.1 DIAGNOSTICS IN ELECTRICAL SYSTEMS

For diagnosis, DAVIE XD is used.

This tool has a two-channel scope and a multimeter function.

DAVIE XD is also used to read data from electronic systems. When a fault arises, it offers the option of selecting a "guided" diagnosis that goes through a series of measurement steps to help locate the cause of the problem.

Refer to the user manual for an extensive description of the operation and possibilities of DAVIE XD.



**CONTENTS**

|   | Page | Date   |
|---|------|--------|
| <b>1. GENERAL</b> .....                           | 1-1  | 200440 |
| 1.1 Connector .....                               | 1-1  | 200440 |
| 1.2 Contact .....                                 | 1-1  | 200440 |
| 1.3 Contact kits .....                            | 1-2  | 200440 |
| <b>2. REMOVAL AND INSTALLATION</b> .....          | 2-1  | 200440 |
| 2.1 Removal and installation, connectors .....    | 2-1  | 200440 |
| 2.2 Removal and installation, contacts .....      | 2-2  | 200440 |
| 2.3 Fitting contacts to electrical wires .....    | 2-9  | 200440 |
| 2.4 Fitting a SCAT seal .....                     | 2-16 | 200440 |
| 2.5 Fitting an electrical buffer connection ..... | 2-17 | 200440 |
| 2.6 Removal and installation, earth wire .....    | 2-19 | 200440 |
| 2.7 Repairing CAN network wiring .....            | 2-20 | 200440 |



## 1. GENERAL

The increasing application of electronics in vehicles means a much broader range of connectors, contacts and wiring is being used. Be sure to pay special attention to this during repairs, so as to avoid unnecessary faults.

### 1.1 CONNECTOR

A connector is a removable connection between two or more electrical wires or components. The female contacts are on one side and the male contacts on the other side. This way they can be connected and disconnected.

The connector should protect the contacts against unwanted electrical connections and external influences. It also ensures the proper connection of the applicable contacts.

### 1.2 CONTACT


A connector has one or more contacts. These contacts are available in various sizes and models.

However, they all have the same design:

The mating part (1) enables the electrical connection between the contacts.


The contact press part (2) is the electrical connection between the stripped part of the wire and the contact.

The relief part (or pull relief) (3) relieves the contact press part from mechanical wear. The insulation relief is placed over the insulating sheath and/or the SCAT.



E501479

With contacts, three dimensions are important: the diameter (1) of the wire to be connected, the size of the contact press part (2), which is linked to the wire diameter, and the size of the mating part (3).



E501504


1.3 CONTACT KITS

Contact kit A

Contact kit A (DAF no. 0694960) is available for the contacts, except SCAT contacts and micro-timer contacts.

There is a sticker on the inside of the box to facilitate selection of the contact, contact crimping tool and ejector tool.

3




W 5 03 019

At the top the DAF no. of the contact is shown. Roman numerals I and II, shown below the illustrations, refer to the contact crimping tool to be used.

The numeral or letter added to Roman numeral I or II indicates the hole in the contact crimping tool in which the contact is to be placed. Roman numerals III to VII refer to the type of ejector tool to be used for removing the contact from the connector.

The information at the bottom refers to the core section suitable for the contact.



W 5 03 018

**Contact kit B**

Additional contact crimping and ejector tools are required for SCAT contacts and for micro-timer contacts. Contact kit B (DAF no. 1240065) is available for this purpose. There is a sticker on the inside of the box to facilitate selection of the contact, contact crimping tool and ejector tool (to be used in the same way as for contact kit A).

**Note:**

The proper ejector tool and the proper contact crimping tool for each contact can also be found through "Parts Rapido".






## 2. REMOVAL AND INSTALLATION

### 2.1 REMOVAL AND INSTALLATION, CONNECTORS

#### Unlocking the connectors

The connectors can often be locked with one another or with a component. They can be divided into:

- A. active locking.  
This means that the lock must be activated. With this type a lock must often be pressed.
- B. passive locking.  
Opens when the parts are pulled apart with a certain force.




E501480

#### Two connectors in one housing

These connectors consist of two separate connectors. To remove the contacts first remove the connectors from the connector housing. Push the locking lip aside before removal. The connector can then be slid out of the connector housing.

For example:

- connector for VIC electronic unit




E501484

2.2 REMOVAL AND INSTALLATION, CONTACTS

**Contact lock**

There are various types of contact locks. A few examples are given below. When a lock is applied, individually for each contact, this is called a primary lock. An extra general lock for several contacts in a connector is a secondary lock.




E501481

3

**Primary contact lock**

To keep an individual contact in the connector in place, a contact is often furnished with one or more locking bolts. This is a primary lock. These locking bolts should never be damaged, with a view to pressing and ejecting the contacts.



E501483

**Secondary contact lock**

This type of lock is normally used on 2 and 3-row connectors.

For connectors (1) with a locking lip (2) first remove the lip before removing the contacts. This is a secondary lock. The locking lip is on the side of the connector and can usually be recognised from a colour that is different from the colour of the connector. The lip is removed entirely. Now the contacts can be removed using the proper ejector tool by unlocking the primary lock.

Examples:


- cab connectors
- electronic unit connectors

The contacts may also be locked secondarily by the lower part of the connector. After tilting this lower part, the contacts can be removed by unlocking the primary lock using the proper ejector tool.

This type of lock is used only on 2-row connectors.

For example:

- MTCO connector



E501497

A different type of secondary lock consists of two sliding parts of the connector. The upper half (on the wire insert side) and the lower half form the extra contact lock.


To unlock this secondary contact lock the upper half of the connector must be pushed away slightly in the direction of the arrows on the connector housing.

The contacts can then be removed from the connector using the proper ejector tool.

After any installation of wires with contacts, the connector must be pressed into the lock again. If this is not done it will not fit into the counterpart.

Application examples:

- connector for CDS electronic unit
- connector for ECAS-2/3 electronic unit
- connector for UPEC electronic unit



E500475


### Ejecting contacts

For repair or extension of the wiring a contact may have to be replaced or added. Using special ejector tools a contact can be removed from the connector without being damaged. For the proper ejector tools, see "Parts Rapido".

1. Push the wire with contact forwards (1). The locking bolt (2) is now free from the connector (3).
2. Push the proper ejector tool (4) into the front of the connector. This will push the locking bolt (2) down.
3. The contact can now be removed by gently pulling the wire.

#### Note:

If the wire is pulled before the ejector tool pushes the locking bolt down, the contact will only be fixed in the connector even more.



E501482

Contacts are also used in which the locking bolt (2) is on the rear of the connector (3).

1. Pull the wire and contact backwards (1). The locking bolt (2) is now free from the connector (3).
2. Push the proper ejector tool (4) into the back of the connector. This will push the locking bolt (2) up.
3. The contact can now be removed by gently pushing the wire forwards.

**Note:**


Here the locking bolt works exactly the opposite to the usual connectors.

Application examples:

- EMAS pressure sensor connector
- accelerator sensor connector for CF series / XF series

For each contact a specific ejector tool is required.

The proper ejector tool for each contact can be found through "Parts Rapido".



E501696

**Locking an MQS (Micro Quadlock System) contact**

Before the contact can be removed, the lock must be unlocked with a needle-shaped object.


1. First press the lock at the end of the connector (1). At the same time gently pull the wire (2) until resistance is felt.
2. Then press the second lock (3) and again gently pull the wire (2).
3. The contact can now be removed from the connector.

**Note:**

This type of contact is locked twice and must therefore be unlocked twice.

Application example:

- connector for VIC electronic unit




E501486

### Removing contacts from the Bosch 89-pin connector

To remove a contact from this connector proceed as follows:

1. Fold the protective cover around the wiring harness down by pushing the lock outwards.
2. Now push the two outer halves of the protective cover outwards and then upwards. The protective cover can now be removed.
3. The pink secondary contact lock (1) must be slid to the centre of the connector to enable the contacts to be removed.
4. The contacts can now be removed using the proper ejection tool.



E501485

#### Note:

The larger contacts are locked with four locking bolts. The smaller contacts are locked with two locking bolts.

Always unlock the locks when adding contacts!


### Fitting the Bosch 89-pin connector

When refitting the protective cover, ensure that the siphon and slide are both in the "unlocked" position.

If they are not, the connector, when fitted, will not be locked correctly on the electronic unit. As a result, the contact between the connector and the electronic unit may be bad.

Application example:

- connector for ECS-DC3 electronic unit



E501498

**Removing 39-pin connector contacts**


1. Loosen union G.
2. Push pressure ring H and seal K back slightly over the wiring.
3. Then eject the contacts from connector housing F using a special ejector tool from contact kit A or B.

**Fitting 39-pin connector contacts**

1. Fit union G, pressure ring H over the wiring.
2. Fit new contacts to the wires using the correct tool.
3. Insert the wires and contacts through seal K.
4. Press the contacts to their definitive positions in connector housing F.
5. Press seal K against connector housing F.
6. Position pressure ring H so that the two ridges on the side of connector housing F fall into the pressure ring recesses.
7. Tighten union G by hand.

**Note:**

- Pressure ring H has contact numbers (their purpose is to enable the contacts to be positioned correctly). These contact numbers must be in the same position as the contact numbers on the connector housing.
- When an incorrectly positioned wire is removed the seal will leak. If a new wire is not inserted a sealing plug should be fitted.



E500477


# 3

### Removing contacts from 39-pin connector counterpart

1. Loosen end union nut A and tapered coupling nut B and push these as far as possible back over the insulation pipe.
2. Push pressure ring H and seal K as far as possible back over the wiring harness.
3. Push union E back over the wiring harness.
4. Carefully remove the sealing ring (2).
5. Carefully loosen the locking lugs (3) in connector housing F.
6. Remove centring sleeve D from connector housing C.
7. Then eject the contacts from connector housing C using a special ejector tool from contact kit A or B.

### Fitting contacts in 39-pin connector counterpart

1. Push end union nut A and tapered coupling nut B as far as possible back over the insulation pipe.
2. Fit the centring sleeve (D) in connector housing C so that all openings are positioned opposite one another.
3. Check that all locking lugs (3) are positioned in the lock openings (1).
4. Insert the wires without contacts through pressure ring H and seal K.
5. Fit new contacts to the wires using the correct tool.
6. Feed the cable harness through tapered coupling nut B.
7. Press seal K against connector housing C.
8. Position pressure ring H so that the two ridges on the side of connector housing C fall into the pressure ring recesses.
9. Press the connector pins into their correct positions in connector housing C.
10. Fit sealing ring (2) around centring sleeve D and press it until the stop of connector housing C.



E500478



**Note:**

- When carrying out the last two steps it is important not to twist the cable harness as this can lead to serious damage (wire breakage).
  - Tighten the respective union nuts by hand. Do not use tools (pliers) to do this.
11. Screw tapered coupling nut B onto connector housing C.
  12. Screw end union nut A (with insulation pipe) onto tapered coupling nut B.

### 2.3 FITTING CONTACTS TO ELECTRICAL WIRES

The increasing application of electronics in vehicles means a much broader range of connectors, contacts and wiring is being used. The result of this is that more attention has to be paid to making and repairing connections. The following criteria should be taken into account:

1. Wires with a reduced insulation thickness, with retention of the mechanical properties, for use with core sections from 0.5 to 2.5 mm<sup>2</sup>.
2. Wires with a normal insulation thickness, for use with core sections from 4 to 120 mm<sup>2</sup>.
3. Wires for various temperature ranges:  
T1: from -40°C to +70°C (in cab and chassis) and  
T2: from -40°C to +100°C (in engine compartment and gearbox)

**Note:**

In view of the mechanical strength required, the minimum permissible core section is 1 mm<sup>2</sup>, with the exception of cab wiring. At certain points this may be 0.5 mm<sup>2</sup>.

To ensure the reliability of systems and connections, the following points should be observed when repairs or extensions are made to the wiring:

# 3

- A. Always choose the following:
- the correct type of contact
  - the correct wire diameter for the contact used
  - the correct type of contact material (tin-plated, silver-plated or gold-plated)
- B. Use the right tool for the job. Wire ends are always clamped to a contact. Special crimping tools have been developed for this purpose.

**Note:**

Connections will only be reliable if these crimping tools are used and the contact is fitted in the correct hole.

- C. Strip the correct length of wire. Always use stripping pliers. The rule of thumb is:  
strip length = crimp-sleeve length + 1 mm.

Make sure that the core is not damaged during stripping or problems may occur after some time.

**Note:**

A good connection will only be obtained if points A, B and C are complied with. This implies that both the copper core and the insulation are firmly clamped in place.


**Crimping wire to a contact**

Choose the right crimping tool and place the contact in the correct hole.


**Note:**

The proper crimping tool for each contact can be found through "Parts Rapido".

The contact may never be in a twisted, slanting or slid position (X) in the press clamp opening.



1. Place the wire in the contact.
2. The stripped wire part, the copper conductor, must be in the contact press part (1). The wire insulation must be in the relief part (2).
3. Check again whether the wire is in the correct position in the contacts (1 and 2) and press the contact press parts (3 and 4) together.
4. Do not interrupt the contact pressure before the tool is completely compressed in the end position. Only then is full contact pressure reached and the tool can be opened.



E501502


**Copper connection**

- 1A. Wire diameter too large
- 1B. Wire diameter too small
- 2A. Crimp height too great (hole in crimping tool too large)
- 2B. Crimp height too small (hole in crimping tool too small)
- 3A. Asymmetric crimping
- 3B. Asymmetric crimping
- 4. Proper contact crimping

S = material thickness

x = cracking

- 1A. There is a risk that copper conductors could stick out, which would adversely affect the fixed position of the other copper conductors. This may result in a short circuit and loose contact.
- 1B. The contact may crack and the copper conductors may not be sufficiently fixed in the contact.
- 2A. Copper conductors are not sufficiently fixed in the contact. The wire will come loose of the contact.
- 2B. The contact will be damaged. The contact may crack after some time and the wire will then come loose from the contact.
- 3A and B. The contact will be damaged and the copper conductors are not fully fixed in the contact. The wire may come loose. The height of any bulge on the contact may not exceed the material thickness of the contact. The width of this bulge may not exceed half the material thickness.



E501494













3

**Insulation connection**

Different types of crimping are allowed:

1. normal crimping: the two sides of the relief part fully engage the insulation.
  2. double crimping: two wires are clamped in one contact.
  3. overlap crimping: the two sides of the relief part engage one another slightly.
  4. double overlap crimping: two wires are clamped in one contact, the two sides of the relief part engaging one another slightly.
- A. If the insulation connection is correct, the wire is clamped in the relief part with the correct pressure and the insulation is not broken.
- B. If the contact pressure is too high the insulation could break, possibly causing a short circuit.  
This may for instance be caused by:
- using the wrong crimping tool
  - using an improper hole in the crimping tool (too small)
  - a defect in the crimping tool delaying the interruption of the contact pressure.
- C. If the contact pressure is not sufficient the insulation may not be clamped and the wire may come loose. This will interrupt the electrical connection but may also result in a short circuit.  
This may for instance be caused by:
- using the wrong crimping tool
  - using an improper hole in the crimping tool (too big)
  - interrupting the contact pressure prematurely.

**3**

|   | A  | B  | C   |
|---|--|--|---|
| 1 |   |   |   |
| 2 |   |   |   |
| 3 |   |   |   |
| 4 |  |  |  |


E501511

- 1. Normal crimping
- 2. Double crimping
- 3. Overlap crimping
- 4. Double overlap crimping

- A. Proper insulation connection
- B. The insulation is broken
- C. The insulation is not secured

With double crimping the thinnest wire is always at the bottom.


A connection can be checked by gently pulling the wire after the contact is placed in the connector. The lock of the locking bolt in the connector should then be felt.



E501501

**Examples of wire-contact connections**

- A. Wire not sufficiently slid forwards.  
The wire is not sufficiently slid forwards to ensure a proper current transfer and pull relief.
- B. Stripped part of the wire too short.  
The stripped part of the wire is too short to ensure a proper current transfer whereas a part of the insulation is clamped underneath the contact press part.
- C. Wire too far backwards.  
If the stripped part of the wire is too long and the wire is placed correctly relative to the contact press part, the pull relief will cover too little of the wire.
- D. Wire too far forwards.  
If the stripped part of the wire is too long and the wire is placed correctly relative to the pull relief, the copper conductors at the front will stick out too far past the contact press part.
- E. Copper conductors not clamped.  
Copper conductors not clamped may cause a short circuit to other wires nearby.
- F. This is a correct connection.



E501499

### 2.4 FITTING A SCAT SEAL

SCATs are used in places where wires are exposed to heavy conditions (environment or application of the vehicle), with the risk of water entering the connector.


The SCAT seal, which is made of silicone, prevents corrosion inside the connector and keeps the seal properties intact in the event of temperature changes.

The SCAT seal is pressed around the wire with the relief part of the contact.

The SCATs are available in various colours and sizes.

# 3

1. Select the right SCAT for the wire, contact and connector.
2. Slide the SCAT onto an unstripped wire (A).
3. Slide the SCAT far enough onto the wire and strip the wire to the proper length (B).
4. Slide the SCAT back to the tip of the stripped wire so that the copper just sticks out of the SCAT (C).
5. Place the contact in the proper manner (D) around the SCAT (2) and the stripped wire (1).
6. Now crimp the contact around the SCAT and the wire using the proper crimping tool.



E501503



## 2.5 FITTING AN ELECTRICAL BUFFER CONNECTION

A buffer connection is made when at least two wire ends must be connected to one another. This may be required because of a wire repair or if a wire is to be added to a connection.

### Note:

When adding a new wire to an existing wire, both wires must be of the same thickness. If part of the existing wire is to be removed, try to make sure that the wire number can still easily be found on the wire.

The contact crimping part (1) is the electrical connection to the stripped wire part. The central stop (2) is a limiter, preventing the wire to be connected from being inserted too far. The insulation is a crimp insulating sleeve with glue layer (3), which, after heating by a blow drier, will offer protection against unwanted electrical contact and corrosion.



There are three different buffer connectors available: red, blue and yellow. Depending on the wire thicknesses to be connected (and possibly the number of wires to be connected) a specific colour must be used.

- red diameter 0.25 - 0.75 mm<sup>2</sup>
- blue diameter 1.0 - 2.5 mm<sup>2</sup>
- yellow diameter 4.0 - 6.0 mm<sup>2</sup>




**Connecting more than two wires to one another is not recommended. The glue layer of the crimping insulation is not sufficient to seal all resulting gaps. So this is certainly not permitted outside the cab.**

It is very important to carry out contact crimping in the correct way to prevent electrical faults. For cold fusion a contact crimping tool is required. This tool creates a cold fusion between wire and buffer connector.



E501489



E501491

### Fitting the contact crimp connector

1. Select the right buffer connector for the wires to be connected.

**Note:**

If three wires of the same diameter have to be connected after all, choose a buffer connector that is the same diameter as two of the wires. The single wire on the other side must be stripped to double length and folded double.

The same applies when a wire is used on one side that is twice the diameter of the other.

2. Strip the wire to a length of 4 to 5 mm.


**Note:**

The stripped wire tip may **not** be twisted.


3. Choose the proper contact crimping tool on the basis of the buffer connector and wire diameter, and check the holes to be used.
4. Place the buffer connector in the hole of the tool and clamp it gently so the buffer connector will remain in the hole.
5. Slide the stripped wire ends into the side of the buffer connector that is engaged by the contact crimping tool.

**Note:**

The insulation of the wire may not be slid into the contact part of the buffer connector.



E501490




E501492

6. Compress the contact crimping tool: Do not interrupt the contact crimping before the tool is completely compressed to the end position. Only then is full contact crimping achieved and the tool is opened.
7. Repeat this for the other ends of the buffer connector.
8. Check the contact crimping for damage and pull the wires to ensure they are properly fixed.

**Note:**

Improper contact crimping means a bad connection, which may cause failures.



E501493



**Avoid breathing in the vapours produced when heating the crimping insulation.**

9. Heat the crimping insulation to fix it properly to the wire insulation. Ensure that the insulation does not get burnt. If the insulation gets burnt it will become brittle and easily break or crack.


## 2.6 REMOVAL AND INSTALLATION, EARTH WIRE

When a failure occurs in an electrical system, one of the first things to be checked is the earth connection, with particular attention being paid to earth connection on the chassis.

### Points for special attention when checking earth connection on chassis

If an earth connection has been removed and is being re-installed, pay attention to the following:

- the bolt, nut, earth strip and washers must be cleaned (e.g. using a steel brush or sand paper). If a component is corroded, it must be replaced by a new one.
- clean all dirt and paint from the area around the engine/chassis earth connection on both sides of the chassis member so that the bare metal is visible.



E501495

- clean all dirt and paint from the area around the battery/chassis earth connection on the inside of the chassis member so that the bare metal is visible.
- on the earth strip side, the cleaned area must be larger than the contact area of the earth strip.
- on the nut side, the cleaned area must be larger than the contact surface of the nut.
- after fitting the earth connection, a protective zinc primer should be applied to both sides of it and it should be painted.

## 3


## 2.7 REPAIRING CAN NETWORK WIRING

When repairing or replacing CAN wiring, the original twisted lengths and diameters of the wiring must be taken into consideration. A 10% tolerance in the twisted length of the wiring is permitted. Winding density 40-50 turns/m.

When repairing the wiring, the winding density must be maintained, with the provision that it is permissible for the wiring at the point of repair to have no windings over a maximum length of 60 mm. When the wiring is being repaired, it must be secured in a wire tie at the end and in the middle.

### Replacing CAN wire

1. Measure the length of the original wire when untwisted.
2. Measure the diameter of the original wire. Always take a wire of the same diameter or, if this is not available, of the next size up.
3. Preferably choose a wire of the same colour as the original wire.
4. Follow the routing of the original wire and secure the wire in the original way.



E500977

## CONTENTS

|  | Page | Date   |
|--|------|--------|
| <b>1. SAFETY INSTRUCTIONS</b> .....            | 1-1  | 200440 |
| 1.1 Batteries .....                            | 1-1  | 200440 |
| 1.2 Battery charging .....                     | 1-1  | 200440 |
| <b>2. CHARGING BATTERIES</b> .....             | 2-1  | 200440 |
| 2.1 General .....                              | 2-1  | 200440 |
| 2.2 Methods of charging .....                  | 2-2  | 200440 |
| <b>3. STORAGE OF BATTERIES</b> .....           | 3-1  | 200440 |
| 3.1 General .....                              | 3-1  | 200440 |
| 3.2 Storage up to four weeks. ....             | 3-1  | 200440 |
| 3.3 Storage for more than four weeks .....     | 3-2  | 200440 |
| <b>4. INSPECTION OF BATTERIES</b> .....        | 4-1  | 200440 |
| 4.1 Visual inspection .....                    | 4-1  | 200440 |
| 4.2 Inspection of the charging condition ..... | 4-2  | 200440 |
| 4.3 Inspection using a battery tester .....    | 4-4  | 200440 |



## 1. SAFETY INSTRUCTIONS

### 1.1 BATTERIES

- Always remove the earth lead before working on batteries.
- When connecting battery leads, always connect the earth lead last.
- Always handle batteries carefully and hold them upright.
- The sulphuric acid in the batteries is an aggressive and poisonous liquid. While working on batteries, wear protective clothing, gloves and safety goggles.
- In case of contact with cloths, the skin or the eyes, wash immediately with copious amounts of water. Consult a doctor in case of contact with eyes or skin.
- When topping up batteries, never allow the fluid level to rise more than 10 mm above the plates or to go higher than the level indicator.
- Never put down tools or other materials that could accidentally short-circuit the battery terminals on the batteries or in the vicinity of batteries. Short-circuited battery terminals may cause the battery to explode.
- Secure the batteries well after completing the work, but not too tightly.

### 1.2 BATTERY CHARGING

- During battery charging, an explosive gas mixture may be released.
- Only charge batteries in a well ventilated area.
- Never smoke or allow naked flames or sparks in the vicinity of the battery.
- Allow frozen batteries to thaw before charging.
- Switch the charger off before disconnecting the leads to the battery.





## 2. CHARGING BATTERIES

### 2.1 GENERAL

- A battery may only be charged using DC current. Connect the positive terminal of the battery to the positive (+) connection of the charger and the negative terminal of the battery to the negative (-) connection of the charger.  
The cell sealing plugs may remain on the battery during charging (except during fast charging).  
During charging, the cell voltage will rise. This increase in voltage depends on the charging current applied and the temperature. During normal charging, the cell voltage will rise from about 2 volts/cell to about 2.65 volts/cell. If a charging voltage of about 2.35 to 2.4 volts/cell (about 14.2 volts in a 12 V battery) is exceeded, this will start off active gas development. As a consequence of the rise in voltage during charging, the charging current will, as a rule, fall gradually.  
Overcharging will reduce the service life of a battery.
- If the charging of the battery is continued after it has been fully charged (even with a low current), this will lead to corrosion (corrosive attack) of the grids of the positive battery plates. This type of wear leads to premature redundancy of the battery.  
Depending on the capacity of the charger, the normal charging time is between 8 and 15 hours.  
If during charging the temperature of the battery acid rises to more than 55°C, the charging should be stopped. High temperatures reduce the service life of the battery.
- A battery may be said to be charged if the charging voltage has not increased for more than 2 hours and the acid density (relative density) has reached the nominal value (for example, 1.28 kg/dm<sup>3</sup>) and does not rise further.

- A charged battery must be used immediately. If this is not possible, maintain the battery as described in the section "Storage of batteries".
- A discharged battery must be charged as soon as possible. If a discharged battery is not recharged, the battery plates may become sulphated (i.e. hard), which will lead to permanent loss of capacity.

## 2.2 METHODS OF CHARGING



**Always disconnect the battery clamps before charging.**

4

### Normal charging

- Normal charging is done to restore partially or fully discharged batteries to full capacity. In most cases, a charging current of  $\frac{1}{20}$  to  $\frac{1}{10}$  of the capacity is selected.
- It is important to reduce the charging current during gas development and to switch the charger off when the battery is charged.

### Fast charging

- With this charging method, multiples of the normal charge current (approx. 3 to 5 times) are used in order to achieve an acceptable charge condition in the shortest possible time.
- Before fast charging, remove the battery leads in order to prevent damage to the electronic components.
- Remove the cell sealing plugs so that the released gases can easily escape.
- To prevent overcharging, switch to a lower charging current on reaching the gas pressure (2.35 to 2.4 volts/cell).

**Note:**

Avoid fast charging. Only use this method in exceptional cases. Fast charging causes battery overloading, which reduces the service life of the battery.

**Buffer charging**

- With this method, the consumer and the charger are both connected to the battery. The charger delivers sufficient current to ensure that the battery remains virtually fully charged. The battery will deliver peak currents to the consumer.
- Buffer charging is best done at a constant (stabilised) voltage.

**Trickle charging**

- A fully charged battery that is not used for some time will start to discharge of its own accord. It may discharge at a rate of 0.1% to 1% per day. Trickle charging compensates for such discharges.
- The charging current for trickle charging should be around 0.1 A per 100 Ah.



### 3. STORAGE OF BATTERIES

#### 3.1 GENERAL

Before storing batteries, carry out the following operations:

1. Remove the battery clamps.
2. Clean the battery terminals and the top of the batteries.
3. Grease the battery terminals with petroleum jelly.
4. Check the electrolyte level. The electrolyte level must be approx. 10 mm above the plates or up to the level indicator, if there is one.  
If necessary, top up the batteries with distilled water.
5. Check the charging condition of the batteries and charge them if necessary. See the section "Inspection and adjustment".

#### 3.2 STORAGE UP TO FOUR WEEKS.

If batteries (whether as separate units or fitted in a vehicle) are not going to be used for an extended period of time not exceeding four weeks, the following measures should be taken:

1. Do **not** connect the battery leads to the batteries.
2. Check the battery charge level regularly. See "Inspection and adjustment".  
If the voltage falls below 12.4 volts, or if the relative density of the electrolyte in one or more of the cells is less than 1.23 kg/dm<sup>3</sup>, the battery must be charged.

**Note:**

The higher the ambient temperature, the more rapidly the battery discharges.  
The lower the relative density of the electrolyte, the higher the risk of the battery freezing.

**3.3 STORAGE FOR MORE THAN FOUR WEEKS**

If the batteries will not be used for more than four weeks, the following measures should be taken:

1. Remove the batteries from the vehicle and store them in a frost-free, dry, cool and well ventilated room.
2. Check the charging condition of the batteries regularly, at least once every four weeks. See "Inspection and adjustment". If the voltage falls below 12.4 volts, or if the relative density of the electrolyte in one or more of the cells is less than 1.23 kg/dm<sup>3</sup>, the battery must be charged.
3. Limit the storage period to a maximum of three months. The longer the period of storage, the greater the permanent loss of capacity.

## 4. INSPECTION OF BATTERIES

### 4.1 VISUAL INSPECTION

- A white dividing line at  $\frac{1}{3}$  of the plate height (this can be seen through transparent battery boxes) indicates that the battery has been allowed to remain in a seriously discharged condition.
- If the electrolyte is brown and the battery consumes a lot of fluid, this indicates that the battery is overcharged.
- If the electrolyte is turbid and milky and the cells have a white deposit, the battery has become damaged due to insufficient charging (deep discharge).

**4.2 INSPECTION OF THE CHARGING CONDITION****Relative density**

- The charging and discharging of the battery leads to a chemical reaction in the battery, which involves sulphuric acid. The sulphuric acid concentration drops as the battery discharges.  
The concentration, measured as relative density ( $\text{kg}/\text{dm}^3$ ), is a useful yardstick for determining the charging condition of the battery.
- An acidimeter can be used to check the charging condition.  
Relative density at  $27^\circ\text{C}$  in  $\text{kg}/\text{dm}^3$   
Charged battery : 1.28  
Half-charged battery : 1.20  
Discharged battery : 1.10
- Measurement corrections are necessary if temperatures are significantly lower or higher. For every  $10^\circ\text{C}$  of lower temperature, subtract 0.007 points from the measured value. For each  $10^\circ\text{C}$  of higher temperature, 0.007 points must be added. In batteries in good condition, the relative density must be the same in all the cells. The maximum difference between the highest and lowest relative density may not exceed  $0.03 \text{ kg}/\text{dm}^3$ .

**Note:**

If the relative density in one of the cells is much lower than in the other cells, the cause may be cell closure. If the relative density of two adjacent cells is much lower than in the other cells, this indicates a leak in the cell partition. In both cases, the battery must be replaced.



**Voltage**

- The charging condition of the batteries can also be measured using a sensitive, preferably digital voltmeter. This method can only be used 1 to 2 hours after full completion of charging or discharging. Measure the absolute rest voltage (the positive and negative clamps must be removed from the battery). The charging condition of the battery can be calculated using the formula: voltage per cell = relative density ( $\text{kg}/\text{dm}^3$ ) + 0.84.

**Example:**

For a fully charged battery, the relative density per cell is  $1.28 \text{ kg}/\text{dm}^3$ . The voltage per cell is therefore  $1.28 + 0.84 = 2.12 \text{ V}$ . A 12 V battery has 6 cells. The total voltage for a charged battery is  $6 \times 2.12 = 12.72 \text{ V}$ . The voltage of a half-charged battery is approx. 12.24 V. The voltage of a discharged battery is approx. 11.75 V.

**4.3 INSPECTION USING A BATTERY TESTER**

- The general condition of the battery can be checked quickly using a battery tester. For this check, a load is applied to the battery and then the discharge voltage at the battery terminals is measured. The load applied to the battery must be at least 3 times the capacity of the battery.
- The rule of thumb is that the test can be carried out when the battery is sufficiently charged (relative density 1.25 - 1.28 kg/dm<sup>3</sup>).  
At normal temperatures (10-20°C), the charging voltage for a properly charged battery must be 10 volts after 10 seconds. In the case of a partially discharged battery (relative density 1.25 kg/dm<sup>3</sup>), the reading should be at least 9 volts.  
It is important that the voltage be measured directly at the battery terminals.

## CONTENTS

|  | Page | Date   |
|--|------|--------|
| <b>1. CONNECTION OF ACCESSORIES</b> .....  | 1-1  | 200440 |
| 1.1 General .....  | 1-1  | 200440 |
| 1.2 Reserve wires .....  | 1-3  | 200440 |
| 1.3 Dashboard lead-through connectors, general .....   | 1-8  | 200440 |
| 1.4 Dashboard lead-through connectors for<br>superstructure functions application connectors ..... | 1-9  | 200440 |
| 1.5 Dashboard lead-through connector for<br>engine speed control application connector .....       | 1-15 | 200440 |
| 1.6 Automatic gearboxes application connector .....  | 1-18 | 200440 |
| 1.7 Connector for 12V connection in roof console .....   | 1-20 | 200440 |
| 1.8 Connectors for connecting the radio .....  | 1-20 | 200440 |




## 1. CONNECTION OF ACCESSORIES

### 1.1 GENERAL

On LF vehicles the various possibilities for application connectors and reserve wiring consist of a number of different wiring harnesses.

One extensive application chassis wiring harness is connected to dashboard lead-through connectors 716, 78 and 826.

The following connectors connected to this wiring harness can be found on the chassis: A068, 816, 823, 824, 825, 852 and 851.




E501747


This wiring harness is referred to as the application wiring harness. Wiring harness versions that are less extensive are also possible.

The various applications are described individually below.



Connector 825 is again connected to connector 757, the B connector, of the ECS-DC3 electronic unit.



716



6




E501531

## 1.2 RESERVE WIRES

### Additional wiring


A number of return wires (A) run from the roof console to the fuse box (C) through connector 806. These wires run via dashboard lead-through connector 716 and via the application wiring harness to superstructure functions application 823.

Reserve wires (B) run from the dashboard to superstructure functions application connector 823 via dashboard lead-through connector 716.



E501748

- A. Roof console reserve wires X007 - X014
- B. Dashboard reserve wires X003 - X006
- C. Fuse box reserve wires X011 - X014
- 716. Green 16-pin dashboard lead-through connector
- 806. Brown 8-pin dashboard connector
- 823. Black 12-pin chassis connector





# 5

# CONNECTION OF ACCESSORIES


LF45/55 series

Connection of accessories

824 is a superstructure functions application connector that will be described below.

Under the tachograph is a brown 8-pin connector (806) containing the reserve wiring to the roof console.

**Pin pattern for wiring harness connector 806:**




| Pin no. | Wire no. | Description   |
|---------|----------|---|
| 1       | X007     | Reserve wire between connector 716 and roof console |
| 2       | X008     | Reserve wire between connector 716 and roof console |
| 3       | X009     | Reserve wire between connector 716 and roof console |
| 4       | X010     | Reserve wire between connector 716 and roof console |
| 5       | X011     | Reserve wire between fuse box and roof console      |
| 6       | X012     | Reserve wire between fuse box and roof console      |
| 7       | X013     | Reserve wire between fuse box and roof console      |
| 8       | X014     | Reserve wire between fuse box and roof console      |

6


There is a green 16-pole connector (716) with 8 reserve wires in the dashboard lead-through.

**Pin pattern for wiring harness connector 716:**



| Pin no. | Wire no. | Description                               |
|---------|----------|---|
| A1      | 3458     | Automatic gearbox fault message           |
| A2      | 1240     | Power supply after contact of fuse box    |
| A3      | 3746     | Gear selection during fault               |
| A4      | 4614     | “ABS active” signal for automatic gearbox |
| A5      | -        | -   |
| A6      | X002     | Power supply before contact               |
| A7      | X003     | Reserve wire to/from dashboard            |
| A8      | X004     | Reserve wire to/from dashboard            |
| B1      | X005     | Reserve wire to/from dashboard            |
| B2      | X006     | Reserve wire to/from dashboard            |
| B3      | X007     | Reserve wire to/from roof console         |
| B4      | X008     | Reserve wire to/from roof console         |
| B5      | X009     | Reserve wire to/from roof console         |
| B6      | X010     | Reserve wire to/from roof console         |
| B7      | 3725     | RAS-EC “stop”                             |
| B8      | 3726     | RAS-EC “warning”                          |

**ATTENTION:** The power supply **before** contact (X002) is fuse-protected via fuse E048 (25 A). The power supply **after** contact (1240) is only present if relay G188 is fitted. The power supply **after** contact is fuse-protected via fuse E156 (25 A).



# 5


# CONNECTION OF ACCESSORIES

LF45/55 series

Connection of accessories

Connector 823 can be found on the chassis near the fuel tank.

**Pin pattern for wiring harness connector 823:**



| Pin no. | Wire no. | Description                       |
|---------|----------|-----------------------------------|
| 1       | X003     | Reserve wire to/from dashboard    |
| 2       | X004     | Reserve wire to/from dashboard    |
| 3       | X005     | Reserve wire to/from dashboard    |
| 4       | X006     | Reserve wire to/from dashboard    |
| 5       | -        | -                                 |
| 6       | -        | -                                 |
| 7       | X007     | Reserve wire to/from roof console |
| 8       | X008     | Reserve wire to/from roof console |
| 9       | X009     | Reserve wire to/from roof console |
| 10      | X010     | Reserve wire to/from roof console |
| 11      | -        | -                                 |
| 12      | -        | -                                 |

6


## 1.3 DASHBOARD LEAD-THROUGH CONNECTORS, GENERAL

At the front of the cab there are a number of connectors placed one next to the other in the dashboard lead-through zone 1 for connectors. There are also lead-throughs for a number of earth wires and for the main power supply wire.


In the descriptions of the various connectors in the dashboard connector lead-through, the view is always from outside the cab.

When a vehicle is fitted with application connectors, this means that two specific wire harnesses are fitted.

- Chassis wiring harness.  
Dashboard lead-through connectors 716, 718 and 826 connected to superstructure functions application connectors 823 and 824, engine speed control application connector A068, PTO connectors 816 and 851.
- Engine wiring harness.  
Fitted with connector 825 for the engine speed control and connector 852 for "remote throttle".




E501355




E501550

### 1.4 DASHBOARD LEAD-THROUGH CONNECTORS FOR SUPERSTRUCTURE FUNCTIONS APPLICATION CONNECTORS

Together with connectors 809 and 810, application connector A070 forms part of the standard chassis wiring harness. These connectors are connected to dashboard lead-through connectors 713 and 714. Connectors 809 and 810 are not fitted on vehicle type FT.




E501742



E501749

Superstructure functions application connector 824 is part of the extensive application wiring harness and is connected to dashboard lead-through connectors 716 and 718. Connector 824 is located on the inside of the chassis side member, near the fuel tank.




# 5

# CONNECTION OF ACCESSORIES

LF45/55 series

Connection of accessories


Pin pattern for wiring harness connector 713:



| Pin no. | Wire no. | Description                                |
|---------|----------|--|
| A1      | 3503     | Sensor, fuel level                         |
| A2      | 3402     | Parking brake                              |
| A3      | 5104     | Reversing buzzer                           |
| A4      | 4517     | Differential lock valve                    |
| A5      | -        |  |
| A6      | 3406     | Brake lining wear signal                   |
| A7      | 1217     | Reversing switch                           |
| A8      | 2036     | Direction indicator, left                  |
| A9      | 2037     | Direction indicator, right                 |
| A10     | 2170     | Rear light, left                           |
| A11     | 2169     | Rear light, right                          |
| A12     | 2152     | Fog lights, rear                           |
| A13     | 4601     | Stop lights                                |
| B1      | 1356     | ABS, drawn vehicle                         |
| B2      | 4591     | Reversing buzzer, dashboard switch         |
| B3      | 1110     | Power supply before contact, drawn vehicle |
| B4      | 1240     | Power supply after contact                 |
| B5      | 5051     | Fuel filter heating system                 |
| B6      | 3659     | Alarm                                      |
| B7      | 2009     | Direction indicator, left, drawn vehicle   |
| B8      | 2008     | Direction indicator, right, drawn vehicle  |
| B9      | 3408     | Differential lock dashboard switch         |
| B10     | 3428     | ABS warning, drawn vehicle                 |
| B11     | 3412     | Cab lock                                   |
| B12     | 2155     | Superstructure lighting                    |


6

**Pin pattern for wiring harness connector 714:**



| Pin no. | Wire no. | Description                                  |
|---------|----------|--|
| A1      | 3639     | Air pressure sensor, power supply, circuit 2 |
| A2      | 3638     | Air pressure sensor, earth, circuit 1        |
| A3      | 3639     | Air pressure sensor, power supply, circuit 1 |
| A4      | 3640     | Air pressure sensor signal, circuit 1        |
| A5      | 3020     | Vehicle speed sensor, earth                  |
| A6      | 3021     | Vehicle speed sensor, power supply           |
| A7      | 3018     | Vehicle speed sensor signal, "real time"     |
| A8      | 3019     | Vehicle speed sensor signal, "coded"         |
| B1      | 4030     | Range-change protection, gearbox             |
| B2      | 3660     | Alarm  |
| B3      | 4721     | Neutral switch, gearbox                      |
| B4      | 4596     | Activates PTO valve                          |
| B5      | 5049     | 'Water in fuel' sensor                       |
| B6      | 1264     | Alarm battery                                |
| B7      | 3638     | Air pressure sensor, earth, circuit 2        |
| B8      | 3641     | Air pressure sensor signal, circuit 2        |

**Pin pattern for wiring harness connector 809:**



| Pin no. | Wire no. | Description      |
|---------|----------|------------------|
| 1       | 2170     | Rear light, left |
| 2       | M        | Earth            |




# 5

# CONNECTION OF ACCESSORIES

LF45/55 series


Connection of accessories

Pin pattern for wiring harness connector 810:



| Pin no. | Wire no. | Description       |
|---------|----------|-------------------|
| 1       | 2169     | Rear light, right |
| 2       | M        | Earth             |

Pin pattern for wiring harness connector A070:




| Pin no. | Wire no.     | Description                           |
|---------|--------------|---------------------------------------|
| 1       | 1110         | Power supply before contact           |
| 2       | 2155<br>2169 | FA work lamp<br>Rear light, right, FT |
| 3       | 4601         | "Stop light" signal                   |
| 4       | 4591         | "Reversing light" signal              |
| 5       | 1264         | Alarm, power supply                   |
| 6       | 3659         | Alarm, superstructure/drawn vehicle   |
| 7       | 3660         | Alarm, superstructure/drawn vehicle   |
| 8       | M            | Earth                                 |

**Note:**

On FT vehicles pin 2 for possible superstructure lighting is occupied by wire 2169.

6


**Pin pattern for wiring harness connector 824:**



| Pin no. | Wire no. | Description                                   |
|---------|----------|---|
| 1       | X002     | Power supply before contact                   |
| 2       | 1240     | Power supply after contact                    |
| 3       | 3435     | "Engine is running" signal (via the VIC unit) |
| 4       | 3412     | Cab lock (via the VIC unit)                   |
| 5       | 3700E    | V-CAN, high                                   |
| 6       | 3701E    | V-CAN, low                                    |
| 7       | M        | Earth   |
| 8       | M        | Earth   |

### 1.5 DASHBOARD LEAD-THROUGH CONNECTOR FOR ENGINE SPEED CONTROL APPLICATION CONNECTOR


The optional application connector for the engine speed control system (connector A068) is a 12-pin Econoseal connector. Most of the pins of connector A068 are connected to dashboard lead-through connector 718 and engine wiring harness connector 825.



E501751

Connector A068 is located on the co-driver's side near the air filter housing. In the dashboard lead-through, the wiring harness from connector A068 is connected to the dashboard wiring harness via connector 718.

**Pin pattern for wiring harness connector 718:**



| Pin no. | Wire no. | Description                       |
|---------|----------|-----------------------------------|
| A1      | 4177     | Remote control for main switch    |
| A2      | 3524     | PTO status                        |
| A3      | 4176     | Remote control for main switch    |
| A4      | 3435     | “Engine is running” signal        |
| A5      | 1123     | ADR MTCO (A1)                     |
| A6      | 4594     | PTO remote control                |
| A7      | 3700E    | V-CAN, high                       |
| A8      | 3412     | Cab lock                          |
| B1      | M        | Earth                             |
| B2      | M        | Earth                             |
| B3      | 3143     | ESC enable                        |
| B4      | 3144     | “N1” signal                       |
| B5      | 3145     | “N2” signal                       |
| B6      | 3146     | “N3” signal                       |
| B7      | 3514     | MTCO vehicle speed signal (D3/B7) |
| B8      | 3701E    | V-CAN, low                        |

Connector A068 is also connected to engine wiring harness connector 825, which in turn is connected to B connector 757 on the ECS-DC3 electronic unit.

**Pin pattern for wiring harness connector 825:**

825 ZT



| Pin no. | Wire no. | Description           |
|---------|----------|-----------------------|
| 1       | 3003     | “Engine speed” signal |
| 2       | 3039     | Vmax application      |

# 5

# CONNECTION OF ACCESSORIES

LF45/55 series


Connection of accessories

The engine wiring harness also has a 4-pin connector for "remote throttle" (852).

**Pin pattern for wiring harness connector 852:**

852

ZT




| Pin no. | Wire no. | Description                     |
|---------|----------|---------------------------------|
| 1       | 4680     | Accelerator pedal sensor earth  |
| 2       | B68      | 5 V power supply                |
| 3       | B85      | "Remote throttle" signal        |
| 4       | B21      | Accelerator pedal sensor ON/OFF |

**Pin pattern for wiring harness connector A068:**

A068

ZT



| Pin no. | Wire no. | Description                |
|---------|----------|----------------------------|
| 1       | M        | Earth                      |
| 2       | -        | -                          |
| 3       | 3003     | "Engine speed" signal      |
| 4       | 3039     | Vmax application           |
| 5       | -        | -                          |
| 6       | -        | -                          |
| 7       | 3143     | ESC enable                 |
| 8       | 3144     | "N1" signal                |
| 9       | 3145     | "N2" signal                |
| 10      | 3146     | "N3" signal                |
| 11      | 4594     | PTO remote control         |
| 12      | 1240     | Power supply after contact |

6

**1.6 AUTOMATIC GEARBOXES APPLICATION CONNECTOR**

The automatic gearbox application connector is entirely connected to the electronic unit of the automatic gearbox.


The connector's functions described below are those programmed as standard. Depending on the software programmed in the electronic unit, the functions may thus differ from the functions on the vehicle:

- A096 Automatic gearbox socket, superstructure (AT2000)
- A074 Automatic gearbox socket, superstructure

**Note:**

For a detailed explanation of the application connectors on an automatic gearbox, see the "Superstructure guidelines" book.

**Pin pattern for wiring harness connector A068:**



**6**

| Pin no. | Wire no. | Description  |
|---------|----------|--|
| 1       | 4006     | PTO activation only in neutral   |
| 2       | 5628     | PTO request  |
| 3       | 110      | Second shift program   |
| 4       | 111      | "Range inhibit" prevents the PTO from remaining active when the gearbox is put into a gear by accident, for instance |
| 5       | 112      | Switching off overdrive  |
| 6       | 4596     | PTO activation   |
| 7       | 3718     | Switched gear indicator  |
| 8       | -        |  |


# 5

# CONNECTION OF ACCESSORIES

LF45/55 series

Connection of accessories

Pin pattern for wiring harness connector A070:




| Pin no. | Wire no. | Description   |
|---------|----------|---|
| 1       | 5646     | Feedback of neutral position  |
| 2       | 153      | "Range inhibit" prevents the PTO from remaining active when the gearbox is put into a gear by accident, for instance. |
| 3       | 5628     | PTO request   |
| 4       | -        |   |
| 5       | 6035     | Braking signal  |
| 6       | 5648     | Automatic neutral position  |
| 7       | -        |   |
| 8       | -        |   |
| 9       | 167      | Vehicle speed signal  |
| 10      | 5647     | Earth   |
| 11      | 177      | Kickdown  |
| 12      | 5644     | Speed limiter for footboard protection  |
| 13      | -        |   |

6

## 1.7 CONNECTOR FOR 12V CONNECTION IN ROOF CONSOLE

In the roof console there is a white 2-pin connector, 790, whose purpose is to connect a CB set. This connector has the following wires: 1153 and earth.



E501163


## 1.8 CONNECTORS FOR CONNECTING THE RADIO

### Radio connection

Behind the radio panel there is a connector (connector no. 784) (to ISO standard) for the radio connection; this connector is provided with a power supply before contact of 12 V/10 A (15 A) (1153), power supply after contact (1143) and earth. The wiring for the loudspeakers, connector 785, to the speaker locations above the doors has also been fitted ready for use as standard.

Connectors for connecting the radio.

- 784 Power supply to radio
- 785 Loudspeakers for radio



E501148



**CONTENTS**

|                                   | <b>Page</b> | <b>Date</b> |
|-----------------------------------|-------------|-------------|
| 1. LIST OF ABBREVIATIONS .....    | 1-1 ....    | 200440      |
| 2. MARKING OF WIRING .....        | 2-1 ....    | 200440      |
| 3. READING CIRCUIT DIAGRAMS ..... | 3-1 ....    | 200440      |
| 4. READING SECTION DIAGRAMS ..... | 4-1 ....    | 200440      |



## 1. LIST OF ABBREVIATIONS

| Abbreviation              | Explanation   | Translation/description                                     |
|---------------------------|---|---|
| ABS-D                     | Antilock Braking System - version D                         | Antilock braking system - version D                         |
| ABS/ASR-E                 | Antilock Braking System/Anti-Slip Regulation - version E    | Antilock braking system/Anti-slip regulation - version E    |
| ACH-W                     | Additional Cab Heater - Webasto                             | Cab heater - Webasto  |
| AGC-A                     | Automatic Gearbox Control - Allison                         | Automatic Allison gearbox control                           |
| AIRCO                     | Air conditioning  | Air conditioning  |
| ALS-S                     | Alarm system - Scorpion                                     | Alarm system - Scorpion                                     |
| ASR                       | Anti-Slip Regulation  | Anti-slip regulation  |
| CAN                       | Controller Area Network                                     | Multiplex digital communication network                     |
| CCU                       | CAN Connection Unit   | CAN connection unit   |
| CDB                       | Central Distribution Board                                  | Central box   |
| CDM                       | CAN Data Manager  | CAN Data Manager  |
| CDS-3                     | Central Door Locking System version 3                       | Central door locking system - version 3                     |
| CO                        | Change Over   | Changeover contact  |
| CXB                       | CAN extension box   | CAN extension box   |
| DAVIE XD                  | DAF Vehicle Investigation Equipment - version XD            | DAF vehicle diagnostic tool - version XD                    |
| DIP-4                     | DAF Instrument Pack - version 4                             | DAF instrument panel - version 4                            |
| DVB                       | DoorVerBinding  | Through-connection  |
| ECAS-2                    | Electronically Controlled Air Suspension system - version 2 | Electronically controlled air suspension system - version 2 |
| ECAS-3                    | Electronically Controlled Air Suspension system - version 3 | Electronically controlled air suspension system - version 3 |
| ECS-DC3                   | Engine Control System DAF Cummins - version 3               | DAF Cummins engine management system - version 3            |
| FMS                       | Fleet Management System                                     | Fleet Management System                                     |
| MTCO                      | Modular Tachograph  | Modular tachograph  |
| NC                        | Normally Closed   | Normally closed contact                                     |
| NO                        | Normally Open   | Normally open contact                                       |
| PTO                       | Power Take-Off  | Power take-off  |
| RAS-EC                    | Rear Axle Steering - Electronically Controlled              | Electronically controlled rear axle steering                |
| VIC                       | Vehicle Intelligence Centre                                 | Vehicle intelligence centre                                 |
| VLG/ADR/GGVS/PETREG/RTMDR | Vervoer te Land Gevaarlijke Stoffen                         | Transport of hazardous substances                           |



## 2. MARKING OF WIRING

### INTRODUCTION

This standard sets out specifications for the uniform use of markings on electrical wiring.

The marking system consists of a numerical system and a colour coding system, thus ensuring a clear wiring layout and precluding faulty connections and manufacturing errors.

The marking system does not apply to vehicles subject to special conditions, such as military vehicles.

#### Numerical and colour coding

Each numerical code consists of four digits, the first of which refers to the main group and to the colour.

#### Main groups

Power supplies (red)  
1000 to 1999

Lighting (yellow)  
2000 to 2999

Warning and control functions (blue)  
3000 to 3999

Power consumers (grey)  
4000 to 6999

Special applications (colour as desired)  
6000 to 6999

Earth connections (white)  
Not marked  
9000 to 9499 test and signal earth

I-CAN wiring (twisted)  
3565 CAN-L (yellow)  
3566 CAN-H (grey)

V-CAN wiring (twisted)  
3700 CAN-L (yellow)  
3701 CAN-H (blue)

#### Notes:

- The "M" with serial number coding on earth wiring is used for production-related reasons.
- In the case of straight splicing of the wiring (cascading), the numerical codes are shown on each separate wire followed by a serial letter.

**Earth connections**

The application of electronic systems has made it necessary to divide the earth connections into groups. There is a distinction to be made between two different types of earth connection:

- switching earth
- test and signal earth

The switching earth is the conventional type of earth.

The test and signal earth is used exclusively for electronic systems.

The wiring colour for both types of earth is white, but the test and signal earth wiring is marked with numerical codes (from 9000 to 9500).



**NEVER USE THE TEST AND SIGNAL EARTH WHEN FITTING AN ELECTRICAL COMPONENT**

If you do this, electronic components may not work correctly.

If an electronic component needs to be connected, the earth for this system must be connected to the central earth connection in the cab.


This connecting point is located under the central box behind the dashboard.

**Abbreviations used in colour coding**

| <b>Colour</b> | <b>Abbreviation</b> | <b>Colour</b> | <b>Abbreviation</b> |
|---------------|---------------------|---------------|---------------------|
| red           | rd                  | yellow        | gl                  |
| brown         | bn                  | white         | wt                  |
| green         | gn                  | grey          | gs                  |
| blue          | bw                  | black         | zt                  |
| orange        | oe                  | violet        | vi                  |
| pink          | re                  |               |                     |

3. READING CIRCUIT DIAGRAMS

The circuit diagram is intended to show the various circuits in the simplest way possible. Symbols are used to do this.



E501056

- In the diagram, the indications "1000" and "1010" are shown at the top, left side.  
Explanation to these indications:  
1000 = power supply before contact.  
1010 = power supply after contact.
- The indication "M" is shown at the bottom of the diagram, left side.  
Explanation to this indication:  
M = earth connection.

3. To make it easier to find your way around the circuit diagram, a “search bar” is included at the bottom, which contains numbers.  
These numbers are called location numbers.

In the legend to the circuit diagram the description of the basic code (ECN) is followed by the relevant location number. In this way, a specific component can immediately be located in the diagram.

4. There is an arrow above location numbers 60, 63, 64 and 68 in the example diagram. At the bottom of this arrow is a number. This number refers to the location number on the search bar where you can find the relevant wire number.
5. Under the “M” (earth connection) line, there are the codes “NC”, relating to relay G154, “CO”, relating to relay G107, and “NO”, relating to relay G000.  
What this code means:  
  - NC = normally closed contact
  - CO = changeover contact
  - NO = normally open contact

These contacts can be found at the location numbers shown under the codes “NC”, “CO” and “NO”.

At the relay contacts shown in the diagram you will also find the location numbers that indicate the relay coil locations.

6. In the circuit diagram you will find the basic codes (for example E002). What these codes stand for can be found in the legend to the relevant circuit diagram.
7. If the wire numbers remain unchanged they will not be repeated in the circuit diagram. For instance, in the example diagram wire 1101 is connected to connection point 87 of relay contact G107, but also to connection point 2 of component C622.





























Wire 2100 (at location number 64) is connected to connection point 30 of relay G154, but also to connection point 85 of relay G000, etc.



Symbols used

|    |  |    |  |    |  |    |  |
|----|--|----|--|----|--|----|--|
| 1  |  | 2  |  | 3  |  | 4  |  |
| 5  |  | 6  |  | 7  |  | 8  |  |
| 9  |  | 10 |  | 11 |  | 12 |  |
| 13 |  | 14 |  | 15 |  | 16 |  |
| 17 |  | 18 |  | 19 |  | 20 |  |
| 21 |  | 22 |  | 23 |  | 24 |  |
| 25 |  | 26 |  | 27 |  | 28 |  |

7

|   |   |  |   |
|---|---|--|---|
| <p>29</p>    | <p>30</p>    | <p>31</p>     | <p>32</p>    |
| <p>33</p>    | <p>34</p>    | <p>35</p>     | <p>36</p>    |
| <p>37</p>   | <p>38</p>   | <p>39</p>    | <p>40</p>   |
| <p>41</p>  | <p>42</p>  | <p>43</p>  | <p>44</p>  |
| <p>45</p>  | <p>46</p>  | <p>47</p>   | <p>48</p>  |
| <p>49</p>  | <p>50</p>  | <p>51</p>   | <p>52</p>  |
| <p>53</p>  | <p>54</p>  | <p>55</p>  | <p>56</p>  |

E502011

| Symbol number | Description   |
|---------------|---|
| 1             | Loudspeaker   |
| 2             | Electropneumatic or hydraulic valve, 1 driving coil   |
| 3             | Electropneumatic or hydraulic valve, 2 driving coils  |
| 4             | Electropneumatic or hydraulic valve, 3 driving coils  |
| 5             | Diode   |
| 6             | Bipolar diode   |
| 7             | LED   |
| 8             | LED with series resistor  |
| 9             | 4-position switch, key-operated   |
| 10            | 3-position switch with fixed central position, manually operated, spring return   |
| 11            | Dual 3-position switch with fixed central position, manually operated, spring return  |
| 12            | Potentiometer with series resistor  |
| 13            | Potentiometer without series resistor   |
| 14            | Dual switch; one 2-position switch, manually operated, changeover contact, one 2-position switch, manually operated, contact normally open                |
| 15            | Dual switch; one 2-position switch, spring return, contact normally open, one 3-position switch, fixed central contact, spring return, changeover contact |
| 16            | 2-position switch with fixed 0-position, spring return, contact normally open   |
| 17            | Through-connection  |
| 18            | Relay with changeover contact   |
| 19            | Relay with changeover contact   |
| 20            | Switch, pressure-controlled, dual break, contact normally closed  |
| 21            | Switch, pressure-controlled, dual break, contact normally open  |
| 22            | Switch, temperature-controlled, single break, contact normally closed   |
| 23            | Switch, mechanically operated, dual break, contact normally closed  |
| 24            | Switch, mechanically operated, dual break, contact normally open  |
| 25            | Pressure - voltage converter  |
| 26            | Temperature - voltage converter   |
| 27            | Revs - pulse converter  |
| 28            | 2-position switch, single break, contact normally open, foot-pedal-operated   |

| <b>Symbol number</b> | <b>Description</b>  |
|----------------------|---|
| 29                   | 2-position switch, float-operated, dual break, contact normally closed                                      |
| 30                   | Sensor, Impedance   |
| 31                   | Sensor, Induction   |
| 32                   | DC motor, key-operated  |
| 33                   | DC motor  |
| 34                   | 2-speed DC motor  |
| 35                   | Starter motor   |
| 36                   | Bulb  |
| 37                   | Resistor  |
| 38                   | Fuse  |
| 39                   | Heating element   |
| 40                   | Temperature-switched heating element  |
| 41                   | Socket with two contact sockets   |
| 42                   | 2-position switch, fixed central position, manually operated  |
| 43                   | Timer   |
| 44                   | Threefold switch, fixed central position, contact normally open, manually operated, spring return           |
| 45                   | Fluid level, voltage converter  |
| 46                   | Twisted wire  |
| 47                   | Buzzer  |
| 48                   | 2-position switch, manually operated, single break, contact normally open, in combination with tubular lamp |
| 49                   | 2-position switch, key-operated, single break, contact normally open  |
| 50                   | Protected wire with earth connection  |
| 51                   | Switch, temperature-operated, single break, contact normally closed   |
| 52                   | Switch, pressure-operated, single break, contact normally closed  |
| 53                   | Twofold, 2-position, magnetically operated reed switch, single break, contact normally open                 |
| 54                   | Generator   |
| 55                   | Steering angle sensor   |
| 56                   | VSC module  |

## 4. READING SECTION DIAGRAMS

### EXPLANATION OF THE POSITION NUMBERS IN THE SECTION DIAGRAMS

In the section diagram only information that is functional in the section diagram described is shown in detail.


1. The wiring is shown in the same colours as the wiring in the vehicle.
2. The wire numbers are as they are printed on the wiring in the vehicle. Suffixes to wire numbers, such as A, B, C, etc., have been omitted.
3. Basic code of a component. For component descriptions, see the legend to the diagram. For more information, see the relevant section diagram.
4. Number of the wire connection point or the PCB track on the component.
5. The basic code of the connector and the connection point on this connector.
6. The symbols indicate which system or component is being referred to (in most cases the symbol is also shown on the lens of the warning lamp or switch).
7. PCB tracks.
8. The central box and instrument panel PCBs are grey.
9. Removable components are shown in white.

- 10. Reference to the component and connection point and to the section (section diagram) which gives further information about this component.

|            |
|------------|
| G178<br>85 |
| 7          |

- G178 = Basic code number of the component
- 85 = Connection point on the component
- 7 = Reference to section diagram 7

- 11. **ATTENTION!** The situation on the vehicle may be different, because of different specifications. Always consult the legend to the diagram.
- 12. The housing of this component is connected to earth. The line shown is therefore not a wire.
- 13. Search bar numbers.
- 14. Drawing number as well as section number.
- 15. Relation to the circuit diagram.







CONTENTS

|   | Page | Date   |
|---|------|--------|
| 1. GENERAL LOCATION OF COMPONENTS .....                                       | 1-1  | 200440 |
| 1.1 Introduction .....  | 1-1  | 200440 |
| 1.2 Location of components in relation to circuit diagram 1427090/03-04 ..... | 1-2  | 200440 |



## 1. GENERAL LOCATION OF COMPONENTS

### 1.1 INTRODUCTION

This main group contains an overview of components that do **not** occur in a system manual.

The location of system components is shown in the appropriate system manual.

There is a sticker in the central box, which indicates what relays, through-connections and fuses can be found on the PCB.

## 1.2 LOCATION OF COMPONENTS IN RELATION TO CIRCUIT DIAGRAM 1427090/03-04

Column 1 = basic codes of component  
 Column 2 = description  
 Column 3 = location  
 Column 4 = page number

| 1    | 2   | 3  | 4 |
|------|---|--|---|
| A000 | FA drawn vehicle socket (7-pin)                                 | Chassis rear end                               | 1 |
| A001 | Socket, rear fog lamp/reversing light, FT drawn vehicle (7-pin) | Behind cab                                     | 1 |
| A004 | ABS socket, FA drawn vehicle (7-pin)                            | Chassis rear end                               | 1 |
| A011 | Socket, 12 V accessories (2-pin)                                | Electrical panel, underside                    | 4 |
| A021 | Diagnostic socket (16-pin)                                      | Under floor mat, driver's side                 | 3 |
| A032 | AGC diagnostic socket   | On chassis side member above air supply unit   | 6 |
| A074 | Automatic gearbox socket, superstructure                        | On second side member behind gearbox           | 6 |
| A087 | CCU/CDM socket (2-pin)  | Under central box                              | 2 |
| A510 | Alarm system battery  | In central box, above ABS unit                 | 4 |
| B003 | Electric drop glass operation motor, driver's side              | In driver's side door                          | 3 |
| B004 | Electric drop glass operation motor, co-driver's side           | In co-driver's side door                       | 3 |
| B042 | Air dryer heating element                                       | In air supply unit                             | 7 |
| B043 | Air conditioning compressor                                     | Engine, front left                             | 7 |
| B079 | Low-range downshift protection valve                            | Left side of gearbox                           | 1 |
| B182 | Water separator fuel heating element                            | Rear side of fuel tank, on fuel filter housing | 2 |
| B192 | Exhaust brake valve   | On the RH chassis side member                  | 7 |
| B199 | Central door locking motor, driver's side                       | In door under door lock, driver's side         | 3 |

| 1    | 2  | 3   | 4 |
|------|--|---|---|
| B200 | Central door locking motor, co-driver's side             | In door under door lock, co-driver's side | 3 |
| B201 | Internal electrical components for AGC automatic gearbox | In bottom of gearbox housing              | 6 |
| B241 | Fuel filter/water separator heating element sensor       | Rear side of fuel tank, under fuel filter | 2 |
| B245 | PTO 1 control valve                                      | On the RH chassis side member             | 7 |
| B338 | Alarm system horn  | Front of side member, left                | 5 |
| B341 | Glow element   | In inlet manifold                         | 5 |
| B360 | Seat belt tensioner, driver's side                       | In roll-up mechanism, driver's seat       | 4 |
| B361 | Airbag module  | In steering wheel                         | 4 |
| B399 | Cooling fan 1, AGC automatic gearbox                     | Depending on vehicle application          | 6 |
| B400 | Cooling fan 2, AGC automatic gearbox                     | Depending on vehicle application          | 6 |
| B401 | Horn   | Front of side member, left                | 5 |
| C062 | Stepwell lighting, left                                  | At the bottom of door, driver's side      | 3 |
| C063 | Stepwell lighting, right                                 | At the bottom of door, co driver's side   | 3 |
| C119 | Interior lighting with switch, driver's side             | At the bottom, centre, in roof console    | 3 |
| C525 | Main switch  | Dashboard, centre panel                   | 4 |
| C553 | Mechanical main switch                                   | Chassis side member                       | 2 |
| C622 | Lighting switch  | Next to steering column, left             | 4 |
| C715 | Rotating beam switch                                     | Overhead panel                            | 3 |
| C725 | Work lamp switch   | Dashboard, centre panel                   | 4 |
| C727 | Fog lamp switch, front/rear                              | Dashboard, electrical panel               | 4 |
| C736 | Roof hatch switch  | Overhead panel                            | 3 |
| C748 | Cross-axle differential lock switch                      | Dashboard, electrical panel               | 4 |
| C750 | PTO 1 switch   | Dashboard, centre panel                   | 4 |
| C763 | Instrument lighting dimming potentiometer                | Dashboard, electrical panel               | 4 |

| 1    | 2   | 3   | 4 |
|------|---|---|---|
| C765 | Switch for warning lamps  | Dashboard, centre panel                       | 4 |
| C773 | Fog lamp switch, rear   | Dashboard, electrical panel                   | 4 |
| C774 | Central door locking switch   | Dashboard, centre panel                       | 4 |
| C804 | Switch, adjustable speed limiter                                      | Dashboard, electrical panel                   | 4 |
| C835 | Switch to turn off interior detection                                 | Overhead panel                                | 3 |
| C836 | Switch to turn off superstructure/drawn vehicle loadspace detection   | Dashboard, centre panel                       | 4 |
| C854 | Chassis main switch   | On outside of chassis, next to the batteries  | 7 |
| C864 | Drop glass operation switch, co-driver's side (driver's side door)    | In door panel, co-driver's side               | 3 |
| C865 | Drop glass operation switch, co-driver's side (co-driver's side door) | In door panel, driver's side                  | 3 |
| C866 | Drop glass operation switch, driver's side (driver's side door)       | In door panel, driver's side                  | 3 |
| C867 | Mirror heating switch   | Dashboard, electrical panel                   | 4 |
| C868 | Mirror adjustment switch  | In door panel, driver's side                  | 3 |
| C871 | Potentiometer for headlamp height adjustment                          | Next to steering column, right                | 4 |
| C880 | Reversing buzzer switch   | Dashboard, centre panel                       | 4 |
| C892 | Heater fan switch   | In heating/ventilation panel                  | 4 |
| C893 | Air conditioning switch   | In heating/ventilation panel                  | 4 |
| D609 | Light switch diode  | In diode block, against bottom of central box | 2 |
| D610 | Diode, main beam/dipped beam  | In diode block, against bottom of central box | 2 |
| D715 | Alarm system LED  | Overhead panel                                | 3 |
| D758 | Diode to prevent feedback to the VIC                                  | In diode block, against bottom of central box | 2 |
| D787 | Diode, air conditioning compressor link                               | Internal in air conditioning-compressor link  | 7 |

| 1    | 2   | 3  | 4 |
|------|---|--|---|
| D802 | Electronic unit, ECAS-2 (6x2)                                 | Top side of attachment plate, central box            | 5 |
| D822 | AGC vehicle interface module                                  | On inside of chassis in AGC box                      | 6 |
| D851 | Electronic unit, ECAS-3 (4x2)                                 | Top side of attachment plate, central box            | 5 |
| D866 | Electronic unit, AGC-A4 automatic gearbox control             | On inside of chassis in AGC box                      | 6 |
| D867 | Automatic gearbox selector                                    | In cab on floor                                      | 6 |
| D900 | Electronic unit, VIC  | On inside of attachment plate, central box           | 5 |
| D905 | Electronic unit, CDS  | In roof console, co-driver's side                    | 3 |
| D909 | Electronic unit, alarm system, ultrasonic                     | In central box, above ABS unit                       | 4 |
| D910 | Electronic unit, battery charger                              | In central box, above ABS unit                       | 4 |
| D911 | Electronic unit, ALS-S alarm system                           | Against heater housing, left side                    | 4 |
| D912 | Electronic unit, immobiliser                                  | Against steering column near ignition/starter switch | 4 |
| D924 | Electronic unit for main switch                               | In main switch box on chassis                        | 7 |
| D926 | Electronic unit, airbag/seat belt tensioner                   | Under floor pan, driver's side                       | 4 |
| D941 | Electronic unit, ABS/ASR, D version                           | On top side, central box, horizontal                 | 5 |
| D942 | Fuse box  | Central box  | 5 |
| D958 | Electronic unit, converter with power supply for radio memory | Next to central box, outside                         | 2 |
| D960 | Airbag contact unit   | Under steering wheel                                 | 4 |
| D961 | Electronic unit, ABS/ASR, E version                           | On top side, central box, horizontal                 | 5 |
| E153 | Fuse, power supply for main switch                            | In main switch box on chassis                        | 7 |
| E286 | Main fuse   | Behind battery box on chassis                        | 2 |
| E299 | Fuse, windscreen heating                                      | Behind battery box on chassis                        | 2 |

| 1    | 2   | 3   | 4 |
|------|---|---|---|
| E330 | Fuse, 'sens' wire main switches                   | In main switch box on chassis                           | 7 |
| E349 | Main fuse, cab                                    | Behind battery box on chassis                           | 2 |
| E354 | Fuse, automatic gearbox, AGC fan                  | In AGC box on chassis                                   | 6 |
| E501 | Reversing light switch                            | On gearbox  | 1 |
| E509 | Air conditioning switch, high/low pressure        | In evaporator pipe, on outside of cab, co-driver's side | 1 |
| E569 | Neutral position switch, gearbox                  | Gearbox   | 1 |
| E585 | Selector switch, automatic gearbox (AT 1000/2000) | Bottom left on outside of gearbox housing               | 6 |
| E587 | Switch for stop lights/clutch                     | Above brake pedal and clutch pedal                      | 3 |
| E597 | Switch, cooling fans, automatic gearbox (AGC)     | In AGC oil cooling radiator                             | 6 |
| F000 | Parking brake switch                              | On valve relay, chassis                                 | 1 |
| F009 | Control switch, cab tilting                       | In cab lock, driver's side                              | 1 |
| F087 | Control switch, gearbox PTO                       | On PTO housing, type-dependent                          | 7 |
| F533 | Vehicle speed sensor                              | Gearbox, rear end                                       | 1 |
| F601 | Output shaft speed sensor, automatic gearbox      | At rear of gearbox                                      | 6 |
| F602 | Input shaft speed sensor, automatic gearbox       | At front of gearbox                                     | 6 |
| F651 | Ambient temperature sensor                        | Between A-pillar and door, left side                    | 1 |
| F652 | Air pressure sensor                               | On air supply unit                                      | 7 |
| F670 | Sensor, turbine speed, automatic gearbox          | On gearbox  | 6 |
| F671 | Accelerator pedal sensor, ECS-DC3                 | Above accelerator                                       | 3 |
| G014 | Glow plug relay                                   | Behind battery box on chassis                           | 2 |
| G185 | Starting circuit interrupter relay                | On Vehicle Interface Module in AGC box                  | 6 |
| G201 | Fuel heating relay, FPH-E                         | Back of central box                                     | 2 |
| G350 | Reversing light relay, automatic gearbox          | On Vehicle Interface Module in AGC box                  | 6 |



# 5


# LOCATION OF COMPONENTS

LF45/55 series


General location of components

| 1    | 2   | 3  | 4 |
|------|---|--|---|
| G367 | Main switch relay, power supply               | In main switch box on chassis                                    | 7 |
| G368 | Main switch relay, earth                      | In main switch box on chassis                                    | 7 |
| G397 | Windscreen heating relay                      | In main switch box on chassis                                    | 7 |
| G425 | Main switch relay                             | In main switch box on chassis                                    | 7 |
| G444 | Cooling fan relay, automatic gearbox (AGC-A4) | In AGC box on chassis  | 6 |
| G507 | Earth, 1-pin, chassis - cab                   | Outside, under windscreen  | 2 |
| G516 | Central cab earth, co-driver's side           | Inside, central box  | 2 |
| G517 | Central cab earth, driver's side              | Outside, driver's side   | 2 |
| G520 | Central earth, chassis, front end             | Chassis side member, behind the shock absorber, driver's side    | 2 |
| G524 | Earth point, glow element                     | Left side of engine, cylinder head                               | 5 |
| G525 | Central earth, flywheel                       | Chassis side member, behind the shock absorber, co-driver's side | 2 |







E501243





E501713





E501746






8

E501703







CONTENTS

|   | Page | Date   |
|---|------|--------|
| 1. LOCATION OF CONNECTORS .....                   | 1-1  | 200440 |
| 1.1 List of connectors .....                      | 1-1  | 200440 |
| 1.2 Drawings showing location of connectors ..... | 1-9  | 200440 |



## 1. LOCATION OF CONNECTORS

### 1.1 LIST OF CONNECTORS

- Column 1 = Connector coding  
 Column 2 = Number of connection points on connector  
 Column 3 = Colour of connector  
 Column 4 = Description of connector, if applicable  
 Column 5 = Location of connector in the vehicle  
 Column 6 = Reference to page number (see "Drawings showing location of connectors")

| 1   | 2  | 3      | 4  | 5                             | 6  |
|-----|----|--------|--|-------------------------------|----|
| 340 | 35 | Black  | ECAS-2 electronic unit                     | Above central box             | 20 |
| 700 | 25 | Brown  | PCB connector                              | On PCB of central box         | 2  |
| 701 | 25 | White  | PCB connector                              | On PCB of central box         | 2  |
| 702 | 25 | Yellow | PCB connector                              | On PCB of central box         | 2  |
| 703 | 25 | Red    | PCB connector                              | On PCB of central box         | 2  |
| 704 | 2  | Brown  | PCB connector                              | On PCB of central box         | 2  |
| 705 | 2  | Grey   | PCB connector, power supply before contact | On PCB of central box         | 2  |
| 706 | 2  | Black  | PCB connector                              | On PCB of central box         | 2  |
| 707 | 8  | Yellow | PCB connector                              | On PCB of central box         | 2  |
| 708 | 8  | Violet | PCB connector                              | On PCB of central box         | 2  |
| 709 | 8  | Red    | PCB connector                              | On PCB of central box         | 2  |
| 710 | 8  | Brown  | PCB connector                              | On PCB of central box         | 2  |
| 711 | 8  | Grey   | PCB connector                              | On PCB of central box         | 2  |
| 712 | 8  | White  | PCB connector                              | On PCB of central box         | 2  |
| 713 | 25 | Yellow | Dashboard lead-through connector           | Dashboard lead-through zone 1 | 4  |
| 714 | 16 | Brown  | Dashboard lead-through connector           | Dashboard lead-through zone 1 | 4  |
| 715 | 16 | Red    | ABS-D, ABS/ASR-E                           | Dashboard lead-through zone 1 | 4  |
| 716 | 16 | Green  | Dashboard lead-through connector           | Dashboard lead-through zone 1 | 4  |
| 717 | 16 | Blue   | Automatic gearbox                          | Dashboard lead-through zone 1 | 4  |
| 718 | 16 | White  | Engine speed control                       | Dashboard lead-through zone 1 | 4  |

| 1   | 2  | 3      | 4   | 5                                   | 6  |
|-----|----|--------|---|-------------------------------------|----|
| 719 | 8  | White  | Accelerator pedal sensor                                    | Dashboard lead-through zone 1       | 4  |
| 720 | 8  | Red    | Dashboard lead-through connector                            | Dashboard lead-through zone 1       | 4  |
| 721 | 8  | Yellow | Headlights/ indicator lamps, front                          | Dashboard lead-through zone 1       | 4  |
| 722 | 8  | Grey   | Headlamp height adjustment/ fog lamps, front                | Dashboard lead-through zone 1       | 4  |
| 723 | 8  | Violet | ECAS  | Dashboard lead-through zone 1       | 4  |
| 724 | 8  | Brown  | Dashboard lead-through connector                            | Dashboard lead-through zone 1       | 4  |
| 725 | 4  | Black  | Cab heater  | Dashboard lead-through zone 1       | 4  |
| 726 | 4  | Grey   | Headlight/windscreen washer                                 | Dashboard lead-through zone 1       | 4  |
| 727 | 4  | Yellow | ASR   | Dashboard lead-through zone 1       | 4  |
| 728 | 4  | Blue   | Alarm siren   | Dashboard lead-through zone 1       | 4  |
| 729 | 6  | Black  | Alarm battery charger                                       | Central box                         | 21 |
| 730 | 2  | Grey   | Dashboard lead-through connector                            | Dashboard lead-through zone 1       | 4  |
| 731 | 8  | Yellow | Windscreen wiper motor                                      | Dashboard lead-through zone 2       | 5  |
| 732 | 8  | White  | Door functions  | Dashboard lead-through zone 2       | 5  |
| 733 | 8  | Red    | Door functions  | Dashboard lead-through zone 2       | 5  |
| 734 | 8  | Violet | Air conditioning switch                                     | Dashboard lead-through zone 2       | 5  |
| 735 | 8  | White  | Central door locking  | Side of central box                 | 3  |
| 736 | 8  | Blue   | Loudspeakers, rotating beams, roof hatch, interior lighting | Side of central box                 | 3  |
| 737 | 16 | Black  | Central door lock   | Roof console, centre                | 9  |
| 738 | 16 | Black  | Door wiring, driver's side                                  | Between A-pillar and door           | 8  |
| 739 | 16 | Black  | Door wiring, co-driver's side                               | Between A-pillar and door           | 8  |
| 740 | 4  | Black  | Alarm/immobiliser LED, roof console                         | Side of central box                 | 3  |
| 741 | 8  | White  | Steering column switch, cruise control/engine speed         | Next to steering column, inner side | 10 |
| 742 | 8  | Blue   | Steering column switch, windscreen wipers/washer            | Next to steering column, inner side | 10 |
| 743 | 9  | Black  | A connector, VIC electronic unit                            | In central box                      | 6  |
| 744 | 24 | Black  | B connector, VIC electronic unit                            | In central box                      | 6  |

| 1   | 2  | 3      | 4   | 5   | 6  |
|-----|----|--------|---|---|----|
| 745 | 52 | Black  | C connector, VIC electronic unit                          | In central box                                | 6  |
| 746 | 40 | Black  | D connector, VIC electronic unit                          | In central box                                | 6  |
| 747 | 9  | Black  | E connector, VIC electronic unit                          | In central box                                | 6  |
| 748 | 25 | Black  | Connector, ECAS electronic unit                           | Above central box                             | 7  |
| 749 | 15 | Black  | Connector, ABS-D electronic unit                          | Above central box                             | 7  |
| 750 | 18 | Black  | Connector, ABS-D electronic unit                          | Above central box                             | 7  |
| 751 | 8  | Blue   | Connector, heater / air conditioning                      | On heater housing                             | 21 |
| 752 | 8  | White  | MTCO A connector  | On rear of MTCO                               | 12 |
| 753 | 8  | Yellow | MTCO B connector  | On rear of MTCO                               | 12 |
| 754 | 8  | Black  | Remote control system, ECAS                               | Outside, driver floor pan                     | 7  |
| 755 | 14 | Black  | Connector, DIP  | On rear of DIP                                | 1  |
| 756 | 8  | Grey   | Connector for cab heater system, Webasto                  | Outside of central box                        | 3  |
| 757 | 89 | Black  | B connector for ECS-DC3 engine management electronic unit | On left of engine                             | 18 |
| 758 | 2  | Black  | Reversing buzzer  | Left-hand chassis side member, near fuel tank | 15 |
| 759 | 6  | Black  | Fuel pre-heating  | Left-hand chassis side member, near fuel tank | 14 |
| 760 | 6  | Black  | ECAS-3 chassis wiring harness, 45LF                       | Left-hand chassis side member, near fuel tank | 15 |
| 761 | 13 | Black  | ABS   | Left-hand chassis side member, near fuel tank | 15 |
| 762 | 13 | Black  | Tail lights/differential lock                             | Left-hand chassis side member, near fuel tank | 15 |
| 763 | 13 | White  | Drawn vehicle connection                                  | Left-hand chassis side member, near fuel tank | 15 |
| 764 | 7  | Black  | Tail lights, right  | On tail light unit, right                     | 15 |
| 765 | 7  | Black  | Tail lights, left   | On tail light unit, left                      | 15 |

# LOCATION OF CONNECTORS

5

Location of connectors

LF45/55 series

| 1   | 2  | 3     | 4  | 5   | 6  |
|-----|----|-------|--|---|----|
| 766 | 3  | Black | Differential lock  | In chassis side member, near rear axle          | 16 |
|     |    |       |  | Dashboard lead-through zone 1                   | 33 |
| 767 | 2  | Black | Break lining wear  | In chassis side member, near rear axle          | 17 |
| 768 | 6  | Black | Engine connector   | At front of engine block                        | 18 |
| 769 | 7  | Black | Air pressure sensor                                      | On top of air supply unit                       | 13 |
| 771 | 14 | Black | Cruise control   | Steering column, right                          | 10 |
| 772 | 10 | Black | Lighting / horn switch, steering column                  | Steering column, left                           | 10 |
| 773 | 6  | Black | Direction indicator switch, steering column              | Steering column, left                           | 10 |
| 774 | 4  | White | 12 V accessories connection                              | Outside of central box                          | 3  |
| 775 | 4  | Black | Immobiliser  | Right of steering column                        | 10 |
| 776 | 2  | Black | Engine brake valve                                       | Right-hand chassis side member, near air filter | 16 |
| 777 | 2  | Black | Direction indicator, left side                           | On mudguard support, left                       | 13 |
| 778 | 2  | Black | Direction indicator, right side                          | On mudguard support, right                      | 14 |
| 779 | 3  | Black | Glow plug relay  | Chassis side member, near air supply unit       | 18 |
| 780 | 2  | Black | Work lamp  | Under cross member, rear cab suspension         | 17 |
| 781 | 2  | Black | Seat heating   | Under floor mat, driver's seat                  | 7  |
| 782 | 6  | Black | ECAS-3 chassis wiring harness, LF55                      | Left-hand chassis side member, near fuel tank   | 15 |
| 783 | 2  | Black | ECAS-3 chassis wiring harness, height sensor, left, LF55 | Left-hand chassis side member, near fuel tank   | 15 |
| 784 | 8  | Black | Power supply to radio                                    | Behind E-panel, dashboard                       | 12 |
| 785 | 8  | White | Loudspeakers for radio                                   | Behind E-panel, dashboard                       | 12 |
| 786 | 8  | Blue  | Clutch/stop light switch                                 | Under MTCO                                      | 11 |
| 787 | 8  | White | Engine brake switch                                      | Under MTCO                                      | 11 |
| 788 | 6  | Black | Mirror adjustment/heating, driver's side                 | Outside of door, behind mirror bracket shield   | 8  |
| 789 | 6  | Black | Mirror adjustment/heating, co-driver's side              | Outside of door, behind mirror bracket shield   | 8  |

9



| 1   | 2  | 3      | 4  | 5  | 6  |
|-----|----|--------|--|--|----|
| 790 | 2  | White  | CB set   | Under panel of roof console                        | 9  |
| 791 | 8  | Black  | Electronic unit, cab heater                      | Under storage compartment, behind co-driver's seat | 19 |
| 792 | 4  | Black  | Electronic unit, cab heater                      | Under storage compartment, behind co-driver's seat | 19 |
| 793 | 12 | Black  | Cab heater control and timer                     | Side wall, behind driver's seat                    | 19 |
| 794 | 2  | Black  | Cab heater, fuel pump                            | Chassis side member, driver's side                 | 20 |
| 795 | 8  | Violet | Cab heater                                       | Under storage compartment, behind co-driver's seat | 19 |
| 796 | 12 | Black  | A connector, alarm electronic unit               | Next to heater housing                             | 21 |
| 797 | 21 | Black  | B connector, alarm electronic unit               | Next to heater housing                             | 21 |
| 798 | 10 | White  | Diode block                                      | Below, on central box                              | 3  |
| 799 | 6  | Blue   | Ultrasonic unit                                  | Above, on central box                              | 21 |
| 800 | 4  | Yellow | Alarm, interior detection, superstructure        | In side of central box                             | 3  |
| 801 | 4  | White  | Airbag   | Under MTCO   | 11 |
| 802 | 30 | Black  | Airbag electronic unit                           | In floor pan under driver's seat                   | 7  |
| 803 | 8  | Green  | Airbag   | Under MTCO   | 11 |
| 805 | 2  | Black  | ECAS-2, voltage and earth                        | Dashboard lead-through zone 1                      | 31 |
| 806 | 8  | Brown  | Reserve wiring                                   | Under MTCO   | 11 |
| 807 | 6  | Black  | LED electronic unit                              | Above central box                                  | 20 |
| 808 | 8  | Yellow | Ignition/starter switch                          | Next to steering column, inner side                | 10 |
| 809 | 2  | Black  | Superstructure lighting, left                    | Between air supply unit and fuel tank              | 13 |
| 810 | 2  | Black  | Superstructure lighting, right                   | Between air inlet filter and battery pack          | 13 |
| 811 | 2  | Grey   | Seat belt tensioner                              | Rear of co-driver's seat                           | 23 |
| 812 | 8  | Black  | Ignition unit, airbag                            | Steering column on airbag ignition unit            | 22 |
| 813 | 2  | Black  | MTCO earth, activated when main switch turned on | Dashboard lead-through zone 1                      | 4  |

| 1   | 2  | 3      | 4  | 5  | 6  |
|-----|----|--------|--|--|----|
| 814 | 2  | Black  | Rotating beam, driver's side                                 | Roof console, co-driver's side                           | 9  |
| 815 | 2  | Black  | Rotating beam, co-driver's side                              | Roof console, co-driver's side                           | 9  |
| 816 | 2  | Black  | PTO control switch   | In chassis wiring harness                                | 26 |
| 817 | 2  | Yellow | Airbag   | On steering wheel, between ignition unit and airbag unit | 22 |
| 818 | 2  | Green  | Seat belt tensioner  | Rear of co-driver's seat                                 | 23 |
| 819 | 2  | Black  | Seat heating   | Rear of co-driver's seat                                 | 23 |
| 820 | 15 | Black  | Connector, ABS/ASR-E electronic unit                         | Above central box  | 24 |
| 821 | 18 | Black  | Connector, ABS/ASR-E electronic unit                         | Above central box  | 24 |
| 822 | 8  | Black  | Main switch  | Right-hand chassis side member                           | 30 |
| 823 | 12 | Black  | Spare wiring, superstructure functions application connector | Left-hand chassis side member, near fuel tank            | 25 |
| 824 | 8  | Black  | Superstructure functions application connector               | Left-hand chassis side member, near fuel tank            | 25 |
| 825 | 2  | Black  | Motor connector, Vmax/engine speed                           | Left-hand chassis side member, near gearbox              | 25 |
| 826 | 1  | Black  | PTO control  | Dashboard lead-through zone 1                            | 4  |
| 827 | 36 | Black  | A connector for ECS-DC3 engine management electronic unit    | On left of engine  | 18 |
| 828 | 16 | Black  | C connector for ECS-DC3 engine management electronic unit    | On left of engine  | 18 |
| 829 | 13 | Black  | Chassis connector, automatic transmissions                   | Chassis cross member behind gearbox                      | 28 |
| 830 | 4  | Black  | Motor connector, automatic transmissions                     | Left-hand chassis side member, near air supply unit      | 28 |
| 831 | 4  | Black  | Connector, external current limiter, ADR unit                | On chassis in ADR box                                    | 31 |
| 832 | 4  | Black  | Connector, external current limiter, ADR unit                | On chassis in ADR box                                    | 31 |
| 833 | 2  | Black  | Power supply, MTCO ADR earth connector                       | Dashboard lead-through zone 1                            | 30 |
| 834 | 3  | Black  | VIC power supply and ADR alternator                          | Dashboard lead-through zone 1                            | 30 |
| 835 | 13 | Black  | Cab functions chassis connector, RAS-EC                      | Left-hand chassis side member, near gearbox              | 26 |

| 1   | 2  | 3     | 4   | 5   | 6  |
|-----|----|-------|---|---|----|
| 836 | 4  | Black | Oil level sensor, RAS-EC                                    | Next to oil tank, on left under cab                         | 27 |
| 837 | 68 | Black | Connector, RAS-EC electronic unit                           | In between two cross members halfway between two rear axles | 27 |
| 838 | 4  | Black | Angle sensor, rear, RAS-EC                                  | On left-hand brake booster, trailing axle                   | 27 |
| 839 | 4  | Black | Front axle angle sensor 1                                   | On top of steering box                                      | 27 |
| 840 | 3  | Black | Front axle angle sensor 2                                   | On bottom of steering box                                   | 27 |
| 841 | 7  | Black | Steering valve, RAS-EC                                      | On rear axle cross member                                   | 27 |
| 842 | 2  | Black | Wheel speed sensor, RAS-EC                                  | On inside of left-hand chassis side member, near rear axles | 27 |
| 843 | 13 | Black | Automatic gearbox selector (MD3060)                         | Left-hand chassis side member, near fuel tank               | 28 |
| 844 | 2  | Black | Activation of cooling fans, automatic gearbox               | On chassis in AGC box                                       | 28 |
| 845 | 1  | Black | Temperature switch, cooling fans, automatic gearbox         | On chassis in AGC box                                       | 28 |
| 846 | 2  | Black | Temperature switch, cooling fans, automatic gearbox         | On oil cooler radiator unit                                 | 29 |
| 847 | 2  | Black | Activation of cooling fan 1, automatic gearbox              | On oil cooler radiator unit                                 | 29 |
| 848 | 2  | Black | Activation of cooling fan 2, automatic gearbox              | On oil cooler radiator unit                                 | 29 |
| 849 | 1  | White | Light, automatic gearbox selector (MD3060)                  | Underside of central box                                    | 29 |
| 850 | 6  | Black | Intermediate connector for diagnostic connector             | Inside of left-hand chassis side member                     | 28 |
| 851 | 4  | Black | Activates PTO valve   | Inside of right-hand chassis side member                    | 26 |
| 852 | 4  | Black | "Remote throttle" application                               | Chassis cross member behind gearbox                         | 25 |
| 853 | 32 | Grey  | Connector, electronic unit, automatic gearbox (AT1000/2000) | On chassis in AGC box                                       | 31 |

# LOCATION OF CONNECTORS

5

Location of connectors

LF45/55 series

| 1   | 2  | 3     | 4  | 5   | 6  |
|-----|----|-------|--|---|----|
| 854 | 32 | Red   | Connector, electronic unit, automatic gearbox (AT1000/2000)                  | On chassis in AGC box                               | 31 |
| 855 | 31 | Black | Internal components, automatic gearbox (MD3060)                              | On rear of automatic transmission                   | 28 |
| 856 | 16 | Black | Engine speed sensors for automatic gearbox (MD3060)                          | On rear of automatic transmission                   | 28 |
| 857 | 20 | Grey  | Automatic gearbox selector (MD3060)  | Under floor mat, engine tunnel                      | 29 |
| 858 | 4  | Black | Chassis connector, low-range downshift protection valve                      | Left-hand chassis side member, near air supply unit | 24 |
| 859 | 2  | Black | Exhaust brake connector  | At front of engine block                            | 18 |
| 900 | 20 | Black | Engine speed sensors, selector switch, automatic gearbox (AT1000/2000)       | On rear of automatic transmission                   | 31 |
| 901 | 8  | Black | Chassis connector, RAS-EC components, front                                  | Left-hand chassis side member, near fuel tank       | 26 |
| 902 | 2  | Black | Alternator connector, voltage before contact in combination with main switch | At front of engine block                            | 18 |
| 903 | 13 | Black | Chassis connector, ECAS-2  | Left-hand chassis side member, near fuel tank       | 26 |
| 904 | 2  | Black | Intermediate connector, ECAS-2,-pressure sensor                              | -   | 31 |
| 905 | 32 | Black | S connector, electronic unit, automatic gearbox (MD3060)                     | On chassis in AGC box                               | 28 |
| 906 | 32 | Blue  | T connector, electronic unit, automatic gearbox (MD3060)                     | On chassis in AGC box                               | 28 |
| 907 | 32 | Grey  | V connector, electronic unit, automatic gearbox (MD3060)                     | On chassis in AGC box                               | 28 |
| 908 | 2  | Black | Cooling fan connector, automatic gearbox (AT1000/2000)                       | On oil cooler radiator unit                         | 31 |
| 952 | 5  | Black | Transmission connector   | Left-hand chassis side member, near air supply unit | 32 |

9

| 1   | 2 | 3     | 4                   | 5  | 6  |
|-----|---|-------|---------------------|--|----|
| 953 | 2 | Black | Fuel level sensor   | Left-hand chassis side member,<br>near fuel tank | 32 |
| 954 | 4 | Black | Fuel tank connector | Left-hand chassis side member,<br>near fuel tank | 32 |
| 955 | 2 | Black | FMS power connector | Central box                                      | 33 |

## 1.2 DRAWINGS SHOWING LOCATION OF CONNECTORS

### Explanation of connector drawings

- A: Connector coding  
 B: Colour of connector  
 BN = brown  
 BW = blue  
 GL = yellow  
 GS = grey  
 OE = orange  
 RD = red  
 VI = violet  
 WT = white  
 ZT = black  
 C: List of pin numbers on connector  
 The pin numbers on the connector are where possible viewed from the wire input side






# 5

# LOCATION OF CONNECTORS

LF45/55 series

Location of connectors


















E501228

# LOCATION OF CONNECTORS

5

Location of connectors

LF45/55 series



E501210

9











# 5



# LOCATION OF CONNECTORS

LF45/55 series

Location of connectors



E501375



E501719






9

# 5








## LOCATION OF CONNECTORS

LF45/55 series

Location of connectors



E501213




E501214

# 5


LF45/55 series

# LOCATION OF CONNECTORS




Location of connectors




E500992






E501142







E501215







E501370



E501377



E501217






E501218

# 5




# LOCATION OF CONNECTORS

LF45/55 series

Location of connectors



E501720







E501378

# LOCATION OF CONNECTORS







5

Location of connectors

LF45/55 series



E501743



E501379

9









# 5





# LOCATION OF CONNECTORS

LF45/55 series




Location of connectors



E501380



E501224




E501225

# 5




LF45/55 series

## LOCATION OF CONNECTORS


Location of connectors




E501241




E501382




E501399




E501400




E501233



E501383



E501145



E501226


9

# 5


# LOCATION OF CONNECTORS

LF45/55 series








Location of connectors




E501162



E501236





E501384



E501568



E501721





# LOCATION OF CONNECTORS

Location of connectors

LF45/55 series



E501385





E501386

# 5



# LOCATION OF CONNECTORS

LF45/55 series

Location of connectors



E501387




E501722

# LOCATION OF CONNECTORS





5

Location of connectors



LF45/55 series




E501689




E501723



9



E501234



E501389




# 5





## LOCATION OF CONNECTORS

LF45/55 series


Location of connectors




E501390




E501391








E501237



E501392



E501718




E501724

# 5


LF45/55 series

# LOCATION OF CONNECTORS



Location of connectors




E500992




E501347






E501393




E500994



E501310





E501394




E501366

E501395



E501374

E501396




# 5




## LOCATION OF CONNECTORS




LF45/55 series

Location of connectors




E501397






E501398



E501725





# 5




LF45/55 series

# LOCATION OF CONNECTORS



Location of connectors



E501726



E501727




E501728

# LOCATION OF CONNECTORS




5

Location of connectors


LF45/55 series




E501729





E501730



9



E501731






# 5









# LOCATION OF CONNECTORS

LF45/55 series

Location of connectors



E501732









E501733

# LOCATION OF CONNECTORS






5

Location of connectors




LF45/55 series



E501734



E501735



E501736


9

# 5





# LOCATION OF CONNECTORS

LF45/55 series



Location of connectors




E501737





E501738




E501739







E501740



E501694



E501741



# 5

# LOCATION OF CONNECTORS

LF45/55 series



Location of connectors

## ECAS-2







E501754

## Main switch



E501782

## AT1000/2000





E501783

# LOCATION OF CONNECTORS



5

Location of connectors



LF45/55 series



E502130



E502134



E502132


9

# 5

## LOCATION OF CONNECTORS



LF45/55 series

Location of connectors




E502137

E502138



E502135

E502136







**CONTENTS**

|  | <b>Page</b> | <b>Date</b> |
|--|-------------|-------------|
| 1. INTRODUCTION .....  | 1-1 .....   | 200440      |
| 2. ELECTRICAL SYSTEM .....                                       | 2-1 .....   | 200440      |
| 2.1 Circuit diagram 1427090/03 .....                             | 2-1 .....   | 200440      |
| 2.2 Overview of basic codes for circuit diagram 1427090/03 ..... | 2-2 .....   | 200440      |
| 2.3 Section diagrams from circuit diagram 1427090/03 .....       | 2-13 ...    | 200440      |



## 1. INTRODUCTION

This main group includes the entire electrical system shown in the form of **section diagrams** and an **overview of connectors/pin allocations**.

**Note:**

For the location of the connectors in the vehicle, see main group "Location of connectors".



**2. ELECTRICAL SYSTEM****2.1 CIRCUIT DIAGRAM 1427090/03**

This page can be used to make your own notes on the circuit diagram.

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---


---

---




---


---

---



OPERATE DISCONNECT  
 0-25% ALL FUSE R.C.T. THROUGHTOUT  
 HOOFOSCHAL ELAAT  
 0-25% Only with  
 main switch





## 2.2 OVERVIEW OF BASIC CODES FOR CIRCUIT DIAGRAM 1427090/03

- 1 Basic code number  
2 Description  
3 Number on search bar

| 1    | 2   | 3  |
|------|---|--|
| A000 | Drawn vehicle socket (7-pin)                          | 0095 0096 0224 0231<br>0262 0681           |
| A001 | Rear fog light/reversing light socket (7-pin)         | 0251 0256 0270 0286<br>0682                |
| A004 | Socket, ABS/EBS, drawn vehicle (7-pin)                | 0403                                       |
| A011 | Socket, 12 V accessories (2-pin)                      | 0361                                       |
| A021 | Diagnostics socket (16-pin)                           | 0592                                       |
| A032 | AGC diagnostics socket                                | 0528 0574                                  |
| A068 | Application connector, engine speed control           | 581  |
| A070 | Application connector, superstructure (8-pin)         | 0177 0186 0188 0263<br>0271 0287 0288 0682 |
| A074 | Automatic gearbox socket, superstructure (MD3060)     | 0568                                       |
| A087 | CCU/CDM socket (2-pin)                                | 0599                                       |
| A096 | Automatic gearbox socket, superstructure (AT2000)     | 0522                                       |
| A500 | Batteries (2x)  | 0002 0015                                  |
| A510 | Alarm system battery                                  | 0174                                       |
| A513 | Alternator  | 0019                                       |
| B000 | Windscreen wiper motor                                | 0165                                       |
| B001 | Windscreen wiper pump                                 | 0169                                       |
| B003 | Electric drop glass operation motor, driver's side    | 0328                                       |
| B004 | Electric drop glass operation motor, co-driver's side | 0323                                       |
| B005 | Mirror adjustment motor, left                         | 0335 0339                                  |
| B006 | Mirror adjustment motor, right                        | 0332 0342                                  |
| B009 | Roof hatch motor                                      | 0297                                       |
| B010 | Starter motor   | 0035 0041                                  |
| B017 | Mirror heating, driver's side                         | 0344                                       |
| B018 | Mirror heating, co-driver's side                      | 0345                                       |
| B023 | Radio   | 0366 0371                                  |
| B024 | Loudspeaker, left                                     | 0365 0372                                  |



| 1    | 2   | 3         |
|------|---|-----------|
| B025 | Loudspeaker, right  | 0367 0371 |
| B030 | Cigar lighter, driver's side                                    | 0357      |
| B032 | Seat heating, driver's side                                     | 0353      |
| B042 | Air dryer heating element                                       | 0319      |
| B043 | Air conditioning compressor                                     | 0382      |
| B068 | Fuel metering pump, cab heater                                  | 0386      |
| B079 | Low-range downshift protection valve                            | 0119      |
| B129 | Left-hand headlamp height adjuster motor                        | 0234      |
| B130 | Right-hand headlamp height adjuster motor                       | 0236      |
| B131 | Solenoid valve, pump unit/injector, cylinder 1                  | 0613 0651 |
| B132 | Solenoid valve, pump unit/injector, cylinder 2                  | 0615 0659 |
| B133 | Solenoid valve, pump unit/injector, cylinder 3                  | 0616 0658 |
| B134 | Solenoid valve, pump unit/injector, cylinder 4                  | 0618 0654 |
| B135 | Solenoid valve, pump unit/injector, cylinder 5                  | 0619      |
| B136 | Solenoid valve, pump unit/injector, cylinder 6                  | 0621      |
| B176 | Reversing buzzer  | 0266      |
| B182 | Water separator fuel heating element                            | 0313      |
| B192 | Exhaust brake valve   | 0633 0671 |
| B199 | Central door locking motor, driver's side                       | 0311      |
| B200 | Central door locking motor, co-driver's side                    | 0304      |
| B201 | Internal electrical components for automatic gearbox            | 0510 0561 |
| B237 | ABS/ASR-D differential lock valve, rear axle                    | 0443      |
| B238 | ECAS valve, driven axle, air supply                             | 725       |
| B243 | Cross-axle differential lock control valve                      | 0394      |
| B245 | PTO 1 control valve   | 0080      |
| B250 | ECAS valve, driven axle, air supply                             | 0709      |
| B253 | ECAS valve, driven axle, air supply                             | 0749      |
| B254 | ECAS valve, steered leading axle/trailing axle, lifting bellows | 0753      |
| B256 | ABS valve, front axle, left                                     | 0413 0436 |
| B257 | ABS valve, front axle, right                                    | 0414 0438 |
| B258 | ABS valve, driven axle, left                                    | 0416 0439 |
| B259 | ABS valve, driven axle, right                                   | 0441      |

| 1    | 2                                      | 3         |
|------|--|-----------|
| B334 | Fuel pump control solenoid valve       | 0612 0650 |
| B338 | Alarm system horn                      | 0176      |
| B341 | Glow element                           | 0047      |
| B360 | Seat belt tensioner, driver's side     | 0474      |
| B361 | Airbag module                          | 0476      |
| B371 | Windscreen heating                     | 0349      |
| B377 | Heater motor                           | 0375      |
| B381 | RAS-EC valve block                     | 0454      |
| B399 | Cooling fan 1, automatic gearbox (AGC) | 0501 0535 |
| B400 | Cooling fan 2, AGC automatic gearbox   | 0537      |
| B401 | Horn                                   | 0085      |
| B402 | ABS resistor                           | 0428      |
| B525 | Modular tachograph (MTCO)              | 0052      |
| C000 | Dipped beam, left                      | 0239      |
| C001 | Dipped beam, right                     | 0241      |
| C002 | Main beam, left                        | 0242      |
| C003 | Main beam, right                       | 0244      |
| C006 | Left spotlight                         | 0245      |
| C007 | Right spotlight                        | 0246      |
| C008 | Fog lamp, front left                   | 0253      |
| C009 | Fog lamp, front right                  | 0255      |
| C014 | Direction indicator lamp, front left   | 0088      |
| C015 | Direction indicator lamp, front right  | 0092      |
| C016 | Direction indicator lamp, side left    | 0089      |
| C017 | Direction indicator lamp, side right   | 0093      |
| C018 | Direction indicator lamp, rear left    | 0090      |
| C019 | Direction indicator lamp, rear right   | 0094      |
| C020 | Stop light, left                       | 0259      |
| C021 | Stop light, right                      | 0261      |
| C022 | Rear light, left                       | 0222      |
| C023 | Rear light, right                      | 0229      |
| C024 | Fog lamp, rear left                    | 0249      |

| 1    | 2  | 3              |
|------|--|----------------|
| C025 | Fog lamp, rear right   | 0251           |
| C026 | Reversing light, left  | 0268           |
| C027 | Reversing light, right   | 0270           |
| C062 | Stepwell lighting, left  | 0278           |
| C063 | Stepwell lighting, right   | 0280           |
| C071 | Work lamp  | 0289           |
| C110 | Bunk light, bottom   | 0282           |
| C111 | Bunk light, top  | 0283           |
| C119 | Interior lighting with switch, driver's side                             | 0276           |
| C144 | Rotating beam, left  | 0292           |
| C145 | Rotating beam, right   | 0293           |
| C156 | Marker light, left, 1 <sup>st</sup>                                      | 0226           |
| C157 | Marker light, right, 1 <sup>st</sup>                                     | 0228           |
| C158 | Marker light, left, 2 <sup>nd</sup>                                      | 0219           |
| C159 | Marker light, right, 2 <sup>nd</sup>                                     | 0221           |
| C553 | Mechanical main switch   | 0002           |
| C622 | Lighting switch  | 0201           |
| C715 | Rotating beam switch   | 0293           |
| C725 | Work lamp switch   | 0289           |
| C727 | Fog lamp switch, front/rear  | 0212           |
| C736 | Roof hatch switch  | 0297           |
| C742 | Traction assistance switch   | 0739           |
| C748 | Cross-axle differential lock switch                                      | 0394           |
| C750 | PTO 1 Switch   | 0082           |
| D758 | Diode to prevent feedback to the VIC                                     | 120            |
| C763 | Instrument lighting dimming potentiometer                                | 0110           |
| C765 | Switch for warning lamps   | 0098           |
| C773 | Fog lamp switch, rear  | 0215           |
| C774 | Central door locking switch  | 0306           |
| C775 | Switch, steering column, direction indicators/horn/dipped beam/main beam | 0085 0088 0208 |
| C804 | Switch, adjustable speed limiter   | 0113           |

| 1    | 2   | 3                   |
|------|---|---------------------|
| C835 | Switch to turn off interior detection   | 0194                |
| C836 | Switch to turn off superstructure/drawn vehicle loadspace detection                   | 0197                |
| C841 | Accessories/ignition/starter switch   | 0023                |
| C842 | Windscreen wipers/washer steering column switch                                       | 0163 0165 0167 0168 |
| C853 | Cab main switch   | 0006                |
| C854 | Chassis main switch   | 0006                |
| C864 | Drop glass switch, co-driver's side (driver's side door)                              | 0323                |
| C865 | Drop glass switch, co-driver's side (driver's side door)                              | 0322                |
| C866 | Drop glass switch, driver's side (driver's side door)                                 | 0327                |
| C867 | Mirror heating switch   | 0345                |
| C868 | Mirror adjustment switch  | 0333 0339           |
| C871 | Potentiometer, headlamp height adjustment   | 0233                |
| C880 | Switch, reversing buzzer  | 0266                |
| C891 | Steering column switch, windscreen wiper/washer, cruise control, engine speed control | 0483                |
| C892 | Heater fan switch   | 0376                |
| C893 | Air conditioning switch   | 0379                |
| D521 | Electronic unit, cab heater   | 0387                |
| D529 | Remote control system, ECAS   | 0702 0718 0735      |
| D609 | Light switch diode  | 0202                |
| D610 | Diode, main beam/dipped beam  | 0208                |
| D715 | Alarm system LED  | 0177                |
| D784 | Diode, Swedish lighting   | 0204                |
| D785 | Diode, Swedish lighting   | 0204                |
| D787 | Diode, air conditioning compressor link   | 0381                |
| D802 | ECAS-2 (6x2) electronic unit  | 0748                |
| D822 | Vehicle interface module AGC  | 0541                |
| D836 | Electronic unit for VLG current limiter   | 0012                |
| D851 | Electronic unit, ECAS-3 (4x2)   | 0710 0726           |
| D866 | Electronic unit, AGC-A4 automatic gearbox control                                     | 0552                |

| 1    | 2   | 3              |
|------|---|----------------|
| D867 | Automatic gearbox selector  | 0553           |
| D899 | DIP-4 instrument panel  | 0070           |
| D900 | VIC electronic unit   | 0080 0091 0132 |
| D903 | ECS-DC3 electronic unit   | 0620 0659      |
| D904 | Menu Control Switch, MCS  | 0124           |
| D905 | Electronic unit, CDS  | 0308           |
| D909 | Electronic unit, alarm system, ultrasonic   | 0181           |
| D910 | Electronic unit, battery charger  | 0174           |
| D911 | Electronic unit, ALS-S alarm system   | 0186           |
| D912 | Electronic unit, immobiliser  | 0060           |
| D924 | Electronic unit for main switch   | 0010           |
| D926 | Electronic unit, airbag/seat belt tensioner   | 0476           |
| D931 | LED unit, immobiliser   | 0063           |
| D936 | Electronic unit for automatic gearbox (AGC-T1000/2000)  | 0514           |
| D940 | Electronic unit, RAS-EC   | 0461           |
| D941 | Electronic unit for ABS/ASR, D model  | 0417           |
| D942 | Fuse box  | -              |
| D958 | Electronic unit, converter with power supply for radio memory   | 0360           |
| D960 | Airbag contact unit   | 0475           |
| D961 | Electronic unit, ABS/ASR, E version   | 0440           |
| E004 | Fuse, dipped beam, driver's side  | 0239           |
| E005 | Fuse, dipped beam, co-driver's side   | 0240           |
| E006 | Fuse, main beam, driver's side  | 0242           |
| E009 | Fuse, front fog lamps   | 0249           |
| E013 | Fuse, stop lights   | 0259           |
| E018 | Windscreen wiper motor fuse   | 0029           |
| E019 | Fuse, horn  | 0085           |
| E023 | Fuse, switch, tachograph timer  | 0049           |
| E025 | Fuse, windscreen wiper motor/windscreen washer motor  | 0163           |
| E026 | Fuse, cigar lighter/door switches/electronic unit, 24/12 V converter with power supply for radio memory | 0357           |

| 1    | 2   | 3         |
|------|---|-----------|
| E027 | Fuse, electronic unit, 24/12 V converter, with power supply for radio memory                      | 0359      |
| E028 | Fuse, interior lighting/bunk lamps/central door lock  | 0273      |
| E031 | Fuse, heater fan  | 0373      |
| E035 | Fuse, voltage regulation generator/ECS-DC3  | 0021      |
| E039 | Fuse, seat heating  | 0353      |
| E043 | Fuse, ABS, drawn vehicle  | 0401      |
| E044 | Fuse, mirror heating/electric mirror adjustment/electric drop glass operation                     | 0321      |
| E048 | Fuse, drawn vehicle power supply  | 0033      |
| E051 | ECAS fuse   | 0734      |
| E052 | Fuse for work lamp  | 0286      |
| E053 | Fuse, diagnostic connector/alarm system/ECAS  | 0587      |
| E058 | Fuse for cab heater   | 0385      |
| E062 | ECAS fuse   | 0703 0719 |
| E091 | Fuse, air dryer heating element/water separator/RAS-EC/engine speed control application connector | 0319      |
| E108 | Fuse, VIC   | 0103      |
| E114 | Fuse, cab heater/warning lamps  | 0390      |
| E143 | Fuse, tachograph/alarm system/immobiliser/ABS-D/ABS/ASR-E   | 0057      |
| E144 | Fuse, automatic gearbox (AGC)   | 0504      |
| E153 | Fuse, power supply for main switch  | 0008      |
| E156 | Fuse for accessories lighting   | 0034      |
| E158 | Fuse, DIP-4 instrument panel  | 0067      |
| E160 | ECS-DC3 fuse  | 0601 0640 |
| E163 | Fuse, rotating beams/roof hatch   | 0293      |
| E165 | Fuse, FPH-E fuel heater after contact   | 0313      |
| E190 | Fuse, ABS-D / ABS / ASR-E   | 0427 0450 |
| E198 | Fuse, central door lock   | 0308      |
| E277 | Fuse, VIC   | 0106      |
| E279 | Fuse, voltage regulation generator  | 0021      |

| 1    | 2   | 3         |
|------|---|-----------|
| E280 | Fuse, VIC   | 0104      |
| E282 | Fuse, engine brake switch/stop light switch   | 0257      |
| E283 | Fuse, headlamp height adjustment/width marker light, 1 <sup>st</sup> , left and right/tail light, right | 0226      |
| E284 | Fuse, width marker light, 2 <sup>nd</sup> , left and right/left rear light/search lighting              | 0218      |
| E285 | Fuse, VIC/fog light switch  | 0212      |
| E286 | Main fuse   | 0047      |
| E290 | Fuse, RAS-EC  | 0453      |
| E297 | Fuse, airbag and seat belt tensioner system   | 0473      |
| E299 | Fuse, windscreen heating  | 0349      |
| E330 | Fuse, 'sens' wire main switches   | 0016      |
| E349 | Main fuse, cab  | 0002 0015 |
| E354 | Fuse, automatic gearbox, AGC fan  | 0501 0534 |
| E501 | Reversing light switch  | 0264      |
| E508 | Temperature switch for air conditioning compressor  | 0380      |
| E509 | Air conditioning switch, high/low pressure  | 0382      |
| E514 | Cab stepwell lighting/interior lighting door switch, driver's side                                      | 0278      |
| E515 | Cab stepwell lighting/interior lighting door switch, co-driver's side                                   | 0280      |
| E564 | Engine brake switch   | 0130      |
| E569 | Neutral position switch, gearbox  | 0125      |
| E581 | Cab heater timer unit   | 0388      |
| E585 | Selector switch for AT 1000/2000 automatic gearbox  | 0515      |
| E587 | Switch for stop lights/clutch   | 0127      |
| E597 | Switch, cooling fans, automatic gearbox (AGC)   | 0501      |
| F000 | Parking brake switch  | 0115      |
| F006 | Control switch for differential lock, 1 <sup>st</sup> differential                                      | 0116      |
| F009 | Control switch, cab tilting   | 0121      |
| F087 | Control switch, gearbox PTO   | 0079      |
| F107 | Control switch for brake lining wear, front left  | 0488      |
| F108 | Control switch for brake lining wear, front right   | 0490      |
| F111 | Control switch for brake lining wear, rear left   | 0492      |
| F112 | Control switch for brake lining wear, rear right  | 0493      |

| 1    | 2  | 3              |
|------|--|----------------|
| F113 | Control switch, brake lining wear, rear left, 2 <sup>nd</sup> rear axle (6x2)  | 0495           |
| F114 | Control switch, brake lining wear, rear right, 2 <sup>nd</sup> rear axle (6x2) | 0497           |
| F116 | Oil level switch, RAS-EC   | 0462           |
| F512 | Wheel speed sensor, front axle, left   | 0407 0430      |
| F513 | Wheel speed sensor, front axle, right  | 0408 0432      |
| F514 | Wheel speed sensor, driven axle, left  | 0410 0433      |
| F515 | Wheel speed sensor, driven axle, right   | 0411 0435      |
| F533 | Vehicle speed sensor   | 0050           |
| F552 | Crankshaft sensor  | 0601 0640      |
| F558 | Camshaft sensor  | 0603 0641      |
| F565 | Fuel temperature sensor  | 0604 0642      |
| F566 | Coolant temperature sensor   | 0605 0644      |
| F601 | Output shaft speed sensor, automatic gearbox                                   | 0504 0556      |
| F602 | Input shaft speed sensor, automatic gearbox                                    | 0505 0557      |
| F603 | Ultrasonic transmitter   | 0180           |
| F604 | Ultrasonic receiver  | 0182           |
| F608 | Fuel level sensor  | 0109           |
| F612 | Height sensor, ECAS, rear axle, left   | 0705 0721 0742 |
| F613 | Height sensor, ECAS, rear axle, right  | 0707 0743      |
| F615 | ECAS pressure sensor, driven axle, left/right                                  | 0746           |
| F647 | Engine oil pressure and temperature sensor                                     | 0608 0648      |
| F648 | Fuel rail pressure sensor  | 0607 0645      |
| F649 | Charge boost pressure and temperature sensor                                   | 0610 0647      |
| F651 | Ambient temperature sensor   | 0104           |
| F652 | Air pressure sensor  | 0106           |
| F670 | Automatic gearbox turbine speed sensor   | 0507           |
| F671 | ECS-DC3 accelerator pedal sensor   | 0623 0662      |
| F686 | Alarm system radar sensor  | 0185           |
| F692 | Water separator sensor   | 0316           |
| F695 | Trailing axle angle sensor   | 0457           |
| F696 | Front axle angle sensor  | 0459           |



| 1    | 2  | 3                   |
|------|--|---------------------|
| F705 | Diode for switching off cab heater with running engine | 0455                |
| G000 | Rear light/marker light and search light relay         | 0201 0210           |
| G001 | Dipped beam relay                                      | 0206 0239           |
| G002 | Main beam relay  | 0208 0242           |
| G004 | Fog lamp relay, front                                  | 0212 0253           |
| G005 | Fog lamp relay, rear                                   | 0118 0249           |
| G008 | Windscreen wiper relay                                 | 0166 0171           |
| G014 | Glow plug relay  | 0047 0631 0669      |
| G015 | Contact relay  | 0027 0030           |
| G036 | Stop light relay                                       | 0258 0259           |
| G185 | Starting circuit interrupter relay                     | 0541 (in VIM D822)  |
| G188 | Lighting relay, accessories                            | 0030 0034           |
| G201 | Fuel heating relay, FPH-E                              | 0313 0634 0673      |
| G203 | Takeover relay, starter motor                          | 0037 0038 0042 0044 |
| G294 | Relay, automatic gearbox                               | 0541 (in VIM D822)  |
| G350 | Reversing light relay, automatic gearbox               | 0541 (in VIM D822)  |
| G353 | Contact relay  | 0028 0314           |
| G354 | Windscreen wiper relay                                 | 0025 0163           |
| G355 | Seat heating relay                                     | 0353 0354           |
| G367 | Main switch relay, power supply                        | 0008                |
| G368 | Main switch relay, earth                               | 0010 0015           |
| G397 | Relay, windscreen heating                              | 0349                |
| G425 | Main switch relay                                      | 0064 0102           |
| G444 | Relay, cooling fans, automatic gearbox (AGC-A4)        | 0534 0535           |
| G507 | Earth, 1-pin, chassis - cab                            | -                   |
| G516 | Central cab earth, co-driver's side                    | -                   |
| G517 | Central cab earth, driver's side                       | -                   |
| G520 | Central earth, chassis, front end                      | -                   |
| G522 | Central earth, starter motor                           | -                   |
| G523 | Central earth, engine                                  | -                   |
| G524 | Earth point, glow element                              | -                   |
| G525 | Central earth, flywheel                                | -                   |

| <b>1</b> | <b>2</b>  | <b>3</b>  |
|----------|---|-----------|
| G528     | Central earth connection, cab, left                               | -         |
| G529     | Central earth connection, cab, right                              | -         |
| G735     | Through-connection for Swedish lighting                           | 0205      |
| G742     | Through-connection, VIC/DIP-4                                     | 0065      |
| G743     | Through-connection, main beam                                     | 0242      |
| G744     | Through-connection, cab heater/warning lamps/central door locking | 0301      |
| G748     | Node, V-CAN   | 0195      |
| G750     | Node, V-CAN   | 0448 0599 |
| G752     | Node, V-CAN   | 0059      |
| G753     | Node, V-CAN   | 0596      |

### 2.3 SECTION DIAGRAMS FROM CIRCUIT DIAGRAM 1427090/03

Overview of section diagrams of circuit diagram 1427090/03

| Section diagram no. | Title of section diagram                                  |
|---------------------|---|
| A                   | Voltage before and after contact                          |
| B                   | Overview of earthing points                               |
| C                   | CAN overview  |
| 1                   | Main switch   |
| 2                   | Ignition/starter switch/charging circuit                  |
| 3                   | MTCO tachograph   |
| 4                   | Immobiliser   |
| 5                   | Pre-glowing   |
| 6                   | DIP-4   |
| 7                   | Direction indicators/warning lamps                        |
| 8                   | VIC   |
| 9                   | Marker lights/parking lights/tail lights                  |
| 10                  | Reversing lights/buzzer                                   |
| 11                  | Lighting/dipped beam/main beam/Swedish lighting/fog lamps |
| 12                  | Stop lights/cab tilting gear                              |
| 13                  | Differential lock   |
| 14                  | Interior lighting   |
| 15                  | Mirror heating/windscreen heating/mirror adjustment       |
| 16                  | Search lighting   |
| 17                  | Air conditioning/heater fan                               |
| 18                  | Seat heating/accessories connection                       |
| 19                  | Horn/cigar lighter/work lamp/air dryer                    |
| 20                  | ABS-D   |
| 21                  | ABS/ASR-E   |
| 22                  | ECS-DC3/exhaust brake                                     |
| 23                  | Cruise control  |
| 24                  | AGC automatic transmission (AT1000/2000)                  |
| 25                  | AGC automatic transmission (MD3060)                       |
| 26                  | PTO   |

| <b>Section diagram no.</b> | <b>Title of section diagram</b>   |
|----------------------------|---|
| 27A                        | ECAS-3 LF45   |
| 27B                        | ECAS-3 LF55   |
| 27C                        | ECAS-2 LF55   |
| 29                         | Headlamp height adjustment/rotating beams   |
| 30                         | 24/12 V 10/15 A converter for radio   |
| 31                         | CDS-3/drop glass operation/roof hatch   |
| 33                         | Windscreen wipe/wash system   |
| 34                         | ACH-W with timer  |
| 35                         | Application connectors, engine speed control, superstructure functions and spare wiring |
| 36                         | Break lining wear   |
| 37                         | ALS-S/battery charger, alarm BV2/BV3  |
| 38                         | Sockets, FA/FT  |
| 39                         | Water separator/fuel pre-heating  |
| 40                         | Airbag/seat belt tensioner  |
| 41                         | RAS-EC  |



## A VOLTAGE BEFORE AND AFTER CONTACT

### VOLTAGE BEFORE CONTACT

Wire 1000 runs from the batteries (A500) to the starter motor (B010), connecting point 30, and via the main fuse (E349, 80 A) to dashboard lead-through zone 1. Wire 1000 runs from the glow plug relay fuse (E286, 125 A) to the glow plug relay (G014). Wire 1000 and the + distribution bolt in dashboard lead-through zone 1 provide a constant voltage at pins 1 and 2 of connector 705 on the PCB.

This provides "voltage before contact" for the entire PCB. Power is also provided (by wire 1000) from point 30 on the starter motor to the B+1 connection of the alternator (A513). Wire 1000 goes from the + distribution bolt to the ignition/starter switch (C841).


### VOLTAGE AFTER CONTACT

When the ignition/starter switch (C841) is set to the "contact" position (connection between points 1 and 4), relay G015 is energised via wire 4001.

This then connects wire 1000 (voltage before contact) to wire 1010 (voltage after contact).

When the ignition/starter switch (C841) is turned against the spring pressure (connection between points 1 and 2), relay G015 remains activated.

When the ignition/starter key is released, the contact/starter switch automatically springs back and remains in the "contact" position.



A

1427090/03


EL001553

**B OVERVIEW OF EARTHING POINTS**

This section diagram gives an overview of all the earth connections, with wire markings and connector points.


**VARIANTS****Location**

- G516 central earth, cab  
 32 These earth points are also used with an ABS-D (D941) system  
 35 Connector 790 is designed for a CB set  
 68,70 The earth connection ends at connector 718.  
 The application wiring harness connected to 718 makes an earth connection directly on the chassis



E501365






**B**

1427090/03

EL001554





B

1427090/03

EL001555


10

**C CAN OVERVIEW**

This section diagram gives an overview of all the CAN connections, with wire markings and connector points.

**SEE THE SYSTEM MANUAL FOR MORE INFORMATION****VARIANTS**

| Location |   |
|----------|---|
| 2        | The terminating resistor is in the automatic transmission wiring harness  |
| 8        | Electronic unit, automatic gearbox, AGC-T1000/2000 (D936):<br>If MD3060 gearbox is fitted, the electronic unit is for AGC-A4 automatic gearbox operation (D866) |
| 16       | The terminating resistor is in the wiring harness of the ECS-DC3 engine management system   |



C


1427090/03

EL001556

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53

**1. MAIN SWITCH****MANUALLY OPERATED EARTH BREAKER**

Turning main switch C553 anti-clockwise will break the earth connection between the batteries (A500) and the chassis earth point G525. Because the tachograph (B525) must have a power supply and earth connection at all times, earth wire 9001 is connected directly to the earth connection of the batteries through 2-pin dashboard lead-through connector 813 in zone 1.



1

1427090/03

EL001558

10

**ELECTRICALLY OPERATED MAIN SWITCH**

The main switch (D924) can be closed:

- electrically in the cab
- electrically on the chassis

**Closing the main switch electrically in the cab**



**ATTENTION: switch C854 must be in the "main switch on" position (connection between contacts 1 and 2).**


Switch C853 (switch for main switch in cab) connects the C1 and C2 connections to the C4 and C5 connections via wire 4176, contacts 5 - 7 of switch C853, wire 4177, contacts 1 - 2 of switch C854 and wire 4178. Relays G367 and G368 are immediately energised through wire 4174 and connection point A3 (A3 is connected to earth for 0.5 seconds). This closes the connection between points 88a and 88 of both relay G367 and relay G368. The positive and the negative terminals of the batteries are now connected to the vehicle's power supply. Immediately after switch C853 closes, connection point C2 is internally connected to point A7.

Connection point A5 is connected to the positive terminal via wire 3173 after connection point 88 of relay G367. This connection transmits a signal to the ECU to indicate that relay G367 has switched.

**Closing the main switch electrically on the chassis**



**ATTENTION: switch C853 must be in the "main switch on" position (connection between contacts 5 and 7).**



Switch C854 (switch for main switch on the chassis) connects the C1 connection to the C4 and C5 connections via wire 4176, contacts 5 - 7 of switch C853, wire 4177, contacts 1 - 2 of switch C854 and wire 4178. Relays G367 and G368 are immediately energised through wire 4174 and connection point A3 (A3 is connected to earth for 0.5 seconds). This closes the connection between points 88a and 88 of both relay G367 and relay G368. The positive and the negative terminals of the batteries are now connected to the vehicle's power supply.

Immediately after switch C854 closes, connection point C2 is internally connected to point A7.

Connection point A5 is connected to the positive terminal via wire 3173 after connection point 88 of relay G367. This connection transmits a signal to the ECU to indicate that relay G367 has switched.

The main switch (D924) can be opened:

- electrically in the cab
- electrically on the chassis

**Opening the main switch electrically in the cab**



**ATTENTION: switch C854 must be in the "main switch on" position (connection between contacts 1 and 2).**

Switch C853 (switch for main switch in cab) disconnects wire 4176, contacts 5 - 7 of switch C853, wire 4177, contacts 1 - 2 of switch C854 and the C1 and C2 connections from the C4 and C5 connections via wire 4178.



**ATTENTION: switch C853 must be in the "main switch on" position (connection between contacts 5 and 7).**



Two actions are carried out immediately after switch C853 is opened:

1. Connection point A7 is connected to earth (A2).
2. After a delay of approx. 6 seconds, relays G367 and G368 are connected to earth for approx. 0.5 sec. via wire 4175 and connection point A4. This breaks the connection between points 88a and 88 of relays G367 and G368. The positive and the negative terminals of the batteries are now disconnected from the vehicle's power supply.

If the engine is running, it is switched off.

Connection point A5 is connected to the positive terminal via wire 3173 after connection point 88 of relay G367. This connection transmits a signal to the ECU to indicate that relay G367 has switched.

**Opening the main switch electrically on the chassis**

Switch C854 (switch for main switch in cab) breaks the C1 and C2 connections to the C4 and C5 connections via wire 4176, contacts 5 - 7 of switch C853, wire 4177, contacts 1 - 2 of switch C854 and wire 4178.

Two actions are carried out immediately after switch C854 is opened:

1. Connection point A7 is connected to earth (A2) in the unit.
2. After a delay of approx. 6 seconds, relays G367 and G368 are connected to earth for approx. 0.5 seconds via wire 4175 and connection point A4. This breaks the connection between points 88a and 88 of relays G367 and G368. The positive and the negative terminals of the batteries are now disconnected from the vehicle's power supply.

If the engine is running, it is switched off.


Connection point A5 is connected to the positive terminal via wire 3173 after connection point 88 of relay G367. This connection transmits a signal to the ECU to indicate that relay G367 has switched.

**Note:**


When one of the switches (C853 or C854) that activate the electronic unit (close main switch) is operated, relays G367 and G368 are activated after approximately 3 seconds. If one of the switches is operated again within the 3 seconds, the electronic unit (D924) will select the priority 'main switch ON'.

**VARIANTS**

| Location |  |
|----------|--|
| 76       | G368, main switch relay, earth fitted depending on the requirements for transporting hazardous substances<br>These wires are only present if ADR is fitted   |
| 88,90    | Earth connection to connector 834 is only present if ADR is fitted   |
| 94       | Connector 831: Only present if the system is fitted with an external current limiter (D826)  |
| 97       | Connector 832: Only present if the system is fitted with an external current limiter (D826)  |
| 98,101   | Electronic unit for VLG current limiter (D826): Fitted depending on the requirements for transporting hazardous substances. Version with production date < 2002-49: current limiter (D826) used as shown |
| 99       | Version with production date > 2002-49: current limiter integrated into the MTCO (B525)  |
| 98,101   |  |







1

1427090/03

EL001557

10

## 2. IGNITION/STARTER SWITCH/CHARGING CIRCUIT

### CONTACT CIRCUIT

When ignition/starter switch C841 is turned to the "accessories" position (contact 1 connected to contact 6), the "accessories" relay (G355) is energised via wire 1130. If ignition switch C841 is turned further (contact 1 is connected to 4), ignition relay G015 will be activated via wire 4001. Wire 1010 is supplied with power.

### STARTING CIRCUIT

When the contact switch is turned to the "start" position, contacts 1 and 2 in this switch are connected. Power is supplied to relay G203 via wire 4002. The VIC (D900) connects G203 to earth when the neutral position switch (E569) in the gearbox is closed. Relay G203 now supplies power via wire 4009 to connection point 50 of the starter motor (B010). As a result, the starter motor is energised.

This means that if the gearbox is not in neutral the VIC does not connect relay G203 to earth and the relay is therefore not energised.

### CHARGING CIRCUIT


When the ignition is switched on, power is supplied to both the B+ connection and connection 15 (pin 3) of the alternator. An internal resistor in the alternator is energised by an IC in the carbon brush holder. This resistor ensures that a low level of current passes through the energising resistor. This excites a magnetic field in the alternator.

After starting, the voltage on terminals B+ and 15 (pin 3) will rise to about 28.5 V. Once this voltage is reached, the control IC in the regulator interrupts the pre-exciter coil to enable the voltage to be regulated. The magnetic field will now disappear, so that the generator will not be energised for a short period of time. As a result, the voltage on outputs B+ and 15 will drop.

The regulator reactivates when the voltage drops below 27.6 V. This means that the voltage supplied by the generator remains relatively constant. The batteries are supplied through generator output B+1.

The alternator charging current warning lamp is activated via wire 1020, which is connected to the VIC (D900). The VIC controls the DIP via the CAN network. The voltage on wire 1020 is switched by the control IC. Errors are also shown on the DIP display through this connection.

The alternator is also equipped with a 'sens' connection (pin 4). However, this connection is not used and is now connected directly to B+2. The function of this connection is to correct the voltage difference between B+ and the batteries.



2

1427090/03


EL001559

10

### 3. TACHOGRAPH SEE THE SYSTEM MANUAL FOR MORE INFORMATION

**Location**

19 Electronic unit, ECAS-3 (D851):  
If ECAS-2 fitted, then electronic  
unit D802



3

1427090/03

EL001560


1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53

10

**10**

**4. IMMOBILISER  
SEE THE SYSTEM MANUAL FOR MORE  
INFORMATION**





4


1427090/03

EL001561

10

**10**

**5. PRE-GLOWING  
SEE THE SYSTEM MANUAL FOR MORE  
INFORMATION**



5


1427090/03

EL001562

10

**10**

**6. DIP-4  
SEE THE SYSTEM MANUAL FOR MORE  
INFORMATION**



6


1427090/03

EL001563

**7. DIRECTION INDICATORS AND WARNING LIGHTS**  
**SEE THE SYSTEM MANUAL FOR MORE INFORMATION**

**VARIANTS**

| <b>Location</b> |   |
|-----------------|---|
| 15,18           | Connector 763:<br>Not fitted on vehicle type FT |
| 26,28,31        | Connector 762:<br>Not fitted on vehicle type FT |



7

1427090/03


EL001564

**8. VIC**  
**SEE THE SYSTEM MANUAL FOR MORE**  
**INFORMATION**

**VARIANTS**

| Location |  |
|----------|--|
| 33,39    | Connector 762:<br>Not fitted on vehicle type FT  |
| 88       | Electronic unit, ABS/ASR-E (D961): If ABS-D fitted, then electronic unit D941  |
| 116      | Electronic unit, automatic gearbox, AGC-T1000/2000 (D936): If MD3060 gearbox is fitted, the electronic unit is for AGC-A4 automatic gearbox operation (D866) |
| 156      | Connector 780:<br>Not fitted on vehicle type FA. Wire 2155 only fitted in application connector A070   |
| 182      | Connector 763: Not fitted on vehicle type FT   |






8

1427090/03

EL001565





10

8

1427090/03

EL001566





8

1427090/03

EL001567

10



8

1427090/03

EL001568

160 161 162 163 164 165 166 167 168 169 170 171 172 173 174 175 176 177 178 179 180 181 182 183 184 185 186 187 188 189 190 191 192 193 194 195 196 197 198 199 200 201 202 203 204 205 206 207 208 209 210 211 212




## 9. MARKER LIGHTS/PARKING LIGHTS/TAIL LIGHTS, FA/FT

By switching the lighting switch (C622) to the 1<sup>st</sup> position (connection between contacts 2 and 1), relay G000 is activated through wire 2100. Relay G000 provides the left/right marker lighting on top of the cab and the left tail light with voltage through fuse E284, wire 2170. A connection is also fitted in drawn vehicle socket A000 (pin 2). The right-hand tail light and the parking light receives power via fuse E283, wire 2169. A connection is also provided in drawn vehicle socket A000 (pin 6).

### VARIANTS

| Location |   |
|----------|---|
| 21       | Connector 809: Only fitted on vehicle type FA   |
| 24       | Connector 810: Only fitted on vehicle type FA   |
| 34,36,39 | Connector 762:<br>Not fitted on vehicle type FT |



**10. REVERSING LIGHTS/BUZZER**

When the contact is switched on, power is supplied to the reversing light switch (E501) via E018 and wire 1217.

This switch is mounted in the gearbox. The contacts are closed when the gearbox is switched to the "reverse" position.


Power is then supplied via wire 4591 to the reversing lights (C026/C027) and drawn vehicle connector A001.

The reversing buzzer (B176) can only be activated via wire 5104 if the dashboard switch (C880) is in position I. Switching C880 to the 0 position turns off the reversing buzzer. The application connector (A070) also has a connection that is switched by the reversing light switch (E501).

**VARIANTS****Location**

|        |                               |
|--------|-------------------------------|
| 22, 27 | Connector 762:                |
|        | Not fitted on vehicle type FT |
| 32     | Connector 758:                |
|        | Not fitted on vehicle type FT |





10

1427090/03

EL001570

10

## 11. LIGHTING/DIPPED BEAM/MAIN BEAM/SWEDISH LIGHTING/FOG LAMPS

**MARKER, PARKING AND TAIL LIGHTS**  
FOR SECTION DIAGRAM AND  
EXPLANATION: SEE SECTION DIAGRAM 9

### LIGHT SWITCH

#### Position 1 ("town lights")

By switching the lighting switch (C622) to the 1st position (connection between contacts 2 and 1), relay G000 is activated through wire 2100. Relay G000 provides power to the marker lights and tail lights and to the fog lamps switch (C727), pins 1 and 2. This is done via fuse E285, wire 2639. There is also a connection via the same fuse and wire to the VIC (pin C7745) for the "light on" buzzer (in DIP).

#### Position 2 ("dipped beam")

By switching the lighting switch (C622) to the 2nd position (connection between contacts 2 and 4), relay G001 is energised through wire 2110. Power for the dipped beam headlights (C000) and the VIC is supplied via fuse E004 and wire 2114 through pin D36/746. Dipped beam C001 is supplied with power via fuse E005 and wire 2113. Diode D609 ensures that relay G000 remains activated when the light switch is turned to position 2.

### MAIN BEAM

#### "Signalling light"

Steering column switch C775 is supplied with power before contact at pin B3. This power supply is used for signalling. During signalling, points B3 and B4 are connected to each other. This is a spring-loaded connection. Relay G002 is activated via wire 2120. Relay G002 supplies power to the main beam headlights (C002/C003) via fuse E006, through-connection G743 and wire 2122. Wire 2122 is also connected to pin C6/745 of the VIC and the spotlights (C006/C007). The VIC switches on the "main beam" indicator in the DIP via the I-CAN.

Diode D610 prevents voltage from getting to relays G000 and G001 through connection A4 when the main beam switch is pulled back further during signalling. Otherwise this would activate all the other lights during signalling.

#### "Main beam"

When the main beam headlights are switched on, points A4 and B4 of the steering column switch (C775) are connected to each other. Pin A4 is supplied with power via diode D610 when light switch C622 is turned to position 2. Relay G002 is then again energised via wire 2120, as a result of which the main beam headlights (C002/C003) will come on.

### SWEDISH LIGHTING

Swedish lighting is provided using through-connection G735. When the vehicle ignition is switched on, relays G000 and G001 are directly activated via fuse E282. As a result, the dipped beam headlights are activated and the fog lamp switch (C727) is supplied with power. Diodes D784 and D785 are fixed on the PCB of the fuse box. In vehicles that do not have Swedish lighting, diode D784 prevents relay G001 from being activated when the light switch (C622) is in position I. Diode D785 prevents relay G000 from being activated when the light switch is moved to position II.

The interior lighting will NOT switch off when the engine is started.

**VARIANTS****Location**

|       |  |
|-------|--|
| 9     | Removable through-connection G735 for Swedish lighting (see label on fuse box) |
| 11    | The diode is located on PCB D492   |
| 15    | Diode located in diode block on the bottom of the central console              |
| 18    | Diode located in diode block on the bottom of the central console              |
| 24    | If only a rear fog light is fitted, switch C727 is replaced by switch C773.    |
| 26    | The diode is located on PCB D492   |
| 76,81 | Connector 762:<br>Not fitted on vehicle type FT                                |

**SPOTLIGHT**

Operating the main beam switch (C775) energises main beam relay G002 via wire 2120. Relay G002 supplies power to the spotlights (C006/C007) via fuse E006 and wire 2122.

**FRONT FOG LIGHTS**


Moving the fog lamp switch (C727) to position I (fog lamps, front) activates relay G004 via wire 2140, provided that light switch C622 is in position 1. Relay G004 supplies the front fog lamps (C008/C009) with power through fuse E009 and wire 2142. The VIC (D900) also receives power through wire 2140 at pin D34/746. The VIC switches on the "front fog lamps" indicator on the instrument panel through I-CAN.

**REAR FOG LIGHTS**

When the fog lamp switch (C727) is set to position II, which is spring-loaded, the VIC receives a voltage signal at pin D35/746, provided that light switch C622 is in position 1. The VIC then activates relay G005 through pin C40/745. Relay G005 supplies power to the rear fog lamps (C024/C025) via fuse E009, wire 2152.

If the lighting or the ignition has been turned off and the lighting is then turned on again, the fog lamp switch (C727) will have to be re-set to position II in order to switch on the rear fog lamps.

Power is also supplied to drawn vehicle connector A001 (pin 7) via wire 2152.




10

11

1427090/03

EL001571





54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100 101 102 103 104 105 106

11

1427090/03

EL001572

10

**12. STOP LIGHTS/CAB TILTING GEAR****STOP LIGHTS**


When stop light/clutch operating switch E587 is operated (connection between contacts 4 and 3) by depressing the brake pedal, relay G036 is energised via wire 4602. Power will also be supplied to the VIC (pin D32/746). Through fuse E013, wire 1209, contacts 3 and 5 of relay G036 and wire 4601 a voltage is now applied to the right stop light (C021) and the left stop light (C020), so that they come on. The lights that are connected via drawn vehicle socket A000 will also come on. The ECAS-3 unit (D851) or ECAS-2 unit (D802) then also receives a signal. Application connector A070 is also connected to wire 4601.

**CAB TILTING GEAR**

The switch for the cab lock (F009) is a "normally closed" switch. The switch is opened when the cab is in the driving position. When the cab is tilted, the switch closes and pin B16/744 of the VIC is connected to earth via wire 4312. When the alarm is active it knows that the cab is in the driving position because a small current goes to earth through the control switch for cab tilting (F009). Diode D758 prevents this current from also flowing to earth through the VIC (the VIC in sleep mode), in which case the alarm would not know whether the cab is being tilted intentionally or by accident.

**VARIANTS****Location**

|       |   |
|-------|---|
| 23,28 | Connector 762:<br>Not fitted on vehicle type FT   |
| 29    | Electronic unit, ECAS-3 (D851):<br>On a 6x2 vehicle, ECAS-2<br>electronic unit D802 (7/340) |



12

1427090/03

EL001573

10

### 13. DIFFERENTIAL LOCK


If the contact switch (C841) is activated, a voltage is applied through fuse E018 and wire 1217 to the switch for the cross-axle differential lock (C748). If switch C748 is operated, a voltage is applied to the operating valve for the cross-axle differential lock (B243) through wire 4517. If the differential is locked, the differential lock control switch (F006) connects pin C34/745 of the VIC to earth via wire 3408. The VIC will activate the DIP through I-CAN to switch on the "differential lock switched on" indicator.

#### VARIANTS

##### Location

17,21 Connector 762:  
Not fitted on vehicle type FT





13

1427090/03

EL001574


#### 14. INTERIOR LIGHTING

Power is supplied to the door switches (E514 and E515) through fuse E028 and wire 1107. If the door on the driver's side is opened, door switch E514 is activated (connection between 1 and 2). As a result, power will be supplied via wire 2600 to the left-hand stepwell lighting (C062) and to pin D1/746 of the VIC (D900). The VIC also turns on the interior lighting (C119) via pin A4/743, provided that the switches are in the correct position. At the same time, a voltage signal is applied to the alarm system electronic unit (D911) if the alarm system was activated, it can be triggered in this way to activate the alarm horn and hazard warning lights. Switch E515 provides exactly the same function on the co-driver's side.

When the door on the driver's side is closed (contact between 1 and 2 interrupted), power is no longer supplied to pin D1/746 of the VIC. From this moment, pin A4/743 will continue to be supplied with power for about another 9 seconds.

When the vehicle ignition is switched on, the power supply to pin A4/743 of the VIC will cease immediately. The lighting will be switched off immediately.

In an SL cab, the bunk lights (C110 and C111) receive power through fuse E028. Operating the switches in the bunk lights turns the lights on. The interior lighting (C119) also contains a bunk light function that is activated in exactly the same way.



14

1427090/03

EL001575

10

## 15. MIRROR HEATING/WINDSCREEN HEATING/MIRROR ADJUSTMENT

### MIRROR HEATING

When the ignition/starter switch (C841) is set to the "contact" position (connection between points 1 and 4), relay G353 is energised via wire 4001. This relay supplies power to the mirror heating switch (C867) and the mirror adjustment switch (C868) via fuse E044 and wire 1208.

When the mirror heating switch (C867) is operated, power is supplied to mirror heating B017 (driver's side) and B018 (co-driver's side) via wire 4532.

The time-dependent windscreen heating relay (G397) will also be energised. This relay will automatically be de-activated after 12 minutes.

### WINDSCREEN HEATING SYSTEM

If the vehicle has a windscreen heating system, the windscreen heating relay (G397) will be energised when the mirror heating system is activated.

The windscreen heating system (B371) will be supplied with power via fuse E299. The windscreen heating relay (G397) will automatically be de-activated after 12 minutes.


### MIRROR ADJUSTMENT

The outside mirrors are adjusted using "joystick" switches C868 (driver's side and co-driver's side). If the handle of the switch is moved from the rest position (centre) in a particular direction, power will be supplied to mirror adjustment motor B005 (left-hand side) or B006 (right-hand side) and the mirror in question will follow the movement of the handle.

When pins 10 and 5 are connected, mirror adjustment switch C868 is in the "right mirror" position. When pins 8 and 4 are connected, the mirror adjustment switch is in the "left mirror" position.

For this, wires 4770 and 4774 (left-hand side) or 4771 and 4774 (right-hand side) supply power to the motor for the left/right movement. Wires 4772 and 4774 (left-hand side) or 4771 and 4774 (right-hand side) supply power to the adjusting motor for the up and down movement.

The mirror adjustment system can only be used if the contact relay (G353) is energised.



15

1427090/03

EL001576

## 16. SEARCH LIGHTING

### SEARCH LIGHTING


Search lighting refers to lights or LEDs in the various function switches.

When the lighting switch (C622) is operated, relay G000 is energised. This relay supplies power to turn on the various search lighting lamps or LEDs through fuse E284 and wire 2170. This also activates the tachograph lighting (B525).

### VARIANTS

#### Location

44, 52 Connector 762:  
Not fitted on vehicle type FT



16


1427090/03

EL001577

10







16

1427090/03

EL001578

10


## 17. AIR CONDITIONING/HEATER FAN

### HEATER FAN

The heater motor (B377) is supplied with voltage after contact through fuse E031. The motor is activated when the heater fan switch (C892) is turned, so that earth is connected. The heater fan motor is fitted with an overheating protection device between contact 7 and the connection points of the operating switch.

### AIR CONDITIONING

Depending on the engine temperature, voltage is applied to wire 5189 from pin A1743 of the VIC unit. When the engine temperature goes above a certain value, the VIC unit switches this voltage off so as to prevent the engine from overheating. When the temperature falls back below a particular temperature, the voltage is switched on again. To supply the air conditioning switch (C893) with voltage, the parallel switch in the heater fan switch (C892) must be closed. This switch is closed in positions 1 to 4. The air-conditioning compressor temperature switch (E508) prevents the heater fan from freezing and is closed at normal operating temperature. The air conditioning operating switch, high/low pressure, is operated depending on the pressure in the air conditioning system. When all conditions have been met, the air conditioning compressor (B043) is activated. Diode D787 is fitted in the air conditioning compressor so as to damp high voltage peaks that can arise during switch-off.



17

1427090/03

EL001579

10

**18. SEAT HEATING/ACCESSORIES CONNECTION****SEAT HEATING**

When the vehicle is put into accessories position, relay G355 is energised. This relay supplies power to the driver's side seat heating system (B032) via fuse E039 and wire 1227.

If the seat heating switch is activated, the heating element will start warming up. When the maximum temperature is reached, a thermal switch in the seat heating system switches off the heating element.

**ACCESSORIES CONNECTION**


12 V accessories socket A011 is connected to 24 V/12 V converter D958 through a white 2-pin connector. 12 V is applied to A011 before contact.

The converter is supplied with power at pin 3 after contact via contact switch C841 and fuse E026.

The "before contact" connection, 1000, is connected via fuse E027 at pin 2. 12 V before contact is applied to CB connector 790 in the roof console through connector 774 on the outside of the central box.

**VARIANTS****Location**

31 12 V connector, at top of roof console, to be used with CB, for example.



**19. HORN/CIGAR LIGHTER/WORK LAMP/AIR DRYER****HORN**

The horn (B401) is activated before contact via steering column switch C775 (1000). The horn is supplied with power via wire 4979 and fuse E019.

**CIGAR LIGHTER**

If the ignition switch (C841) is in the accessories position (connection between contacts 1 and 6), cigar lighter B030 is supplied with power via fuse E026 and wire 1105. By depressing the cigar lighter, the heating element is warmed up.

**WORK LAMP**

Work lamp switch C725 is supplied with voltage from power supply before contact and via fuse E052. When the switch is operated voltage is applied to the work lamp (C071) and to pin C9/745 of the VIC unit in order to activate the "work lamp" indicator on the DIP via I-CAN.

**AIR DRYER**

When the ignition switch (C841) is on (connection between contacts 1 and 4), relay G353 is activated. This relay supplies power to the air dryer heating element (B042) via fuse E091 and wire 1240. When the maximum temperature is reached, a thermal switch in the air dryer switches off. The water separator sensor (F692) is supplied with power via the same wire.


**VARIANTS****Location**

20,24

Connector 780:

Not fitted on vehicle type FA.

Wire 2155 only fitted in application connector A070



19

1427090/03

EL001581


10

**20. ABS-D**  
**SEE THE SYSTEM MANUAL FOR MORE INFORMATION**

**VARIANTS**

| <b>Location</b>       |   |
|-----------------------|---|
| 14                    | Resistor B402:<br>Fixed on PCB D942   |
| 13,15,17,19,<br>32,34 | Connector 761:<br>Not fitted on vehicle type FT                                   |
| 29                    | Valve, ABS-D, ABS/ASR-E,<br>right front axle, B257:<br>Not fitted on 4S/2M system |





20

1427090/03


EL001582

10

**21. ABS/ASR-E**  
**SEE THE SYSTEM MANUAL FOR MORE INFORMATION**

**VARIANTS**

| Location                      |   |
|-------------------------------|---|
| 14                            | Resistor B402: Fixed on PCB D942  |
| 12,14,16,18,31,33,36,38,40,42 | Connector 761: Not fitted on vehicle type FT                                |
| 29                            | Valve, ABS-D, ABS/ASR-E, right front axle, B257: Not fitted on 4S/2M system |



21

1427090/03


EL001583

10

**22. ECS-DC3/EXHAUST BRAKE**  
**FOR MORE INFORMATION SEE SYSTEM**  
**MANUAL**

**VARIANTS**


| Location |  |
|----------|--|
| 49       | Connector 852: Optional connector for "remote throttle" function                   |
| 66       | The CAN terminating resistor is fitted in the wiring harness, near the B connector |
| 129      | This part of the ECS-DC3 electronic unit relates to the BE engine (4-cylinder)     |
| 186      | This part of the ECS-DC3 electronic unit relates to the CE engine (6-cylinder)     |



22

1427090/03

EL001584




10

22

1427090/03

EL001585

D942



22


1427090/03

107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159


EL001586

10

D942



D903



22

1427090/03

160 161 162 163 164 165 166 167 168 169 170 171 172 173 174 175 176 177 178 179 180 181 182 183 184 185 186 187 188 189 190 191 192 193 194 195 196 197 198 199 200 201 202 203 204 205 206 207 208 209 210 211 212


EL001587





### 23. CRUISE CONTROL

The right-hand steering column switch C891 is a multi-function switch for windshield wiper/washer functions and cruise control/engine speed control. The VIC sends the desired commands in respect of vehicle/engine speed to the ECS-DC3 electronic unit via the CAN network (see system manual). When the innermost ring of switch C891 is rotated (B5 with B6), power is supplied to pin 17/745. The "ON" function is now activated. When the outermost ring of switch C891 is rotated downwards (B2 with B1), power is supplied to pin C18/745. This activates the "SET+" function. When the outermost ring of switch C891 is rotated upwards (B2 with B7), power is supplied to pin C19/745. This activates the "RES -" function. Operating the RES button at the end of the switch has the same effect as turning the "RES -" rotary switch.



23

1427090/03

EL001588

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53

10

**24. AGC AUTOMATIC GEARBOX (AT1000/2000)****VARIANTS****Location**

122 Application connector (A096)

Power supply before contact is obtained directly from the batteries (A500) via a 10 A fuse (E144) and wire 1302.

The voltage before contact can also be found in the diagnostic socket for the automatic gearbox (A032).

Voltage after contact is obtained via fuse E279 and wire 1211.

The AT 1000/2000 automatic gearbox selector switch (E585) receives power after contact through fuse E016 and wire 1217. The reversing lights are activated from the same switch via wire 4591.


The earth connections are connected directly to the earth side of the batteries (A500).

The electrical system of the automatic gearbox is almost completely located on the chassis.

Connections leading into the cab are provided for a number of VIC functions:

- fault messages from the automatic gearbox (B25/853) to the VIC unit (D900)
- "Range inhibit" (B23/853) to the VIC unit (D900)
- CAN connections (B29/853 and B32/853) to the VIC unit (D900)
- Neutral position protection (G/900) to the VIC unit (D900)


Diagnosis of the automatic gearbox takes place via the CAN network, which is connected to the diagnostic socket (A032) and the VIC unit (D900).



24

1427090/03

EL001589





10

24

1427090/03

54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100 101 102 103 104 105 106

EL001590



24

1427090/03

107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159

10

EL001591

## 25. AGC AUTOMATIC GEARBOX (MD3060)

Power supply before contact is obtained directly from the batteries (A500) via wire 336 and a 10 A fuse (MAIN) in the VIM (D822, pins J1 and J2). The electronic unit (D866) receives voltage before contact at pin V1/907 and V16/907 from the VIM (D822, pins R1 and R2) via wires 1164.

Voltage after contact is obtained via fuse E279 and wire 1211. Wire 1211 is connected directly to electronic unit D866 (pin S4/905). The wire also runs to the VIM (pin C1) and various relays in de VIM are supplied with voltage after contact via a 10 A fuse (IGN). The voltage after contact can also be found in the diagnostic socket for the automatic gearbox (A032).

The earth connections are connected directly to the earth side of the batteries (A500) and also run to the electronic unit (D866) via the VIM (pins K1 and K2).

The electrical system of the automatic gearbox is almost completely located on the chassis.

Connections leading into the cab are provided for a number of VIC functions:

- fault messages from the automatic gearbox (S31/905) to the VIC unit (D900)
- CAN connections (S13/905 and S29/905) to the VIC unit (D900)
- Vehicle interface module (D822, pin F1) to the VIC unit (D900)


Diagnosis of the automatic gearbox takes place via the CAN network, which is connected to the diagnostic socket (A032) and the VIC unit (D900).

### Note:

Where an automatic gearbox is fitted, there are two dashboard lead-through connectors, 716. One connector is occupied by spare wiring (see application connectors) and the other has 3 occupied positions (A1, wire 3458; A3, wire 123; and A4, wire 4614), only one of which is connected.

The 716 with the spare wiring is not then connected and hangs loose near the dashboard lead-through.






25

1427090/03

EL001592





10

25

1427090/03

EL001593




25

1427090/03

107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159

**26. PTO**

When the PTO operating switch (C750) is operated, pin B15/744 of the VIC is connected to earth. Depending on the conditions programmed in the VIC (for example parking brake activated or vehicle speed below a certain value), the PTO operating valve (B245) is supplied with power via pin B23/744 of the VIC. If the PTO is in fact switched on, the gearbox-PTO control switch F087 is operated to provide feedback to connection point B14/744 of the VIC. This will activate the indicator on the DIP.



26

1427090/03


EL001595

10

**27A. ECAS-3 4x2 LF45**  
**FOR MORE INFORMATION SEE SYSTEM**  
**MANUAL**

**VARIANTS**

**Location**  
16 Fuse E051 may also be fitted  
instead of fuse E062.



27A

1427090/03


EL001596

**27B. ECAS-3 4x2 LF55**  
**FOR MORE INFORMATION SEE SYSTEM**  
**MANUAL**

**VARIANTS**

**Location** 16 Fuse E051 may also be fitted  
instead of fuse E062.





27B


1427090/03

EL001597

10

**10**

**27C. ECAS-2 (6x2) LF55  
FOR MORE INFORMATION SEE SYSTEM  
MANUAL**




27C

1427090/03

EL001598



D942



27C

1427090/03

EL001599

54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100 101 102 103 104 105 106

## 29. HEADLAMP HEIGHT ADJUSTMENT / ROTATING BEAMS


### HEADLAMP HEIGHT ADJUSTMENT

Power before contact is supplied at pin 2 of the lighting switch (C622). If a connection is made to switch C622 (contacts 2 and 1), a voltage is applied to contact 1 of relay G000 (tail light/width marker light relay) via wire 2100. Once the relay is energised, a connection is made between points 3 and 5. As a result, a voltage is applied through relay G000 (contacts 3 - 5), wire 2101, fuse E283 and wire 2169 to pin 2 of switch C871 (potentiometer for headlamp height adjustment). Via the same wire, power is also supplied to pin 1 of the headlamp height-adjustment motor on the left (B129) and right (B130).

When the headlamp height switch is operated, the voltage at pin 1 of the switch will change, so that the headlamp height adjustment motors on the left (B129) and right (B130) will be activated via wire 4953 at pin 3. Depending upon the position of C871 (headlamp height adjustment potentiometer), the motor in the headlamp will be activated. This will continue until electrical equilibrium is achieved. This equilibrium refers to the voltage difference that exists between wires 2169 and 4953 of C871, B129 and B130. The voltage difference should be the same for all three components.

### ROTATING BEAMS

The rotating beam switch (C715) is supplied with power before contact via fuse E163 and wire 1104. When the switch is operated, rotating beam left (C144) and rotating beam right (C145) will be supplied with power via wire 2018.



29

1427090/03

EL001600

10

**30. 24 V/12 V CONVERTER FOR RADIO****Note:**

The following description of the operation and connection is intended as a general guideline only.

Also refer to the manufacturer's installation instructions supplied with the radio.

The converter has three 12 V outputs.

- Pin 4: 12 V output before contact
- Pin 6: 12 V output before contact
- Pin 9: 12 V output switched via accessories/ignition switch (C841)

If the contact switch (C841) is in the "accessories" position (connection between contacts 1 and 6), the converter (D958) is supplied with power through wire 1130 and fuse E026. The converter receives power before contact at pin 2 via fuse E027. The converter has an internal fuse to protect the 12 V outputs.


The radio has an aerial connection and 2 loudspeaker outputs which can be used to connect loudspeakers B024 and B025. For more information, see "Connection of accessories".

**VARIANTS****Location**

19

Connector 790: Optional connector for, say, the CB or CD player.





30

1427090/03

EL001601


1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53

### 31. CDS-3/DROP GLASS OPERATION/ROOF HATCH

#### DROP GLASS OPERATION

When the vehicle ignition is switched on (connection between pins 1 and 4, C841), relay G353 is energised. Via fuse E044 and wire 1208, relay G353 supplies power to the electric drop glass door switches (C864 in the co-driver's door, C865 in the driver's door for the co-driver's door, and C866 in the driver's door).

There are two independent drop glass switches. In the rest position, pins 7 and 4 of the switch are connected to power supply via wire 1208. Depending on the side on which the switch is operated, pin 7 or 4 will be connected to earth and the drop glass motor (B003 - driver's side, B004 - co-driver's side) will be activated.



31

1427090/03

EL001602

**CENTRAL DOOR LOCKING**

**Purpose:**

- Automatic locking of both doors when one of the doors is locked with the key/button.
- Automatic locking of both doors using remote control.
- If one of the two doors is unlocked using the key/button, only this door will be unlocked; the other door will remain locked.
- Automatic unlocking of the driver's side door using remote control.


**Conditions: both doors locked.**

- **Unlocking co-driver's side door using key.**

This is equivalent to opening a door without central locking. The other door remains locked.

- **Unlocking the co-driver's side door using switch C774.**

When switch C774 is operated (pin 3 connected to pin 1), connection DO of component B200 is connected to earth. The co-driver's door will unlock.




E501717

- **Unlocking using remote control.**

If the door unlocking button on the remote control unit is pressed, the remote control unit will send a fixed-code signal to the CDS electronic unit (D905). When the CDS electronic unit (D905) recognises the remote control unit on the basis of the fixed code, the remote control unit will send coded messages to the unit (D905). These messages are coded with a rolling code. This rolling code will change every time the remote control is operated. After the CDS electronic unit (D905) has accepted the messages, it will send a signal to the VIC (D900). As a result, the VIC will switch on the interior lighting for a specific period of time.

The CDS unit (D905) now switches pin 13 to earth. This will only activate the motor (B199). The CDS unit (D905) checks the status of the output to the motor (B199). This is done to ensure that the DL connection is not connected to earth when the motor is in the "open" position. The CDS unit can deduce from this whether the driver's side door has been successfully unlocked. The CDS unit (D905) will then send a message to the VIC (D900) via pin 2 stating that the driver's side door has been successfully unlocked. If the driver's side door is not unlocked properly after three attempts, a message will be sent to the VIC (D900) to inform it that the door has not unlocked successfully.



10

Conditions: both doors unlocked.

- Locking driver's side door with key/button.

The D905 unit will measure an earth signal at pin 15 through connection DL. D905 will now connect pin 12 to earth, which will also activate B200. The co-driver's side door will now lock as well.

- Locking the driver's side door with key/button.

The operation is as described above, except that unit D905 will now measure an earth signal at pin 12 and it will connect pin 15 of component B199 to earth. The door on the driver's side will now also be locked.

- Locking co-driver's side door using switch C774.

When switch C774 is operated (pin 3 connected to pin 7), an earth signal is created at pin 3 of unit D905. D905 will now connect pin 12 to earth, which will activate B200. This will lock the door on the co-driver's side.

- The doors on the driver's and co-driver's sides are locked using the remote control unit.

When the lock doors button on the remote control unit is pressed, a procedure starts that is comparable to the procedure for opening the doors.

## ROOF HATCH

### Opening roof hatch

When the roof hatch switch (C736) is operated and a connection is made between contacts 2 and 6 and therefore between contacts 1 and 3, a voltage is applied to pin 1 of the roof hatch motor (B009) through fuse E163, switch C736 and wire 4761. The roof hatch will open.

### Closing roof hatch

When the roof hatch switch (C736) is operated and a connection is made between contacts 8 and 6 and therefore between contacts 7 and 3, a voltage is applied to pin 2 of the roof hatch motor (B009) through fuse E163, switch C736 and wire 4760. The roof hatch will now close.


However, during the locking operation the CDS unit (D905) will connect pins 12 and 15 to earth. This will activate the motors (B199 and B200). The CDS unit (D905) then checks the status of the outputs to the motors (B199 and B200). It uses this information to determine whether the doors have been successfully locked. The CDS unit (D905) will then send a message to the VIC (D900) via pin 2 stating that the doors have been successfully locked. As a result, the VIC (D900) will switch off the interior lighting. If the doors are not locked properly after three attempts, a message will be sent to the VIC (D900), stating that the locking operation was not successful.

### Initialisation

When the CDS unit is supplied with power for the first time (on installing or replacing the electronic unit) or when new hand-held transmitters are used (up to 8), the unit must recognise these hand-held transmitters. To enable the hand-held transmitters to communicate with the CDS unit, the unit and the hand-held transmitters must be taught using DAVIE.







31

1427090/03

EL001603

10


**33. WINDSCREEN WIPE/WASH SYSTEM**

**FOR MORE INFORMATION SEE SYSTEM MANUAL**

**VARIANTS****Location**

25

Steering column switch (C842):  
If the vehicle is fitted with  
cruise control/engine  
speed control, the Basic Code  
Number of the stalk switch is  
C891.



33


1427090/03

EL001604

10

**10**

**34. ACH-W WITH TIMER  
FOR MORE INFORMATION SEE SYSTEM  
MANUAL**



1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53

34

1427090/03


EL001605

35. APPLICATION CONNECTOR, ENGINE SPEED CONTROL, SUPERSTRUCTURE FUNCTIONS AND SPARE WIRING

FOR MORE INFORMATION SEE "CONNECTION OF ACCESSORIES"

VARIANTS

|                         |   |
|-------------------------|---|
| <b>Location</b>         |   |
| 28,30,32,34             | The spare wires are bundled together behind the dashboard central panel   |
| 36,38,40,42,44,46,48,50 | The spare wires are bundled together in the co-driver's side roof console |
| 44,46,48,50             | The spare wires are bundled together behind the fuse box.                 |




35

1427090/03


EL001606







D942



54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100 101 102 103 104 105 106

35

1427090/03

GS20

EL001607



10

**36. BREAK LINING WEAR**

If one of the brake linings is too thin, pin 17, connector 744 of the VIC will, via wire 3406, be interrupted by the appropriate brake lining wear control switch (F107, F108, F111, F112, F113 or F114). The VIC will send a message to the instrument panel, which will then activate the "brake lining wear" indicator.

**VARIANTS****Location**

- |       |  |
|-------|--|
| 11,30 | Connector 762:   |
| 22,26 | Not fitted on vehicle type FT<br>Brake lining wear switches F113<br>and F114:<br>Only applicable to 6x2 vehicles |



1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53

36


1427090/03

EL001608

10

**37. ALS-S/BATTERY CHARGER FOR ALARM BV2/BV3  
FOR MORE INFORMATION SEE SYSTEM  
MANUAL****VARIANTS****Location**

- 1 If trailer protection fitted.  
93 Where an immobiliser system is fitted, the optional LED alarm system (D715) can be made to flash by the LED unit D931 when the ignition is turned off.




37

1427090/03

EL001609





37

1427090/03

EL001610

10

**38. SOCKETS, FA/FT****12 V PLUG (A011)**

Pin 1 is connected to the 24/12 V converter (12 V before contact) through wire 1153.

Pin 2 is connected to the earth connection of the converter.

**DIAGNOSTIC SOCKET (A021)**


The diagnostic socket is located to the left of the driver's seat on the floor plate. This is the socket for the DAVIE connection.

Power before contact is supplied to pin 1 through fuse E053. Pin 2 is connected to earth. The remaining pins are for communication with the various systems and are connected to those systems.

| Pin no. | Wire no. | Colour | Description                                    |
|---------|----------|--------|--|
| 1       | 1229     | red    | Power supply before contact                    |
| 2       | 9107     | white  | Earth  |
| 3       | 3425     | blue   | ABS-D/ABS/ASR-E                                |
| 4       | -        |        |  |
| 5       | -        |        |  |
| 6       | -        |        |  |
| 7       | 4732     | black  | ECAS-3/ECAS-2                                  |
| 8       | 3646     | blue   | CDS, ALS-S, airbag/seat belt tensioner, RAS-EC |
| 9       | 4047     | black  | VIC  |
| 10      | -        |        |  |
| 11      | -        |        |  |
| 12      | 4733     | black  | DIP-4  |
| 13      | -        |        |  |
| 14      | 3037     | blue   | Cab heater                                     |
| 15      | 3700     | yellow | CAN-network (ECS-DC3, MTCO)                    |
| 16      | 3701     | blue   | CAN-network (ECS-DC3, MTCO)                    |



|   |   |  |   |
|---|---|--|---|
| <b>DRAWN VEHICLE SOCKET (A000) (7-pin)</b>  |   | <b>DRAWN VEHICLE ABS/EBS SOCKET (A004)</b> |   |
| Pin 1   | connected to earth.   | Pin 1                                      | of the drawn vehicle ABS/EBS socket (A004) is connected directly to power before contact via fuse E043 and wire 1119. |
| When a connection is made between contacts 2 and 1 (marker light/parking light position) by switching on the lighting switch (C622), relay G000 is energised. Relay G000 supplies power to wire 2101 via wire 1000. Via fuses E284 and E283, power is supplied to connector A000 at pin 2 (via wire 2170) and pin 6 (via wire 2169) respectively. |   | Pin 2                                      | connected directly to power after contact via fuse E282 and wire 1356.  |
| Pin 2   | switches the left-hand rear light.  | Pin 3                                      | connected to earth.   |
| Pin 3   | is connected via wire 2008 to connection point E7/747 of the VIC (D900) (direction, left).  | Pin 4                                      | connected to earth.   |
| Pin 4   | is connected via wire 4601 and fuse E013 to relay G036 (brake light relay).   | Pin 5                                      | connected to pin C32/745 of the VIC (D900) via wire 3428.   |
| Pin 5   | is connected via wire 2008 to pin E4/747 of the VIC (D900) (direction, right).  | Pin 6                                      | -   |
| Pin 6   | switches the right-hand rear light.   | Pin 7                                      | -   |
| Pin 7   | -   | <b>VARIANTS</b>                            |   |
| <b>SUPERSTRUCTURE APPLICATION CONNECTOR (A070)</b>  |   | <b>Location</b>                            |   |
| Pin 1   | connected to power before contact via wire 1110 and fuse E052.  | 26   | Electronic unit, ABS/ASR, E version (D961):<br>Or electronic unit for ABS/ASR, D version (D941)                       |
| Pin 2   | on vehicle type FA, connected to the VIC and the work lamp switch (C725) through wire 2155, fuse E283 and wire 2101. On vehicle type FT, pin 2 is connected to the right-hand rear light through wire 2169. | 49   | Electronic unit, ECAS-3 (D851):<br>Or electronic unit ECAS-2 (D802)   |
| Pin 3   | connected to connection point 5 of G036 (stop light relay) via wire 4601 and fuse E013.   | 79,81,91,<br>117,126,135                   | Connector 762:<br>Not fitted on vehicle type FT   |
| <b>REAR FOG LAMP/REVERSING LIGHT SOCKET (A001)</b>  |   | 86,88,122,<br>129,144,<br>148,150          | Connector 763:<br>Not fitted on vehicle type FT   |
| Pin 1   | connected to earth.   |  |   |
| Pin 2   | -   |  |   |
| Pin 3   | connected via wire 4591 to pin 2 of E501 (reversing lamp switch).   |  |   |
| Pin 4   | connected via wire 1110 to power before contact (1000) via fuse E052.   |  |   |
| Pin 5   | -   |  |   |
| Pin 6   | connected via wire 1356 to power after contact (1010) via fuse E282.  |  |   |
| Pin 7   | connected via wire 2152 to relay G005 (rear fog lamp relay).  |  |   |




**10**

**38**

1427090/03

EL001611




54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100 101 102 103 104 105 106

38

1427090/03

EL001612

10



10

38

1427090/03

EL001613



**39. WATER SEPARATOR/FUEL PRE-HEATING****WATER SEPARATOR**

The water separator sensor (F692) is supplied with power via relay G353 and fuse E091. If the water level in the fuel filter becomes too high, the VIC receives a signal at pin D8/746. A warning is then indicated on the DIP through the VIC.

**FUEL PRE-HEATING**


Depending on the temperature, the ECS-DC3 electronic unit (D903) activates the fuel heater relay (G201).

The relay supplies power to the water separator fuel heating element (B182) through fuse E165.

**VARIANTS****Location**

34

Fuel heating relay G201:  
May be placed behind the central box.



39

1427090/03

EL001614


10

#### 40. AIRBAG/SEAT BELT TENSIONER FOR MORE INFORMATION SEE SYSTEM MANUAL

##### SAFETY INSTRUCTIONS

- Never disconnect an electrical connection in the airbag or seat belt tensioner circuits with the ignition switched on.
- Repairing or modifying the wiring of pyrotechnic systems (systems with airbag(s) and/or seat belt tensioner(s)) is not permitted. The wiring must be replaced if damaged.
- The pyrotechnic units (airbags and/or seat belt tensioners) must be checked using the DAVIE-XD Direct Test. Test lamps, multimeters and oscilloscopes (including those that are part of DAVIE-XD) present a danger and are therefore not permitted.
- Only the wiring harnesses may be checked using test lamps, multimeters or oscilloscopes. Ensure beforehand that no pyrotechnic or electronic units whatsoever are still connected to the wiring harness to be tested.
- Before any work is carried out on a pyrotechnic part (airbag and/or seat belt tensioner):
  - a. switch off the ignition.
  - b. the battery terminal clamp must be carefully separated from the negative terminal.
  - c. wait at least 5 minutes.





1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53

40


1427090/03

EL001615

10

**10**

**41. RAS-EC  
FOR MORE INFORMATION SEE SYSTEM  
MANUAL**





41

1427090/03

EL001916

10



41

1427090/03

54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100 101 102 103 104 105 106

EL001617



## CONTENTS

|   | Page | Date   |
|---|------|--------|
| 1. INTRODUCTION .....   | 1-1  | 200440 |
| 2. CHANGES IN THE ELECTRICAL SYSTEM<br>FROM CHASSIS NUMBER 0L247507 ..... | 2-1  | 200440 |
| 2.1 Overview of the changes in the electrical system .....                | 2-1  | 200440 |
| 2.2 Circuit diagram 1427090/04 .....                                      | 2-2  | 200440 |
| 2.3 Overview of basic codes for circuit diagram 1427090/04 .....          | 2-3  | 200440 |
| 2.4 Section diagrams from circuit diagram 1427090/04 .....                | 2-13 | 200440 |



## 1. INTRODUCTION

This main group includes the entire electrical system shown in the form of **circuit diagrams** and an **overview of connectors/pin allocations**.

### **Circuit diagrams**

All information that relates to the complete electrical system of the vehicle is found in the circuit diagrams with the exception of the connectors.

### **Note:**

For the location of the connectors in the vehicle, see "Location of connectors".





## 2. CHANGES IN THE ELECTRICAL SYSTEM FROM CHASSIS NUMBER 0L247507

### 2.1 OVERVIEW OF THE CHANGES IN THE ELECTRICAL SYSTEM

| Section diagram | Electrical system                                   | Changes   | From chassis number |
|-----------------|---|---|---------------------|
| A               | Voltage before and after contact                    | Battery earth and starter motor modified for LF55   | 0L247507            |
| C               | CAN overview  | CDM-unit (D969) added   | 0L252611            |
| 1               | Main switch   | Battery earth and starter motor modified for LF55   | 0L247507            |
| 2               | Ignition/starter switch/charging circuit            | Battery earth and starter motor modified for LF55   | 0L247507            |
| 5               | Pre-glowing   | Battery earth and starter motor modified for LF55   | 0L247507            |
| 8               | VIC   | Connector 858 changed to 952 for LF45   | 0L248731            |
| 10              | Reversing lights/buzzer                             | LF45 wiring harness modified  | 0L248731            |
| 12              | Stop lights/cab tilting gear                        | CDM variant added   | 0L252611            |
| 13              | Differential lock                                   | LF45 wiring harness modified  | 0L248731            |
| 15              | Mirror heating/windscreen heating/mirror adjustment | Battery earth and starter motor modified for LF55   | 0L247507            |
| 19              | Horn/cigar lighter/work lamp/air dryer              | CDM variant added   | 0L252611            |
| 22              | ECS-DC3/exhaust brake                               | <ul style="list-style-type: none"> <li>- Oil pressure sensor (F647) replaced by engine oil pressure control switch (F011)</li> <li>- Fuel temperature sensor (F566) no longer fitted</li> </ul> | 0L253643            |
| 24              | AGC automatic gearbox (AT1000/2000)                 | Battery earth and starter motor modified for LF55   | 0L247507            |
| 25              | AGC automatic gearbox (MD3060)                      | Battery earth and starter motor modified for LF55   | 0L247507            |
| 31              | CDS-3/drop glass operation/roof hatch               | CDM variant added   | 0L252611            |
| 32              | CDM   | New   | 0L252611            |
| 39              | Water separator/fuel pre-heating                    | CDM variant added   | 0L252611            |

The other section diagrams from circuit diagram 1427090/04 contain no functional changes compared with circuit diagram 1427090/03.

**2.2 CIRCUIT DIAGRAM 1427090/04**

This page can be used to make your own notes on the circuit diagram.

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---





---

---


---

---

---



OPERAIE DINGNOTE  
G-25, A11 FFU, P.11, THOPASSING  
HOOFDSCHEI ELAAT



# 5

## CHANGES IN THE ELECTRICAL SYSTEM

LF45/55 series

Changes in the electrical system from chassis number 0L247507

### 2.3 OVERVIEW OF BASIC CODES FOR CIRCUIT DIAGRAM 1427090/04

- 1 Basic code number
- 2 Description
- 3 Number on search bar

| 1    | 2   | 3  |
|------|---|--|
| A000 | Drawn vehicle socket (7-pin)                          | 0095 0096 0224 0231<br>0262 0681           |
| A001 | Rear fog light/reversing light socket (7-pin)         | 0251 0256 0270 0286<br>0682                |
| A004 | Socket, ABS/EBS, drawn vehicle (7-pin)                | 0403                                       |
| A011 | Socket, 12 V accessories (2-pin)                      | 0361                                       |
| A021 | Diagnostic socket (16-pin)                            | 0592                                       |
| A032 | AGC diagnostic socket                                 | 0528 0574                                  |
| A068 | Application connector, engine speed control           | 581  |
| A070 | Application connector, superstructure (8-pin)         | 0177 0186 0188 0263<br>0271 0287 0288 0682 |
| A074 | Automatic gearbox socket, superstructure              | 0568                                       |
| A087 | CCU/CDM socket (2-pin)                                | 0599                                       |
| A096 | Automatic gearbox socket, superstructure (AT2000)     | 0522                                       |
| A500 | Batteries (2x)  | 0002 0015                                  |
| A510 | Alarm system battery                                  | 0174                                       |
| A513 | Alternator  | 0019                                       |
| B000 | Windscreen wiper motor                                | 0165                                       |
| B001 | Windscreen wiper pump                                 | 0169                                       |
| B003 | Electric drop glass operation motor, driver's side    | 0328                                       |
| B004 | Electric drop glass operation motor, co-driver's side | 0323                                       |
| B005 | Mirror adjustment motor, left                         | 0335 0339                                  |
| B006 | Mirror adjustment motor, right                        | 0332 0342                                  |
| B009 | Roof hatch motor                                      | 0297                                       |
| B010 | Starter motor   | 0035 0041                                  |
| B017 | Mirror heating, driver's side                         | 0344                                       |
| B018 | Mirror heating, co-driver's side                      | 0345                                       |
| B023 | Radio   | 0366 0371                                  |
| B024 | Loudspeaker, left                                     | 0365 0372                                  |

## CHANGES IN THE ELECTRICAL SYSTEM

5

Changes in the electrical system from chassis number 0L247507

LF45/55 series

| 1    | 2   | 3         |
|------|---|-----------|
| B025 | Loudspeaker, right  | 0367 0371 |
| B030 | Cigar lighter, driver's side                                    | 0357      |
| B032 | Seat heating, driver's side                                     | 0353      |
| B042 | Air dryer heating element                                       | 0319      |
| B043 | Air conditioning compressor                                     | 0382      |
| B068 | Fuel metering pump, cab heater                                  | 0386      |
| B079 | Low-range downshift protection valve                            | 0119      |
| B129 | Left-hand headlamp height adjuster motor                        | 0234      |
| B130 | Right-hand headlamp height adjuster motor                       | 0236      |
| B131 | Solenoid valve, pump unit/injector, cylinder 1                  | 0613 0651 |
| B132 | Solenoid valve, pump unit/injector, cylinder 2                  | 0615 0659 |
| B133 | Solenoid valve, pump unit/injector, cylinder 3                  | 0616 0658 |
| B134 | Solenoid valve, pump unit/injector, cylinder 4                  | 0618 0654 |
| B135 | Solenoid valve, pump unit/injector, cylinder 5                  | 0619      |
| B136 | Solenoid valve, pump unit/injector, cylinder 6                  | 0621      |
| B176 | Reversing buzzer  | 0266      |
| B182 | Water separator fuel heating element                            | 0313      |
| B192 | Exhaust brake valve   | 0633 0671 |
| B199 | Central door locking motor, driver's side                       | 0311      |
| B200 | Central door locking motor, co-driver's side                    | 0304      |
| B201 | Internal electrical components for automatic gearbox            | 0510 0561 |
| B237 | ABS/ASR-D differential lock valve, rear axle                    | 0443      |
| B238 | ECAS valve, driven axle, air supply                             | 725       |
| B243 | Cross-axle differential lock control valve                      | 0394      |
| B245 | PTO 1 control valve   | 0080      |
| B250 | ECAS valve, driven axle, air supply                             | 0709      |
| B253 | ECAS valve, driven axle, air supply                             | 0749      |
| B254 | ECAS valve, steered leading axle/trailing axle, lifting bellows | 0753      |
| B256 | ABS valve, front axle, left                                     | 0413 0436 |
| B257 | ABS valve, front axle, right                                    | 0414 0438 |
| B258 | ABS valve, driven axle, left                                    | 0416 0439 |
| B259 | ABS valve, driven axle, right                                   | 0441      |

11

**5****CHANGES IN THE ELECTRICAL SYSTEM****LF45/55 series**

Changes in the electrical system from chassis number 0L247507

| <b>1</b> | <b>2</b>                              | <b>3</b>  |
|----------|---------------------------------------|-----------|
| B334     | Fuel pump control solenoid valve      | 0612 0650 |
| B338     | Alarm system horn                     | 0176      |
| B341     | Glow element                          | 0047      |
| B360     | Seat belt tensioner, driver's side    | 0474      |
| B361     | Airbag module                         | 0476      |
| B371     | Windscreen heating                    | 0349      |
| B377     | Heater motor                          | 0375      |
| B381     | RAS-EC valve block                    | 0454      |
| B399     | Cooling fan 1, AGC automatic gearbox  | 0501 0535 |
| B400     | Cooling fan 2, AGC automatic gearbox  | 0537      |
| B401     | Horn                                  | 0085      |
| B402     | ABS resistor                          | 0428      |
| B525     | Modular tachograph (MTCO)             | 0052      |
| C000     | Dipped beam, left                     | 0239      |
| C001     | Dipped beam, right                    | 0241      |
| C002     | Main beam, left                       | 0242      |
| C003     | Main beam, right                      | 0244      |
| C006     | Left spotlight                        | 0245      |
| C007     | Right spotlight                       | 0246      |
| C008     | Fog lamp, front left                  | 0253      |
| C009     | Fog lamp, front right                 | 0255      |
| C014     | Direction indicator lamp, front left  | 0088      |
| C015     | Direction indicator lamp, front right | 0092      |
| C016     | Direction indicator lamp, side left   | 0089      |
| C017     | Direction indicator lamp, side right  | 0093      |
| C018     | Direction indicator lamp, rear left   | 0090      |
| C019     | Direction indicator lamp, rear right  | 0094      |
| C020     | Stop light, left                      | 0259      |
| C021     | Stop light, right                     | 0261      |
| C022     | Rear light, left                      | 0222      |
| C023     | Rear light, right                     | 0229      |
| C024     | Fog lamp, rear left                   | 0249      |

## CHANGES IN THE ELECTRICAL SYSTEM

5

Changes in the electrical system from chassis number 0L247507

LF45/55 series

| 1    | 2   | 3              |
|------|---|----------------|
| C025 | Fog lamp, rear right  | 0251           |
| C026 | Reversing light, left   | 0268           |
| C027 | Reversing light, right  | 0270           |
| C062 | Stepwell lighting, left   | 0278           |
| C063 | Stepwell lighting, right  | 0280           |
| C071 | Work lamp   | 0289           |
| C110 | Bunk light, bottom  | 0282           |
| C111 | Bunk light, top   | 0283           |
| C119 | Interior lighting with switch, driver's side                                | 0276           |
| C144 | Rotating beam, left   | 0292           |
| C145 | Rotating beam, right  | 0293           |
| C156 | Marker light, left, 1 <sup>st</sup>   | 0226           |
| C157 | Marker light, right, 1 <sup>st</sup>  | 0228           |
| C158 | Marker light, left, 2 <sup>nd</sup>   | 0219           |
| C159 | Marker light, right, 2 <sup>nd</sup>  | 0221           |
| C553 | Mechanical main switch  | 0002           |
| C622 | Lighting switch   | 0201           |
| C715 | Rotating beam switch  | 0293           |
| C725 | Work lamp switch  | 0289           |
| C727 | Fog lamp switch, front/rear   | 0212           |
| C736 | Roof hatch switch   | 0297           |
| C742 | Traction assistance switch  | 0739           |
| C748 | Cross-axle differential lock switch   | 0394           |
| C750 | PTO 1 switch  | 0082           |
| D758 | Diode to prevent feedback to the VIC  | 120            |
| C763 | Instrument lighting dimming potentiometer                                   | 0110           |
| C765 | Switch for warning lamps  | 0098           |
| C773 | Fog lamp switch, rear   | 0215           |
| C774 | Central door locking switch   | 0306           |
| C775 | Steering column switch, direction indicators/horn/dipped beam/<br>main beam | 0085 0088 0208 |
| C804 | Switch, adjustable speed limiter  | 0113           |
| C835 | Switch to turn off interior detection                                       | 0194           |

11



# 5

## CHANGES IN THE ELECTRICAL SYSTEM

LF45/55 series

Changes in the electrical system from chassis number 0L247507

| 1    | 2   | 3                   |
|------|---|---------------------|
| C836 | Switch to turn off superstructure/drawn vehicle loadspace detection                   | 0197                |
| C841 | Accessories / ignition / starter switch   | 0023                |
| C842 | Windscreen wipers/washer steering column switch                                       | 0163 0165 0167 0168 |
| C853 | Cab main switch   | 0006                |
| C854 | Chassis main switch   | 0006                |
| C864 | Drop glass operation switch, co-driver's side (driver's side door)                    | 0323                |
| C865 | Drop glass operation switch, co-driver's side (co-driver's side door)                 | 0322                |
| C866 | Drop glass operation switch, driver's side (driver's side door)                       | 0327                |
| C867 | Mirror heating switch   | 0345                |
| C868 | Mirror adjustment switch  | 0333 0339           |
| C871 | Potentiometer, headlamp height adjustment   | 0233                |
| C880 | Reversing buzzer switch   | 0266                |
| C891 | Steering column switch, windscreen wiper/washer, cruise control, engine speed control | 0483                |
| C892 | Heater fan switch   | 0376                |
| C893 | Air conditioning switch   | 0379                |
| D521 | Electronic unit, cab heater   | 0387                |
| D529 | Remote control system, ECAS   | 0702 0718 0735      |
| D609 | Light switch diode  | 0202                |
| D610 | Diode, main beam/dipped beam  | 0208                |
| D715 | Alarm system LED  | 0177                |
| D784 | Diode, Swedish lighting   | 0204                |
| D785 | Diode, Swedish lighting   | 0204                |
| D787 | Diode, air conditioning compressor link   | 0381                |
| D802 | Electronic unit, ECAS-2 (6x2)   | 0748                |
| D822 | AGC vehicle interface module  | 0541                |
| D826 | Electronic unit for VLG current limiter   | 0012                |
| D851 | Electronic unit, ECAS-3 (4x2)   | 0710 0726           |
| D866 | Electronic unit, AGC-A4 automatic gearbox control                                     | 0552                |
| D867 | Automatic gearbox selector  | 0553                |
| D899 | DIP-4 instrument panel  | 0070                |

## CHANGES IN THE ELECTRICAL SYSTEM

5

Changes in the electrical system from chassis number 0L247507

LF45/55 series

| 1    | 2   | 3              |
|------|---|----------------|
| D900 | Electronic unit, VIC  | 0080 0091 0132 |
| D903 | Electronic unit, ECS-DC3  | 0620 0659      |
| D904 | Menu Control Switch, MCS  | 0124           |
| D905 | Electronic unit, CDS  | 0308           |
| D909 | Electronic unit, alarm system, ultrasonic   | 0181           |
| D910 | Electronic unit, battery charger  | 0174           |
| D911 | Electronic unit, ALS-S alarm system   | 0186           |
| D912 | Electronic unit, immobiliser  | 0060           |
| D924 | Electronic unit for main switch   | 0010           |
| D926 | Electronic unit, airbag/seat belt tensioner   | 0476           |
| D931 | LED unit, immobiliser   | 0063           |
| D936 | Electronic unit for automatic gearbox (AGC-T1000/2000)  | 0514           |
| D940 | Electronic unit, RAS-EC   | 0461           |
| D941 | Electronic unit, ABS/ASR, D version   | 0417           |
| D942 | Fuse box  | -              |
| D958 | Electronic unit, converter with power supply for radio memory   | 0360           |
| D960 | Airbag contact unit   | 0475           |
| D961 | Electronic unit, ABS/ASR, E version   | 0440           |
| D969 | Electronic unit, CDM  | 0761           |
| E004 | Fuse, dipped beam, driver's side  | 0239           |
| E005 | Fuse, dipped beam, co-driver's side   | 0240           |
| E006 | Fuse, main beam, driver's side  | 0242           |
| E009 | Fuse, front fog lamps   | 0249           |
| E013 | Fuse, stop lights   | 0259           |
| E018 | Fuse, windscreen wiper motor  | 0029           |
| E019 | Fuse, horn  | 0085           |
| E023 | Fuse, switch, tachograph timer  | 0049           |
| E025 | Fuse, windscreen wiper motor/windscreen washer motor  | 0163           |
| E026 | Fuse, cigar lighter/door switches/electronic unit, 24/12 V converter with power supply for radio memory | 0357           |
| E027 | Fuse, electronic unit, 24/12 V converter, with power supply for radio memory                            | 0359           |
| E028 | Fuse, interior lighting/bunk lights/central door lock   | 0273           |

11

# 5

## CHANGES IN THE ELECTRICAL SYSTEM

LF45/55 series

Changes in the electrical system from chassis number 0L247507

| 1    | 2   | 3         |
|------|---|-----------|
| E031 | Fuse, heater fan  | 0373      |
| E035 | Fuse, instruments and warning lamps/parking brake switch/power supply after contact                     | 0021      |
| E039 | Fuse, seat heating  | 0353      |
| E043 | Fuse, ABS, drawn vehicle  | 0401      |
| E044 | Fuse, mirror heating/electric mirror adjustment/electric drop glass operation                           | 0321      |
| E048 | Fuse, drawn vehicle power supply  | 0033      |
| E051 | Fuse, ECAS  | 0734      |
| E052 | Fuse, work lamp   | 0286      |
| E053 | Fuse, diagnostic connector/LED unit/alarm system  | 0587      |
| E058 | Fuse, cab heater  | 0385      |
| E062 | Fuse, ECAS  | 0703 0719 |
| E091 | Fuse, air dryer heating element/water separator/RAS-EC/engine speed control application connector       | 0319      |
| E108 | Fuse, VIC   | 0103      |
| E114 | Fuse, cab heater/warning lamps  | 0390      |
| E143 | Fuse, tachograph/alarm system/immobiliser/ABS-D/ABS/ASR-E   | 0057      |
| E144 | Fuse, AGC-A4 automatic gearbox  | 0504      |
| E153 | Fuse, power supply for main switch  | 0008      |
| E156 | Fuse, accessories lighting  | 0034      |
| E158 | Fuse, DIP-4 instrument panel  | 0067      |
| E160 | Fuse, ECS-DC3   | 0601 0640 |
| E163 | Fuse, rotating beams/roof hatch   | 0293      |
| E165 | Fuse, FPH-E fuel heater after contact   | 0313      |
| E190 | Fuse, ABS-D / ABS / ASR-E   | 0427 0450 |
| E198 | Fuse, central door lock   | 0308      |
| E277 | Fuse, VIC   | 0106      |
| E279 | Fuse, generator voltage control   | 0021      |
| E280 | Fuse, VIC   | 0104      |
| E282 | Fuse, engine brake switch/stop light switch   | 0257      |
| E283 | Fuse, headlamp height adjustment/width marker light, 1 <sup>st</sup> , left and right/tail light, right | 0226      |

## CHANGES IN THE ELECTRICAL SYSTEM

5

Changes in the electrical system from chassis number 0L247507

LF45/55 series

| 1    | 2  | 3         |
|------|--|-----------|
| E284 | Fuse, width marker light, 2 <sup>nd</sup> , left and right/tail light, left /search lighting | 0218      |
| E285 | Fuse, VIC/fog light switch   | 0212      |
| E286 | Main fuse  | 0047      |
| E290 | Fuse, RAS-EC   | 0453      |
| E297 | Fuse, airbag and seat belt tensioner system  | 0473      |
| E299 | Fuse, windscreen heating   | 0349      |
| E330 | Fuse, 'sens' wire main switches  | 0016      |
| E349 | Main fuse, cab   | 0002 0015 |
| E354 | Fuse, automatic gearbox, AGC fan   | 0501 0534 |
| E501 | Reversing light switch   | 0264      |
| E508 | Temperature switch for air conditioning compressor   | 0380      |
| E509 | Air conditioning switch, high/low pressure   | 0382      |
| E514 | Cab stepwell lighting/interior lighting door switch, driver's side                           | 0278      |
| E515 | Cab stepwell lighting/interior lighting door switch, co-driver's side                        | 0280      |
| E564 | Engine brake switch  | 0130      |
| E569 | Neutral position switch, gearbox   | 0125      |
| E581 | Cab heater timer unit  | 0388      |
| E585 | Selector switch, automatic gearbox (AT 1000/2000)  | 0515      |
| E587 | Switch for stop lights/clutch  | 0127      |
| E597 | Switch, cooling fans, automatic gearbox (AGC)  | 0501      |
| F000 | Parking brake switch   | 0115      |
| F006 | Differential lock control switch, 1 <sup>st</sup> differential                               | 0116      |
| F009 | Control switch, cab tilting  | 0121      |
| F011 | Control switch, engine oil pressure  | 0608 0647 |
| F087 | Control switch, gearbox PTO  | 0079      |
| F107 | Control switch, brake lining wear, front left  | 0488      |
| F108 | Control switch, brake lining wear, front right   | 0490      |
| F111 | Control switch, brake lining wear, rear left   | 0492      |
| F112 | Control switch, brake lining wear, rear right  | 0493      |
| F113 | Control switch, brake lining wear, rear left, 2 <sup>nd</sup> rear axle (6x2)                | 0495      |
| F114 | Control switch, brake lining wear, rear right, 2 <sup>nd</sup> rear axle (6x2)               | 0497      |

# 5

## CHANGES IN THE ELECTRICAL SYSTEM

LF45/55 series

Changes in the electrical system from chassis number 0L247507

| 1    | 2  | 3              |
|------|--|----------------|
| F116 | Oil level switch, RAS-EC                       | 0462           |
| F512 | Wheel speed sensor, front axle, left           | 0407 0430      |
| F513 | Wheel speed sensor, front axle, right          | 0408 0432      |
| F514 | Wheel speed sensor, driven axle, left          | 0410 0433      |
| F515 | Wheel speed sensor, driven axle, right         | 0411 0435      |
| F533 | Vehicle speed sensor                           | 0050           |
| F552 | Crankshaft sensor                              | 0601 0640      |
| F558 | Camshaft sensor                                | 0603 0641      |
| F566 | Coolant temperature sensor                     | 0605 0644      |
| F601 | Output shaft speed sensor, automatic gearbox   | 0504 0556      |
| F602 | Input shaft speed sensor, automatic gearbox    | 0505 0557      |
| F603 | Ultrasonic transmitter                         | 0180           |
| F604 | Ultrasonic receiver                            | 0182           |
| F608 | Fuel level sensor                              | 0109           |
| F612 | Height sensor, ECAS, rear axle, left           | 0705 0721 0742 |
| F613 | Height sensor, ECAS, rear axle, right          | 0707 0743      |
| F615 | Pressure sensor, ECAS, driven axle, left/right | 0746           |
| F648 | Fuel rail pressure sensor                      | 0607 0645      |
| F649 | Charge boost pressure and temperature sensor   | 0610 0647      |
| F651 | Ambient temperature sensor                     | 0104           |
| F652 | Air pressure sensor                            | 0106           |
| F670 | Sensor, turbine speed, automatic gearbox       | 0507           |
| F671 | Accelerator pedal sensor, ECS-DC3              | 0623 0662      |
| F686 | Radar sensor, alarm system                     | 0185           |
| F692 | Water separator sensor                         | 0316           |
| F695 | Angle sensor, trailing axle                    | 0457           |
| F696 | Angle sensor, front axle                       | 0459           |
| F705 | Speed sensor, AS Tronic                        | 0455           |
| G000 | Rear light/marker light and search light relay | 0201 0210      |
| G001 | Dipped beam relay                              | 0206 0239      |
| G002 | Main beam relay                                | 0208 0242      |
| G004 | Relay, front fog lamp                          | 0212 0253      |

## CHANGES IN THE ELECTRICAL SYSTEM

5

Changes in the electrical system from chassis number 0L247507

LF45/55 series

| 1    | 2   | 3                   |
|------|---|---------------------|
| G005 | Relay, rear fog lamp                          | 0118 0249           |
| G008 | Windscreen wiper relay                        | 0166 0171           |
| G014 | Glow plug relay                               | 0047 0631 0669      |
| G015 | Contact relay                                 | 0027 0030           |
| G036 | Stop light relay                              | 0258 0259           |
| G185 | Starting circuit interrupter relay            | 0541 (in VIM D822)  |
| G188 | Lighting relay, accessories                   | 0030 0034           |
| G201 | Fuel heating relay, FPH-E                     | 0313 0634 0673      |
| G203 | Transfer relay, starter motor                 | 0037 0038 0042 0044 |
| G294 | Relay, automatic gearbox                      | 0541 (in VIM D822)  |
| G350 | Reversing light relay, automatic gearbox      | 0541 (in VIM D822)  |
| G353 | Contact relay                                 | 0028 0314           |
| G354 | Windscreen wiper relay                        | 0025 0163           |
| G355 | Seat heating relay                            | 0353 0354           |
| G367 | Main switch relay, power supply               | 0008                |
| G368 | Main switch relay, earth                      | 0010 0015           |
| G397 | Windscreen heating relay                      | 0349                |
| G425 | Main switch relay                             | 0064 0102           |
| G444 | Cooling fan relay, automatic gearbox (AGC-A4) | 0534 0535           |
| G507 | Earth, 1-pin, chassis - cab                   | -                   |
| G516 | Central cab earth, co-driver's side           | -                   |
| G517 | Central cab earth, driver's side              | -                   |
| G520 | Central earth, chassis, front end             | -                   |
| G522 | Central earth, starter motor                  | -                   |
| G523 | Central earth, engine                         | -                   |
| G524 | Earth point, glow element                     | -                   |
| G525 | Central earth, flywheel                       | -                   |
| G528 | Earth point, cab, airbag LHD/cab heater RHD   | -                   |
| G529 | Earth point, cab, cab heater LHD/airbag RHD   | -                   |
| G735 | Through-connection, Swedish lighting          | 0205                |
| G742 | Through-connection, VIC/DIP-4                 | 0065                |
| G743 | Through-connection, main beam                 | 0242                |

11

# 5

## CHANGES IN THE ELECTRICAL SYSTEM

LF45/55 series

Changes in the electrical system from chassis number 0L247507

| 1    | 2   | 3         |
|------|---|-----------|
| G744 | Through-connection, cab heater/warning lamps/central door locking | 0301      |
| G748 | Node, V-CAN   | 0195      |
| G750 | Node, V-CAN   | 0448 0599 |
| G752 | Node, V-CAN   | 0059      |
| G753 | Node, V-CAN   | 0596      |

### 2.4 SECTION DIAGRAMS FROM CIRCUIT DIAGRAM 1427090/04

| Section diagram no. | Title of section diagram                            |
|---------------------|---|
| A                   | Voltage before and after contact                    |
| C                   | CAN overview  |
| 1                   | Main switch   |
| 2                   | Ignition/starter switch/charging circuit            |
| 5                   | Pre-glowing   |
| 8                   | VIC   |
| 10                  | Reversing lights/buzzer                             |
| 12                  | Stop lights/cab tilting gear                        |
| 13                  | Differential lock                                   |
| 15                  | Mirror heating/windscreen heating/mirror adjustment |
| 19                  | Horn/cigar lighter/work lamp/air dryer              |
| 22                  | ECS-DC3/exhaust brake                               |
| 24                  | AGC automatic gearbox (AT1000/2000)                 |
| 25                  | AGC automatic gearbox (MD3060)                      |
| 31                  | CDS-3/drop glass operation/roof hatch               |
| 32                  | CDM   |
| 39                  | Water separator/fuel pre-heating                    |

**A VOLTAGE BEFORE AND AFTER CONTACT****VOLTAGE BEFORE CONTACT**

Wire 1000 runs from the batteries (A500) to the starter motor (B010), connecting point 30, and via the main fuse (E349, 80 A) to dashboard lead-through zone 1. Wire 1000 runs from the main fuse (E286, 125 A) to the glow plug relay (G014). Wire 1000 and the + distribution bolt in dashboard lead-through zone 1 provide a constant voltage at pins 1 and 2 of connector 705 on the PCB.

This provides "voltage before contact" for the entire PCB. Power is also provided (by wire 1000) from point 30 on the starter motor to the B+1 connection of the alternator (A513). Wire 1000 goes from the + distribution bolt to the ignition/starter switch (C841).

**VOLTAGE AFTER CONTACT**


When the ignition/starter switch (C841) is set to the "contact" position (connection between points 1 and 4), relay G015 is energised via wire 4001.

This then connects wire 1000 (voltage before contact) to wire 1010 (voltage after contact).

When the ignition/starter switch (C841) is turned against the spring pressure (connection between points 1 and 2), relay G015 remains activated.

When the ignition/starter key is released, the contact/starter switch automatically springs back and remains in the "contact" position.





A

1427090/04

EL001618


**C CAN OVERVIEW**

This section diagram gives an overview of all the CAN connections, with wire markings and connector points.

**SEE THE SYSTEM MANUAL FOR MORE INFORMATION**

**VARIANTS**

| <b>Location</b> |   |
|-----------------|---|
| 2               | The terminating resistor is in the automatic transmission wiring harness  |
| 8               | Electronic unit, automatic gearbox, AGC-T1000/2000 (D936):<br>If MD3060 gearbox is fitted, the electronic unit is for AGC-A4 automatic gearbox operation (D866) |
| 16              | The terminating resistor is in the wiring harness of the ECS-DC3 engine management system   |



1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53

C


1427090/04

EL001619

## 1. MAIN SWITCH

### MANUALLY OPERATED EARTH BREAKER

Turning main switch C553 anticlockwise will break the earth connection between the batteries (A500) and the chassis earth point. Because the tachograph (B525) must have a power supply and earth connection at all times, earth wire 9001 is connected directly to the earth connection of the batteries through 2-pin dashboard lead-through connector 813 in zone 1.



1

1427090/04

EL001620

## ELECTRICALLY OPERATED MAIN SWITCH

The main switch (D924) can be closed:

- electrically in the cab
- electrically on the chassis

**Closing the main switch electrically in the cab**



**ATTENTION: switch C854 must be in the "main switch on" position (connection between contacts 1 and 2).**


Switch C853 (switch for main switch in cab) connects the C1 and C2 connections to the C4 and C5 connections via wire 4176, contacts 5 - 7 of switch C853, wire 4177, contacts 1 - 2 of switch C854 and wire 4178. Relays G367 and G368 are immediately energised through wire 4174 and connection point A3 (A3 is connected to earth for 0.5 seconds). This closes the connection between points 88a and 88 of both relay G367 and relay G368. The positive and the negative terminals of the batteries are now connected to the vehicle's power supply. Immediately after switch C853 closes, connection point C2 is internally connected to point A7.

Connection point A5 is connected to the positive terminal via wire 3173 after connection point 88 of relay G367. This connection transmits a signal to the ECU to indicate that relay G367 has switched.

**Closing the main switch electrically on the chassis**



**ATTENTION: switch C853 must be in the "main switch on" position (connection between contacts 5 and 7).**



Switch C854 (switch for main switch on the chassis) connects the C1 connection to the C4 and C5 connections via wire 4176, contacts 5 - 7 of switch C853, wire 4177, contacts 1 - 2 of switch C854 and wire 4178. Relays G367 and G368 are immediately energised through wire 4174 and connection point A3 (A3 is connected to earth for 0.5 seconds). This closes the connection between points 88a and 88 of both relay G367 and relay G368. The positive and the negative terminals of the batteries are now connected to the vehicle's power supply.

Immediately after switch C854 closes, connection point C2 is internally connected to point A7.

Connection point A5 is connected to the positive terminal via wire 3173 after connection point 88 of relay G367. This connection transmits a signal to the ECU to indicate that relay G367 has switched.

The main switch (D924) can be opened:

- electrically in the cab
- electrically on the chassis

**Opening the main switch electrically in the cab**



**ATTENTION: switch C854 must be in the "main switch on" position (connection between contacts 1 and 2).**

Switch C853 (switch for main switch in cab) disconnects wire 4176, contacts 5 - 7 of switch C853, wire 4177, contacts 1 - 2 of switch C854 and the C1 and C2 connections from the C4 and C5 connections via wire 4178.

**ATTENTION: switch C853 must be in the "main switch on" position (connection between contacts 5 and 7).**




Two actions are carried out immediately after switch C853 is opened:

1. Connection point A7 is connected to earth (A2).
2. After a delay of approx. 6 seconds, relays G367 and G368 are connected to earth for approx. 0.5 sec. via wire 4175 and connection point A4. This breaks the connection between points 88a and 88 of relays G367 and G368. The positive and the negative terminals of the batteries are now disconnected from the vehicle's power supply.

If the engine is running, it is switched off.

Connection point A5 is connected to the positive terminal via wire 3173 after connection point 88 of relay G367. This connection transmits a signal to the ECU to indicate that relay G367 has switched.

**Opening the main switch electrically on the chassis**



Switch C854 (switch for main switch in cab) breaks the C1 and C2 connections to the C4 and C5 connections via wire 4176, contacts 5 - 7 of switch C853, wire 4177, contacts 1 - 2 of switch C854 and wire 4178.

Two actions are carried out immediately after switch C854 is opened:

1. Connection point A7 is connected to earth (A2) in the unit.
2. After a delay of approx. 6 seconds, relays G367 and G368 are connected to earth for approx. 0.5 seconds via wire 4175 and connection point A4. This breaks the connection between points 88a and 88 of relays G367 and G368. The positive and the negative terminals of the batteries are now disconnected from the vehicle's power supply.

If the engine is running, it is switched off.

Connection point A5 is connected to the positive terminal via wire 3173 after connection point 88 of relay G367. This connection transmits a signal to the ECU to indicate that relay G367 has switched.

**Note:**


When one of the switches (C853 or C854) that activate the electronic unit (close main switch) is operated, relays G367 and G368 are activated after approximately 3 seconds. If one of the switches is operated again within the 3 seconds, the electronic unit (D924) will select the priority 'main switch ON'.

**VARIANTS**

| Location |   |
|----------|---|
| 76       | G368, main switch relay, earth: Fitted depending on the requirements for transporting hazardous substances<br>These wires are only present if ADR is fitted.<br>These wires are only present if ADR is fitted   |
| 88, 90   |   |
| 94       | Earth connection to connector 834 is only present if ADR is fitted  |
| 97       | Earth connection to connector 834 is only present if ADR is fitted<br>Connector 831:<br>Only present if the system is fitted with an external current limiter (D826)<br>Connector 832:<br>Only present if the system is fitted with an external current limiter (D826)<br>Electronic unit, VLG current limiter (D826):<br>Fitted depending on the requirements for transporting hazardous substances.<br>Version with production date < 2002-49: current limiter (D826) used as shown<br>Version with production date > 2002-49 with current limiter integrated into the MTCO (B525). |
| 98, 101  |   |
| 99       |   |
| 98, 101  |   |







1

1427090/04

EL001621

## 2. IGNITION/STARTER SWITCH/CHARGING CIRCUIT

### CONTACT CIRCUIT

When ignition/starter switch C841 is turned to the "accessories" position (contact 1 connected to contact 6), the "accessories" relay (G355) is energised via wire 1130. If ignition switch C841 is turned further (contact 1 is connected to 4), ignition relay G015 will be activated via wire 4001. Wire 1010 is supplied with power.

### STARTING CIRCUIT

When the contact switch is turned to the "start" position, contacts 1 and 2 in this switch are connected. Power is supplied to relay G203 via wire 4002. The VIC (D900) connects G203 to earth when the neutral position switch (E569) in the gearbox is closed. Relay G203 now supplies power via wire 4009 to connection point 50 of the starter motor (B010). As a result, the starter motor is energised.

This means that if the gearbox is not in neutral the VIC does not connect relay G203 to earth and the relay is therefore not energised.

### CHARGING CIRCUIT

When the ignition is switched on, power is supplied to both the B+ connection and connection 15 (pin 3) of the alternator.


An internal resistor in the alternator is energised by an IC in the carbon brush holder. This resistor ensures that a low level of current passes through the energising resistor. This excites a magnetic field in the alternator.

After starting, the voltage on terminals B+ and 15 (pin 3) will rise to about 28.5 V. Once this voltage is reached, the control IC in the regulator interrupts the pre-exciter coil to enable the voltage to be regulated. The magnetic field will now disappear, so that the generator will not be energised for a short period of time. As a result, the voltage on outputs B+ and 15 will drop.

The regulator reactivates when the voltage drops below 27.6 V. This means that the voltage supplied by the generator remains relatively constant. The batteries are supplied through generator output B+1.

The alternator charging current warning lamp is activated via wire 1020, which is connected to the VIC (D900). The VIC controls the DIP via the CAN network. The voltage on wire 1020 is switched by the control IC. Errors are also shown on the DIP display through this connection.


The alternator is also equipped with a 'sens' connection (pin 4). However, this connection is not used and is now connected directly to B+2. The function of this connection is to correct the voltage difference between B+ and the batteries.



1427090/04

EL001622

5. PRE-GLOWING  
SEE THE SYSTEM MANUAL FOR MORE  
INFORMATION



5


1427090/04

EL001623

**8. VIC**  
**SEE THE SYSTEM MANUAL FOR MORE**  
**INFORMATION**

**VARIANTS**



|                 |   |
|-----------------|---|
| <b>Location</b> |   |
| 14              | If the vehicle is fitted with CDM, see section diagram 32   |
| 39              | Connector 762: not fitted on vehicle type FT  |
| 88              | Electronic unit, ABS/ASR-E (D961):<br>If ABS-D fitted, the electronic unit is D941  |
| 116             | Electronic unit, automatic gearbox, AGC-T1000/2000 (D936):<br>If MD3060 gearbox is fitted, the electronic unit is for AGC-A4 automatic gearbox operation (D866) |
| 138             | On vehicle type LF55  |
| 156             | Connector 780:<br>Not fitted on vehicle type FA.<br>Wire 2155 only fitted in application connector A070   |
| 182             | Connector 763: Not fitted on vehicle type FT  |



8

1427090/04

EL001624





8

1427090/04

54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100 101 102 103 104 105 106

EL001625







8

1427090/04

EL001626

D942



D900

8

1427090/04

160 161 162 163 164 165 166 167 168 169 170 171 172 173 174 175 176 177 178 179 180 181 182 183 184 185 186 187 188 189 190 191 192 193 194 195 196 197 198 199 200 201 202 203 204 205 206 207 208 209 210 211 212

EL001627




## 10. REVERSING LIGHTS/BUZZER

When the contact is switched on, power is supplied to the reversing light switch (E501) via E018 and wire 1217.

This switch is mounted in the gearbox. The contacts are closed when the gearbox is switched to the "reverse" position.

Power is then supplied via wire 4591 to the reversing lights (C026/C027) and drawn vehicle connector A001.

The reversing buzzer (B176) can only be activated via wire 5104 if the dashboard switch (C880) is in position I. Switching C880 to the 0 position turns off the reversing buzzer. The application connector (A070) also has a connection that is switched by the reversing light switch (E501).



10

1427090/04

EL001628

**12. STOP LIGHTS/CAB TILTING GEAR**

**STOP LIGHTS**

When stop lights/clutch switch E587 is operated (connection between contacts 4 and 3) by depressing the brake pedal, relay G036 is energised via wire 4602. Power will also be supplied to the VIC (pin D32/746). Through fuse E013, wire 1209, contacts 3 and 5 of relay G036 and wire 4601 a voltage is now applied to the right stop light (C021) and the left stop light (C020), so that they come on. The lights that are connected via drawn vehicle socket A000 will also come on. The ECAS-3 unit (D851) or ECAS-2 unit (D802) then also receives a signal. Application connector A070 is also connected to wire 4601.


**CAB TILTING GEAR**

The switch for the cab lock (F009) is a "normally closed" switch. The switch is opened when the cab is in the driving position. When the cab is tilted, the switch closes and pin B16/744 of the VIC is connected to earth via wire 4312. When the alarm is active it knows that the cab is in the driving position because a small current goes to earth through the control switch for cab tilting (F009). Diode D758 prevents this current from also flowing to earth through the VIC (the VIC in sleep mode), in which case the alarm would not know whether the cab is being tilted intentionally or by accident.

**VARIANTS**

**Location**

- 13 If the vehicle is fitted with CDM, see section diagram 32
- 23,28 Connector 762:
- 29 Not fitted on vehicle type FT  
Electronic unit, ECAS-3 (D851):  
On a 6x2 vehicle, ECAS-2  
electronic unit D802 (7/340)



12


1427090/04

EL001629

### 13. DIFFERENTIAL LOCK

If the contact switch (C841) is activated, a voltage is applied through fuse E018 and wire 1217 to the cross-axle differential lock switch (C748). If switch C748 is operated, a voltage is applied to the operating valve for the cross-axle differential lock (B243) through wire 4517. If the differential is locked, the differential lock control switch (F006) connects pin C34/745 of the VIC to earth via wire 3408. The VIC will activate the DIP through I-CAN to switch on the "differential lock switched on" indicator.





13

1427090/04

EL001630

**15. MIRROR HEATING/WINDSCREEN HEATING/MIRROR ADJUSTMENT**

**MIRROR HEATING**

When the ignition/starter switch (C841) is set to the "contact" position (connection between points 1 and 4), relay G353 is energised via wire 4001. This relay supplies power to the mirror heating switch (C867) and the mirror adjustment switch (C868) via fuse E044 and wire 1208. When the mirror heating switch (C867) is operated, power is supplied to mirror heating B017 (driver's side) and B018 (co-driver's side) via wire 4532. The time-dependent windscreen heating relay (G397) will also be energised. This relay will automatically be de-activated after 12 minutes.

**WINDSCREEN HEATING SYSTEM**

If the vehicle has a windscreen heating system, the windscreen heating relay (G397) will be energised when the mirror heating system is activated. The windscreen heating system (B371) will be supplied with power via fuse E299. The windscreen heating relay (G397) will automatically be de-activated after 12 minutes.


**MIRROR ADJUSTMENT**

The outside mirrors are adjusted using "joystick" switches C868 (driver's side and co-driver's side). If the handle of the switch is moved from the rest position (centre) in a particular direction, power will be supplied to mirror adjustment motor B005 (left-hand side) or B006 (right-hand side) and the mirror in question will follow the movement of the handle.

When pins 10 and 5 are connected, mirror adjustment switch C868 is in the "right-hand mirror" position. When pins 8 and 4 are connected, the mirror adjustment switch is in the "left-hand mirror" position.

For this, wires 4770 and 4774 (left-hand side) or 4771 and 4774 (right-hand side) supply power to the motor for the left/right movement. Wires 4772 and 4774 (left-hand side) or 4771 and 4774 (right-hand side) supply power to the adjusting motor for the up and down movement.

The mirror adjustment system can only be used if the contact relay (G353) is energised.



15

1427090/04

EL001631

**19. HORN/CIGAR LIGHTER/WORK LAMP/AIR DRYER**

**HORN**

The horn (B401) is activated before contact via steering column switch C775 (1000). The horn is supplied with power via wire 4979 and fuse E019.

**CIGAR LIGHTER**

If the vehicle ignition switch (C841) is in the "accessories" position (connection between contacts 1 and 6), cigar lighter B030 is supplied with power via fuse E026 and wire 1105. By depressing the cigar lighter, the heating element is warmed up.

**WORK LAMP**

Work lamp switch C725 is supplied with voltage from power supply before contact and via fuse E052. When the switch is operated voltage is applied to the work lamp (C071) and to pin C9/745 of the VIC unit in order to activate the "work lamp" indicator on the DIP via I-CAN.


**AIR DRYER**

When the vehicle ignition (C841) is on (connection between contacts 1 and 4), relay G353 is activated. This relay supplies power to the air dryer heating element (B042) via fuse E091 and wire 1240.  
When the maximum temperature is reached, a thermal switch in the air dryer switches off. The water separator sensor (F692) is supplied with power via the same wire.

**VARIANTS**

**Location**

20,24 Connector 780:  
Not fitted on vehicle type FA.  
Wire 2155 only fitted in application connector A070  
35 If the vehicle is fitted with CDM, see section diagram 32



1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53

19


1427090/04


EL001632

**22. ECS-DC3/EXHAUST BRAKE  
FOR MORE INFORMATION SEE SYSTEM  
MANUAL**

**VARIANTS**

| Location | Description  |
|----------|--|
| 49       | Connector 852:<br>Optional connector for "remote throttle" function                |
| 66       | The CAN terminating resistor is fitted in the wiring harness, near the B connector |
| 129      | This part of the ECS-DC3 electronic unit relates to the BE engine (4-cylinder)     |
| 186      | This part of the ECS-DC3 electronic unit relates to the CE engine (6-cylinder)     |






11

22 1427090/04

EL001634



D942



22

1427090/04

107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159

11

EL001635

D942


1000  
1010

1000  
1010

11



D903



22

1427090/04

160 161 162 163 164 165 166 167 168 169 170 171 172 173 174 175 176 177 178 179 180 181 182 183 184 185 186 187 188 189 190 191 192 193 194 195 196 197 198 199 200 201 202 203 204 205 206 207 208 209 210 211 212

EL001636



**24. AGC AUTOMATIC GEARBOX (AT1000/2000)**

Power supply before contact is obtained directly from the batteries (A500) via a 10 A fuse (E144) and wire 1302. The voltage before contact can also be found in the diagnostic socket for the automatic gearbox (A032).

**VARIANTS**

**Location**

122 Automatic gearbox socket, superstructure (AT2000), A096

Voltage after contact is obtained via fuse E279 and wire 1211.

The AT 1000/2000 automatic gearbox selector switch (E585) receives power after contact through fuse E016 and wire 1217. The reversing lights are activated from the same switch via wire 4591.


The earth connections are connected directly to the earth side of the batteries (A500).

The electrical system of the automatic gearbox is almost completely located on the chassis.

Connections leading into the cab are provided for a number of VIC functions:

- fault messages from the automatic gearbox (B25/853) to the VIC unit (D900)
- "Range inhibit" (B23/853) to the VIC unit (D900)
- CAN connections (B29/853 and B32/853) to the VIC unit (D900)
- Neutral position protection (G/900) to the VIC unit (D900)


Diagnosis of the automatic gearbox takes place via the CAN network, which is connected to the diagnostic socket (A032) and the VIC unit (D900).





24

1427090/04

EL001637



54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100 101 102 103 104 105 106



24

1427090/04

107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159

**25. AGC AUTOMATIC GEARBOX (MD3060)**

Power supply before contact is obtained directly from the batteries (A500) via wire 336 and a 10 A fuse (MAIN) in the VIM (D822, pins J1 and J2). The electronic unit (D866) receives voltage before contact at pin V1/907 and V16/907 from the VIM (D822, pins R1 and R2) via wires 1164.

Voltage after contact is obtained via fuse E279 and wire 1211. Wire 1211 is connected directly to electronic unit D866 (pin S4/905). The wire also runs to the VIM (pin C1) and various relays in de VIM are supplied with voltage after contact via a 10 A fuse (IGN). The voltage after contact can also be found in the diagnostic socket for the automatic gearbox (A032).

The earth connections are connected directly to the earth side of the batteries (A500) and also run to the electronic unit (D866) via the VIM (pins K1 and K2).

The electrical system of the automatic gearbox is almost completely located on the chassis.

Connections leading into the cab are provided for a number of VIC functions:


- fault messages from the automatic gearbox (S31/905) to the VIC unit (D900)
- CAN connections (S13/905 and S29/905) to the VIC unit (D900)
- Vehicle interface module (D822, pin F1) to the VIC unit (D900)

Diagnosis of the automatic gearbox takes place via the CAN network, which is connected to the diagnostic socket (A032) and the VIC unit (D900).

**Note:**  
Where an automatic gearbox is fitted, there are two dashboard lead-through connectors, 716. One connector is occupied by spare wiring (see application connectors) and the other has 3 occupied positions (A1, wire 3458; A3, wire 123; and A4, wire 4614), only one of which is connected.

The 716 with the spare wiring is not then connected and hangs loose near the dashboard lead-through.








25

1427090/04

EL001640



EL001641





107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159

25

1427090/03

EL001594



25

1427090/04

160 161 162 163 164 165 166 167 168 169 170 171 172 173 174 175 176 177 178 179 180 181 182 183 184 185 186 187 188 189 190 191 192 193 194 195 196 197 198 199 200 201 202 203 204 205 206 207 208 209 210 211 212

EL001643

11




### 31. CDS-3/DROP GLASS OPERATION/ROOF HATCH

#### DROP GLASS OPERATION

When the vehicle ignition is switched on (connection between pins 1 and 4, C841), relay G353 is energised. Via fuse E044 and wire 1208, relay G353 supplies power to the electric drop glass door switches (C864 in the driver's door, C865 in the co-driver's door for the co-driver's door, and C866 in the driver's door).

There are two independent drop glass switches. In the rest position, pins 7 and 4 of the switch are connected to power supply via wire 1208. Depending on the side on which the switch is operated, pin 7 or 4 will be connected to earth and the drop glass motor (B003 - driver's side, B004 - co-driver's side) will be activated.




31

1427090/04

EL001644

11



E501717

## CENTRAL DOOR LOCKING

**Purpose:**


- Automatic locking of both doors when one of the doors is locked with the key/button.
- Automatic locking of both doors using remote control.
- If one of the two doors is unlocked using the key/button, only this door will be unlocked; the other door will remain locked.
- Automatic unlocking of the driver's side door using remote control.

**Conditions: both doors locked.**

- **Unlocking co-driver's side door using key.**  
This is equivalent to opening a door without central locking. The other door remains locked.
- Unlocking co-driver's side door with switch C774.  
When switch C774 is operated (pin 3 connected to pin 1), connection DO of component B200 is connected to earth. The co-driver's door will unlock.



- Unlocking using remote control.  
If the door unlocking button on the remote control unit is pressed, the remote control unit will send a fixed-code signal to the CDS electronic unit (D905). When the CDS electronic unit (D905) recognises the remote control unit on the basis of the fixed code, the remote control unit will send coded messages to the unit (D905). These messages are coded with a rolling code. This rolling code will change every time the remote control is operated. After the CDS electronic unit (D905) has accepted the messages, it will send a signal to the VIC (D900). As a result, the VIC will switch on the interior lighting for a specific period of time.  
The CDS unit (D905) now switches pin 13 to earth. This will only activate the motor (B199). The CDS unit (D905) checks the status of the output to the motor (B199). This is done to ensure that the DL connection is not connected to earth when the motor is in the "open" position. The CDS unit can deduce from this whether the driver's side door has been successfully unlocked. The CDS electronic unit (D905) will then send a message to the VIC (D900) via pin 2 stating that the driver's side door has been successfully unlocked. If the driver's side door is not unlocked properly after three attempts, a message will be sent to the VIC (D900) to inform it that the door has not unlocked successfully.



E501716

11

**Conditions: both doors unlocked.**

- Locking driver's side door with key/button.  
The D905 unit will measure an earth signal at pin 15 through connection DL. D905 will now connect pin 12 to earth, which will also activate B200. The co-driver's side door will now lock as well.
- Locking the driver's side door with key/button.  
The operation is as described above, except that unit D905 will now measure an earth signal at pin 12 and it will connect pin 15 of component B199 to earth. The door on the driver's side will now also be locked.

**- Locking co-driver's side door using switch C774.**

When switch C774 is operated (pin 3 connected to pin 7), an earth signal is created at pin 3 of unit D905. D905 will now connect pin 12 to earth, which will activate B200. This will lock the door on the co-driver's side.

- The doors on the driver's and co-driver's sides are locked using the remote control unit.  
When the lock doors button on the remote control unit is pressed, a procedure starts that is comparable to the procedure for opening the doors.

**VARIANTS****Location**

68 If the vehicle is fitted with CDM, see section diagram 32

**ROOF HATCH****Opening roof hatch**

When the roof hatch switch (C736) is operated and a connection is made between contacts 2 and 6 and therefore between contacts 1 and 3, a voltage is applied to pin 1 of the roof hatch motor (B009) through fuse E163, switch C736 and wire 4761. The roof hatch will open.

**Closing roof hatch**


When the roof hatch switch (C736) is operated and a connection is made between contacts 8 and 6 and therefore between contacts 7 and 3, a voltage is applied to pin 2 of the roof hatch motor (B009) through fuse E163, switch C736 and wire 4760. The roof hatch will now close.

However, during the locking operation the CDS electronic unit (D905) will connect pins 12 and 15 to earth. This will activate the motors (B199 and B200). The CDS electronic unit (D905) then checks the status of the outputs to the motors (B199 and B200). It uses this information to determine whether the doors have been successfully locked. The CDS unit (D905) will then send a message to the VIC (D900) via pin 2 stating that the doors have been successfully locked. As a result, the VIC (D900) will switch off the interior lighting. If the doors are not locked properly after three attempts, a message will be sent to the VIC (D900), stating that the locking operation was not successful.

**Initialisation**

When the CDS electronic unit is supplied with power for the first time (on installing or replacing the electronic unit) or when new hand-held transmitters are used (up to 8), the unit must recognise these hand-held transmitters. To enable the hand-held transmitters to communicate with the CDS unit, the unit and the hand-held transmitters must be taught using DAVIE.






31

1427090/04

EL001645

**32. CDM  
FOR MORE INFORMATION SEE SYSTEM  
MANUAL**



1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53

**39. WATER SEPARATOR/FUEL PRE-HEATING**

**WATER SEPARATOR**

The water separator sensor F692 is supplied with power via relay G353 and fuse E091. If the water level in the fuel filter becomes too high, the VIC receives a signal at pin D8/746. A warning is then indicated on the DIP through the VIC.

**FUEL PRE-HEATING**


Depending on the temperature, the ECS-DC3 electronic unit (D903) activates the fuel heating relay (G201). The relay supplies power to the water separator fuel heating element (B182) through fuse E165.

**VARIANTS**

**Location**

- 34 Fuel heating relay (G201):  
May be placed behind the central box.
- 39 If the vehicle is fitted with CDM,  
see section diagram 32





39

1427090/04

EL001647

